

MISSISSIPPI

Handbook for

Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas

Volume 1

Erosion and Sediment Control Practices



Mississippi Department
of Environmental Quality
Published 2011

Volume 1 Erosion and Sediment Control Manual

Table of Contents

Acknowledgments.....	iii
Chapter 1: Introduction to Erosion and Sediment Processes.....	1-1
Chapter 2: General Planning Concepts for Erosion and Sediment Control and Stormwater Management.....	2-1
Chapter 3: Erosion and Sediment Control Plan Preparation.....	3-1
Chapter 4: Best Management Practices Design	4-1
Site Preparation	
Construction Phasing/Sequencing (CPS)	4-3
Construction-Exit Pad (CEP).....	4-6
Construction Road Stabilization (CRS).....	4-12
Land Grading (LG)	4-16
Topsoiling (TSG).....	4-20
Surface Stabilization	
Chemical Stabilization (CHS).....	4-25
Dust Control (DC).....	4-29
Erosion Control Blanket (ECB).....	4-33
Housekeeping (HK).....	4-43
Mulching (MU).....	4-48
Permanent Seeding (PS)	4-53
Preservation of Vegetation (PV).....	4-64
Retaining Wall (RW).....	4-75
Shrub, Vine and Groundcover Planting (SVG).....	4-80
Sodding (SOD).....	4-93
Surface Roughening (SR).....	4-100
Temporary Seeding (TS).....	4-103
Tree Planting on Disturbed Areas (TP)	4-110
Runoff Conveyance	
Check Dam (CD).....	4-117
Diversion (DV).....	4-131
Drop Structure (DS)	4-156
Grass Swale (GS)	4-162
Level Spreader (LVS).....	4-186
Lined Swale (LS).....	4-190
Outlet Protection (OP).....	4-199
Riprap-lined Swale (RS).....	4-210

Subsurface Drain (SD)	4-218
Temporary Slope Drain (TSD)	4-225

Inlet Protection

Block and Gravel Inlet Protection (BIP).....	4-233
Excavated Inlet Protection (EIP)	4-239
Fabric Drop Inlet Protection (FIP)	4-243
Straw Bale Inlet Protection (SBIP)	4-249

Sediment Control

Brush/Fabric Barrier (BFB).....	4-255
Filter Strip (FS).....	4-261
Floating Turbidity Barrier (FB).....	4-268
Rock Filter Dam (RD).....	4-278
Sediment Barrier (SB)	4-284
Sediment Basin (SBN)	4-298
Straw Bale Sediment Trap (SST).....	4-322
Flocculants and Polymers (FLC).....	4-328

Stream Protection

Introduction to Stream Protection.....	4-334
Buffer Zone (BZ)	4-337
Channel Stabilization (CS).....	4-342
Stream Diversion Channel (SDC)	4-353
Streambank Protection (SP)	4-362
Temporary Stream Crossing (TSC)	4-382

Appendices

(Available in *Appendices: Developing Plans & Designing Best Management Practices*)

A: Erosion and Stormwater Runoff Calculations	A-1
B: State and Federal Regulations, Permits and Applications	B-1
C: MS One-Call and 811 Color Coding.....	C-1
D: Erosion and Sediment Control and Stormwater Pollution Prevention Plan Examples.....	D-1
E: Model Ordinances for Stormwater Control.....	E-1
F: Erosion and Sediment Control and Stormwater Pollution Prevention Inspection Forms	F-1
G: Mississippi Department of Transportation Vegetation Schedule.....	G-1
H: Glossary	H-1
I: References.....	I-1
J: Local Information	J-1

Acknowledgments

The Erosion and Sediment Control and Stormwater Runoff Management Manuals were made possible via a US Environmental Protection Agency grant and are products of a partnership project among the Mississippi Department of Environmental Quality, the Mississippi Department of Transportation and the US Department of Agriculture (USDA)–Natural Resources Conservation Service.

Volume 1 – Erosion and Sediment Control Manual was created by adapting the *Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas* (2009) with Mississippi-specific information where appropriate. The State of Alabama graciously provided their *Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas* for Mississippi to use as a template. Therefore, a special thanks is warranted to the following agencies who worked on Alabama’s Handbook: Alabama Soil and Water Conservation Committee, Alabama Chapter of the Soil and Water Conservation Society, Alabama Association of Conservation Districts, Alabama Department of Environmental Management, Alabama Department of Transportation, Associated General Contractors of Alabama, Home Builders Association of Alabama, and the USDA–Natural Resources Conservation Service.

Volume 2 – Stormwater Runoff Management Manual was created by adapting North Carolina’s *Stormwater Best Management Practices Manual* (2007) with Mississippi-specific information where appropriate. Special thanks go to the North Carolina Division of Water Quality, the North Carolina Department of Environment and Natural Resources, and North Carolina State University for their work in developing the *Stormwater Best Management Practices Manual*.

Steering Committee

Zoffee Dahmash

Mississippi Department of Environmental Quality,
Jackson, Mississippi

Kim Thurman

Mississippi Department of Transportation, Jackson,
Mississippi

Ronn Killebrew

Mississippi Department of Environmental Quality,
Jackson, Mississippi

Brad Lewis

Mississippi Department of Transportation, Jackson,
Mississippi

Jim Morris

Mississippi Department of Environmental Quality,
Jackson, Mississippi

Richard Chisolm

Mississippi Department of Transportation, Jackson,
Mississippi

Hollis Allen

Mississippi Department of Environmental Quality,
Jackson, Mississippi

Paul Rodrigue

Natural Resource Conservation Service, Jackson,
Mississippi

Daniel Stuart

Mississippi Department of Environmental Quality,
Jackson, Mississippi

Handbook Authors

Melissa Gordon Pringle, Ph.D.
Vice President/Principal Scientist,
Eco-Systems, Inc., Jackson, Mississippi

Jay C. Estes, AICP
Principal Planner, Eco-Systems, Inc.,
Hattiesburg, Mississippi

Kimberly M. Miller, AICP
Senior Planner, Eco-Systems, Inc., Gulfport,
Mississippi

Jeremy K. Blakeney
Staff Engineer and Construction Manager,
Eco-Systems, Inc., Jackson, Mississippi

Courtney VanderSchaaf
Scientist III, Eco-Systems, Inc., Gulfport,
Mississippi

J. Norman Sisson
Senior CAD Designer,
Eco-Systems, Inc., Jackson, Mississippi

Technical Advisors

Ramona Garner, Ph.D.
Plant Materials Specialist, East National
Technology Support Center

Special Thanks

Special thanks to the following individuals for providing photos for this manual:

David Derrick
US Army Corps of Engineers, Research and
Development Center

Dr. Richard McLaughlin
Department of Soil Sciences, North Carolina
State University

Jim Morris
Mississippi Department of Environmental
Quality

Chapter 1

Introduction to Erosion and Sediment Processes

This chapter is intended to be an introduction to the processes referred to as erosion, sedimentation and stormwater management. If in-depth information is needed on these subjects, other references should be used.

Erosion and Sedimentation Processes


Erosion

Erosion is the process by which the land surface is worn away by the action of water, wind, ice or gravity. Water-related erosion is the primary problem in the developing areas of Mississippi and is the primary type of erosion that this handbook addresses.

The slow sedimentation and deposition of products from millions of years of geological erosion of upland sources has created the Mississippi we know today. With the exception of shorelines and stream channels where erosion may be rapid and catastrophic, geologic erosion occurs at very slow rates. This natural erosion process, which has taken place over millions of years, has probably occurred at rates comparable to erosion on our current forests.

In contrast to geologic erosion, the erosion accelerated by the disturbances of humans, through agriculture and non-agricultural uses of the land, has caused several inches of erosion over the last 100 to 150 years, a comparatively short period. Thus, "accelerated erosion" can be very significant and can potentially create related adverse impacts. Accelerated erosion occurs in developed or developing areas where developing sites are either poorly planned or the plans that appear adequate are not installed and maintained properly.

Four types of soil erosion on an exposed slope





To understand erosion caused by water, it is helpful to think of the erosive action of water as the effects of the energy developed by rain as it falls or as the energy derived from water's motion as it flows across the land surface. Both falling rain and flowing water, typically referred to as stormwater, perform work in detaching and moving soil particles, but their actions are different. The force of falling rain is applied vertically. The

force of flowing water is applied mostly horizontally.

The energy of raindrops falling on bare soil detaches soil particles. Water flowing over exposed soil picks up detached soil particles. As the velocity of flowing water increases, additional soil particles are detached and transported. Flowing water concentrates because of surface irregularities. If not prevented, these flows will create small channels, or rills, and eventually larger channels, or gullies of varying widths and depths. If the volume and velocity of storm runoff leaving a disturbed site increases because of the activities on the site, it is likely to cause additional erosion of streambanks and within floodplains beyond the rate of geologic erosion.

Although not as prominent in the Southeast as erosion caused by water, wind erosion can cause on-site health and safety problems and is a source of fugitive dust.

Sedimentation and Turbidity

Sedimentation is the process that describes soil particles settling out of suspension as the velocity of water decreases. The larger and heavier particles, gravel and sand, settle out more rapidly than silt and clay particles. Silt and clay particles are easily transported and settle out very slowly. It is difficult, and perhaps impossible in some instances, to totally eliminate the transport of clay and silt particles, even with the most effective erosion control programs.

Turbidity occurs in conjunction with sedimentation. Turbidity—a cloudy, muddy condition in the water—occurs when eroded soil is suspended in the water (i.e. before it settles out). Turbid water can stress or kill fish by clogging their gills and making it difficult for them to identify food sources.

Factors Influencing Erosion

The erosion process is influenced primarily by climate, topography, soils, and vegetative cover. The following description of the factors is an overview adequate for this

handbook; however, it is recognized that this is a very complex subject and many details are not included here.

Climate

Climate includes rainfall, temperature and wind. The frequency, intensity and duration of rainfall are the principal aspects of rainfall influencing the volume of runoff, erosion, and sediment (potential) from a given area. As the volume and intensity of rainfall increase, the ability of water to detach and transport soil particles increases. When storms are frequent, intense, and of long duration, the potential for erosion of bare soils is high. Temperature has a major influence on soil erosion. Frozen soils are relatively erosion resistant. However, bare soils with high moisture content are subject to uplift or “spew” by freezing action and are usually easily eroded upon thawing. Wind contributes to the drying of soil and increases the need for irrigation for new plantings and for applying wind erosion control practices during periods of bare soils.

Topography

Topography includes the shape and slope characteristics of an area or watershed and influences the amount and duration of runoff. The greater the slope length and slope gradient, the greater the potential for runoff, erosion and sediment delivery.

Soils

Soil characteristics include texture, structure, organic matter content and permeability. In addition, in many situations, compaction is significant. These characteristics greatly determine the erodibility of soil.

Soils containing high percentages of sand and silt are the most susceptible to detachment because they lack inherent cohesive characteristics. However, the high infiltration rates of sands either prevent or delay runoff except where overland flow is concentrated. Clearly, well-graded and well-drained sands are usually the least erodible soils in the context of sheet and rill erosion.

Clay and organic matter act as a binder to soil particles, thus reducing erodibility. As the clay and organic matter content of soils increase, the erodibility decreases. However, while clays have a tendency to resist erosion, they are easily transported by water once detached.

Soils high in organic matter resist raindrop impact, and the organic matter also increases the binding characteristics of the soil.

Sandy and silty soils on slopes are highly susceptible to gully erosion where flows concentrate because they lack inherent cohesiveness.

Small clay particles, referred to as colloids, resist the action of gravity and remain in suspension for long periods of time. Colloids are potentially a major contributor to turbidity where they exist.

Vegetative Cover

Vegetative cover is an extremely important factor in reducing erosion at a site. It will:


- a. Absorb energy of raindrops.
- b. Bind soil particles.
- c. Slow velocity of runoff water.
- d. Increase the ability of a soil to absorb water.
- e. Remove subsurface water between rainfall events through the process of evapotranspiration.
- f. Reduce off-site fugitive dust.

By limiting the amount of vegetation disturbed and the exposure of soils to erosive elements, soil erosion can be greatly reduced.

Stormwater

Water flowing over the land during and immediately following a rainstorm is called stormwater runoff. The runoff passing a particular point is equal to the total amount of rainfall upstream of that point less the amounts of infiltration, transpiration, evaporation, surface storage and other losses. The amount of these losses is a function of climate, soils, geology, topography, vegetative cover and, most importantly, land use.

In an undeveloped area, stormwater runoff is managed by nature through the hydrologic cycle. The cycle begins with rainfall. Rain either stands where it falls and evaporates or is absorbed into the ground near the surface, to feed trees and vegetation, ultimately to be returned to the atmosphere by transpiration; or it percolates deeply into the ground replenishing the groundwater supply. The remainder of the rainfall collects into rivulets. This collected runoff increases in quantity as it moves down the watershed, through drainageways, streams, reservoirs and to its ultimate destination, the river and then the sea. Evaporation from the sea surface begins the cycle again.



The Hydrological Cycle
 (Source: NRCS "Stream Corridor Restoration: Principles, Processes, and Practices")

This simple explanation of the hydrologic cycle belies its complexity. Nature's inability to accommodate severe rainfalls without significant damage, even in undeveloped areas, is very apparent. Nature's stormwater management systems are not static but are constantly changing. Streams meander, banks erode, vegetation changes with the seasons, lakes fill in with sediment and eventually disappear. The stripping of ground and tree cover by fire can change an entire system, forcing new natural accommodations throughout the system.

The volume of stormwater runoff is governed primarily by infiltration characteristics and is related to the land use, soil type, topography and vegetative cover. Thus, runoff is directly related to the percentage of the area covered by roofs, streets and other impervious surfaces. Water intercepted by vegetation and evaporated or transpired is lost from runoff. A small portion of the water that infiltrates into the soil and groundwater is delivered to the stream as delayed flow and does not contribute directly to peak stormwater runoff. Impervious surfaces normally contribute almost all of the total rain immediately to stormwater runoff.

There are four distinct yet interrelated effects of land use changes on the hydrology of an area:



1) Changes in peak flow characteristics; 2) changes in total runoff; 3) changes in water quality; and 4) changes in the hydrologic amenities (Leopold, 1968). The hydrologic amenities are what might be called the appearance or the impression that the river, and its channel and valleys, leaves with the observer.

Of all land use changes affecting the hydrology of an area, urbanization is the most impactful. As an area becomes urbanized, the peak rate of runoff and volume of runoff increase. These effects are caused by: 1) a reduction in the opportunity for infiltration, evaporation, transpiration and depression storage; 2) an increase in the amount of imperviousness; and 3) modification of the surface drainage patterns, including the associated development of stormwater management facilities.

Summary of Hazards Associated with Land Development

Land development clearly increases potential erosion and sediment hazards on-site by removing cover, developing cuts and fills that are more susceptible to erosion than the previously undisturbed soils and changing water conveyance routes. More subtle changes related to erosion and sediment include soil compaction (both planned and unplanned), longer slopes, and more and faster stormwater runoff.

Land development, in most instances, has the following potential effects off-site both during and following the development phase and reflect the impacts of changed use of the land on stormwater:

- Increased volumes of storm runoff.
- Higher peak flows of storm runoff if not modified by planned measures.
- Increased loads of sediment and other pollutants associated with the site unless prevented or minimized by planned measures.

The potential off-site effects include increased flooding, accelerated erosion of stream systems, increased sediment deposition in both streams and floodplains, and adverse impacts to the biological communities associated with the streams and floodplains.

Each progression toward more intensive land use tends to disrupt the ongoing natural processes that protect and preserve water quantity and water quality. Therefore, to ensure future protection of water resources, it is imperative that land uses be managed in a responsible way.

As we reflect on the processes and the potential impact, we should recognize the importance of sound site planning, timely and proper installation of the measures planned, and the need for long-term maintenance of measures that sustain site stabilization. If the best available technology is used for planning, design, installation and maintenance of erosion and sediment control and stormwater management, the impacts of land development will be minimized. Other chapters of this handbook present relevant planning considerations, design criteria, and installation and maintenance information.

To address the hazards associated with land disturbance, The National Pollutant Discharge Elimination System (NPDES) Stormwater Program regulates stormwater discharges from construction activities. (Two other sources are also regulated, MS4s and industrial activities.) Most stormwater discharges are considered point sources, and operators of these sources may be required to receive an NPDES permit before they can discharge. This permitting mechanism is designed to prevent stormwater runoff from washing harmful pollutants into local surface waters such as streams, rivers, lakes or coastal waters.

Most states are authorized to implement the NPDES Stormwater Program and administer their own stormwater permitting programs. Mississippi is such a delegated state (see **Appendix B**). EPA remains the permitting authority in a few states, in territories, and on most tribal lands. For these areas, EPA provides oversight and issues stormwater permits.

Chapter 2

General Planning Concepts for Erosion Control, Sediment Control and Stormwater Management

This chapter provides important concepts and other selected information that is important for qualified design professionals to know about various aspects of erosion control, sediment control, and stormwater management. It is believed that the contents will, as a minimum, cause qualified design professionals to recognize when other professionals may need to be involved. A qualified design professional should recognize that planning involves several disciplines and that each discipline has a body of in-depth knowledge that is important and needed on complex sites. Although often discussed separately, erosion control, sediment control, and stormwater management are interrelated and, when planning occurs, the thought process must conceive a system of practices and measures that consider all three together.

The basic details of planning, including step-by-step procedures, are located in Chapter 3.

Potential Erosion and Sediment Problems Associated with Land Development

The principal effect land development activities have on the erosion process consists of exposing disturbed soils to raindrops and to storm runoff. Shaping of land for construction or development purposes alters the soil cover in many ways, often detrimentally affecting physical properties of the soil, onsite drainage and storm runoff patterns and, eventually, off-site stream and stream-flow characteristics. Adverse effects of erosion and sedimentation include impacts on soil, water quantity, water quality, and the aquatic ecosystem. Potential hazards associated with development include the following items:

1. An increase in developed areas exposed to storm runoff and soil erosion.
2. Increased volumes of storm runoff, accelerated soil erosion and sediment yield and higher peak flows caused by:
 - a. Removal of existing protective vegetative cover.
 - b. Exposure of underlying soil or geologic formations potentially more erodible than original soil surface.
 - c. Reduced capacity of exposed soils to absorb rainfall due to compaction caused by heavy equipment.
 - d. Enlarged drainage areas caused by grading operations, diversions and street construction.
 - e. Prolonged exposure of unprotected disturbed areas due to scheduling problems and/or delayed construction.

- f. Shortened times of concentration of surface runoff caused by altering slope steepness, slope length, and surface roughness and through installation of “improved” storm-drainage facilities.
 - g. Increased impervious surfaces associated with the construction of streets, buildings, sidewalks, paved driveways, and parking lots.
3. Creation of exposures facing south and west that may hinder plant growth due to adverse temperature and moisture conditions.
 4. Exposure of subsurface materials that are rocky, acidic, droughty, or otherwise unfavorable to the establishment of vegetation.

Erosion and Sediment Control

A wide array of practices and measures are used for erosion and sediment control. Most of the practices and measures have application over the entire State.

There are numerous simple concepts that can provide an effective framework for minimizing erosion on a construction site and reducing delivery of sediment off of the site.

- Minimize the area disturbed by leaving existing vegetation that does not have to be removed.
- Minimize the period of bare ground by shortening construction periods and staging a project when possible.
- Sequence installation in a manner that supports shortened construction periods and permits the use of temporary and permanent seeding when the practices can be most effective.
- Use sediment control and turbidity measures that minimize sediment and turbid water from leaving the disturbed site.
- Plan appropriate erosion control for all kinds of erosion that may occur depending upon specific site conditions. Give special attention to cut and fill slopes. Give special attention to sites that are transected by streams or are in close proximity to streams or reservoirs.
- Install erosion-control plantings at every opportunity.
- Prevent sediment from leaving a construction site at entrance/exits during muddy periods.

- Maintain practices to ensure their effectiveness. This includes regular and timely inspections.

Potential Stormwater Problems Associated with Land Development

All forms of land use affect water quality. In an undeveloped area, many ongoing physical, chemical and biological processes interact to recycle most of the materials found in the stormwater runoff. As human land use intensifies, these processes are disrupted. Human activities add materials to the land surface (pesticides, fertilizers, animal wastes, oil, grease, heavy metals, etc.). These materials are then washed off by the rainfall and runoff, thereby increasing the pollutant load carried to receiving waters by stormwater runoff.

Of primary importance to water quality is the “first flush”. This term describes the washing action that stormwater has on accumulated pollutants in the watershed. In the early stages of a runoff rain-event, the land surfaces, especially impervious surfaces like streets and parking areas, are flushed clean by the stormwater. This flushing creates a shock loading of pollutants. Extensive studies in Florida have determined that the first flush equates to the first 1” of runoff which carries 90% of the pollution load from a storm (USGS, 1984). More recently, research has identified that the first ½” of runoff provides the first flush in some instances, while other research has determined that runoff in excess of 1”, including cut/fill areas associated with construction, may be more realistic. It is proper to say at this time that the amount of runoff that creates the “first flush” depends on several factors, including the activity, site conditions and pollutants. Treatment of the first flush, whatever the runoff amount, will help ensure that the water-quality impacts of stormwater are minimized.

Finally, the value of the hydrologic environment as an amenity is primarily affected by three factors: stability of the stream channel, accumulation of trash, and disruption of the stream community. A channel which is gradually enlarged because of increased floods caused by urbanization tends to have unstable and unvegetated banks, scoured or muddy channel beds, and unusual accumulations of sediment and debris.



Together with the accumulation of trash in the channel and floodplain (beverage cans, lumber scraps, lawn clippings, concrete, wire, etc.), these all tend to severely decrease the visual attractiveness of a stream. Ultimately, these factors disrupt the natural balance in the streams’ biota resulting from the addition of nutrients, organics, and sediment. These disruptions increase algal growth and turbidity, lower the oxygen content of the water, and thereby change the biological character of the stream.

In summary, each progression toward more intensive land use tends to disrupt the ongoing natural processes that protect and preserve water quality. Therefore, to ensure future protection of water resources, it is imperative that land uses be managed in a responsible way.

What is Stormwater Management?

Historically, urbanization has resulted in the development of stormwater-management systems to reduce flooding. These systems were developed because of their convenience and the protection they provided to property. Often, stormwater-management systems were designed for safety and convenience without recognition of other important considerations. Therefore, no matter how large the rainfall or its duration, the stormwater system was expected to remove the runoff as quickly as possible, and to restore maximum convenience in the shortest possible time. In other words, until recently, stormwater management was concerned with only the quantitative effects of runoff.

Today, however, stormwater management is far more comprehensive. An effective program involves the implementation of actions to control water in its hydrologic cycle with the objectives of providing (1) flood control; (2) nonpoint source pollution control; and (3) off-site erosion control. Stormwater management applies to rural and urban areas alike; however, the techniques presented in this manual are most relevant to urban or urbanizing situations.

To accomplish the three objectives of stormwater management, it is necessary to ensure that the volume, rate, timing and pollutant load of runoff after development are similar to those that occurred prior to development. The approach suggested in this manual is to minimize the adverse impacts of stormwater through a coordinated system of source controls. Source controls emphasize the prevention and reduction of nonpoint pollution and excess stormwater flow before it ever reaches a collection system or receiving waters. Typical control strategies and management criteria to accomplish the objectives of stormwater management are discussed below.

Flood Control

Flood control has historically been the most common goal of local, stormwater-management programs. The property damage, safety hazards, and inconvenience that can result from increased stream flooding in urbanizing watersheds usually get wide public attention and urgent demands for government action. Two levels of drainage systems must be considered in developing a management strategy for flood control: the primary drainage system and the major drainage system.

The primary drainage system consists of the street gutters and ditches, storm sewers, culverts, and open channels that are designed to prevent inconvenience and minor property damages from relatively frequent storm events. Of course, the most effective strategy for flood control at this level is to plan and design the primary drainage system adequately in advance, keeping in mind the future development potential of the drainage area. Unfortunately, many existing drainage systems were designed on a piecemeal, “as needed” basis with little regard for future upstream development. The capacity of such systems often becomes severely inadequate as upstream development progresses, resulting in frequent minor flooding and property damages.

One strategy for dealing with this problem is to replace or modify elements of the primary drainage system to provide the required capacity. This option is often expensive and does not control the source of the problem. However, this may be the only feasible method of correcting existing problems. To prevent future problems, an alternative strategy may be employed. Persons wishing to undertake new development may be required to control runoff from their sites in a manner that will not adversely affect the downstream drainage system. This control is usually accomplished through stormwater detention criteria.

Typical detention criteria will specify that stormwater runoff from a new development must be controlled so that the post-development peak runoff rate does not exceed the pre-development peak rate for some specific frequency design-storm or range of design-storm events. In many localities, a 10-year design storm is specified to preserve the effectiveness of downstream drainage structures that were originally designed to pass a 10-year pre-development storm. Other localities require that larger storms (i.e., 50- to 100-year events) must be detained and released at a controlled rate to reduce the downstream effects of major storms.

It should be kept in mind that, as attempts are made to control larger storm events, requiring slower release rates will also require larger storage volumes in detention systems.

The major drainage system comes into play when the capacity of the primary drainage system is exceeded.

This major system consists of the floodplains and surface-flow routes that water will follow during major storms. The most effective strategy for dealing with flooding at this level is to ensure that stormwater has a route to follow which will not cause major property damage or loss of life. To implement this strategy, floodplain ordinances, zoning regulations, or other land-use controls should be used to restrict floodplain development. In areas where development has already encroached on the floodplain, land owners should be encouraged to purchase flood insurance.

Nonpoint Source Pollution Control

Pollutants that are washed from the land surface and carried into the streams, rivers, and lakes with stormwater runoff have only recently been recognized as major contributors to water-quality degradation in urban and urbanizing watersheds. The goal of controlling this problem is therefore relatively new. Nonpoint-source pollution control is likely to receive highest priority in watersheds that feed public water supplies or recreation reservoirs; however, this goal should be addressed in all local stormwater management programs.

In urban areas, most of the stormwater detention practices that are used to control runoff quantity may also be adapted for use as best management practices for nonpoint-source pollution control. The design criteria of these practices for this purpose, however, are often different. The primary design strategy for pollution removal is to maximize the detention time of captured runoff. Although there have not been many monitoring studies to produce definitive design criteria, it is believed that basin-drawdown times between 30

and 40 hours will result in significant pollutant removal. The required storage volume of detention facilities can be tied to a first-flush capture (i.e., the initial 0.1" to 1" of runoff).

Off-Site Erosion Control

Off-site erosion control, as a management goal, must be addressed in all local stormwater-management programs. The strategies for dealing with this problem are similar to those for flood control. The major difference is in the frequency of the storm that must be controlled.

Studies have shown that most natural stream channels are formed with a bank-full capacity to pass runoff from a storm with a 1.5- to 2-year recurrence interval. As upstream development occurs, the volume and velocity of flow from these relatively frequent storms increases. Even smaller storms with less than 1-year recurrence intervals begin to cause streams to flow full or flood.

Stream channels are often subject to a 3- to 5-fold increase in the frequency of bank-full flows in a typical urbanizing watershed. This increase in flooding frequency places a stress on the channel to adjust its shape and alignment to accommodate the increased flow. Unfortunately, this adjustment takes place in a very short time period (in geologic terms), and the transition is usually not a smooth one. Meandering stream channels which were once parabolic in shape and covered with vegetation typically become straight, wide, rectangular channels with barren, vertical banks. This process of channel erosion often causes significant property damage, and the resulting sediment which is generated is transported downstream, further contributing to channel degradation.

An old strategy for dealing with this problem is to increase the carrying capacity and stability of affected streams through channel modifications (i.e. straightening, widening, lining with non-erodible material, etc.). Modifications to natural, continuous flowing streams, however, can be the subject of intense local controversy and require special permits such as a 404 permit issued by the U.S. Army Corps of Engineers. Recent innovations based on natural, stream-hydrology concepts are rapidly gaining favor and should be considered because of their beneficial effects on the aquatic environment.

Wherever modifications to natural flowing streams are being considered, extreme care must be taken to weigh the benefits of such modifications against the cost and the concerns of the local citizens. Where channel modifications are necessary, an attempt must be made to incorporate measures that will minimize adverse impacts to fish, wildlife, and the aesthetic quality of the stream.

On-site stormwater-detention criteria for new development projects can also be an effective strategy for preventing future increases in channel erosion. However, such criteria should be tied to more frequent storm events than typical flood-control criteria. Maintaining the pre-development peak-runoff rate from a 10-year storm, for example, will probably not effectively reduce downstream erosion since the majority of storm events will pass right through the detention system unimpeded.

For example, the minimum state or local stormwater-management criteria could be tied to a 2-year storm event. Receiving channels would then be capable of passing a 2-year storm without flooding or erosion after development of the site, or stormwater would be detained on the site so that the pre-development peak-flow rate from a 2-year storm is not

exceeded after development. While flows from larger, less frequent storm events may cause erosion problems downstream, it is believed that, because such events will occur less often, streams will have more time to recover and restabilize themselves.

Local stormwater-detention criteria can be made more restrictive by requiring that storms larger than a 2-year event be detained. However, the allowable release rate should be tied to the actual carrying capacity of the receiving stream or the 2-year pre-development peak-runoff rate.

Multiple-Purpose Criteria

Stormwater management criteria for flood control, erosion control, and pollution control are not necessarily mutually exclusive. In many cases, stormwater can be managed to accomplish all three goals simultaneously. For example, a stormwater-detention basin can be designed as a multipurpose structure by incorporating different release rates at different stages (storage elevations).

The first stage is designed to capture an initial volume of runoff (i.e., the first flush) and release it very slowly through a subsurface drainage system. The second stage begins with an orifice cut in the riser pipe which has the capacity to pass stormwater runoff at a 2-year pre-development rate when water elevation reaches the top of the riser. The purpose of this stage would be to control downstream channel erosion from frequent storms. The top of the riser pipe could serve as the outlet for the third stage and may be designed to pass a 10-year storm at a pre-development rate for moderate flood protection downstream. The emergency spillway should be designed to pass at least the 100-year storm. While such a multi-purpose design may not be feasible for all detention systems, there are often innovative approaches which can be taken to satisfy two or more local stormwater-management goals.

Flexibility

Flexibility is extremely important in stormwater-management programs. Each development project has a unique set of conditions and circumstances and a different potential for affecting the downstream drainage system.

Criteria which may be perfectly applicable to one project may be totally unsuitable for another. For example, requiring stormwater detention for flood control may be highly applicable to projects constructed in the upper reaches of a watershed, but may be unnecessary or even undesirable for new projects constructed near the outlet of the watershed.

A qualified design professional should be given an opportunity to design a drainage system which contributes to the achievement of established, local stormwater-management goals in the most cost-effective manner. To accomplish this, each project must be considered on an individual basis.

Principles of Stormwater Management

It is much more efficient and cost effective to prevent problems than to attempt to correct problems after the fact. Sound land-use planning decisions based on the site planning principles are essential as the first, and perhaps the most important, step in managing

stormwater-related problems. All new development plans (e.g., subdivisions, shopping centers, industrial parks, office centers, etc.) and redevelopment plans should include a comprehensive stormwater-management system.

Every piece of land is part of a larger watershed. A stormwater-management system for each development project should be based on, and should support, a plan for the entire drainage basin.

Optimum design of the stormwater-management system should mimic (and use) the features and functions of the natural drainage system, which is largely capital, energy and maintenance-cost free. Every site contains natural features that contribute to the management of stormwater under existing pre-development conditions. Depending upon the site, existing features such as natural drainageways, depressions, wetlands, floodplains, highly permeable soils, and vegetation provide natural infiltration, help control the velocity of runoff, extend the time of concentration, filter sediments and other pollutants, and recycle nutrients. Each development plan should carefully map and identify the existing natural systems. “Natural” engineering techniques should be used to preserve and enhance the natural features and processes of a site and to maximize the economic and environmental benefits. Engineering design can and should be used to improve the effectiveness of natural systems, rather than negate, replace or ignore them.

The volume, rate, timing and pollutant load of stormwater after development should closely approximate the conditions that occurred before development. To accomplish these objectives, two overall concepts must be considered: (1) the perviousness of the site should be maintained to the greatest extent possible, and (2) the rate of runoff should be slowed. Preference should be given to stormwater-management systems that use measures that maintain vegetative and pervious land cover and include on-site storage mechanisms. These systems will promote infiltration and slowing of the runoff.

On-site storage of stormwater should be maximized. Provision for storage can reduce peak runoff rates; aid in groundwater recharge; provide settling of pollutants; lower the probability of downstream flooding, stream erosion and sedimentation; and provide water for other beneficial uses. Stormwater runoff should never be discharged directly into surface or ground waters. Runoff should be routed over a longer distance, through grassed waterways, wetlands, vegetated buffers, and other works designed to increase overland flow. These systems provide time for increased infiltration and evaporation, allow suspended solids to settle, and remove pollutants before they are introduced to waters of the State.

Stormwater-management systems, especially those emphasizing vegetative practices, should be planned, constructed, and stabilized in advance of the facilities that will discharge into them. This principle is frequently ignored, thereby causing unnecessary off-site impacts, extra maintenance, re-working of grades, re-vegetation of slopes and grassed waterways, and extra expense to the developer. The stormwater-management system, including erosion and sedimentation controls, should be constructed and stabilized at the start of site disturbance and construction activities.

The stormwater-management system must be designed beginning with the outlet or point of outflow from the project. The downstream conveyance system should be evaluated to ensure that it contains sufficient capacity to accept the design discharge without adverse downstream impacts such as flooding, streambank erosion, and sedimentation. It may be

necessary to stabilize the downstream conveyance system, especially near the stormwater system outlet. A common problem is a restricted outlet which causes stormwater to back up and exceed the storage capacity of the collection and treatment system, resulting in temporary upstream flooding. This may lead to hydraulic failure of the stormwater-management system causing re-suspension of the pollutants and/or expensive repairs to damaged structures or property. In such circumstances, it is advisable to use more than one outlet or to increase the on-site storage volume.

Stormwater is a component of the total water resources that should not be casually discarded, but used to replenish those resources. Stormwater represents a potential resource out of place, with its location determining whether it is a liability or an asset. Given the water quantity and quality problems and challenges facing Mississippi, it is imperative that stormwater be considered an asset. Treated stormwater has great potential for providing beneficial uses such as irrigation (farm, lawn, parks, golf courses, etc.), recreational lakes, groundwater recharge, industrial cooling and process water, and other non-potable domestic uses.

Whenever practical, multiple-use, temporary-storage basins should be an integral component of the stormwater-management system. All too often, storage facilities planned as part of the system are conventional, unimaginative ponds which are aesthetically unpleasing. Recreational areas (e.g., ball fields, tennis courts, volleyball courts, etc.), greenbelt areas, neighborhood parks, and even parking facilities provide excellent settings for the temporary storage of stormwater. Such areas are not usually in use during periods of precipitation, and the ponding of stormwater for short durations does not seriously impede their primary functions. Storage areas should be designed with sinuous shorelines. Shorelines that are sinuous rather than straight increase the length of the shoreline. The increased shoreline also provides more space for the growth of shoreline vegetation, thus providing for greater pollutant filtering and for increased and diversified aquatic habitat.

Vegetated buffer strips should be retained in their natural state or created along the banks of all water bodies. Vegetated buffers prevent erosion, trap sediment, filter runoff, provide public access, enhance the site amenities, and function as a floodplain during periods of high water. They also provide a pervious strip along a shoreline which can accept sheet flow from developed areas and help minimize the adverse impacts of untreated stormwater.

The stormwater-management system must receive regular maintenance. Failure to provide proper maintenance reduces the pollutant removal efficiency of the system and reduces the system's hydraulic capacity. Lack of maintenance, especially to vegetative systems that may require revegetating, can increase the pollutant load of stormwater discharges. The key to effective maintenance is the clear assignment of responsibilities to an established agency (local government) or organization (homeowners association) and a regular schedule of inspections to determine maintenance needs. In addition, stormwater-system designers should find ways to make their systems as simple, natural, and maintenance free as possible.

Vegetation for Erosion and Sediment Control

Introduction

A dense and healthy vegetative cover protects the soil surface from raindrop impact, a major force in erosion and sedimentation. Also, vegetation shields the soil surface from the scouring effect of overland flow and decreases the erosive capacity of the flowing water by reducing its velocity.

The shielding effect of a plant canopy is augmented by roots and rhizomes that hold the soil, improve its physical condition, and increase the rate of infiltration, further decreasing runoff. Plants also reduce the moisture content of the soil through transpiration, thus increasing its capacity to absorb water.

Suitable vegetative cover offers excellent erosion protection and sediment control. Vegetative cover is essential to the design and stabilization of many structural, erosion-control practices. Vegetative cover is relatively inexpensive to achieve and maintain. Also, it is often the only practical, long-term solution to stabilization and erosion control on many disturbed sites.

Timely vegetative establishment or retention reduces the cost of vegetation, minimizes maintenance and repairs, and makes structural, erosion-control measures more effective and less costly to maintain. Landscaping is also less costly where soils have not been eroded. Natural areas (those left undisturbed) can provide low-maintenance landscaping, shade, and screening. Large trees increase property values if they are properly protected during construction.



Besides preventing erosion, healthy vegetative cover provides a stable land surface that absorbs rainfall, cuts down on heat reflectance and dust, and complements architecture. Property values can be increased dramatically by small investments in erosion control.

Plant selection should be considered early in the process of preparing the erosion and sediment-control plan. A diversity of species can be

grown in Mississippi due to the variation in both soils and climate. However, for practical, economical stabilization and long-term protection of disturbed sites, plant selection should be made with care. Many plants that will grow in Mississippi are inappropriate for soil stabilization because they do not protect the soil effectively, or they cannot be established quickly. Some plants may be very effective for soil stabilization, but are not aesthetically acceptable on some sites. In all cases, native vegetation should be the first plants considered when selecting plant materials for stabilization. Plant

selection is discussed and suggestions are made in the *Surface Stabilization* sections of Chapter 4 entitled *Permanent Seeding, Temporary Seeding, and Shrub, Vine and Groundcover Planting*. Also, a Vegetation Schedule used by the Mississippi Department of Transportation is provided as **Appendix G**.

Stabilization of most disturbed sites requires grasses and/or legumes that grow close together to provide a thick, close-growing cover. This is true even where part of or the entire site is planted to trees or shrubs. In landscape plantings, disturbed areas between trees and shrubs must also be protected either by mulching or by permanent grass, legumes, or mixtures.

Trees are excellent for long-term soil and water protection, but they will not stabilize concentrated flow areas.

Site Planning For Tree Protection

Select and clearly identify trees to be saved before beginning construction. No tree should be destroyed or altered until the construction plans are final. Floodplains and wetlands should be left in their natural condition. Locate roadways so they cause the least damage to valuable trees. Follow contours where feasible to minimize cuts and fills. Minimize trenching by locating several utilities in the same trench. Excavations for basements and utilities should be kept away from the dripline of trees.

Storage areas for construction materials and worker-parking areas should be noted on the site plan, and located where they will not cause soil compacting over roots.

When retaining existing trees in parking areas, leave enough ground ungraded around the tree to allow for its survival. Tree protection measures should be extended from the trunk to the edge of the dripline to protect the root systems from compaction. Tree wells may be needed to protect the roots from too much soil cover, ultimate compaction, and lack of aeration. Specific tree preservation practices are discussed in Chapter 4, *Preservation of Vegetation*.

Locate erosion and sediment-control measures within the limits of clearing and not in wooded areas to prevent deposition of sediment within the dripline of trees being preserved. Sediment basins should be constructed in the natural depressions, if possible, rather than in locations where extensive grading and tree removal will be required.

Selecting Trees to Be Retained or Planted



Trees may be exposed to insufficient sunlight and water; high winds; heat radiation from highways and parking lots; pollutants from cars and industries; root amputation because of sewer, water, gas and electric lines; pruning or “topping” because of power lines; and covering of roots by pavement and compaction. These items make the selection and management of trees extremely important.

The proper development of a forested-urban site requires a plan for tree retention or tree planting before construction begins. An overall requirement for selecting trees is that those trees selected should be appropriate for the proposed use of the development. The selection of tree species depends on the desired function of the tree, whether it be just erosion control or other functions such as shade, privacy screening, noise screening, appearance, enhancement of wildlife habitat, or a combination of these. The following characteristics of a tree should be considered when choosing a tree to retain or plant.

Hardiness

Select trees that are recommended for the area. See practice entitled *Tree Planting on Disturbed Areas*.

Mature Height and Spread

The eventual height of a tree must be considered in relation to location on the site to avoid future problems with buildings and utility lines. See practice entitled *Tree Planting on Disturbed Areas*.

Growth Rate

Some trees attain mature height at an early age; others take many years. Fast-growing trees may be brittle and possibly short-lived, while slow-growing trees are usually less brittle and live longer.

Root System

Avoid trees that have fibrous roots which may cause damage to water lines, septic tanks, or sidewalks and driveways.

Cleanliness

Maintenance problems can be avoided by not selecting trees that drop seedpods, cones, flowers, or twigs, in large amounts.

Moisture and Fertility Requirements

If suitable soils with adequate fertility are not available, trees tolerant of poor growing conditions should be planted.

Ornamental Effects

If a tree is unusually attractive in appearance, some other shortcomings may be overlooked, but make sure the tree is suited to the site.

Evergreen vs. Deciduous

Evergreens retain their leaves or needles throughout the year and are useful for privacy screens and noise barriers. Most deciduous trees drop their leaves in the fall and are preferable as shade trees. Some deciduous trees do not drop their leaves until spring.

Pest Resistance

Insects and disease problems exist among many trees. Each pest is related to the tree species itself, its vigor, and the site on which it is planted. Where control techniques are available, the tree owner's commitment and ability to apply them to a pest problem will determine whether the tree should be planted.

Life Expectancy and Present Age

Tree species with expected long-life spans should be favored. Long-lived species that are old may succumb to the stresses of construction, so younger trees of desirable species are preferred since they are more resilient and will last longer.

Health and Disease Susceptibility

Unhealthy trees and those with damaged areas on the tree should be considered for removal.

Structure

Check for structural defects that indicate weakness or reduce the aesthetic value of a tree: trees growing from old stumps, large trees with overhanging limbs that endanger property, trees with brittle wood, misshapen trunks or crowns, and small crowns at the top of tall trunks. Trees with strong tap- or fibrous-root systems are preferred to trees with weak rooting habits.

Aesthetics

Trees that are attractive and pleasing to the eye are desirable. Trees that have beauty during several seasons of the year are desirable and add value to the site.

Comfort

Trees provide cooling during the summer and buffer the cold winds of winter. Summer temperatures may be 10 degrees cooler under hardwoods than under conifers. Most deciduous trees drop their leaves in winter, allowing the sun to warm buildings and soil. Evergreens are more effective wind buffers.

Wildlife

Preference may be given to trees that provide food and cover for wildlife.

Relationship to Other Trees

Trees growing alone generally are more valuable than trees growing in groups, but trees in groups are more effective in preventing erosion and reducing stormwater runoff.

Suitability for the Site

Consider the height and spread of trees and how they may interfere with proposed structures and overhead utilities. Roots may interfere with walls, walks, driveways, patios, parking lots, waterlines, and septic systems.

Desirable trees should be identified and located on a map as part of the planning process.

Damage to Trees from Construction

Construction activities expose existing trees to a variety of stresses, resulting in injury ranging from superficial wounds to death. Understanding the types of damages that may occur to trees is important in planning for protection.

Surface Impacts

Tree trunks are often damaged during construction activities. Trees scarred by construction equipment are more susceptible to damage by insects and disease. Excessive pruning of trees to prevent contact with utility lines or buildings may destroy the visual appeal of the tree, may provide a source of entry for disease-causing fungi, or may kill the tree.

Wind damage is a greater potential problem than scarring, especially when some of the trees have been removed from a group of trees causing the survivors to be exposed to greater wind velocities. Also, trees develop root anchorage where it is needed the most. Isolated trees develop anchorage rather equally all around, with stronger root development on the side of the prevailing wind. The more a tree has been protected from the wind, the less anchorage it usually has. The result of thinning of trees may be that some of the remaining trees are blown over by strong winds (windthrow). An additional factor related to thinning is that thinning in favor of a single tall tree increases the hazard of lightning strike.

Root Zone Impacts

Disturbing the relationship between soil and tree roots can damage or kill a tree. The roots of an existing tree are established in an area where a specific environment of soil, water, oxygen, and nutrients is present. The mass of the root system must be the correct size to balance the intake of water from the soil with the transpiration of water from the leaves.

Raising the grade as little as 6" can retard the normal exchange of air and gases. Roots may suffocate due to lack of oxygen or be damaged by toxic gases and chemicals released by soil bacteria. Raising the grade may also elevate the water table and change the potential of the soil to function as a growing medium suitable for the trees that were growing there before the filling occurred.

Lowering the grade is usually not as damaging as elevating the grade. Shallow cuts of 6" to 8" will remove most of the topsoil and some feeder roots and expose some to drying and freezing. Deep cuts may sever a large portion of the root system, depriving the tree of

water and increasing the chance of windthrow. Lowering the grade may also lower the water table.

Trenching or excavating through a tree's root system eliminates part of the root system and can be very detrimental. Trees that lose as much as 40 percent of their root system usually die within 2 to 5 years. Tunneling may be a better alternative with species that do not have tap roots.

Soil compaction caused by heavy equipment, materials storage, and paving within the dripline of trees restricts air and water from roots by reducing pore space of the soil and by reducing infiltration.

Site Considerations for Non-woody Vegetation

Species selection, establishment methods, and maintenance procedures should be based on site characteristics, including soils, slope, aspect, climate, and expected management.

Soils

Many soil characteristics influence the selection of plants and their establishment requirements. These include: including acidity, moisture retention, drainage, texture, organic matter, fertility, and slope influence the selection of plants and their establishment requirements. For example, Bahia grass and centipede are suited to droughty soils since they are more drought tolerant than most other grasses. **Appendix A** contains tables that provide a number of interpretations related to the soils that exist in Mississippi. One characteristic that will not be found in tables is the occurrence of compaction created incidentally as a result of equipment traffic, especially when the soil is wet or moist. Compaction can have an adverse impact on plant establishment and maintenance and should be addressed before establishment of vegetative cover



Slope

The steeper the slope, the more essential is a vigorous vegetative cover. Good establishment practices, including seedbed preparation, liming, fertilizing, proper planting, mulching, and anchoring of mulch are critical. The degree of slope may limit the equipment that can be used in seedbed preparation, planting, and maintenance.



Woody plants, shrubs, vines, and trees generally provide better long-term erosion control on steep slopes. They may be more costly and slower to establish, but can provide substantial savings in maintenance. Also, they can be more desirable in the overall landscape plan.

Aspect

Aspect affects soil temperature and available moisture. South- and west-facing slopes tend to be warmer and drier, and often require special treatment. Warm-season species tend to do better on south- and west-facing slopes in Mississippi because they are usually more drought and heat tolerant.

Climate

The regional climate must be considered in selecting well-adapted plant species. Species adaptation and seeding dates in Mississippi are based on three broad geographical areas: North, Central, and South. Climatic differences determine the appropriate plant selections based on such factors as cold-hardiness, heat tolerance, and tolerance to a cool-growing season.

Management Requirements

When selecting plant species for erosion control and stabilization, the post-construction land use and the expected level of maintenance must be considered. In every case, future site management is an important factor in plant selection.

Select plant species that are wear resistant and have rapid wear recovery for sites that receive heavy use, such as a sports field. A wear-resistant plant that also recovers rapidly from foot traffic is Bermuda grass. Bermuda grass also has a fast establishment rate and is adapted to all geographical areas in Mississippi.

Where a neat appearance is desired, use plants that respond to frequent mowing and other types of intensive maintenance. Likely choices for quality turf in north Mississippi are Bermuda grass or fescue, while in central or south Mississippi, Bermuda grass, centipede, or zoysia are good choices.

At sites where low maintenance is desired, low fertility requirements and vegetation persistence are particularly important. *Sericea lespedeza* and tall fescue are good choices in north Mississippi, while Bahia grass and centipede do well in central and south Mississippi.

Seasonal Considerations for Non-Woody Vegetation

Newly constructed slopes and other barren areas should be seeded or sodded as soon as possible after grading. Grading operations should be planned around optimal seeding dates for the particular region, where feasible. The most effective times for planting perennial grasses and legumes generally extend from March through May and from late August through October. Outside these dates, the probability of failure is higher. If the time of year is not suitable for seeding permanent cover (perennial species), a temporary cover should be planted or the area may be stabilized with crimped or tackified mulch. Temporary seedings of annual species (small grains, ryegrass, millets, etc.) often succeed at times of the year that are unsuitable for seeding permanent (perennial) species. Planting dates may differ for temporary species, depending on the geographical area of Mississippi.

Growing seasons must be considered when selecting species. Grasses and legumes are usually classified as warm-season or cool-season in reference to their season of growth. Cool-season species produce most of their growth during the fall and spring and are relatively inactive or dormant during the hot summer months. Therefore, fall is the most dependable time to plant them. Warm-season plants grow most actively during the summer, and go dormant after the first frost in the fall. Spring and early summer are the preferred planting times for warm-season species.

Selecting Shrubs, Vines and Groundcovers to be Retained or Planted

As with trees, several plant characteristics and environmental requirements should be considered when selecting shrubs, vines and groundcovers. Closer adherences to plant requirements yield a greater chance of achieving a successful landscape.

Hardiness

Plants have varying capacities to tolerate cold or heat. Cold tolerance is of most concern. The state of Mississippi spans four plant hardiness zones: Zone 7a (located generally in the northeast corner of the state), Zone 7b (located in the northwest corner of the state spanning the north-central portions of the state), Zone 8a (located along the western portion of the state and throughout the south-central areas), and Zone 8b (located in the six southernmost counties). The zones are determined by the range of average annual minimum temperatures. The average range of minimum temperatures for Zone 7a is 0 to 5 degrees Fahrenheit; Zone 7b is 5 to 10 degrees Fahrenheit; Zone 8a is 10 to 15 degrees Fahrenheit; and for Zone 8b, 15 to 20 degrees Fahrenheit (See Figure-1: Geographical Areas for Species Adaptation).

Landscape plants that are not capable of tolerating temperatures below 10 degrees should not be expected to escape injury during an average winter in Zones 7a and 7b. However, they should be adequately adapted to Zones 8a and 8b.

Plant hardiness can be greatly influenced by nearby bodies of water since water buffers change in temperature. Other structures or other plants can moderate extreme temperatures and shelter landscape plants, enabling marginal species to better tolerate winter conditions.




Figure -1 Geographical Areas for Species Adaptation

Summer Heat Tolerance

A plant's capacity to survive the stress of high temperature is also a concern. Heat interacts with other environmental factors, especially soil moisture conditions and sunlight, to influence the range of adaptability of a plant. Usually associated with high temperatures is rapid depletion of soil moisture, especially in late summer. Direct sunlight increases the severity of heat effects on plants. Since Mississippi has periods of high temperatures and short winters, spruce, hemlock, and yew are generally poor performers. Other conifers such as deodar cedars and cryptomeria are not hardy farther north into Zone 7a, but offer good substitutes for hemlocks and spruces in Mississippi.

Moisture Requirements and Soil Drainage

Landscape plants vary widely in the amount of moisture they need to thrive. If a drought-tolerant plant receives a lot of rain, it can be more susceptible to invasion by normally weak pathogens, especially where the soil drains slowly. On the other hand, plants that require large amounts of water for best performance are easily drought stressed when water is withheld or if planted in very well-drained soils. Such conditions may actually attract insect pests to stressed plants.

Plants that normally require a lot of water can be irrigated so that the ornamental attributes of the plant are maintained. However, this is a misuse of water resources that can be avoided if consideration is given to appropriate plant selection.

Soil pH

Soil pH can have a profound influence on the performance of landscape plants. However, most landscape plants perform adequately within a soil pH range of 5.5 to 6.2. Plants listed in Tables SVG 1-5 should grow satisfactorily within this pH range.

Plant Pest Susceptibility

It is unwise to use pest-susceptible plants in areas where those particular pests thrive. For example, most species of euonymus are attacked by euonymus scale, and Red Tip is highly susceptible to leaf spot. Other landscape options for plant materials might be selected that do not have the same susceptibilities. Plants listed in Tables SVG 1-5 have few major pest problems.

Nutritional Requirements

Newly set plants often require little additional fertilizer because of the presence of residual fertilizer in the root ball. At this stage, supplying water is far more important than adding fertilizer. Also, most well-established shrubs require less fertilizer to maintain an attractive plant than is usually required by poorly established shrubs.

Light Requirement

Plants that require full sun (at least 8 hours of direct sunlight per day) are weakened in low light situations. Plants that need some shade can become damaged and unattractive in full sun.



Rate of Growth and Mature Size

For rapid cover, faster growing plants are desired. However, mature size and other plant characteristics should be considered. For example, where a screen is needed, a slower growing evergreen shrub may be desired over a fast-growing deciduous plant. Take all plant characteristics into account when selecting plants for a site. If money is available, both needs can be met by planting fast-growing, short-lived plants to provide a quick screen and, at the same time, planting slower growing plants and allowing them to mature. When the fast-growing plants become overgrown, they can be removed to allow the more desirable plants to take their place.

Treating Sites to Establish Grass, Legumes, Shrubs, Vines and Groundcover

Topsoiling

The surface layer of an undisturbed soil is often enriched in organic matter and has physical, chemical, and biological properties that make it a desirable planting and growth medium. These qualities are particularly beneficial to plant establishment. Consequently, where practical, topsoil should be stripped prior to construction and stockpiled for use in the final vegetation of the site. Stockpiling topsoil may eliminate costly amendments and repair measures later. Topsoil may not be required for the establishment of less demanding, lower maintenance plants, but it is essential on sites having shallow soils or soils with other severe limitations. It is essential for establishing fine turf and ornamentals.

The need for topsoil should be evaluated, taking into account the amount and quantity of available topsoil and weighing this against the difficulty of preparing a good seedbed on the existing subsoil. Where a limited amount of topsoil is available, it should be reserved for use on the most critical areas.

Soil Amendments

Lime is almost always required on disturbed sites in Mississippi to decrease soil acidity. Lime raises the pH, reduces exchangeable aluminum, supplies calcium and magnesium

for vigorous plant growth, and dispenses heavy clays that impede root penetration. A soil test should be used to determine the need for liming materials.

Plant nutrients, such as phosphorus and potassium, will usually be required even on the best soils. Plant-nutrient application rates for a particular species of vegetative cover should be applied according to a soil-test report.

Soil amendments should be applied uniformly and well mixed with the top 6" of soil during seedbed preparation.

Site Preparation

The soil on a disturbed site must be modified to provide an optimum environment for germination and growth. Addition of topsoil, soil amendments, and tillage are used to prepare a good seedbed. At planting, the soil must be loose enough for water infiltration and root penetration, but firm enough to retain moisture for seedling growth. Tillage generally involves disking, harrowing, chiseling, or some similar method of land preparation. Tillage should be done on the contour, where feasible, to reduce runoff and erosion. Lime and fertilizer should be incorporated during the tillage.

Planting Methods

Seeding is by far the fastest and most economical method that can be used with most species. However, some grasses, such as hybrid Bermuda grass do not produce seed and must be planted vegetatively. Seedbed preparation, liming, and fertilization are essentially the same regardless of the method chosen.

Uniform seed distribution is essential. This is best obtained using a cyclone seeder, conventional grain drill, cultipacker seeder, or hydraulic seeder. The grain drill and cultipacker seeder are pulled by a tractor and require a fairly clean, smooth seedbed.

Seeding rates recommended in this manual have taken into account the "insurance" effect of extra seed. Rates exceeding those given are not recommended because over dense stands are more subject to drought, competitive interference, and are unnecessarily costly.

Because uniform distribution is difficult to achieve with hand broadcasting, it should be considered only as a last resort. When hand broadcasting of seed is necessary, uneven distribution may be minimized by applying half the seed in one direction and the other half at right angles to the first. Small seed should be mixed with sand for better distraction.

A sod seeder (drill seeder or no-till planter) can plant seed into an existing cover or mulch or be used to restore or repair a weak stand. It can be used on moderately uneven, rough surfaces. It is designed to penetrate the sod, open narrow slits, and deposit seed with a minimum of surface disturbance.

Hydroseeding may be the most effective seeding method on steep slopes where equipment cannot work safely. A rough surface is particularly important when preparing slopes for hydroseeding. In contrast to other seeding methods, a rugged or rough seedbed gives the best results.

Sprigging refers to planting stem fragments consisting of runners (stolons) or lateral, below-ground stems (rhizomes), which are sold by the bushel. Sprigs can be hand-planted or planted in furrows using a transplanter. This method works well with Bermuda grass. Sprigs can be covered with soil by light disking, or cultipacking. Common and forage-type hybrid Bermuda grass will cover over much more quickly than the lawn-type Bermuda grass.

Plugging differs from sprigging only in the use of plugs cut from established sod, in place of sprigs. It requires more planting stock, but usually produces a complete cover more quickly than sprigging. It is usually used to introduce a superior grass into an old lawn.

In sodding, the soil surface is completely covered by laying cut sections of turf. It is limited primarily to lawns, steep slopes, and sod waterways in Mississippi. Turf-type Bermuda, centipede, and zoysia are usually the types of turf used for sodding. Plantings must be wetted down immediately after planting, and kept well watered for a week or two thereafter.

Sodding, though quite expensive, is warranted where immediate establishment is required, as in stabilizing drainage ways and steep slopes, or in the establishment of high-quality turf. If properly done, it is the most dependable method and the most flexible in seasonal requirements. Sodding can be done almost any time of the year in Mississippi.

Inoculation of Legumes

Legumes have bacteria called rhizobia, which invade the root hairs and form gall-like “nodules.” The host plant supplies carbohydrates to the bacteria, that supply the plant with nitrogen compounds fixed from the atmosphere. A healthy stand of legumes, therefore, does not require nitrogen fertilizer. *Rhizobium* species are host specific in that a given species will inoculate some legumes but not others. Therefore, successful establishment of legumes requires the presence of specific strains of nodule forming, nitrogen-fixing bacteria on their roots. In areas where a legume has been growing, sufficient bacteria may be present in the soil to inoculate seeded plants, but in other areas the natural *Rhizobium* population may be too low.

In acidic subsoil material, if the specific *Rhizobium* is not already present, it must be supplied by mixing it with the seed at planting. Cultures for inoculating various legume seed are usually available through seed dealers.

Among the legumes listed for use in this manual, crownvetch is the only one generally requiring inoculation. Lespedeza nodule bacteria are widely distributed in the soils of Mississippi unless the site has had all surface soil removed.

Irrigation

Irrigation, though not usually required, can extend planting dates into the summer and ensure seedling establishment. Damage can be caused by both under and over irrigating. If the amount of water applied penetrates only the first few inches of soil, plants may develop shallow root systems that are prone to desiccation during droughts. If supplementary water is used to get seedlings up, it must be continued until plants become completely established.

Mulching

Mulch is essential to the successful establishment of vegetation of most disturbed sites, especially on difficult sites such as southern exposures, channels, and excessively dry soils. The steeper the slope and the poorer the soil, the more valuable mulch becomes. Mulch protects the site from erosion until the vegetation is established. In addition, mulch aids seed germination and seedling growth by reducing evaporation, preventing soil crusting, and insulating the soil against rapid temperature changes.

Mulch may also protect surfaces that cannot be seeded. Mulch prevents erosion in the same manner as vegetation, by protecting the surface from raindrop impact and by reducing the velocity of overland flow.

Small grain straw (wheat, oats, barley, or rye) is the most widely used and one of the best mulch materials. However, other materials, including manufactured mulches, also work well. Mulching materials covered in this manual have their respective advantages and appropriate applications, and a material should not be selected on the basis of cost alone. The effectiveness of straw mulch can be increased by crimping or tacking.

Maintenance

Satisfactory stabilization and erosion control requires a complete vegetative cover. Even small breaches in vegetative cover can expand rapidly and, if not repaired, can result in excessive soil loss from an otherwise stable site. A single heavy rain will enlarge rills and bare spots and, the longer repairs are delayed, the more costly they become. Prompt action will keep soil loss, sediment damage, and repair costs down. New plantings should be inspected frequently and maintenance performed as needed. If rills and eroded areas develop, they must be repaired, seeded, and mulched as soon as possible.

Maintenance requirements extend beyond the seeding phase. Damage to vegetation from disease, insects, traffic, etc., can occur at any time. Pest control (weed or insect) may be needed at any time. Weak or damaged spots must be fertilized, seeded, and mulched as promptly as possible.

Vegetation established on disturbed soils often requires additional fertilization. Frequency and amount of fertilizer to apply can best be determined through periodic soil testing. A fertilization program is required for the maintenance of turf and sod that is mowed frequently. Maintenance requirements should always be considered when selecting plant species for vegetation.

Chapter 3

Erosion and Sediment Control Plan Preparation

What is a Plan for Erosion and Sediment Control and Stormwater Management?

A plan for erosion and sediment control and stormwater management is the document which provides the practices and measures to prevent or reduce erosion on construction sites and minimize the impacts of sediment, turbidity, and hydrologic changes off-site. It is the part of a Stormwater Pollution Prevention Plan (SWPPP) (defined in glossary) or Construction Best Management Practices Plan (CBMPP) that ensures that erosion and sediment control is appropriate for the development activities and planned use of the site. Plan components are described in detail later in this chapter.

Designs of practices are usually prepared after a plan is adopted and, therefore, designs are not considered a part of the plan. Design of practices may also require the plan to be modified based on design requirements. Practice design criteria and guidelines for installation are discussed in Chapter 4 and provide a basis for developing sound specifications.

Who is Responsible for the Plan?

The owner or operator of the land planned for development or needing treatment from a previous disturbance has the responsibility for plan preparation and adequacy. Although the owner or operator may designate a qualified design professional to prepare and implement the plan, the owner or operator retains the ultimate responsibility.

Under the State of Mississippi's General Permit for Large Construction Sites (greater than five acres), "owner or operator" is defined as "the party that has operational control over construction plans and specifications, including the ability to make modifications to those plans and specifications" or "the party has day to day operational control of those activities at a project that are necessary to ensure compliance with a stormwater pollution prevention plan for the site or other permit conditions (i.e., they are authorized to direct workers at a site to carry out activities required by the SWPPP or comply with other permit conditions)."

If it becomes obvious during construction that additional practices or measures are needed or that the planned system is not appropriate, the shortcoming should be brought to the attention of the project manager for action by an appropriate design professional and concurrence by the owner, operator, or their designee. In this scenario, additional planning must continue to ensure that the plan is up-to-date and adequate.

What Is an "Adequate" Plan?

An adequate plan contains sufficient information to describe the system intended to control erosion on the construction site, minimize related off-site sediment delivery and

turbidity, and address potential problems associated with hydrologic changes off-site. If regulations exist, more details may be required to satisfy the approving authority that the potential problems of erosion and sediment will be adequately addressed.

The length and complexity of the plan should be commensurate with the size and complexity of the project, severity of site conditions, and the potential for off-site damage. Obviously, a plan for constructing a house on a single subdivision lot will not need to be as complex as a plan for a shopping center development. Plans for projects undertaken on relatively flat terrain will generally be less complicated than plans for projects constructed with steep slopes with higher erosion and sediment-delivery potential. The greatest level of planning and detail should be evident on plans for projects that are adjacent to flowing streams, wetlands, dense population centers, high-value properties, coastal resources, and other critical habitats where damage may be particularly costly or detrimental to the environment.

The Step-by-Step Procedures for Plan Development outlined later in this chapter are recommended for the development of all plans. **Appendix B** of this manual provides a copy of the State of Mississippi Large Construction general permit, which provides requirements for site plans of developments greater than 5 acres. A sample Erosion and Sediment Control Plan is provided in **Appendix D**.

The checklist following the procedures can be used by qualified design professionals as a checklist for plan content and format.

General Considerations for Preparing Plans

Qualified design professionals should have a sound understanding of state and local laws and regulations related to erosion and sediment control and stormwater management. In addition, they must be competent in the principles of erosion and sediment control and stormwater management.

Developers and qualified design professionals can minimize erosion, off-site sediment delivery, turbidity issues, and other construction problems by selecting areas appropriate for the intended use because tracts of land vary in suitability for development. Knowing the soil type, topography, natural-landscape values, drainage patterns, receiving-stream characteristics and classification, flooding potential, areas of contaminated soil, and other pertinent data are useful in identifying both beneficial features and potential problems and challenges of a site.

A plan should contain enough information to ensure that the party responsible for development of a site can install the measures in the correct sequence at the appropriate season of the year. Sufficient information should be included to provide for maintaining the practices and measures during construction and after installation has been completed. A schedule of regular inspections and repair of erosion and sediment control BMP's should be set forth to ensure that maintenance receives appropriate attention and is accomplished.

Will the development of the site result in increased peak rates of runoff? Will this result in flooding or channel degradation downstream? If so, considerations should be given to

stormwater-control structures on the site. Local ordinances related to stormwater management must be considered and met.

As previously stated, the length and complexity of a plan should be commensurate with the size and complexity of the project, severity of site conditions, and the potential for off-site impacts. A plan may contain a description of the potential erosion and sediment-related problems. If a site is in the coastal zone, in a watershed with a formally designated impacted stream, or has contaminated soil or hazardous waste on the site, additional attention will be required during plan development (see Areas of Special Concern below).

For regulated sites in Mississippi, the plan must satisfy the Mississippi Department of Environmental Quality's (MDEQ) requirement that the potential problems related to erosion, sediment, stormwater, and wastewater will be adequately addressed.

New or innovative conservation measures or modifications to standard measures in this manual may be used if the proposed measure is reviewed by a qualified design professional and determined to be as effective as the practice for which it is being substituted.

Where applicable, the plan for a site should be included in the general-construction contract. To facilitate reviews and its use on the site, the plan should be prepared and assembled so that it may be reviewed as a separate document.

Areas of Special Concern

Contaminated Sites

For sites that are contaminated with hazardous substances (based on background levels), care should be taken to ensure that the contamination is appropriately managed. When soil potentially containing hazardous substances (based on background levels) is excavated at a site, it should be stored in covered roll-off containers or some other conveyance until an adequate waste determination, as required by both State and federal law, has been conducted. Soil that is contaminated above either the U.S. Environmental Protection Agency's or the MDEQ's established toxic concentrations or contaminated with listed hazardous wastes must be manifested and disposed at an approved hazardous waste treatment, storage, disposal (TSD) facility. Also, equipment used in the excavation process must be adequately decontaminated. All investigation-derived waste materials produced as a result of the decontamination procedures must be disposed in accordance with applicable State and federal requirements.

Solid waste that has been disposed of illegally (unpermitted solid waste dumps or burial sites) may be encountered during construction activities, and a variety of solid wastes can be generated during construction activities. Persons should contact the MDEQ's Office of Pollution Control if there are questions on how to proceed if illegal solid-waste dumps or buried solid wastes are encountered, or regarding proper management of solid wastes generated during construction. Brownfield sites (see Glossary for definition) may have issues that call for unique approaches for remediation and or construction. The MDEQ's Groundwater Assessment and Remediation Division provides oversight of assessment

and remediation activities concerning these types of sites through its Brownfield Redevelopment and Voluntary Cleanup Program.

Cultural Resources

Cultural resources that may be altered, disturbed or destroyed by project implementation should be reported. Cultural resources consist of prehistoric and historic archaeological sites and historic structures (bridges, objects, buildings, etc., 50 years or older). If a cultural resource is known to exist or is discovered during project implementation, the Mississippi Department of Archives and History should be contacted immediately for further guidance. The Mississippi Department of Archives and History also maintains a listing of Historic Districts and Historic Structures and is responsible for maintaining a Statewide Archaeological Inventory, a database that contains the locations and significance of previously recorded archaeological sites. A project will be allowed to proceed as planned under normal circumstances, after a cultural resource has been recorded and protected if required.

Stream Alterations

Streams, both perennial and intermittent, are considered “waters” of the United States and are regulated as “wetlands” under the Clean Water Act, Section 404, by the U.S. Army Corps of Engineers. Relocating streams or other modifications must be approved by the Corps of Engineers. In-depth guidance for obtaining approval for alterations of streams is beyond the scope of this manual. Detailed information should be obtained from the U.S. Army Corps of Engineers serving the area.

Stream alterations also require a 401 Clean Water Certification from the U.S. Army Corps of Engineers. Alterations also require approval by the MDEQ under applicable rules of the department.

Associated with streams are the nearby adjacent areas, and local regulations involving buffer zones may prohibit or otherwise restrict disturbances and construction in these areas. Streams and nearby adjacent areas should be avoided whenever possible. If disturbance of these areas is absolutely necessary, the applicable stream protection methods are discussed in-depth in the *Stream Protection* section of Chapter 4. However, as stated, these methods should be used only where absolutely necessary.

Wetlands

Construction plans must respect the wetlands regulations of the Clean Water Act, Section 404, and all applicable MDEQ and Mississippi Department of Marine Resources rules. While the details of the regulations are beyond the scope of this manual, it must be noted that wetlands cannot be altered by dredging and filling except in small increments approved by the U.S. Army Corps of Engineers and, in addition, construction plans shall be prepared to prevent negatively impacting wetlands off-site.

Threatened and Endangered Species

Threatened and endangered species habitats that may be altered, disturbed, or destroyed should be reported. If a threatened and endangered species is found within the proposed work area, the U.S. Fish and Wildlife Service should be consulted before work proceeds.

Components of a Plan

This subtopic describes the typical components that should be included in a plan. Local or state regulations may require additional items or more detailed information than listed. There are typically two components of a plan: a Site-Plan Map showing locations of the planned practices and a Written Narrative. Supporting materials are essential to develop the plan and they should be a part of the associated file material available with the plan. In addition, other components such as a site-location map are needed or required to satisfy regulatory requirements.

Site-Plan Map (Sometimes Referred to as Treatment Map)

This map may include a site-development drawing and a site-erosion and sediment-control drawing depicting types and, to the extent possible, locations of planned conservation practices. Map scales and drawings should be appropriate for clear interpretation. Site planners are urged to use the standard coding system for conservation practices contained at the end of this chapter. Use of the coding system will result in increased uniformity of plans and better readability for plan reviewers, job superintendents, and inspectors statewide. The State of Mississippi's Large Construction General Permit provides specific requirements concerning site maps and can be found in **Appendix C**.

Written Narrative

Where needed, additional information that is not included on the site-plan map should be included in a plan narrative that is written in a clear, concise manner. Typical items to include are the planned measures. Other items that may be needed include (a) a construction schedule that provides information both on sequence and time of year for installing the various practices and measures; (b) information on maintaining the practices and measures during construction and after installation have been completed, and (c) a schedule for regular inspections and repair of erosion and sediment-control and stormwater measures during construction. In some instances, existing conditions at the site and adjacent areas and rationale for those decisions involved in choosing erosion and sediment-control measures may be included to help clarify the plan.

Adequate information provided by the narrative is important for the plan reviewer, the construction superintendent, and the inspector. These details help ensure that erosion- and sediment-control and stormwater measures are understood and properly installed.

Supporting Materials (Referred to Later in Chapter as “Supporting Data”)

These items include inventory information collected and used during the planning process (contour maps, soils maps, charts, or other materials, as applicable, used in evaluating the site and formulating the plan). Supporting materials are important to all those involved in plan formulation and plan reviews and should be available to those with a specific need for them.

Step-By-Step Procedures for Plan Development

The context of the procedures presented in this subtopic is that a professional skilled in erosion and sediment control and stormwater management will assist another professional who is developing the overall site plan.

Step 1–Data Collection

Data collection includes inventorying the existing site conditions to gather information that will help in developing the most effective erosion- and sediment-control plan. The information should be shown on a map and explained in well-organized notes. This information eventually becomes a part of *Supporting Data* and is used to analyze and evaluate the site and practice options.

Topography

A large-scale topographic map of the site should be prepared. The suggested contour interval is usually 1 to 2 feet, depending upon the slope of the terrain. The interval may be increased on steep slopes.

Drainage Patterns

All existing drainage swales and patterns on the site should be located and clearly marked on the topographic map.

Soils

Major soil type(s) on the site should be determined and shown on the topographic map if the information is available. Soils information for previously undisturbed sites can be obtained from a soil survey if one has been published for the county by the Natural Resources Conservation Service. Commercial soils evaluations and borings are available from consultants for many sites. For ease of interpretation, soils information should be plotted directly onto the map or an overlay of the same scale.

Groundcover

The existing vegetation on the site should be determined. Such features as trees and other woody vegetation, grassy areas, and unique vegetation should be shown on the map or described in the notes describing the site. In addition, existing bare- or exposed-soil areas should be indicated. This information may be important in determining clearing limits and establishing stages of construction.

Adjacent Areas

Areas adjacent to the site should be inventoried, and important features that may be impacted by the proposed plan should be marked on the topographic map or identified in the notes. Applicable features include streams, springs, roads, wells, houses, other buildings, utilities, and other land areas.

Floodplain Boundaries

The existence of floodplains should be determined. Sources of information include soil surveys available from the Natural Resources Conservation Service, topographic maps, and floodplain maps that are available from many municipalities, as well as from the Federal Emergency Management Agency (www.fema.gov).

Receiving Waters

The use-classification and special designation of streams and lakes that receive stormwater from the proposed site should be determined.

Wetlands

Wetlands and other areas that are possibly wetlands should be identified. Wetlands may be quite apparent, or some areas may be questionable. Maps developed as part of the National Wetlands Inventory, U.S. Geological Survey (USGS) topographic maps, and soil surveys showing the location of hydric soils should be collected to evaluate an area for wetlands.

Contaminated Sites

Trash, abandoned appliances, potential-contaminated soil and hazardous waste, or any other material that should not be on the site should be identified. Brownfields fit into this category.

Cultural Resources

If federal funds (grants or other directed federal funds) or federal property is involved, a cultural resources review or survey is required before any ground-disturbing activities may begin (Section 106, National Historic Preservation Act). On public and private lands, the Mississippi Department of Archives and History is the primary state agency responsible for archaeological-resources protection. In addition to cultural-resource regulations, there are laws protecting cemeteries and human remains (marked and unmarked); permits are required to excavate graves.

Threatened and Endangered Species

Threatened and endangered species that may exist in the area and their associated habitat should be considered. Lists containing both the species and their habitat characteristics are available from the local office of the Natural Resources Conservation Service.

Step 2–Data Analysis

When all of the data in Step 1 are considered, a picture of a site’s potentials and limitations should emerge. The qualified design professional should be able to determine those areas that have potentially critical erosion hazards and the potential for construction disturbances to cause adverse off-site impacts. Described below are some important points to consider in site analysis.

Topography

Topographic considerations are slope steepness and slope length; that is, the longer and steeper the slope, the greater the erosion potential from surface runoff. Slope modifications with large cuts and fills may exacerbate the potential for erosion.

Drainage Patterns

Swales, depressions, and natural watercourses should be evaluated to plan where water will concentrate and what measures will be needed to maintain a stable condition for concentrated flow. Where it is possible, natural drainageways should be used to convey runoff over and off the site to avoid the expense and problems of constructing an artificial drainage system. Man-made ditches and waterways become part of the erosion and turbidity problem if they are not properly stabilized. Potential for flooding and possible sites for stormwater-detention ponds and sediment basins should be determined.

Soils

Soil properties such as depth-to-bedrock, depth-to-seasonal water table, permeability, shrink-swell potential, and texture should exert a strong influence on development decisions. Also, the flood hazard related to the soils can be determined based on the relationship between soils and flooding. A list of common Mississippi soils along with interpretations for developmental uses is included in Appendix A.

Groundcover

Groundcover is the most important factor in terms of preventing erosion. Any existing vegetation that can be saved will help prevent erosion. Trees and other vegetation protect the soil and beautify the site after construction. It is important to recognize vegetation that can be retained during, and possibly after, construction to assist in stabilizing the site.

Adjacent Areas

Generally, the analysis of adjacent properties should focus on areas downslope or downstream from the construction project. Because of construction-related erosion, the potential for sediment deposition on adjacent properties should be analyzed so that appropriate erosion- and sediment-control measures can be planned.

Floodplains

Floodplains are generally restrictive in nature, and uses planned within them must be consistent with local regulations. The location of facilities within floodplains should

usually be avoided to prevent restriction of flood flows and potential changes in flood stages downstream.

Receiving Waters

Watercourses that will receive direct runoff from the site should be of major concern; these streams should be analyzed to determine their use classification and whether they have a sensitive-water designation. The potential impact from sediment and turbidity pollution on these watercourses should be considered, as well as the potential for downstream-channel erosion due to increased velocity of stormwater runoff from the site.

Wetlands

Wetlands or the absence of wetlands should be determined by a qualified professional. Wetland boundaries should be clearly marked by a wetland delineator to provide a distinct location and boundary to use during the planning, design, and construction phases of a project.

Waste Materials/Contamination

Sites with known or potential contamination by petroleum, chemical spills, etc., should have a thorough assessment conducted by a qualified professional and result in a comprehensive site assessment. Details of this activity are beyond the scope of this manual. The MDEQ should be contacted for assessment procedures.

Cultural Resources

The presence of cultural resources within the area of potential effect (which includes the immediate project area and any off-site areas, such as borrow pits, fill-disposal or temporary-storage areas, and equipment-staging areas) should be considered. Care should be taken to avoid disturbing cultural resources; previously unknown or undocumented cultural resources should be reported to the Mississippi Department of Archives and History.

Threatened and Endangered Species

Habitat for threatened and endangered species should be evaluated. If potential exists for occurrence of such a species, a determination of its occurrence should be made by a qualified professional.

Step 3–Facility Plan Development

This step applies to sites that are in the planning stage where planning of the facilities has not been firmly determined. After analyzing the data about the site and determining any site limitations, the erosion- and sediment-control professional can assist the professional developing the overall site plan and formulate a site plan that is in harmony with the conditions unique to the site. An attempt should be made to locate the buildings, roads, and parking lots and to develop landscaping plans to exploit the strengths and overcome the limitations of the site. Ideally, there can be flexibility in the location of facilities to allow low-impact development concepts to be exploited. The following are some points to consider in making these decisions:

- Fit development to terrain. The development of an area should be tailored, as much as possible, to existing site conditions. For example, confine construction activities to the least critical areas. This will avoid unnecessary land disturbance while minimizing erosion, development costs, and land disturbances.
- Cluster buildings together. This minimizes the amount of disturbed area and concentrates utility lines and connections, while leaving more open, natural space. The cluster concept not only lessens the erodible area, it generally reduces runoff and development costs.
- Minimize impervious areas. Keep paved areas, such as parking lots and roads, to a minimum. This goes hand-in-hand with cluster developments in eliminating the need for duplicating parking areas, access roads, etc. The more land that is kept in vegetative cover, the more water will infiltrate, thus minimizing runoff and erosion. Consider the use of special paving products that will allow water to infiltrate or cellular blocks that have soil and vegetation components.
- Utilize the natural drainage system. If the natural drainage system of a site can be preserved instead of being replaced with storm sewers or concrete channels, the potential for downstream damages due to increased runoff can be reduced.
- Determine if there are any “environmentally sensitive” areas (areas of special concern) to be protected during and after project implementation. In general, most erosion- and sediment-control projects will have an overall beneficial effect to cultural resources since they would be protected from further environmental degradation.

Step 4–Planning for Erosion and Sediment Control and Stormwater Management

When the site-facility plan-layout has been developed, another plan is developed to minimize erosion on-site and delivery of sediment and turbid water off-site. Additional objectives may include those related to increased peaks and runoff associated with a development. These may account for flood control and off-site erosion control.

The following procedure is recommended for formulating the system of practices and measures for erosion and sediment control and stormwater management.

- Divide the site into drainage areas. Determine how runoff will travel over the site.
- Determine limits of clearing and grading. Decide exactly which areas must be disturbed in order to accommodate the proposed construction. Pay special attention to critical areas that can be avoided (areas with high potential for erosion and needing special treatment if disturbed). The important point in this activity is to minimize the areas to be disturbed.

- Select erosion- and sediment-control and stormwater management practices and measures using a systems concept. Practices and measures should be selected that are compatible and, as a system, can be expected to meet objectives for the development or activity.

Consider how erosion and sediment can be controlled in each small drainage area of the entire site. Remember, it is easier to control erosion than to contend with sediment after it has been carried downslope and downstream.

Plan to sequence construction so that no area remains exposed for unnecessarily long periods of time. On large projects, stage the construction, if possible, so that one area can be stabilized before another is disturbed. Sequencing and staging may influence the choice of practices.

The practices and measures in this manual are divided into six broad categories to support planning concepts: site preparation, surface stabilization, runoff conveyance, inlet protection, sediment control, and stream protection. Other categories that are sometimes used, such as vegetative, structural, and management measures, are imbedded into the six categories.

Again, review each drainage area, determine the categories that apply, and select practices to comprise a technically sound and cost-effective system.

- **Site Preparation** (Construction Exit Pad, Land Grading, and Topsoiling)

A Construction Exit Pad should be planned for early installation at each access point where vehicles leave the disturbed area of a construction site and enter a public road. The stockpiling of topsoil should be done as an initial part of earthmoving. Most sites have enough topsoil available for stockpiling to provide adequate amounts for topsoiling the areas to be permanently vegetated. Land-grading techniques can be done to complement erosion-control systems.

- **Surface Stabilization** (Chemical Stabilization; Dust Control; Erosion Control Blanket; Housekeeping; Mulching; Permanent Seeding; Preservation of Vegetation; Retaining Wall; Shrub, Vine and Groundcover; Sodding; Temporary Seeding; and Tree Planting on Disturbed Areas)

Most qualified design professionals agree that vegetative measures should be maximized to provide as much erosion and sediment control as possible. Structural measures are generally more costly than vegetative controls, but they are necessary on areas where vegetation and reinforcement with erosion control blankets or chemical measures will not provide adequate erosion control. Temporary practices from this category are needed on most sites, and final stabilization of all landscapes requires one or more practices from this category.

- **Runoff Conveyance** (Check Dam, Diversion, Drop Structure, Grass Swale, Lined Swale, Outlet Protection, Riprap-lined Channel, Subsurface Drain, and Temporary Slope Drain)

Diversions are particularly important in (1) diverting clean water away from a disturbed site; (2) preventing flows from eroding cut and fill slopes and; (3) breaking (reducing) slope lengths. The other practices in this category are needed to safely move concentrated flows of stormwater in channels. Concentrated flows are the potential cause of gullies, and the runoff-conveyance practices are used to prevent gully erosion. Subsurface drains are used to facilitate another practice, such as Grass Swale, in becoming successfully established and maintained. One or more practices from this category are needed on sites with channel flow.

- **Inlet Protection** (Block and Gravel Inlet Protection, Excavated Inlet Protection, Fabric Drop Inlet Protection, and Straw Bale Inlet Protection)

Inlet protection control practices function primarily on the basis of filtering the sediment-laden water before it enters storm-sewer systems.

- **Sediment Control** (Brush/Fabric Barrier, Filter Strip, Floating Turbidity Barrier, Rock Filter Dam, Sediment Barrier, Sediment Basin, Straw Bale Sediment Trap, Surface Discharge Structures, and Flocculants and Polymers)

Sediment-control practices function primarily on the basis that sediment-laden water will deposit at least part of its load while the water is ponded on the construction site by the practice. All of the sediment-control practices are considered temporary. The effectiveness of each practice is dependent upon the unique attribute of the practice, the texture of the sediment in suspension, and suspension time.

- **Stream Protection** (Buffer Zone, Channel Stabilization, Stream Diversion Channel, Streambank Protection, and Temporary Stream Crossing)

These stream protection practices are primarily intended to be used to preserve or repair streams. Designing new channels is beyond the scope of this manual. One or more of these practices should be considered essential where a construction project includes a perennial or intermittent stream.

Step 5–Plan Assembly

The final step of plan development consists of compiling and consolidating the pertinent information into a site-specific plan for erosion control, sediment control and stormwater management. The major plan components are a narrative and a site-plan map. Supporting data are assembled to substantiate planning options considered and developed and to aid in review of a plan.

The following checklist may be used in assembling the narrative and site-plan map to be sure all major items are included.

Checklist for Plans

Narrative

Explain the solutions for existing and predicted problems in the narrative (tables and charts may be used to display information in a format that is easier to understand).

Project Description

Briefly describe the nature and purpose of the land-disturbing activity and the amount of disturbance involved.

Practices and Measures

Identify the practices and methods that will be used to control erosion on the site, prevent or minimize sediment from leaving the site, and address turbidity and hydrologic changes associated with the proposed project. Sequence and staging of construction activities to minimize disturbance and erosion should be addressed.

Inspections

Prescribe a schedule for inspections and repair of practices.

Maintenance

Include statement(s) explaining how the project will be maintained during construction until final stabilization. In some instances, maintenance that will be needed after construction should be included.

Site-Plan Map

The site-plan map is one or a series of maps or drawings pictorially explaining information contained in the narrative.

Site-Plan Label

The label should include the name of owner, name of site or facility, county name, location (township, range and section), name of qualified design professional, date plan was created and, if applicable, date of latest revision.

Existing Contours

The existing contours of the site should be shown on a map (the scale used for this map should be of sufficient scale for meaningful evaluations). The scale of the site plan may range from 1" = 100 feet to 1" = 20 feet. If existing contours cannot be shown, drainage-pattern arrows must be included.

Existing Vegetation

The existing tree lines, grassy areas, or unique vegetation should be shown on a map.

North Arrow

The direction of north in relation to the site should be shown. The top of all maps should be north, if practical.

Existing Drainage Patterns

The dividing lines and the direction of flow for the different drainage areas should be shown on a map.

Final Contours

Planned post-construction contours should be shown on a map.

Development Features

The outline of buildings, roads, drainage appurtenances, utilities, landscaping features, parking areas, improvements, impervious areas, topographic features, and similar man-made installations should be shown to scale and relative location.

Limits of Clearing and Grading

Areas that are to be cleared and graded should be outlined on a map.

Wetlands

The location of wetlands is important and should be shown accurately and, preferably, on the site map.

Cultural Resources

The locations of cultural resources should be shown accurately on the plan map and construction plans. Their accurate location is essential if these areas are to be avoided or protected during project construction.

Location of Practices and Legend

The locations of the erosion and sediment control and stormwater-management practices used on the site should be shown on a map. A combination of symbols and acronyms is used to identify the practices. A list of the acronyms is included at the end of this chapter under “Legend of Measures for Erosion and Sediment Control and Stormwater Management.”

Site Location or Vicinity Map (if required by regulatory agency)

Provide a small map locating the site in relation to the surrounding area. A portion of a 7.5-minute series USGS topographic map that covers the project area usually meets this requirement.

Supporting Data (relevant materials collected and generated during all stages of planning).

Existing Site Conditions

This material describes the existing topography, vegetation, and drainage.

Adjacent Areas

This material describes the adjacent and neighboring areas such as streams, lakes, residential areas, roads, etc., that might be affected by the land disturbance.

Soils

Include a brief description of the soils on the site giving relevant information such as soil names, mapping unit, erodibility, permeability, depth, texture, soil structure, and any other limitations. The boundaries of the different soil types should be shown on a map.

Critical Areas

Identify and describe areas on the site that have potential and/or serious erosion problems.

Areas of Special Concern

Include relevant information affecting planning on contaminated soils, new or innovative practices, stream alterations, wetlands, and cultural resources. If federal lands or federal funds are involved, a letter from the lead federal agency will be required stating that there would be no adverse effect to cultural resources and allowing the project to proceed as planned or amended. A similar letter from the Mississippi Department of Archives and History may be necessary if cultural resources are present on State and private lands.

Calculations and Design Data Needed During Planning

Include estimates used to evaluate practices that are chosen based on peak flows, acres of runoff, etc.

Legend of Measures for Erosion and Sediment Control and Stormwater Management

A listing of BMPs, their abbreviations, and sample symbols are provided on the next page. It should be noted that no universal symbols exist for erosion- and sediment-control measures. The symbols provided are not required and are only recommendations.

BEST MANAGEMENT PRACTICE (BMP)	ABBREVIATION	SYMBOL
SITE PREPARATION		
CONSTRUCTION PHASING/SEQUENCING	CPS	
CONSTRUCTION EXIT PAD	CEP	
CONSTRUCTION ROAD STABILIZATION	CRS	
LAND GRADING	LG	
TOPSOILING	TSG	
SURFACE STABILIZATION		
CHEMICAL STABILIZATION	CHS	
DUST CONTROL	DC	
EROSION CONTROL BLANKET	ECB	
HOUSEKEEPING	HK	
MULCHING	MU	
PERMANENT SEEDING	PS	
PRESERVATION OF VEGETATION	PV	
RETAINING WALL	RW	
SHRUB, VINE & GROUNDCOVER PLANTING	SVG	
SODDING	SOD	
TEMPORARY SEEDING	TS	
TREE PLANTING IN DISTURBED AREAS	TP	
RUNOFF CONVEYANCE		
CHECK DAM	CD	
DIVERSION	DV	
DROP STRUCTURE	DS	
GRASS SWALE	GS	
LEVEL SPREADER	LVS	
LINED SWALE	LS	
OUTLET PROTECTION	OP	
RIPRAP LINED SWALE	RS	
SUBSURFACE DRAIN	SD	
TEMPORARY SLOPE DRAIN	TDS	

INLET PROTECTION		
BLOCK/GRAVEL INLET PROTECTION	BIP	
EXCAVATED INLET PROTECTION	EIP	
FABRIC DROP INLET PROTECTION	FIP	
STRAW BALE INLET PROTECTION	SBIP	
SEDIMENT CONTROL		
BRUSH FABRIC BARRIER	BFB	
FILTER STRIP	FS	
FLOATING TURBIDITY BARRIER	FB	
ROCK FILTER DAM	RD	
SEDIMENT BARRIER	SB	
SEDIMENT BASIN	SBN	
STRAW BALE SEDIMENT TRAP	SST	
FLOCCULANTS AND POLYMERS	FLC	
STREAM PROTECTION		
BUFFER ZONE	BZ	
CHANNEL STABILIZATION	CS	
STREAMBANK PROTECTION	SP	
TEMPORARY STREAM CROSSING	TSC	
STREAM DIVERSION CHANNEL	SDC	

* NO UNIVERSAL SYMBOLS. THESE ARE RECOMMENDATIONS AND ARE NOT REQUIRED.

Chapter 4

Best Management Practices Design

Introduction

This chapter provides detailed information for best management practices (BMPs) commonly used for the control of erosion and sediment on active construction sites. Practices for erosion and sediment control will be installed in accordance with an approved site plan. (Chapter 3 provides information on developing an erosion and sediment control plan, and Appendix D provides examples of such plans.) The plan should list the sequence of construction activities. Each construction activity contributing to erosion of soil or changes in sediment-laden runoff should have an appropriate practice or practices to control erosion, sediment, and runoff. Minimizing the area exposed to erosion at any one time can significantly reduce erosion and sediment occurrence on the site.

Proper installation and maintenance of structural and vegetative practices approved in the site plan will be considered essential for compliance with the plan or associated permit. This chapter includes practice design standards and construction specifications along with applicable drawings. Design limitations are provided to maintain design integrity, safety, and purpose of the practices.

Purpose of BMP Manual

The purpose of this manual is to assist designers, developers, owners, contractors, and local officials in determining what stormwater regulations apply to their situation, what the BMP to meet those regulations might be, and how to then design and maintain that particular erosion and sediment control BMP. It is intended to provide the competent design professional with the information necessary both to properly meet the minimum requirements of Mississippi's stormwater programs and to be able to design a stormwater BMP that meets the water quality objectives. However, it does not cover every aspect of the civil engineering and structural design necessary for proper BMP system design and construction, nor does it cover every site situation that may occur, or every possible erosion and sediment control solution. The design professional is responsible for the design and construction of a properly functioning BMP that meets all of the applicable regulations, including the water quality objectives, and that considers all the unique conditions of an individual site. Where the designer determines that conformance with this manual would create an unreasonable hardship or where an alternative design may be more appropriate, alternative designs, materials, and methodologies will be considered on a case-by-case basis.

This manual is meant to supplement (not supplant) Mississippi's stormwater regulations by explaining the BMPs that will be allowed and their design criteria, in an easy-to-understand manner. In addition, local communities are free to adopt more stringent requirements than those presented in this manual. In general, if any part of this manual lists requirements different from those imposed by any other ordinance, rule, regulation, or other provision of law, whichever provision is more restrictive or imposes higher protective standards for human or environmental health, safety, and welfare, shall control.

There are figures, example calculations, operation and maintenance items, etc., used throughout this manual. The intention is to provide the reader with visual assistance in device functions, siting, and concepts, as well as guidance on designing, operating, and maintaining specific BMPs. The figures, example calculations, operation and maintenance items, etc., will not represent the proper solution for every situation, and they may contain items that may not exactly fit the requirements listed in the section. The user of this manual must look at these items and use his or her professional judgment as to their proper use in a specific situation (however, any variance from a requirement must be clearly indicated). In the event of a conflict or inconsistency between the text of this manual and any heading, caption, figure, illustration, table, map, etc., the text shall control.

Also used throughout this manual is the phrase “design professional.” This phrase is a generic title for a qualified, registered, Mississippi professional engineer, surveyor, soil scientist, or landscape architect, performing services only in his or her area of competence. Other individuals may be authorized as a “design professional,” if they can demonstrate proper knowledge and ability to MDEQ.

Construction Phasing/Sequencing (CPS)



Practice Description

Construction phasing/sequencing is the coordination of the construction schedule with the necessary erosion, sediment, and stormwater BMP installation. The purpose of construction sequencing is to reduce the amount of on-site erosion and off-site sedimentation. The construction sequence is an orderly listing of all major land-disturbing activities together with the necessary erosion- and sedimentation-control measures planned for a project. This type of schedule guides the contractors on work to be done before other work is started so that serious erosion and sedimentation problems can be avoided. Construction sequencing also allows for a potential reduction in the amount of land area disturbed at any one time during construction.

Planning Considerations

Construction sequencing can ultimately lower the cost of construction by retaining sediment on-site. Studies have shown that land disturbances at construction sites can cause soils to be 2 to 40,000 times more erodible (Harbor, 1999). Erosion leads to sedimentation, often times off-site. Additional costs from permit non-compliance or sedimentation of wetlands or other sensitive areas can occur if stormwater controls are not properly installed. Proper construction phasing begins with preservation of natural vegetation. Existing vegetation should be preserved in areas where it is likely to have the most benefit to hydrology. Preserving as much native vegetation as possible can reduce the impacts of land-disturbance activities. Also, protecting nearby vegetated areas with proper erosion and sediment controls will help maintain the adjacent areas' natural hydrology and help prevent off-site erosion and sedimentation.

Design Criteria and Construction

Vegetation Protection

Identify and map areas requiring special protection, i.e., wetlands, buffer zones, filter strips, and trees. Be sure these areas are clearly marked on drawings, maps, and properly flagged on-site.

Access Points

Define areas for construction-site access, construction routes, and equipment parking. Construction-site access pads must be installed prior to land disturbances. See Construction-Exit Pad (CEP) for details.

Sediment Traps

Install sediment traps (basins, fences, outlet protection) after site access has been established. Additional sediment basins or fencing may be required as land grading begins. Installation information can be found in the *Sediment Control* section.

Runoff Controls

Controlling runoff can be accomplished through diversions, dikes, silt fence and outlet protection. These measures should be installed after sediment practices and before land grading. Additional runoff-control measures may be required during the course of construction. Additional information on runoff-control practices is available in the *Runoff Conveyance* section.

Runoff Conveyance Systems

Runoff conveyance can be accomplished through stabilization of stream banks, check dams, diversion, drop structures, channels or swales, inlet and outlet protection, temporary-slope drains, etc. Whenever possible, stabilize stream banks as early as possible. Install runoff conveyance systems with runoff controls and before land grading. Additional runoff conveyance measures may be required during the course of construction. Additional information is available in the *Runoff Conveyance* section.

Land Clearing and Grading

Begin site preparation including cutting, filling, and grading only after sediment and runoff controls are installed. Install additional control measures as needed.

Surface Stabilization

Surface stabilization includes temporary and permanent seeding, mulching, sodding and installing riprap. These items should be installed immediately on all disturbed areas where work has been completed or significantly delayed.

Building Construction

During the construction phase, any additional erosion and sediment controls should be installed as needed.

Landscaping and Final Stabilization

During the last phase of construction, all open areas should be stabilized through topsoiling, planting trees and shrubs, seeding, mulching, sodding, and final riprap placement. At this point, all non-biodegradable, temporary-control measures should be removed.

Common Problems

Consult with a qualified design professional if any of the following occur:

Sensitive areas such as wetlands have not been properly protected and have been impacted by sediment.

The site's erosion- and sediment-control plan does not adequately address stormwater issues on-site. If site limitations require changes to construction plan, be sure the erosion and sediment plan is amended.

Maintenance

Maintenance inspections should be conducted weekly and after rainfall events of ≥ 0.5 inch in a 24-hour period. All maintenance repairs should be made immediately after periods of rainfall. Pre-storm inspections can prevent BMP failures during large rain events.

References

BMPs from Volume 1

Chapter 4

Land Grading (LG)	4-16
Preservation of Vegetation (PV)	4-64

BMPs from Volume 2

Chapter 2

General Planning Concepts for Stormwater Runoff Management and Overview of Low Impact Design and Smart Growth Concepts	2-1
--	-----

Chapter 4

Infrastructure Planning	
Protection of Natural Features	

Construction-Exit Pad (CEP)



Practice Description

A construction-exit pad is a stone-base pad designed to provide a buffer area where mud- and caked-soil can be removed from the tires of construction vehicles to avoid transporting it onto public roads. This practice applies anywhere traffic will be leaving a construction site and moving directly onto a public road or street.

Planning Considerations

Roads and streets adjacent to construction sites should be kept clean for the general safety and welfare of the public. A construction-exit pad (Figure CEP-1) should be provided where mud can be removed from construction vehicle tires before they enter a public road.

If the action of the vehicle traveling over the gravel pad does not sufficiently remove the mud, or if the site is in a particularly sensitive area, a washing facility should be included with the pad (Figure CEP-2). When a washing facility is required, all wash water shall be diverted into a sediment trap or basin.

If the construction-exit pad is located in an area with soils that will not support traffic when wet, a geotextile liner located beneath the aggregate will be required to provide stability to the pad.

Construction of stabilized roads throughout the development site should be considered to lessen the amount of mud transported by vehicular traffic. The construction-exit pad

should be located to provide for maximum use by construction vehicles. Consideration should be given to limiting construction vehicles to only one ingress and egress point. Measures may be necessary to make existing traffic use the construction-exit pad.

Design Criteria and Construction

Site Preparation

Remove all vegetation and other unsuitable material from the foundation area.

Grading

Grade and crown the area for positive drainage. Utilize a diversion to direct any surface flow away from the construction-exit pad. Any runoff from the pad should be diverted into a sediment trap or basin. Install a pipe under the pad, if needed, to maintain drainage ditches along public roads.

Aggregate Size

Aggregate should be Mississippi Department of Transportation Size 1 Stabilizer. Aggregate surface shall be left smooth and sloped for drainage.

Pad Dimensions

The exit pad shall have a minimum aggregate thickness of 6". The exit pad must be a minimum of 50 feet long and shall provide for entering and parking the longest construction vehicles anticipated. MDOT Drawing ECD-15 provides an example of a stabilized construction entrance. The exit pad shall have a typical width of 20 feet, but may be narrower or wider to equal the full width of the vehicular egress.




Figure CEP-1 Gravel Construction Exit

Geotextiles

A non-woven geotextile meeting the requirements shown in the table below for Class IV geotextiles should be used under the rock when the subgrade is soft or the blow count is less than 10.

Table CEP-1 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTMD 4632	≥ 50	≥ 50	≥ 50	≥ 50
Puncture (pounds)	ASTMD 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD 4751	As specified max. #40 ³			
Permittivity sec ⁻¹	ASTMD 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

¹ Heat-bonded or resin-bonded geotextile may be used for classes III and IV. They are particularly well suited to class IV. Needle-punched geotextile required for all other classes.

² Minimum average roll value (weakest principal direction).

³ U.S. standard sieve size.

Washing

A washing facility shall be provided, if necessary, to prevent mud- and caked-soil from being transported to public streets and highways. It shall be constructed of concrete, stone, and/or other durable materials. Provisions shall be provided for the mud and other material to be carried away from the washing facility into a sediment trap or basin to allow for settlement of the sediment from the runoff before it is released from the site.




Figure CEP-2 Construction Exit with Wash Rack

Common Problems

Consult with a qualified design professional if any of the following occur:

Inadequate runoff control and sediment washes onto public road: install diversions or other runoff-control measures.

Ruts and muddy conditions develop as stone are pressed into soil: increase stone size or pad thickness, or add geotextile fabric.

Pad too short for heavy-construction traffic: consult design professional about extending pad to the necessary length

Maintenance

Remove large chunks of mud- or caked-soil from construction-exit pad daily to minimize sediment buildup.

Inspect stone pad and sediment-disposal area weekly and after storm events or heavy use.

Reshape pad as needed for drainage and runoff control.

Top-dress with clean-specified stone as needed to maintain effectiveness of the practice.

Immediately remove mud or sediment tracked or washed onto public road.

Repair any broken-road pavement immediately.

Remove unneeded exit-pad materials from areas where permanent vegetation will be established.

References

BMPs from Volume 1


Chapter 4

Construction Phasing/Sequencing (CPS)	4-3
Land Grading (LG)	4-16
Housekeeping (HK)	4-43
Preservation of Vegetation (PV)	4-64

MDOT Drawings Referenced


ECD-15 Stabilized Construction Entrance	4-11
---	------

STATE	PROJECT NO.
MISS.	




- NOTES:
1. A STABILIZED CONSTRUCTION ENTRANCE SHALL BE CONSTRUCTED AT POINTS OF EGRESS FROM UNSTABILIZED AREAS OF THE PROJECT TO PUBLIC ROADS WHERE OFFSITE TRACKING OF MUD COULD OCCUR. TRAFFIC FROM UNSTABILIZED AREAS OF THE PROJECT SHALL BE DIRECTED THRU THE STABILIZED ENTRANCE. BARRIERS, FLAGGING, OR OTHER POSITIVE MEANS SHALL BE USED AS REQUIRED TO LIMIT AND DIRECT VEHICULAR EGRESS ACROSS THE STABILIZED ENTRANCE.
 2. THE CONTRACTOR MAY PROPOSE AN ALTERNATIVE TECHNIQUE TO MINIMIZE OFFSITE TRACKING OF SEDIMENT. THE ALTERNATIVE MUST BE REVIEWED AND APPROVED BY THE ENGINEER PRIOR TO IT'S USE.
 3. ALL MATERIALS SPILLED, DROPPED, OR TRACKED ONTO PUBLIC ROADS (INCLUDING THE STABILIZED CONSTRUCTION ENTRANCE AGGREGATE AND CONSTRUCTION MUD) SHALL BE REMOVED DAILY, OR MORE FREQUENTLY IF SO DIRECTED BY THE ENGINEER.
 4. SIZE 1 STABILIZER AGGREGATE SHALL BE USED
 5. THE STABILIZED CONSTRUCTION ENTRANCE SHALL BE MAINTAINED IN A CONDITION THAT WILL ALLOW IT TO PERFORM IT'S FUNCTION TO PREVENT OFFSITE TRACKING. THE STABILIZED CONSTRUCTION ENTRANCE SHALL BE RINSED WHEN NECESSARY TO MOVE ACCUMULATED MUD DOWNWARD THRU THE STONE. ADDITIONAL STABILIZATION OF THE VEHICULAR ROUTE LEADING TO THE STABILIZED ENTRANCE MAY BE REQUIRED TO LIMIT THE MUD TRACKED.
 6. THE NOMINAL SIZE OF A STANDARD STABILIZED CONSTRUCTION ENTRANCE IS 15' X 50' UNLESS OTHERWISE SHOWN IN THE EROSION CONTROL PLAN


PLAN



TRANSITION DETAIL



SECTION A-A



RURAL CONNECTION DETAIL

MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
STABILIZED CONSTRUCTION ENTRANCE	
WORKING NUMBER	ECD-15
SHEET NUMBER	
FILE NAME: EROSION CONTROL ECD-15.DGN	
DESIGN DATE: _____	DATE: _____

Construction Road Stabilization (CRS)

— CRS —



Practice Description

This practice describes the temporary stabilization of construction-access roads and parking areas. The purpose of this BMP is to reduce erosion of temporary and permanent roadbeds between the time of initial clearing and grading and final stabilizations.

Planning Considerations

A construction-exit pad should be provided in conjunction with stabilized construction roads where mud can be removed from construction-vehicle tires before they enter a public road.

If the construction-access road is located in an area with soils that will not support traffic when wet, a geotextile liner located beneath the aggregate will be required to provide stability to the pad.

Construction of stabilized roads throughout the development site should be designed so that construction vehicles are limited to only one ingress and egress point. The existing site contour should be followed as much as possible with slopes of the roads remaining less than 10 percent. Parking areas should be designed at naturally flat areas.

Permanent roads and parking areas should be paved as soon as possible after grading. However, it is understandable that funds for this purpose may not be available in the early phases of the development project. As an alternative, the early application of stone may solve potential erosion and stability problems and eliminate potential costs. Some of the stone will also probably remain in place for use as part of the final base course of the road.

Design Criteria and Construction

Site Preparation

Remove all vegetation and other unsuitable material from the roadway area.

Grading

Stabilize the side slopes of all cuts and fills by grading all slopes to 2:1 or flatter for clay soils and 3:1 or flatter for sandy soils. All exposed slopes should be seeded and/or mulched as soon as possible (see Temporary Seeding, Mulching, and Dust Control).

Aggregate Size

A 6" course of DOT No. 1 aggregate shall be applied immediately after grading or after the completion of the utility installation within the right-of-way. A geotextile may be applied to the roadbed for additional stability.

Drainage

Ensure that proper drainage is provided for and that all drainage along construction roads is directed to sediment control BMPs.




Figure CRS- 1 Construction Road Stabilization

Geotextiles

A non-woven geotextile meeting the requirements shown in the table below for Class IV geotextiles should be used under the rock when the subgrade is soft or the blow count is less than 10.

Table CEP-1 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTMD 4632	≥ 50	≥ 50	≥ 50	≥ 50
Puncture (pounds)	ASTMD 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD 4751	As specified max. #40 ³			
Permittivity sec ⁻¹	ASTMD 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

¹ Heat-bonded or resin-bonded geotextile may be used for classes III and IV. They are particularly well suited to class IV. Needle-punched geotextile required for all other classes.

² Minimum average roll value (weakest principal direction).

³ U.S. standard sieve size.

Width

Roadbeds shall be at least 14feet wide for one-way traffic and 20feet wide for two-way traffic.

Vegetation

All roadside ditches, cuts, fills, and disturbed areas adjacent to parking areas and roads shall be stabilized with appropriate temporary or permanent vegetation according to the applicable practices contained in this manual.

Common Problems

Consult with a qualified design professional if any of the following occur:

Inadequate runoff control and sediment washes onto public road: install diversions or other runoff-control measures.

Ruts and muddy conditions develop as stone are pressed into soil: increase stone size or pad thickness, or add geotextile fabric.

Maintenance

Reshape roadway as needed for drainage and runoff control.

Inspect stone pad and sediment-disposal area weekly and after storm events or heavy use.

Top-dress with clean, specified stone, as needed, to maintain effectiveness of the practice.

References

BMPs from Volume 1

Chapter 4

Construction-Exit Pad (CEP)	4-6
Land Grading (LG)	4-16
Dust Control (DC)	4-29
Mulching (MU)	4-48
Temporary Seeding (TS)	4-103

Land Grading (LG)



Practice Description

Land grading is reshaping of the ground surface to provide suitable topography for buildings, facilities, and other land uses; to control surface runoff; and to minimize soil erosion and sedimentation, both during and after construction. This practice applies to the following sites: where the existing topography must be modified to prepare for another land use and/or where adapting proposed development to the existing landscape can reduce the erosion potential of the site and the cost of installing erosion- and sediment-control measures. In some instances, other practices such as diversions can be used to reduce the length of continuous slopes and reduce erosion potential.

Planning Considerations

A detailed plan should be developed by a qualified design professional for all land-grading activities at the project site. The plan should show all areas to be disturbed, the areas of cut, areas of fill, and the finished elevation for all graded areas.

The grading plan should be designed to protect existing vegetation where possible, especially around natural drainageways. Grading activities should be scheduled to minimize the area disturbed at any one time during the construction process. The plan should include provisions for stabilizing disturbed areas immediately after final grading is completed. Provisions should also be made to protect existing underground utilities. Finally, topsoil should be removed and stockpiled for use in revegetating the site.

The grading plan should also include necessary practices for controlling sediment and erosion at the site. These practices could include stable outlets and slope breaks.

Design Criteria and Construction

Site Preparation



A detailed survey of the construction site should be performed by a qualified surveyor prior to grading-plan development. This survey should include existing topographic information at the site including existing elevations, existing drainage patterns, locations of existing overhead and underground utilities, and construction-limit boundaries.

The grading plan should require that the existing topsoil at sites to be graded be removed as the first step in the grading process. The plan should include a location on the construction site where topsoil will be stockpiled. Stockpiled topsoil should be protected by temporary vegetation (see *Temporary Seeding Practice*) until it is used to cover disturbed areas.

Practice) until it is used to cover disturbed areas.

The plan should include a schedule of disturbance activities that minimizes the area disturbed at any point in time. In areas where clearing of existing vegetation is planned, the area should be cleared and grubbed by removing trees, vegetation, roots, and other debris, such as trash. In areas to be filled, all loose or weak soil and oversized rocks should be removed from the area. The foundation of the area to be filled should consist of soil or rock material of adequate strength to support the proposed fill material and the structures to be built at the site. The exact depth of material to be removed should be determined by a qualified geotechnical professional according to accepted engineering standards.

Grading

A plan for placement of fill should be developed by a qualified geotechnical professional. The plan should specify the source of fill materials, which should be obtained on-site if possible. Materials used for fill, when placed according to the plans and specifications, should provide sufficient strength to support structures planned for construction at the location.

Loose fill material should be placed in layers not exceeding 9" in thickness. The materials should be compacted at a moisture content and to a dry density that will produce the design-bearing strength required for structures planned at the site. A qualified geotechnical engineer should provide fill placement specifications using standard, accepted engineering practices.

Slope lengths at the site should be minimized using diversions as slope breaks to reduce erosion potential (see *Diversion Practice*). The following table gives guidance on the horizontal spacing of slope breaks:

Table LG-1 Guidelines for Spacing Slope Breaks

Slope	Spacing (Ft)
33-50%	20
25-33%	40
15-25%	60
10-15%	80
6-10%	120
3-6%	200
<3%	300

In areas where seepage and ground water are present, subsurface drains should be installed to improve slope stability or soil-bearing capacity (see *Subsurface Drain Practice*).

Steep slopes should be avoided if possible. Slopes that are to be vegetated should be 2 horizontal to 1 vertical or flatter. If the slope is to be maintained by a tractor or other equipment, the slope should be 3 horizontal to 1 vertical or flatter. Slopes should be designed to blend with surrounding topography as much as possible.

Erosion Control

The grading plan should include provisions for stabilization of graded areas immediately after final grading is completed. On areas that will have no additional disturbance, permanent vegetation should be applied immediately to the site (see *Permanent Seeding Practice*). On areas where work is to be interrupted or delayed for 14 working days or longer, such as topsoil stockpiles, the area should be stabilized using mulch or temporary seeding (see *Mulching* or *Temporary Seeding Practices*). Other stabilization measures such as erosion-control blankets, should be used in extreme conditions, such as steep slopes and channels.

Where practical, runoff from undisturbed off-site areas should be diverted around the construction site to prevent erosion on the disturbed areas (see *Diversion Practice*).

Sediment Control

Any required sediment-control practices should be installed before the land-disturbance activities in the drainage area of the sediment-control practice. Until disturbed areas can be stabilized, appropriate sediment-control measures will be maintained to minimize sediment delivery off-site. Measures should include as a minimum:

Sediment Barriers – Placed along toes of slopes and drainageways (see *Sediment Barrier Practice*).

Sediment Basins – Divert sediment-laden runoff to basins as needed to minimize off-site sedimentation (see *Sediment Basin Practice*).

Inlet Protection – Where sediment-laden runoff is diverted to on-site stormwater-drain inlets, the inlets should be protected with an appropriate sediment-control practice.

Stabilized Outlets – All runoff from the site should be conveyed in stabilized channels (see *Grass Swale*, *Lined Swale*, or *Channel Stabilization Practices*).

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on-site indicate grading plan will be ineffective or non-feasible.

Seepage is encountered during construction. It may be necessary to install drains.

Subgrade is soft or has high organic content and can hinder proper compaction of fill. It may be necessary to undercut and replace unsuitable subgrade soil.

Design specifications for sediment-control measures, seed variety, seeding dates, or other erosion-control measures or materials cannot be met. Substitutions may be required. Unapproved substitutions could result in erosion and lead to failure of sediment- and erosion-control measures.

Maintenance

Periodically check all graded areas and the related erosion and sediment-control practices for damage by equipment and especially after heavy rainfalls for damage by runoff.

Repair silt fences and other temporary, sediment-control measures.

Clean sediment out of adjacent diversions and other structures as needed.

Repair any failures that occur in surface stabilization measures, such as plantings.

References

BMPs from Volume 1

Chapter 4

Channel Stabilization (CS)	4-25
Erosion Control Blanket (ECB)	4-33
Mulching (MU)	4-48
Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103
Diversion (DV)	4-131
Grass Swale (GS)	4-162
Lined Swale (LS)	4-190
Subsurface Drain (SD)	4-218
Sediment Barrier (SB)	4-284
Sediment Basin (SBN)	4-298

Topsoiling (TSG)



Practice Description

Topsoiling is the removal of a desirable soil surface, referred to as topsoil, at a site prior to construction and using it on areas to be vegetated. Topsoiling a site usually improves the quality of the plant-growth medium at the site and increases the likelihood of successful plant establishment and performance. This practice applies to sites that are to be disturbed by excavation, compaction or filling, and to other areas where the subsoil is unsuitable for plant growth.

Planning Considerations

Topsoil is the surface layer of the soil profile, generally characterized as darker than the subsoil due to enrichment with organic matter. It is the major zone of root development and biological activity. Microorganisms that enhance plant growth thrive in this layer. Topsoil can usually be differentiated from subsoil by texture as well as color. Clay content usually increases in the subsoil.

The depth of topsoil may be quite variable. On severely eroded sites it may be non-existent.

Advantages of topsoil include its high organic-matter content, friable consistency (soil aggregates can be crushed with only moderate pressure), its available water-holding capacity, and nutrient content. Most often, it is superior to subsoil in the above characteristics. The texture and friability of topsoil are usually much more conducive to seedling emergence and root growth than subsoils.

In addition to being a better growth medium, topsoil is often less erodible than subsoils, and the coarse texture of topsoil increases infiltration capacity and reduces runoff.

Although topsoil provides an excellent growth medium, there are disadvantages to its use. Stripping, stockpiling, and reapplying topsoil, or importing topsoil, may not always be cost effective. Topsoiling can delay seeding or sodding operations, increasing the exposure time of denuded areas. Most topsoil contains weed seeds, and weeds may compete with desirable species.

In site planning, the option of topsoiling should be compared with that of preparing a seedbed in subsoil. The clay content of subsoils does provide high moisture availability and deter leaching of nutrients. When properly limed and fertilized, subsoils may provide a good growth medium, especially if there is adequate rainfall or irrigation water to allow root development in otherwise high-density material.

Topsoiling is strongly recommended where ornamental plants or high-maintenance turf will be grown. Topsoiling is a recommended procedure when establishing vegetation on shallow soils, soils containing potentially toxic materials, and soils of critically low-pH (high acid) levels.

If topsoiling is to be done, the following items should be considered:

- An adequate volume of topsoil should exist on the site. Topsoil will be spread at a compacted depth of 4" or greater.
- The topsoil stockpile should be located so that it meets specifications and does not interfere with work on the site, block drainage, or release appreciable amounts of sediment.
- Allow sufficient time in scheduling for topsoil to be spread and bonded to the subsoil prior to seeding, sodding, or planting.
- Care must be taken not to apply topsoil to subsoil if the two soils have contrasting textures. Clayey topsoil over sandy subsoil is a particularly poor combination because as water creeps along the junction between the soil layers, sloughing of the topsoil may occur.
- If topsoil and subsoil are not properly bonded, water will not infiltrate into the soil profile evenly and it will be difficult to establish vegetation.

Design Criteria and Construction

Materials

Field exploration of the site should be made to determine if there is sufficient surface soil of good quality to justify stripping. Topsoil shall be friable and loamy (loam, sandy loam, silt loam, sandy-clay loam, and clay loam). It shall be free of debris, trash, stumps, rocks, roots, and noxious weeds, and shall give evidence of being able to support healthy vegetation. It shall contain no substance that is potentially toxic to plant growth.

Potential topsoil should be tested by a recognized laboratory. It should meet the following criteria:

- Organic-matter content should be not less than 1.0% by weight.
- The pH range should be from 6.0-7.5. If pH is less than 6.0, lime should be added in accordance with soil-test results or in accordance with the recommendations of the vegetative-establishment practice being used.
- Soluble salts shall not exceed 500 ppm.
- If additional off-site topsoil is needed, it should meet the standards stated above.
- The depth of material meeting the above qualifications should be at least 4". Soil factors such as rock fragments, slope, depth to water table, and layer thickness affect the ease of excavation and spreading of topsoil.

Generally, the upper part of the soil, which is richest in organic matter, is most desirable; however, material excavated from deeper layers may be worth storing if it meets the other criteria listed above.

Stripping

Strip only those areas that will be affected by construction or development. A normal stripping depth is 4-6", but deeper depths may be satisfactory if the soil is suitable and undercutting is allowable in locations such as buildings, water-impoundment structures, roadways, etc. Appropriate sediment-control measures such as sediment barriers, sediment basins, inlet protection, etc., should be in place before the topsoil is stripped. Stripping should not be done on areas intended to support conventional, on-site effluent, disposal lines (field lines).

Stockpiling

The stockpile location should be out of drainageways and traffic routes. Stockpiles should not be placed on steep slopes where undue erosion will take place. Measures should be taken to prevent erosion of the stockpiles. These would include

- Mulching the stockpile when it is left inactive for 14 days or longer.
- Planting temporary vegetation when the stockpile is to be inactive over 30 days.
- Covering the stockpile with plastic whenever the piles are small or any soil loss would damage existing buildings or facilities.
- Planting permanent vegetation when the stockpile use will be inactive over 12 months.
- In cases where the stockpile is small and will be removed in fewer than 14 days, it may be more practical to use a sediment barrier than an erosion-control practice.

Site Preparation

Areas to be covered with topsoil shall be excavated, graded, filled, and shaped to the proper lines, grades, and elevations before topsoil placement is started.

The subgrades should be checked for pH and limed if the pH is less than 6.0. Liming shall be done in accordance with soil tests and in relation to the seeding mixture to be planted. Incorporate lime to a depth of at least 2" by discing.

Applying Topsoil

Immediately before placement of topsoil, the subsoil should be disced or scarified to a depth of 2" to enhance bonding of the subsoil and topsoil. Topsoil should be uniformly spread to a minimally compacted depth of 4". Required volumes of topsoil may be determined using Table TSG-1.

Table TSG-1 Volume of Soil Needed for Topsoiling

Depth to Spread (inches)	Cubic Yards Per 1,000 Sq. Ft.	Cubic Yards Per Acre
1	3.1	134
2	6.2	268
3	9.3	403
4	12.4	537
5	15.5	672
6	18.6	806

When applying topsoil, maintain needed erosion-control practices such as diversions, grass swales, lined swales, etc. Topsoil should not be spread when it or the subgrade is frozen or muddy.

Precautions should be taken to prevent layering of the topsoil over the subsoil. Mixing and bonding of the two soils should be enhanced by use of discing or cultivation tools.

Settling of the topsoil is necessary to bond the soils together, but undue compaction should be prevented. Light compaction is necessary to increase soil strength, reduce erosion, and enhance vegetation establishment. Excessive compaction should be prohibited as it increases runoff and inhibits seed germination and root development.

Surface irregularities that would impede drainage, increase erosion, or otherwise damage the site should be removed in final grading.

Common Problems

Consult with a qualified design professional if any of the following occur:

Depth of surface being stripped is significantly different than anticipated.

Topsoil appears to contain contaminants.

Topsoil appears too compacted during spreading; may need to loosen by discing or scarifying.

Maintenance

Inspect topsoiled areas frequently until vegetation is established.

Repair eroded or damaged areas and revegetate.

Repair sloughing on steep slopes—remove topsoil, roughen subgrade and respread topsoil.

Consult with a qualified design professional if drainage (wetness caused by seepage) or shallowness to bedrock (less than 24") is involved.

References

BMPs from Volume 1

Chapter 4

Land Grading (LG)

4-16

Mulching (MU)

4-48

Temporary Seeding (TS)

4-103

Chemical Stabilization (CHS)



Practice Description

Chemical erosion control on construction sites in the Southeast usually involves a water-soluble anionic polyacrylamide product referred to as PAM. It is used to minimize soil erosion caused by water and wind. PAM is typically applied with temporary seeding and or mulching on areas where the timely establishment of temporary erosion control is so critical that seedings and mulching need additional reinforcement. It may be used alone on sites where no disturbances will occur until site work is continued and channel erosion is not a significant potential problem.

Only PAM is currently included in this practice.

Planning Considerations

Anionic PAM is available in emulsions, powders, and gel bars or logs. Anionic PAM should be used in combination with other Best Management Practices. The use of seed and mulch should be considered for providing erosion protection beyond the life of the anionic PAM. If the area where PAM is applied is disturbed after the application, the application will need to be repeated.

Following are additional considerations to enhance the use of or avoid problems with the use of anionic PAM:

- Use setbacks when applying anionic PAM near natural water bodies.
- Decreased performance by the PAM can be expected if the PAM is exposed to ultraviolet light or if there is a delay between mixing the PAM with water and applying it to the exposed soil.

- When used in flow concentration channels, PAM's effectiveness for stabilization is decreased.
- If seed is applied with the anionic PAM, mulch should be used to protect the seed.
- Never add water to PAM; add PAM slowly to water. If water is added to PAM, the PAM tends to clot and form "globs" that can clog dispensers. This will result in an increased risk of under-application of the product.
- Only use anionic PAM; not all polymers are PAM.
- Requests to use other products on permitted sites should be made to the Mississippi Department of Environmental Quality.

Design Criteria

Application rates shall conform to manufacturers' guidelines for application. The following specific criteria shall be followed:

Only the anionic form of PAM shall be used. Cationic PAM is toxic and shall NOT be used.

PAM and PAM mixtures shall be environmentally benign, harmless to fish, wildlife, and plants. PAM and PAM mixtures shall be non-combustible.

Anionic PAM, in pure form, shall have less than or equal to 0.05% acrylamide monomer by weight, as established by the Food and Drug Administration and the Environmental Protection Agency.

To maintain less than or equal to 0.05% of acrylamide monomer, the maximum application rate of PAM, in pure form, shall not exceed 200/pounds/acre/year. Do not over apply PAM. Excessive application of PAM can lower its infiltration rate or increase suspended solids in water, rather than promoting settling.

Users of anionic PAM shall obtain and follow all Material Safety Data Sheet requirements and manufacturers' recommendations.

Additives such as fertilizers, solubility promoters or inhibitors, etc. to PAM shall be non-toxic.

The manufacturer or supplier shall provide written application methods for PAM and PAM mixtures. The application method shall ensure uniform coverage to the target and avoid drift to non-target areas including waters of the state. The manufacturer or supplier shall also provide written instructions to ensure proper safety, storage, and mixing of the product.

Gel bars or logs of anionic PAM mixtures may be used in ditch systems. This application shall meet the same testing requirements as anionic PAM emulsions and powders.

To prevent exceeding the acrylamide monomer limit in the event of a spill, the anionic PAM in pure form shall not exceed 200 pounds/batch at 0.05% acrylamide monomer or 400 pounds/batch at 0.025% acrylamide monomer.

Application

Prior to the start of construction, the application of PAM should be designed by a qualified design professional and plans and specifications should be available to field personnel.

The application should conform to the design and specifications provided in the plans.

Site Preparation

Prepare site following design and specifications.

Equipment Preparation

If using a liquid application system, pump a surfactant through the injection system before and after injecting concentrated liquid PAM into sprinkler-irrigation systems to prevent valves and tubing from clogging.

PAM used in hydroseeding applications should be the last additive to the mix.

After use, rinse all PAM mixing and application equipment thoroughly with water to avoid formation of PAM residues. Rinse residue should be applied to soil areas to create binding to the soil structure and increase erosion reduction.

PAM Application

Site testing for a PAM product should be conducted before PAM application to verify PAM-product performance and test reports (recommendations) should be supplied to the design professional and contractor before product application.

Toxicity reports, following EPA/600/4-90/027F 24 Hr. Acute Static Screen Toxicity Test (daphnia sp.), should be provided by the supplier to the contractor before application of a PAM product (this is to assure that PAM applications from the recommended product will be non-toxic).

PAM should be mixed and/or applied in accordance with all Occupational Safety and Health Administration (OSHA) Material Safety Data Sheet requirements and the manufacturers' recommendations for the specified use conforming to all federal, state and local laws, rules and regulations.

Emulsion batches should be mixed following recommendations of a testing laboratory that determines the proper product and rate to meet site requirements.

Never add water to PAM, but instead add PAM slowly to water.

Dry form (powder) may be applied by hand spreader or a mechanical spreader.

Mixing with dry, silica sand will aid in spreading. Pre-mixing of dry form PAM into fertilizer, seed, or other soil amendments is allowed when specified in the design plan. Application method should ensure uniform coverage to the target area.

Installation Verification

Check all components of the practice during installation to ensure that specifications are being met.

Common Problems

Consult with a qualified design professional if any of the following occur:

Problems with application equipment clogging.

Application specifications for PAM cannot be met; alternatives may be required. Unapproved application techniques could lead to failure.

Visible erosion occurs after application.

Maintenance

An operation and maintenance plan must be prepared for use by the operator responsible for PAM application. Plan items should include the following items:

Reapply PAM to disturbed or tilled areas that require continued erosion control.

Maintain equipment to provide uniform application rates.

Rinse all PAM mixing and application equipment thoroughly with water to avoid formation of PAM residues and discharge rinse water to soil areas where PAM stabilization may be helpful.

Downgradient deposition from the use of PAM may require periodic sediment removal to maintain normal functions.

References

BMPs from Volume 1

Chapter 4

Mulching (MU)	4-48
Temporary Seeding (TS)	4-103

Dust Control (DC)



Practice Description

Dust control includes a wide range of techniques that prevent or reduce movement of wind-borne soil particles (dust) during land disturbing activities. This practice applies to construction routes and other disturbed areas where on-site and off-site damage or hazards may occur if dust is not controlled.

Planning Considerations

Construction activities that disturb soil can be a significant source of air pollution. Large quantities of dust can be generated, especially in “heavy” construction activities such as land grading for road construction and commercial, industrial, or subdivision development.

The scheduling of construction operations so that the least amount of area is disturbed at one time is important in planning for dust control.

The greatest dust problems occur during dry periods. Therefore, to the extent practicable, do not expose large areas of bare soil during drought conditions.

Where wind erosion is a potential cause of dust problems, preserving vegetation should be considered as a passive measure. Leave undisturbed buffer areas between graded areas wherever possible.

Installing temporary- or permanent- surface stabilization measures immediately after completing land grading will minimize dust problems.

Design Criteria and Construction

Dust-control requirements should be designed by a qualified design professional and plans and specifications should be made available to field personnel prior to start of construction. Whenever possible, leave vegetated-buffer areas undisturbed between graded areas.

Scheduling

Schedule construction operations so that the smallest area is disturbed at any one time.

Permanent Methods

Vegetative Cover

For disturbed areas not subject to traffic, vegetation provides the most practical method of dust control. Establish vegetative cover according to the *Permanent Seeding* or *Temporary Seeding Practice*.

Topsoiling

This entails covering the surface with less erosive soil material. See *Topsoiling Practice* for guidance.

Stone

Stone used to stabilize construction roads can also be effective for dust control. Stone should be spread a minimum of 6" thick over construction roads in the disturbed area. For heavily traveled roads or roads subjected to heavy loads, the stone thickness should be 8" to 10". A non-woven geotextile meeting the requirements shown in the Table DC-1 for Class IV geotextiles should be used under the rock when the subgrade is soft or the blow count is less than 10.

Temporary Methods

Mulches

Mulch offers a fast, effective means of controlling dust when properly applied. See *Mulching Practice* for guidelines on planning and installing the practice.

Temporary Vegetative Cover

For disturbed areas where no activity is anticipated for 14 days or longer, temporary seeding can effectively control dust. Establish vegetative cover according to *Temporary Seeding Practice* guidelines.

Calcium Chloride

Calcium chloride may be applied by mechanical spreader as loose, dry granules or flakes at a rate that keeps the surface moist, but not so high as to cause water pollution or plant damage. Sites may need to be retreated because the product degrades over time.

Table DC-1 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTM D 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTM D 4632	≥ 50	≥ 50	≥ 50	≥ 50
Puncture (pounds)	ASTM D 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTM D 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTM D 4751	As specified max. no.40 ³			
Permittivity sec-1	ASTM D 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

- ¹ Heat-bonded or resin-bonded geotextile may be used for classes III and IV. They are particularly well suited to class IV. Needle-punched geotextile are required for all other classes.
- ² Minimum average roll value (weakest principal direction).
- ³ U.S. standard sieve size.

Spray-on Adhesives

Spray-on adhesives may be used on mineral soils for dust control. Traffic must be kept off treated areas to prevent the product from becoming ineffective. Examples of spray-on adhesives for use in dust control are listed in Table DC-2.

Table DC-2 Spray-on Adhesives for Dust Control on Mineral Soil

Material	Water Dilution	Type of Nozzle	Apply Gal/Ac
Latex Emulsion	12.5:1	Fine Spray	235
Resin In Water	4:1	Fine Spray	300

Chemical Stabilization (CHS)

PAM may be used on mineral soils for dust control. Traffic must be kept off treated areas to prevent the product from becoming ineffective. The manufacturer or supplier shall provide written application methods for PAM and PAM mixtures. The application method shall ensure uniform coverage to the target and avoid drift to non-target areas including waters of the State. The manufacturer or supplier shall also provide written instructions to ensure proper safety, storage, and mixing of the product. Refer to the *Planning Considerations for Chemical Stabilization (PAM) Practice* for planning considerations before deciding to use this product.

Sprinkling or Irrigation

Sprinkling is especially effective for dust control on haul roads and other traffic routes. Sprinkle the site until the surface is wet. Repeat as needed. Also, bare areas may be kept wet with irrigation to control dust as an emergency treatment.

Tillage

Tillage is used to roughen the site and bring clods and moist soil to the surface. This is a temporary emergency measure that can be used on large, open, disturbed areas as soon as soil blowing starts. Begin tilling on the windward edge of the site. The depth of tillage is determined by the depth to moist soil and the amount of moist soil desired at the surface. In sandy soils, the depth to moist soil may make tillage impractical.

Barriers

A board fence, wind fence, sediment fence, hay bales, or similar barriers can control air currents and blowing soil. Place barriers perpendicular to prevailing air currents at intervals about 15 times the barrier height.



Figure 1 Sand Fence (<http://www.gulfmex.org/crp/7004/fence.jpg>)

Street Cleaning

Use a street sweeper to remove the source materials.

Maintenance

Check construction site during vehicular traffic or windy conditions to see if measures are working adequately. Maintain dust-control measures continuously throughout dry-weather periods, until all disturbed areas have been stabilized.

References

BMPs from Volume 1

Chapter 4

Topsoiling (TSG)	4-20
Chemical Stabilization (CHS)	4-25
Mulching (MU)	4-48
Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103

Erosion Control Blanket (ECB)



Practice Description

To aid in controlling erosion on critical areas by providing a protective cover made of straw, jute, wood or other plant fibers; plastic, nylon, paper or cotton. This practice is best utilized on slopes and channels where the erosion hazard is high, and plant growth is likely to be too slow to provide adequate protective cover. Erosion control blankets are typically used as an alternative to mulching but can also be used to provide structural erosion protection. Some important factors in the choice of a blanket are: soil conditions, steepness of slope, length of slope, type and duration of protection required to establish desired vegetation, and probable shear stress.

Planning Considerations

Care must be taken to choose the type of blanket that is most appropriate for the specific project needs. Fourteen classes of erosion control blankets are discussed in this practice. Manufacturer's instructions and recommendations, as well as a site visit by the qualified design professional and site-plan reviewer are highly recommended to determine a product's appropriateness.

Temporary Erosion Control Blankets

Benefits of using temporary, erosion-control blankets include the following:

- Protection of the seed and soil from raindrop impact and subsequent displacement.
- Thermal consistency and moisture retention for the seedbed area.
- Stronger and faster germination of grasses and legumes.

- Spreading stormwater runoff to prevent rill erosion of slopes.
- Prevention of sloughing of topsoil added to steeper slopes.
- Because temporary blankets will deteriorate in a short period of time, they provide no enduring reduction in erosion potential.

Table ECB-1 Types of Erosion Control Blankets

Type of Erosion Control	Main Use	Comments
Netting	Synthetic or natural fiber mesh installed over disturbed area to hold organic mulch and/or seed in place.	Provides minimal structural erosion resistance. Mulch applied using standard procedures.
Biodegradable Erosion Control Blanket	Natural fiber blanket held together by netting to provide temporary erosion protection on slopes up to 1:1; and channels with permissible shear stress up to 4 lbs./ft.	Provides 1- to 5-year protection from erosion. Metal staples used as anchors.
Permanent Erosion Control Blanket	Synthetic blanket material which provides permanent erosion control on slopes up to 1:1; channels with increased water flow velocities and increased shear stress.	Provides minimal protection from wave action around ponds and lakes. Permanent erosion control blankets extend the limits of vegetation. Metal staples used as anchors.
Turf Reinforcement Mat	3-dimensional permanent synthetic mat that provides a matrix to greatly reinforce the root system of the desired vegetation for permanent erosion protection in high flow channels and on critical slopes.	Provides a substantial increase in erosion resistance. May provide erosion protection equivalent to stone or concrete liners.

Permanent Erosion Control Blankets

Permanent erosion control blankets are also known as permanent-soil reinforcing mats or turf-reinforcement mats. Roots penetrate and become entangled in the matrix, forming a continuous anchorage for surface growth and promoting enhanced energy dissipation.

Benefits of using permanent, erosion-control blankets, in addition to the benefits gained from using a temporary blanket include the following:

Sediment from stormwater flows is deposited in the matrix providing a fine soil-growth medium for the development of roots.

In stormwater channels, blankets and the vegetative-root system form an erosion resistant cover which resists hydraulic uplift and shear forces of channel flows.

Tables ECB-2 and ECB-3 give typical applications of the different classes of erosion control blankets.

Table ECB-1 Temporary Erosion Control Blanket Classes and Applications

Class	Application
1.A	Designed for use on geotechnically stable slopes with gradients up to 5:1 and channels with shear stresses up to .25 pounds per square foot.
1.B	Designed for use on geotechnically stable slopes with gradients up to 4:1 and channels with shear stresses up to .5 pounds per square foot.
1.C	Designed for use on geotechnically stable slopes with gradients up to 3:1 and channels with shear stresses up to 1.5 pounds per square foot.
1.D	Designed for use on geotechnically stable slopes with gradients up to 2:1 and channels with shear stresses up to 1.75 pounds per square foot.
2.A	Designed for use on geotechnically stable slopes with gradients up to 5:1 and channels with shear stresses up to .25 pounds per square foot.
2.B	Designed for use on geotechnically stable slopes with gradients up to 4:1 and channels with shear stresses up to .5 pounds per square foot.
2.C	Designed for use on geotechnically stable slopes with gradients up to 3:1 and channels with shear stresses up to 1.5 pounds per square foot.
2.D	Designed for use on geotechnically stable slopes with gradients up to 2:1 and channels with shear stresses up to 1.75 pounds per square foot.
3.A	Designed for use on geotechnically stable slopes with gradients up to 5:1 and channels with shear stresses up to .25 pounds per square foot.
3.B	Designed for use on geotechnically stable slopes with gradients up to 1.5:1 and channels with shear stresses up to 2 pounds per square foot.
4	Designed for use on geotechnically stable slopes with gradients up to 1:1 and channels with shear stresses up to 2.25 pounds per square foot.

Table ECB-3 Permanent Erosion Control Blanket Classes and Applications

Class	Application
5.A	Designed for use on geotechnically stable slopes with gradients up to 0.5:1 and channels with shear stresses up to 6 pounds per square foot.
5.B	Designed for use on geotechnically stable slopes with gradients up to 0.5:1 and channels with shear stresses up to 8 pounds per square foot.
5.C	Designed for use on geotechnically stable slopes with gradients up to 0.5:1 and channels with shear stresses up to 10 pounds per square foot.

Design Criteria and Construction

Prior to the start of construction, the application of erosion control blankets should be designed by a qualified design professional and plans and specifications should be available to field personnel.

Site Preparation

Grade the site in accordance with the approved design to a smooth and uniform surface, free of debris.

Add and incorporate topsoil where needed.

Make sure seedbed is firm, yet friable.

General

All blankets shall be nontoxic to vegetation and to the germination of seed and shall not be injurious to the unprotected skin of humans. Erosion control products shall be of sufficient strength to hold the prepared ground and, if applicable, cover material (mulch, sod, etc.) in place until an acceptable growth of natural or planted material is established.

Erosion control products shall be identified by a classification designation (Class 1.A, 1.B, 1.C, etc.) where the classification is based on the physical properties of the product.

Class Designations and Durability

Erosion control products shall have the configurations and durability as shown in Tables ECB-4 and ECB-5.

Table ECB-4 Typical Configuration and Durability of Temporary Erosion Control Blankets

Class Designation	Usual Configuration	Typical Durability
1.A Ultra-short term mulch control netting	Mulch control netting consisting of rapidly degrading photodegradable synthetic mesh or woven biodegradable natural fiber netting.	3 months
1.B Ultra-short term netless erosion control blanket	An erosion control blanket composed of processed rapidly degrading natural and/or polymer fibers mechanically interlocked or chemically adhered together to form a continuous matrix.	3 months
1.C Ultra-short term single net erosion control blanket or open weave textile	An erosion control blanket composed of processed degradable natural and/or polymer fibers mechanically bound together by a single rapidly degrading, synthetic or natural fiber netting to form a continuous matrix. Or an open weave textile composed of processed rapidly degrading natural or polymer yarns or twines woven into a continuous matrix.	3 months
1.D Ultra-short term double net erosion control blankets	An erosion control blanket composed of processed natural or polymer fibers mechanically bound between 2 rapidly degrading, synthetic or natural fiber nettings to form a continuous matrix.	3 months
2.A Short-term mulch control netting	Mulch control netting consisting of photodegradable synthetic mesh or woven biodegradable natural fiber netting.	12 months
2.B Short-term netless erosion control blanket	An erosion control blanket composed of processed degradable natural and/or polymer fibers mechanically interlocked or chemically adhered together to form a continuous matrix.	12 months
2.C Short-term single net erosion control blanket or open weave textile	An erosion control blanket composed of processed degradable natural and/or polymer fibers mechanically bound together by a single degradable, synthetic or natural fiber netting to form a continuous matrix. Or an open weave textile composed of processed degradable natural or polymer yarns or twines woven into a continuous matrix.	12 months
2.D Short-term double net erosion control blanket	An erosion control blanket composed of processed natural or polymer fibers mechanically bound between 2 synthetic or natural fiber nettings to form a continuous matrix.	12 months
3.A Extended-term mulch control netting	Mulch control netting consisting of a slow degrading synthetic mesh or woven natural fiber netting.	24 months
3.B Extended-term erosion control blanket or open weave textile	An erosion control blanket composed of processed slow degrading natural and/or polymer fibers mechanically bound together between 2 slow degrading synthetic or natural fiber nettings to form a continuous matrix. Or an open weave textile composed of processed slow degrading natural or polymer yarns or twines woven into a continuous matrix.	24 months
4 Long-term erosion control blanket or open weave textile	An erosion control blanket composed of processed slow degrading natural and/or polymer fibers mechanically bound together between 2 slow degrading synthetic or natural fiber nettings to form a continuous matrix. Or an open weave textile composed of processed slow degrading natural or polymer yarns or twines woven into a continuous matrix.	36 months

Table ECB-5 Typical Configuration and Durability of Permanent Erosion Control Blankets

Class Designation	Usual Configuration	Typical Durability
5.A Permanent turf reinforcement mat	A non-degradable turf reinforcement mat with sufficient thickness, strength and void space for permanent erosion protection and vegetation reinforcement.	Permanent
5.B Permanent turf reinforcement mat	A non-degradable turf reinforcement mat with sufficient thickness, strength and void space for permanent erosion protection and vegetation reinforcement.	Permanent
5.C Permanent turf reinforcement mat	A non-degradable turf reinforcement mat with sufficient thickness, strength and void space for permanent erosion protection and vegetation reinforcement.	Permanent

Materials Physical Requirements

A properly designed erosion control blanket installation requires selection of a product manufactured with physical properties to withstand the stresses the product will be subjected to for the design life of the product. Table ECB-6 gives the minimum physical requirements for each class of blanket.

Table ECB-6 Minimum Physical Requirements For Erosion Control Blankets

Property						
Class	Minimum Tensile Strength (pounds/ft.) (ASTM 4595) ¹	Minimum Permissible Shear Stress (pounds/sq. ft.) (ASTM D 6460) ^{2, 5}	Maximum Factor for Temporary Products (ASTM D 6459) ^{3, 5}	"C" for	UV Stability (Minimum % tensile retention) for Permanent Products (ASTM D 4355) (500 hour exp.)	Minimum Thickness (inches) For Permanent Products (ASTM 6525) ⁴
1.A ⁶	5	0.25	0.10 @ 5:1		N/A	N/A
1.B	5	0.50	0.10 @ 4:1		N/A	N/A
1.C	50	1.50	0.15 @ 3:1		N/A	N/A
1.D	75	1.75	0.20 @ 2:1		N/A	N/A
2.A ⁶	5	0.25	0.10 @ 5:1		N/A	N/A
2.B	5	0.50	0.10 @ 4:1		N/A	N/A
2.C	50	1.50	0.15 @ 3:1		N/A	N/A
2.D	75	1.75	0.20 @ 2:1		N/A	N/A
3.A ⁶	25	0.25	0.10 @ 5:1		N/A	N/A
3.B	100	2.00	0.25 @ 1.5:1		N/A	N/A
4	125	2.25	0.25 @ 1:1		N/A	N/A
5.A ⁷	125	6.00	N/A		80	0.25
5.B ⁷	150	8.00	N/A		80	0.25
5.C ⁷	175	10.00	N/A		80	0.25

- 1 Minimum average roll values, machine direction. For turf reinforcement mats used in field conditions with high loading and/or high survivability requirements tensile strengths of 3000 pounds/ft or greater.
- 2 Minimum shear stress the rolled erosion control products or turf reinforcement mats can sustain without physical damage or excess erosion (>.5" of soil loss) during a 30 minute flow event in large scale testing. These performance test values should be supported by periodic bench scale testing under similar test conditions and failure criteria using Erosion Control Technology Council Test Method no. 3. For temporary products the permissible shear stress levels were established for each class based on historical experience with products characterized by Manning's roughness coefficients in the range of 0.03 to 0.05.
- 3 "C" factor calculated as ratio of soil loss from rolled erosion control product protected slope (tested at the specified gradient) to soil loss from unprotected (control) plot in large scale testing. These performance test values should be supported by periodic bench scale testing under similar test conditions and failure criteria using Erosion Control Technology Council Test Method no.2.
- 4 Minimum average roll values.
- 5 Other large scale test methods may be determined acceptable.
- 6 Obtain maximum "C" factor and allowable shear stress for mulch control nettings with the netting used in conjunction with pre-applied mulch material.
- 7 For turf reinforcement mats containing degradable components, all property values must be obtained on the non-degradable portion of the matting alone.

Product Placement

The erosion control product should be placed immediately after completion of the preparation of the area where the product will be placed.

Follow the manufacturer's recommendations for installation or use the following instructions. If there is a conflict, follow the manufacturer's recommendations. Strips shall be rolled out flat, parallel to the direction of flow, in flumes and ditches. On steep cut or fill slopes, strips shall be rolled out flat, and perpendicular to the direction of flow to reduce rill erosion. When 2 or more strips are required to cover an area, they shall overlap at least 3" (75 mm); however, excelsior blankets will not require lapping but are to be butted together and stapled with half of each staple located in each of the adjoining blankets. Ends of strips shall overlap at least 6" (150 mm) with the upgrade section on top. The upslope end (anchor slot) of each strip shall be buried in 6" (150 mm) vertical slots, and soil tamped firmly against it. Figure ECB-1 shows typical erosion control blanket installation. When conditions are warranted by the opinion of the qualified design professional, any other edge exposed to excessive flow shall be buried as noted above. The erosion control product shall be spread evenly and smoothly, and shall be in contact with the soil at all points. The product should not be stretched tight in such a manner that the material "tents" over the soil surface. If the manufacturer's recommendations for installation of the erosion control product are different than those given here, the Contractor will be required to follow the more stringent of the two.




Figure ECB - 1 Erosion Control Blanket Placement (Source: EPA)

Check slots shall be 24" (600 mm) minimum width and separate strips of erosion control product placed at right angles to the direction of water flow immediately prior to placing the general covering of the product. Check slots shall be made by burying a tight fold of

the product vertically in the soil a minimum of 6" (150 mm) deep, and tamping and stapling the fold in place. Check slots shall be placed so that one check slot, junction slot, or anchor slot of the erosion control product occurs every 50 feet (15 m) of slope. If the manufacturer's recommendations for the installation of check slots are different than those given here, the Contractor will be required to follow the more stringent of the two.

Each strip shall be stapled in 3 rows, at each edge and the center, with staples spaced not more than 3 feet (900 mm) longitudinally. Check slots and ends of strips shall be stapled at 9" (225 mm) intervals across their width.

For temporary blankets, staples should be U-shaped wire with an 11-gauge thickness or greater. Staples should be of sufficient thickness for soil penetration without undue distortion. The legs of the staples shall be at least 6" long with a crown of 1". Appropriate biodegradable staples can be used in lieu of wire staples.

Permanent blankets shall be anchored in one of two ways. Blankets can be anchored using sound wood stakes, 1" by 3" stock sawn in a triangular shape. The length of the stakes shall be from 12" to 18" depending upon the soil compaction at the site. Stakes shall be installed on 4 feet centers along each edge of the blanket. Blankets can also be anchored using U shaped staples of 11 gauge steel or greater with a minimum leg length of 8" and a 2" crown.




Figure ECB - 2 Erosion Control Blanket Detail

Construction Verification

Check finished grade, dimensions and staple spacing of erosion control blankets. Check materials for compliance with specifications.

Common Problems

Consult with a qualified design professional if any of the following occur:

Movement of the blanket or erosion under the blanket is observed.

Poor contact between the soil and the erosion control blanket results in surface water flowing under rather than over the blanket, causing erosion; retrench or reanchor to direct water over blanket.

Blanket inadequately or improperly stapled results in tenting, blanket movement or displacement; reinstall and ensure blanket is properly anchored.

Unstable slope results in blanket or slope failure; determine cause of slope failure, stabilize slope and reinstall blanket.

Variations in topography on site indicate erosion control mat will not function as intended; changes in plan may be needed, or a blanket with a shorter or longer life may be needed.

Design specifications for seed variety, seeding dates or erosion control materials cannot be met; substitution may be required. Unapproved substitutions could result in failure to establish vegetation or breach of contract.

Maintenance

Inspect after storm events until vegetation is established for erosion or undermining beneath the blankets. If any area shows erosion, pull back that portion of the blanket, add tamped soil and reseed; then resecure the blankets.

If blankets should become dislocated or damaged, repair or replace and resecure immediately.

References

BMPs from Volume 1

Chapter 4

Land Grading (LG)

4-16

Mulching (MU)

4-48

Housekeeping Practices (HK)



Practice Description

Housekeeping practices describes the various activities and measures, in addition to the specific practices used for erosion and sediment control that are essential during construction for the protection of environmental quality. Housekeeping is applicable at all construction sites.

Planning Considerations

In addition to the sediment- and erosion-control practices included in the manual that deal directly with sediment and erosion control, some general housekeeping practices are essential to the pollution prevention aspect of a Stormwater Pollution Prevention Plan. Housekeeping addresses these practices. Included in the practice are the following different areas:

- Inspection and Maintenance Procedures
- Materials Inventory
- Spill Prevention and Material Management Practices
- Spill Controls
- Hazardous Products
- Air Emissions (excessive odor)
- Other Good Housekeeping Practices (i.e. fugitive spray, excessive noise and aesthetics)

Design Criteria

Inspection and Maintenance Procedures

The following inspection and maintenance procedures need to be followed to maintain adequate sediment and erosion controls:

- All control measures need to be inspected at least once per week and following any accumulation of rainfall of 1/2" or more within a 24-hour period.
- All measures need to be maintained in good working order. If a repair is necessary, it should be initiated within 24 hours of report.
- Silt fence and straw bales need to be inspected weekly for proper anchorage and leakage underneath. Silt fencing should also be inspected for tears.
- Built-up sediment needs to be removed from silt barriers when it has reached 1/2 of the height of the barrier. Sediment needs to be placed in a stabilized site to prevent re-entry into the same site or another entrapment area.
- Sediment basins need to be inspected for depth of sediment on a monthly basis and built-up sediment needs to be removed when 1/2 of the basin volume is filled.
- Temporary and permanent seeding and plantings need to be inspected for bare spots, washouts and healthy growth. A person should be designated to be responsible for maintaining planted areas until growth has reached 1" in height and the area planted has 70% ground cover.

Materials Inventory

A materials list should be compiled for items that will be stored outside on the site during construction. For example:

- _____ Pipe, fittings and joint compounds for underground utility piping
- _____ Gravel and stone bedding material
- _____ Concrete forming materials
- _____ Other (specify) _____
- _____
- _____
- _____

NOTE: Fuels, oils and other petroleum products; forming oils and compounds; fertilizers; pesticides; strippers; detergents; cleaners; or any other hazardous or toxic compounds should not be stored outside on the site unless specifically agreed upon by all responsible parties, including those persons responsible for enforcing local ordinances and policies. On-site storage should meet all local, state and federal rules regarding secondary containment. Additionally, local ordinances may require fencing and security measures for storage of these products.

Spill Prevention and Material Management Practices

Petroleum Products

All vehicles kept on the site need to be monitored for leaks and receive regular preventive maintenance to reduce the chance of leakage. A Spill Prevention Control and Countermeasures (SPCC) plan should be developed for the facility to address the safe storage, handling and clean up of petroleum products and other chemicals. Petroleum products should be stored in tightly sealed containers, that are clearly labeled. If petroleum products are stored on site, a secondary containment facility will be required if the cumulative storage capacity of all tanks, greater than 55 gallons, at the site exceeds 1,320 gallons.

Fueling & Servicing

No fueling, servicing, maintenance, or repair of equipment or machinery should be done within 50 feet of a stream, or within 100 feet of a stream classified for public water supply (PWS), with special designation, protected vegetation (tree drip-line), or a sinkhole.

Mud Tracking

A stabilized construction entrance needs to be designated on the plan. The practice construction exit pad provides design details for planning such an entrance.

Only designated entrances should be used for construction access to the site. The General Contractor should be responsible for keeping mud cleaned from adjoining streets on a daily basis if needed.

Concrete Trucks

Concrete trucks should be allowed to wash only in locations where discharge is directed to a sediment basin. It is not permissible to discharge concrete wash directly to streams or storm drains. Alkalinity and chemical additives could be harmful to fish, stream bottom macroinvertebrates and wildlife.

Disposal of Oil

No fuels, oils, lubricants, solvents, or other hazardous materials can be disposed of on the site. All hazardous material must be properly disposed of in accordance with State law.

Trash/Solid Waste

The General Contractor is responsible for disposing of all solid waste from the site in accordance with State law. Dumpsters or other collection facilities must be provided as needed. Solid waste may not be buried on the site.

Sanitary Waste

The General Contractor is responsible for providing sanitary facilities on the site. Sanitary waste may be disposed only in locations having a State permit.

Other Discharges

Water for pressure testing sanitary sewers, flushing water lines, sand blasting, concrete cleansing, etc., may be discharged only in approved areas. Discharge of hydrostatic test water may require additional permitting, particularly if chlorinated public water is used.

Spill Controls

In addition to the good housekeeping practices and material management practices listed previously, the following procedures need to be followed for spill prevention and clean-up:

- Manufacturer's recommended methods for spill cleanup needs to be clearly posted and site personnel need to be made aware of the procedures and the location of the information and cleanup supplies. Refer to material safety data sheets (Material Safety Data Sheet).
- Material and equipment necessary for spill cleanup needs to be kept in the material storage area on-site. Equipment and materials include, but are not limited to; brooms, dust pans, mops, rags, gloves, goggles, absorbent clay (kitty litter), sand, sawdust, absorbent mats, and plastic and metal trash containers specifically for this purpose.
- All spills need to be cleaned up immediately after discovery and properly containerized for proper disposal. Burial is not acceptable.
- The spill area must be kept well ventilated and personnel need to wear appropriate protective clothing to prevent injury from contact with a hazardous substance.
- Spills of toxic or hazardous material must be reported immediately to the appropriate state or local government agency, regardless of the size.
- The spill prevention plan needs to be adjusted to include measures to prevent this type of spill from being repeated, and the plan needs to show how to clean up the spill if another one does occur.

Contaminated Soils

Removal of contaminated soils and underground storage tanks should be based on information provided by the Mississippi Department of Environmental Quality following a proper site assessment.

Hazardous Products

Products must be kept in original containers unless they are not resealable. If product is transferred to a new container, it must be properly marked and labeled.

Original labels and material safety data sheets should be retained.

If surplus product must be disposed, disposal must be done in accordance with Mississippi Department of Environmental Quality regulations.

Air Emissions

Open burning must meet the criteria found in the State of Mississippi's Air Emissions Regulations found in APCS-1, Section 3.7. Other considerations are discussed below.

Burning

Burning on the site may require a permit from the Mississippi Forestry Commission. County or city ordinances may also apply. Starting disposal fires with diesel fuel or old tires is not a recommended practice. The use of burn pits with fans to generate hot disposal fires decreases the fire disposal time and minimizes smoke.

Dust Control

Apply measures that minimize dust. Stabilizing areas with mulch as soon as possible can minimize dust. Watering should be provided in unstabilized areas (See *Dust Control Practice*).

Other Good Housekeeping Practices

In addition to the foregoing, the following good housekeeping practices need to be followed during the construction of the project:

- An effort should be made to store only enough products to do the job.
- All materials stored on-site should be stored in a neat, orderly manner in their appropriate containers and, if possible, under a roof or other enclosure.
- Products should be kept in their original containers with the original manufacturer's label.
- Whenever possible, all of a product should be used up before disposing of the container.
- Manufacturer's recommendations for proper use and disposal must be followed (see Material Safety Data Sheet).
- The site superintendent should inspect daily to ensure proper usage, storage and disposal of materials.
- Fertilizers need to be applied only in the minimum amounts recommended by the manufacturer.
- All paint containers need to be tightly sealed and stored when not required for use. Excess paint shall not be dumped into the storm sewer system but should be properly disposed of according to manufacturer's instructions (see Material Safety Data Sheet) and State regulations.
- The site should be kept clean and well groomed (trash picked up regularly, weeds mowed and signs maintained).
- Offsite fugitive spray from dust control, sand blasting and pressure washing must be minimized to the extent possible.
- Locate activities that generate odors and noise as far from surrounding properties as possible (this item includes portable toilets, burn sites, fueling areas, equipment repair areas and dumpsters).

References

BMPs from Volume 1

Chapter 4

Dust Control (DC)

4-29

Mulching (MU)



Practice Description

Mulching is the application of plant residues such as straw or other suitable materials to the soil surface. Mulch protects the soil surface from the erosive force of raindrop impact and reduces the velocity of overland flow. It helps seedlings germinate and grow by conserving moisture, protecting against temperature extremes and controlling weeds. Mulch also maintains the infiltration capacity of the soil. Mulch can be applied to seeded areas to help establish plant cover. It can also be used in unseeded areas to protect against erosion over the winter or until final grading and shaping can be accomplished except in areas with concentrated flow.

Planning Considerations

Surface mulch is the most effective, practical means of controlling runoff and erosion on disturbed land prior to vegetation establishment. Mulch absorbs the energy associated with raindrops and thereby minimizes soil-particle detachment, which is the initiation step of erosion.

Mulch also reduces soil moisture loss by evaporation, prevents crusting and sealing of the soil surface, moderates soil temperatures, and provides a suitable microclimate for seed germination.

Organic mulches such as straw, wood chips and shredded bark have been found to be very effective mulch materials. Materials containing weed and grass seeds that may compete with establishing vegetation should not be used. Also, decomposition of some wood products can tie up significant amounts of soil nitrogen, making it necessary to modify fertilization rates or add fertilizer with the mulch.

A variety of erosion-control blankets have been developed in recent years for use as mulch, particularly in critical areas such as waterways and channels. Various types of netting materials are also available to anchor organic mulches.

The choice of materials for mulching should be based on soil conditions, season, type of vegetation to establish, and size of the area. Properly applied and tacked mulch is always beneficial. Mulching is especially important when conditions of germination are not optimum, such as midsummer and early winter, and on difficult sites with cut slopes, or fill slopes and droughty soils.

Straw is the most commonly used material in conjunction with seeding. Wheat straw is the mostly commonly used straw, and can be spread by hand or with a mulch blower. If the site is susceptible to blowing wind, the straw should be tacked down with a tackifier, a crimper, or a disk to prevent loss. Some site developers always require that straw mulch be tacked by an approved method.

Wood chips are suitable for areas that will not be closely mowed, and around ornamental plantings. Chips do not require tacking. Because they decompose slowly, they must be treated with 12 pounds of nitrogen per ton to prevent nutrient deficiency in plants. They can be an inexpensive mulch if the chips are obtained from trees cleared on the site.

Wood fiber refers to short cellulose fibers applied as a slurry in hydroseeding operations. Wood-fiber hydroseeder slurries may be used to tack straw mulch on steep slopes, critical areas, and where harsh climatic conditions exist.

Compost, peanut hulls, and pine straw are organic materials that potentially make excellent mulches but may only be available locally or seasonally. Creative use of these materials may reduce costs.

Jute mesh or the various types of netting is very effective in holding mulch in place on waterways and slopes before grasses become established.

Erosion-control blankets promote seedling growth in the same way as organic mulches and are suited for use in areas with concentrated flows (see *Erosion-Control Blanket Practice*).

Design Criteria and Installation

Mulching should be designed by a qualified design professional and plans and specifications should be made available to field personnel prior to start of construction.

Site Preparation

Divert runoff water from areas above the site that will be mulched.

Remove stumps, roots, and other debris from the construction area.

Grade area as needed to permit the use of equipment for seeding, mulching, and maintenance. Shape area so that it is relatively smooth.

If the area will be seeded, follow seeding specifications in the design plan and apply mulch immediately after seeding.

Spreading the Mulch

Select a mulch material based on the site and practice requirements, availability of material, and availability of labor and equipment. Table MU-1 lists commonly used mulches.

Uniformly spread organic mulches by hand or with a mulch blower at a rate which provides about 75% ground cover. When spreading straw mulch by hand, divide the area to be mulched into sections of approximately 1000 sq. ft. and place 70-90 pounds of straw (1 ½ to 2 bales) in each section to facilitate uniform distribution. Caution, an over-application of wheat straw will reduce stand success – do not over-apply wheat straw when mulching a seeding application!

Anchor straw- or wood-cellulose mulch by one of the following methods:

- Crimp with a weighted, straight, notched disc or a mulch-anchoring tool to punch the straw into the soil.
- Tack with a liquid tackifier designed to hold mulch in place. Use suitable spray equipment and follow manufacturer's recommendations.
- In more erosive areas, cover with netting, using a degradable natural or synthetic mesh. The netting should be anchored according to manufacturer's specifications (see *Erosion-Control Blanket Practice*).
- On steep slopes and other areas needing a higher degree of protection, use one of the following: 1) heavy natural nets without additional mulch; 2) synthetic netting with additional mulch or; 3) erosion control mats/blankets. These areas include grassed waterways, swales and diversion channels.
- Install netting and mats/blankets according to manufacturer's specifications making sure materials are properly anchored (see *Erosion-Control Blanket Practice*).

Table MU-1 Mulching Materials and Application Rates

Material	Rate Per Acre and (Per 1000 ft.²)	Notes
Straw with Seed	1 ½-2 tons (70 lbs-90 lbs)	Spread by hand or machine to attain 75% groundcover; anchor when subject to blowing.
Straw Alone (no seed)	2 ½-3 tons (115 lbs-160 lbs)	Spread by hand or machine; anchor when subject to blowing.
Wood Chips	5-6 tons (225 lbs-270 lbs)	Treat with 12 lbs. nitrogen/ton.
Bark	35 cubic yards (0.8 cubic yard)	Can apply with mulch blower.
Pine Straw	1-2 tons (45 lbs-90 lbs)	Spread by hand or machine; will not blow like straw.
Peanut Hulls	10-20 tons (450 lbs-900 lbs)	Will wash off slopes. Treat with 12 lbs. nitrogen/ton.

Liquid-mulch binders can also be used to tack mulch subject to being blown away by wind. Applications of liquid-mulch binders and tackifiers should be heaviest at the edges of areas and at crests of ridges and banks, to resist wind. Binders should be applied uniformly to the rest of the area. Binders may be applied after mulch is spread or may be sprayed into the mulch as it is being blown onto the soil. Applying straw and binder together is the most effective method. Liquid binders include an array of commercially available synthetic binders.

Straw mulch may also be anchored with lightweight plastic, cotton, jute, wire or paper netting which is stapled over the mulch. The manufacturer's recommendations on stapling netting should be followed.

Verification of Installation

Check materials and installation for compliance with specifications.

Common Problems

Consult with qualified design professional if either of the following occurs:

Variations in topography on site indicate the mulching materials will not function as intended; changes in plan may be needed.

Design specifications for mulching materials or seeding requirements cannot be met; substitution may be required. Unapproved substitutions could result in erosion or seeding failure.

Problems that require remedial actions:

Erosion, washout and poor plant establishment; repair eroded surface, reseed, re-mulch and anchor mulch.

Mulch is lost to wind or stormwater runoff; reapply mulch and anchor appropriately by crimping, netting or tacking.

Maintenance

Inspect all mulched areas periodically and after rainstorms for erosion and damage to the mulch. Repair promptly and restore to original condition. Continue inspections until vegetation is well established. Keep mower height high if plastic netting is used to prevent netting from wrapping around mower blades or shaft.

References

BMPs from Volume 1

Chapter 4

Erosion-Control Blanket (ECB)	4-33
Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103

Permanent Seeding (PS)



Practice Description

Permanent seeding is the establishment of perennial vegetation on disturbed areas from seed. Permanent vegetation provides economical long-term erosion control and helps prevent sediment from leaving the site. This practice is used when vegetation is desired and appropriate to permanently stabilize the soil.

Planning Considerations

The advantages of seeding over other means of establishing plants include the smaller initial cost, lower labor input, and greater flexibility of method.

Disadvantages of seeding include potential for erosion during the establishment stage, seasonal limitations on suitable seeding dates, and weather-related problems such as droughts.

The probability of successful plant establishment can be maximized through good planning. The selection of plants for permanent vegetation must be site specific. Factors that should be considered are types of soils, climate, establishment rate, and management requirements of the vegetation. Other factors that may be important are wear, mowing tolerance, and salt tolerance of vegetation.

Plant selection for permanent vegetation should be based on plant characteristics, site and soil conditions, time of year of planting, method of planting, and the intended use of the vegetated area. Climate factors can vary widely in Mississippi. Important plant attributes are discussed in *Vegetation Establishment for Erosion and Sediment Control* in Chapter 2.

Plant selection may include companion plants to provide quick cover on difficult sites, late seedings, or where the desired permanent cover may be slow to establish. Annuals are usually used for companion plants and should be selected carefully to prevent using a species that provide so much competition that it prevents the establishment of the desired species.

Seeding properly carried out within the optimum dates has a higher probability of success. It is also possible to have satisfactory establishment when seeding outside these dates. However, as plantings are deviated from the optimum dates, the probability of failure increases rapidly. Seeding dates should be taken into account in scheduling land-disturbing activities.

Site quality impacts both short-term and long-term plant success. Sites that have compacted soils, soils that are shallow to rock, or have textures that are too clayey or too sandy should be modified whenever practical to improve the potential for plant growth and long-term cover success.

The operation of equipment is restricted on slopes steeper than 3:1, severely limiting the quality of the seedbed that can be prepared. Provisions for establishment of vegetation on steep slopes can be made during final grading. In construction of fill slopes, for example, the last 4-6" might not be compacted. A loose, rough seedbed with irregularities that hold seeds and lime and fertilizer is essential for hydroseeding. Cut slopes should be roughened (see *Land Grading Practice*).

Proper mulching is critical to protect against erosion on steep slopes. When using straw, anchor with netting. On slopes steeper than 2:1, jute, excelsior, or synthetic matting may be required.

The use of irrigation (temporary or permanent) will greatly improve the success of vegetation establishment.

Design Criteria and Installation

Prior to start of construction, plant materials, seeding rates and planting dates should be specified by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the installation process.

Permanent seeding should be done during the specified planting period whenever possible. When sites are only available for planting outside of the recommended planting period, either an out-of-season permanent seeding, a temporary seeding, mulching or chemical stabilization will be more appropriate than leaving the surface bare for an extended period. If lime and fertilizer application rates are not specified, take soil samples during final grading from the top 6" in each area to be seeded. Submit samples to a soil testing laboratory for lime and fertilizer recommendations.

Scheduling

The schedule for work at the site should consider the recommended planting period and whenever practical, the site work should accommodate seeding during the recommended planting period.

Plant Selection

Select plants that can be expected to meet planting objectives. To simplify plant selection, use Figure PS-1 Geographical Areas for Species Adaptation and Table PS-1, Commonly Used Plants for Permanent Cover. Mixtures commonly specified by the Mississippi Department of Transportation are an appropriate alternative for plantings on rights-of-ways. Additional information related to plantings in Mississippi is found in Chapter 2 under the section *Vegetation for Erosion and Sediment Control*.

The plants used for temporary vegetation may be used for companion plants provided the seeding rate is reduced by one half. See the *Temporary Seeding Practice* for additional information on establishing temporary vegetation. **Ryegrass or other highly competitive plants should not be used as a companion plant.**




Figure PS-2 Geographical Areas for Species Adaptation

Table PS-1 Commonly Used Plants for Permanent Cover with Seeding Rates and Dates

Species	Seeding Rates/Ac	Planting Time	Desired pH Range	Fertilization Rate/Acre	Method of Establishment	Zone of Adaptability	Native / Introduced
Common Bermuda	15 lbs. alone 10lbs. mix	3/1 – 7/15 9/1 – 11/30	6.0 – 7.0	600 lbs. 13-13-13	Seed or sod	All	Introduced * Potential for Invasiveness
Bahia	40 lbs. alone 30 lbs. mix	3/1 – 7/15 9/1 – 11/30	6.0 – 7.0	600 lbs. 13-13-13	Seed	Central and South	Introduced
Fescue	40 lbs. alone 30 lbs. mix	9/1 – 11/30	6.0 – 7.0	600 lbs. 13-13-13	Seed	North and Central	Native
Saint Augustine	--	3/1 – 7/15	6.0 – 7.0	600 lbs. 13-13-13	Sod only	Central and South	Native
Centipede	4 lbs. alone 2.5 lbs mix	3/1 – 7/15	6.0 – 7.0	600 lbs. 13-13-13	Seed or sod	All	Introduced
Carpet Grass	15 lbs. alone 10 lbs. mix	3/1 – 7/15	6.0 – 7.0	600 lbs. 13-13-13	Seed or sod	All	Native
Zoysia Grass	--	3/1 – 7/15	6.0 – 7.0	600 lbs. 13-13-13	Sod only	All	Introduced
Creeping Red Fescue	30 lbs. alone 22.5 lbs. mix	9/1 – 11/30	6.0 – 7.0	600 lbs. 13-13-13	Seed	All	Native
Weeping Lovegrass	10 lbs. alone 5 lbs. mix	3/1 – 7/15	6.0 – 7.0	600 lbs. 13-13-13	Seed	All	Introduced
*Wheat	90 lbs. alone	9/1 – 11/30	6.0 – 7.0	600 lbs 13-13-13	Seed	All	Native
*Ryegrass	30 lbs.	9/1 – 11/30	6.0 – 7.0	600 lbs 13-13-13	Seed	All	Native
*White Clover	5 lbs.	9/1 – 11/30	6.0 – 7.0	400 lbs 6-24-24	Seed	All	Introduced
*Crimson Clover	15 lbs.	9/1 – 11/30	6.0 – 7.0	400 lbs 6-24-24	Seed	All	Introduced
Sericea Lespedeza	40 lbs.	3/1 – 7/15 9/1 – 11/30	6.0 – 7.0	400 lbs. 13-13-13	Seed	All	Introduced
*Hairy Vetch	30 lbs.	9/1 – 11/30	6.0 – 7.0	400 lbs 6-24-24	Seed	All	Introduced
*Browntop Millet	40 lbs. alone 15 lbs. mix	4/1 – 8/30	6.0 – 7.0	600 lbs 13-13-13	Seed	All	Introduced

* Note on Annuals: For permanent seeding, annuals can only be used in a mixture with perennials.

Seedbed Requirements

Establishment of vegetation should not be attempted on sites that are unsuitable due to compaction or inappropriate soil texture, poor drainage, concentrated overland flow, or steepness of slope until measures have been completed to correct these problems. To maintain a good stand of vegetation, the soil must meet certain minimum requirements as a growth medium. A good growth medium should have these attributes:

- Sufficient pore space to permit root penetration.
- Enough fine-grained soil material (silt and clay) to maintain adequate moisture and nutrient supply.
- Sufficient depth of soil to provide an adequate root zone. The depth to rock or impermeable layers such as hardpans should be 12" or more, except on slopes steeper than 2:1 where topsoiling is not feasible.
- A favorable pH range for plant growth, usually 6.0-6.5.
- Sufficient nutrients (nitrogen, phosphorus and potassium) for initial plant establishment.
- Freedom from large roots, branches, stones, or large clods. Clods and stones may be left on slopes steeper than 3:1 if they are to be hydroseeded.

If any of the above attributes are not met; i.e., if the existing soil is too dense, coarse, shallow or acidic to foster vegetation – chiseling, topsoil, or special amendments should be used to improve soil conditions. The soil conditioners described below may be beneficial or topsoil may be applied (for guidance on topsoiling see *Topsoiling Practice*). These amendments should only be necessary where soils have limitations that make them poor for plant growth or for turf establishment.

- Peat-appropriate types are sphagnum moss peat, reed-sedge peat, or peat humus, all from fresh-water sources. Peat should be shredded and conditioned in storage piles for at least 6 months after excavation.
- Sand-should be clean and free of toxic materials.
- Vermiculite-use horticultural grade.
- Rotted manure-use stable or cattle manure not containing undue amounts of straw or other bedding materials.
- Thoroughly rotted sawdust-should be free of stones and debris. Add 6 lbs of nitrogen to each cubic yard.

Soil Amendments

Liming Materials

Lime (Agricultural limestone) should have a neutralizing value of not less than 90 percent calcium carbonate equivalent and 90 percent will pass through a 10-mesh sieve and 50 percent will pass through a 60-mesh sieve.

Selma chalk should have a neutralizing value of not less than 80-percent calcium carbonate equivalent and 90 percent will pass through a 10-mesh sieve.

Other liming materials that may be selected should be provided in amounts that provide equal value to the criteria listed for agricultural lime or be used in combination with agricultural limestone or Selma chalk to provide equivalent values to agricultural limestone.

Plant Nutrients

Commercial grade fertilizers that comply with current Mississippi Fertilizer Laws should be used to supply nutrients required to establish vegetation.

Rates of Soil Amendments

Lime and fertilizer needs should be determined by soil tests. Soil testing is performed by the Mississippi State University Extension Service Soil Testing Laboratory and provides recommendations based on field tests on Mississippi soils. The local county Cooperative Extension Service can provide information on obtaining soil tests. Commercial laboratories that make recommendations based on soil analysis may be used.

When soil tests are not available, use the following rates for application of soil amendments.

Lime (Agricultural Limestone or Equivalent – see Liming Materials)

Sandy soils: Use 1 ton/acre (exception on sandy soils – if the cover will be tall fescue and clover use 2 tons/acre).

Clayey soils: 2 tons/acre.
(Do not apply lime to alkaline soils).

Fertilizer

Grasses alone: Use 400 lbs/acre of 8-24-24 or the equivalent. Apply 30 lbs of additional nitrogen when grass has emerged and begun growth (approximately 0.8lbs/1000 ft²).

Grass-legume mixtures: Use 800 to 1200 lbs/acre of 5-10-10 or the equivalent.

Legumes Alone: Use 800 to 1200 lbs/acre of 0-10-10 or the equivalent.

Note: Fertilizer can be blended to meet exact fertilizer recommendations. Take soil test recommendations to local fertilizer dealer for bulk fertilizer blends. This may be more economical than bagged fertilizer.

Application of Soil Amendments

Apply lime and fertilizer evenly and incorporate into the top 6" of soil by disking, chiseling, or other suitable means during seedbed preparation. Operate machinery on the contour.

Seedbed Preparation

Install necessary sediment-control practices before seedbed preparation and complete grading according to the approved plan.

Grade and loosen the soil to a smooth, firm surface to enhance rooting of seedlings and reducing rill erosion. Break up large clods and loosen compacted, hard, or crusted-soil surfaces with a disk, ripper, chisel, harrow or other tillage equipment. Avoid preparing the seedbed under excessively wet conditions. Operate the equipment on the contour.

For broadcast seeding and drilling, tillage, as a minimum, should adequately loosen the soil to a depth of at least 6", alleviate compaction, and smooth and firm the soil for the proper placement of seed.

For no-till drilling, the soil surface does not need to be loosened unless the site has surface compaction.

Incorporate lime and fertilizer to a depth of at least 6" with a disk or rotary tiller on slopes of up to 3:1. On steeper slopes, lime and fertilizer may be applied to the surface without incorporation. Lime and fertilizer may be applied through hydroseeding equipment; however, fertilizer should not be added to the seed mixture during hydroseeding. Lime may be added with the seed mixture.

Planting Methods

Seeding

Use certified seed for permanent seeding whenever possible. Certified seed is inspected by the Mississippi Crop Improvement Association to meet high quality standards and will be tagged with a "Certified Seed" tag. (Note: all seed sold in Mississippi is required by law to be tagged to identify seed purity, germination, and presence of weed seeds. Seed must meet state standards for content of noxious weeds.)

Seeding dates are determined using Figure PS-1 and Table PS-1.

Inoculate legume seed with the *Rhizobium* bacteria appropriate to the species of legume. Details of legume inoculation are located in Chapter 2 in the part on *Vegetation for Erosion and Sediment Control* under Inoculation of Legumes.

Seed should be uniformly planted with a cyclone seeder, a drill seeder, a cultipacker seeder, or by hand on a fresh, firm, friable seedbed. If the seedbed has been sealed by rainfall, it should be disked so the seed will be sown into a freshly prepared seedbed.

When using broadcast-seeding methods, subdivide the area into workable sections and determine the amount of seed needed for each section. Apply one-half the seed while moving back and forth across the area, making a uniform pattern; then apply the second half in the same way, but moving at right angles to the first pass.

Cover broadcast seed by raking or chain dragging; then firm the surface with a roller or cultipacker to provide good seed contact. Small grains should be planted no more than 1" deep and grasses and legume seed no more than ½" deep.

Hydroseeding

Surface roughening is particularly important when hydroseeding, as a roughened slope will provide some natural coverage for lime, fertilizer, and seed. The surface should not be compacted or smooth. Fine seedbed preparation is not necessary for hydroseeding operations; large clods, stones, and irregularities provide cavities in which seeds can lodge.

Mix seed, inoculant if required, and a seed carrier with water and apply as a slurry uniformly over the area to be treated. The seed carrier should be a cellulose fiber, natural wood fiber or other approved fiber mulch material which is dyed an appropriate color to

facilitate uniform application of seed. Use the correct legume inoculant at 4 times the recommended rate when adding inoculant to a hydroseeder slurry. The mixture should be applied within one hour after mixing to reduce damage to seed.

Fertilizer should not be mixed with the seed-inoculant mixture because fertilizer salts may damage seed and reduce germination and seedling vigor.

Fertilizer may be applied with a hydroseeder as a separate operation after seedlings are established.

Agricultural lime is usually applied as a separate operation and spread in dry form. It is not normally applied with a hydraulic seeder because it is abrasive and, also, may clog the system. On the other hand, liquid lime is applied with a hydraulic seeder but because of cost is used primarily to provide quick action for benefit of plants during their seedling stage with the bulk of liming needs to be provided by agricultural lime. Dry lime may be applied with the fertilizer mixture.

Sprigging

Hybrid Bermuda grass cannot be grown from seed and must be planted vegetatively. Vegetative methods of establishing common and hybrid Bermuda grass, centipede grass and zoysia include sodding, plugging and sprigging (see *Sodding Practice*).

When sprigs are planted with a sprigging machine, furrows should be 4-6" deep and 2 feet apart. Place sprigs no farther than 2 feet apart in the row and so that at least one rooting node is in the furrow.

Broadcasting of sprigs is not recommended as the practice requires additional vegetative material and is an unreliable method of planting. Hand planting of sprigs is recommended instead with furrows 4-6" deep and 2 feet apart. Place sprigs no farther than 2 feet apart in the row and so that at least one rooting node is in the furrow.

Mulching

The use of mulch provides instant cover and helps ensure establishment of vegetation under normal conditions and is essential to seeding success under harsh site conditions (see *Mulching Practice*). Harsh site conditions include slopes steeper than 3:1 and adverse soils (shallow, rocky, or high in clay or sand). Areas with concentrated flow should be treated differently and require sod, a hydromulch formulated for channels or an appropriate erosion control blanket.

Irrigation

Moisture is essential for seed germination and vegetation establishment. Supplemental irrigation can be very helpful in assuring adequate stands in dry seasons or to speed development of full cover. It is a requirement for establishment of vegetation from sod and sprigs and should be used elsewhere when feasible. However, irrigation is rarely critical for low-maintenance vegetation planted at the appropriate time of the year.

Water application rates must be carefully controlled to prevent runoff. Inadequate or excessive amounts of water can be more harmful than no supplemental water.

Installation Verification

Check materials and installation for compliance with specifications during installation of products.

Common Problems

Consult with a qualified design professional if the following occurs:

Design specifications for seed variety, seeding dates or mulching cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Seeding at the wrong time of the year results in an inadequate stand. Reseed according to specifications of a qualified design professional (see recommendations under *Maintenance*)

Inadequate mulching results in an inadequate stand, bare spots or eroded areas—prepare seedbed, reseed, cover seed evenly and tack or tie down mulch, especially on slopes, ridges and in channels (see recommendations under *Maintenance*).

Maintenance

Generally, a stand of vegetation cannot be determined to be fully established until vegetative cover has been maintained for 1 year from planting.

Reseeding

Inspect seedlings monthly for stand survival and vigor. Also, inspect the site for erosion.

If stand is inadequate identify the cause of failure (choice of plant materials, lime and fertilizer quantities, poor seedbed preparation or weather) and take corrective action. If vegetation fails to grow, have the soil tested to determine whether pH is in the correct range or nutrient deficiency is a problem.

Stand conditions, particularly the coverage, will determine the extent of remedial actions such as seedbed preparation and reseeded. A qualified design professional should be consulted to advise on remedial actions. Consider drill seeding where possible.

Eroded areas should be addressed appropriately by filling and/or smoothing, and reapplication of lime, fertilizer, seed and mulch.

Fertilizing

Satisfactory establishment may require refertilizing the stand in the second growing season. Follow soil test recommendations or the specifications provided to establish and maintain the planting.

Mowing

Mow vegetation on structural practices such as embankments and grass-lined channels to prevent woody plants from invading.

Other areas should be mowed to compliment the use of the site.

Certain species can be weakened by mowing regimes that significantly reduce their food reserves stored for the next growing season: fescue should not be mowed close during the summer; sericea should not be mowed close in late summer.

Bermuda grass is tolerant of most mowing regimes and can be mowed often and close, if so desired, during its growing season.

References

Volume 1

Chapter 2

Vegetation for Erosion and Sediment Control 2-10

Chapter 4

Land Grading (LG) 4-16

Topsoiling (TSG) 4-20

Mulching (MU) 4-48

Temporary Seeding (TS) 4-103

Appendices Volume

Appendix G

MDOT Vegetation Schedule G-1

Preservation of Vegetation (PV)



Practice Description

Preservation of vegetation is the avoidance of an area during land disturbing and construction activities to prevent mechanical and other injury to desirable plants in the planned landscape. The practice provides erosion and sediment control and is applicable where vegetative cover is desired and the existing plant community is compatible with the planned landscape.

Planning Considerations

Preservation of vegetation requires good site management to minimize the impact of construction activities on existing vegetation.

Plants to save should be identified prior to any construction activity.

Proper maintenance, especially during construction, is important to ensure healthy vegetation that can control erosion.

Different species, soil types, and climatic conditions will require different maintenance activities.

Design Criteria and Installation

Preservation requirements should be designed by a qualified design professional and plans should be made available to field personnel prior to start of construction

Mark Plant Area for Retention

Groups of plants and individual trees to be retained should be located on a plan map.



Limits of clearing should be planned outside the drip line of groups or individual trees to be saved. The clearing should never be closer than 5 feet to the trunk of a tree.

Flagging or other appropriate means of marking the site of the groups of plants and individual trees to be retained should be required before construction begins. Individual trees to be retained should be marked with a highly visible paint or surveyor's ribbon in a band circling the tree at a height visible to equipment operators.

Plant Protection

Restrict construction equipment, vehicular traffic, stockpiles of construction materials, topsoil etc., from the areas where plants are retained and restrict these activities from occurring within the drip line of any tree to be retained. Trees being removed shall not be pushed into trees to be retained. Equipment operators shall not clean any of their equipment by slamming it against trees to be retained.

Restrict burning of debris within 100 feet of the plants being preserved. Fires shall be limited in size to prevent damage to any nearby trees.

Toxic material shall not be stored any closer than 100 feet to the drip line of any trees to be retained. Toxic materials shall be managed and disposed of according to state laws.

Fencing and Armoring

Groups of plants and trees should be protected by fencing or armoring where necessary (See Figure PV-1). The following types of fencing or armoring may be used:

- Board Fence; a board fence may be constructed with 4" square posts set securely in the ground and protruding at least 4 feet above the ground. A minimum of 2 horizontal boards should be placed between the posts. The fence should be placed at the limits of the clearing around the drip line of the tree. If it is not practical to erect a fence at the drip line, construct a triangular fence near the trunk. The limits of clearing will still be the drip line as the root zone within the drip line will still require protection.
- Cord Fence; Posts at least 2" square or 2" in diameter set securely in the ground and protruding at least 4 feet above the ground; posts should be placed at the limits of clearing with 2 rows of cord 1/4" or thicker at least 2 feet apart running between posts with strips of surveyor's tape tied securely to the string at intervals of 3 feet or less.

- Earth Berms; Temporary earth berms may be constructed. The base of the berm on the tree side should be located along the limits of clearing. Earth berms may not be used for this purpose if their presence will create drainage patterns that cause erosion.
- Additional Trees; Additional trees may be left standing as protection between the trees to be retained and the limits of clearing. However, in order for this alternative to be used, trees in the buffer must be no more than 6 feet apart to prevent passage of equipment and material through the buffer.
- Plan for these additional trees to be evaluated prior to the completion of construction and either given sufficient treatment to ensure survival or be removed.
- Trunk Armoring; As a last resort, a tree may be armored with burlap wrapping and 2" studs wired vertically no more than 2" apart to a height of 5 feet. The armoring should encircle the tree trunk. Nothing should ever be nailed to a tree. The root zone within the drip line will still require protection.
- Fencing and armoring devices should be in place before any construction work is done and should be kept in good condition for the duration of construction activities. Fencing and armoring should not be removed until the completion of the construction project.




Figure PV- 1 Fencing and Armoring

Raising the Grade

When the ground level must be raised around an existing tree or group of trees, several methods may be used to insure survival.

A well may be created around a group of trees or an individual tree slightly beyond the drip line to retain the natural soil in the area of the feeder roots (see Figure PV-2).

When the well alternative is not practical or desirable, remove vegetation and organic matter from beneath the tree or trees for a distance of 3 feet beyond the drip line and loosen the surface soil to a depth of approximately 3" without damaging the roots.

Apply fertilizer in the root area of the tree to be retained. A soil test is the best way to determine what type of fertilizer to use. In the absence of a soil test, fertilizer should be applied at the rate of 1 to 2 pounds of 10-8-6 or 10-6-4 per inch of diameter at breast height (dbh) for trees under 6" dbh and at the rate of 2 to 4 pounds of 10-8-6 or 10-6-4 per inch of dbh for trees over 6" dbh.

A dry well shall be constructed so as to allow for tree trunk diameter growth (see Figure PV-3). A space of at least 1 foot between the tree trunk and the well wall is adequate for old, slow growing trees. Clearance for younger trees shall be at least 2 feet. The well shall be high enough to bring the top just above the level of the proposed fill. The well wall shall taper slightly away from the tree trunk at a rate of 1" per foot of wall height.

The well wall shall be constructed of large stones, brick, building tile, concrete blocks, or cinder blocks. Openings should be left through the wall of the well to allow for free movement of air and water. Mortar shall only be used near the top of the well and only above the porous fill.

Drain lines composed of 4" high quality drain tiles shall begin at the lowest point inside the well and extend outward from the tree trunk in a wheel and spoke pattern with the trunk as the hub. Radial drain lines shall slope away from the well at a rate of $\frac{1}{8}$ " per foot. The circumference line of tiles should be located beneath the drip line of the trees. Vertical tiles or pipes shall be placed over the intersections of the two tile systems if a fill of more than 2 feet is contemplated. Vertical tiles shall be held in place with stone fill. Tile joints shall be tight. A few radial tiles shall extend beyond each intersection and shall slope sharply downward to insure good drainage. Tar paper or its approved equivalent shall be placed over the tile and/or pipe joints to prevent clogging and large stone shall be placed around and over drain tiles and/or pipes for protection.

A layer of 2" to 6" stone shall be placed over the entire area under the tree from the well outward at least as far as the drip line. For fills up to 2 feet deep, a layer of stone 8" to 12" thick should be adequate.

A thick layer of this stone not to exceed 30" will be needed for deeper fills. A layer of $\frac{3}{4}$ " to 1" stone covered by straw, fiberglass mat, or a manufactured filter fabric shall be used to prevent soil from clogging the space between stones. Cinders shall not be used as fill material. Filling shall be completed with porous soil such as topsoil until the desired grade is reached. This soil shall be suitable to sustain specified vegetation.




Figure PV- 2 Tree Well

Crushed stone shall be placed inside the dry well over the openings of the radial tiles to prevent clogging. The area between the trunk and the well wall shall either be covered by an iron grate or filled with a 50-50 mixture of crushed charcoal and sand to prevent anyone from falling into the dry well.

Where water drainage through the soil is not a problem, coarse gravel in the fill may be substituted for the tile. This material has sufficient porosity to ensure air drainage. Instead of the vertical tiles or pipes in the system, stones, crushed rock and gravel may be added so that the upper level of these porous materials slants toward the surface in the vicinity below the drip line.

Raising the grade on only one side of a tree or group of trees may be accomplished by constructing only half of one of these systems.

Lowering the Grade

Shrubs and trees shall be protected from the harmful grade cuts by the construction of a tree wall (see Figure PV-4). Following excavation, all tree roots that are exposed and/or damaged shall be trimmed cleanly and covered with moist peat moss, burlap or other suitable material to keep them from drying out.

The wall shall be constructed of large stones, brick, building tile, concrete block or cinder block. The wall should be backfilled with topsoil, peat moss, or other organic matter to retain moisture and aid in root development. Apply fertilizer and water thoroughly. The tree plants should be pruned to reduce the leaf surface in proportion to the amount of root loss. Drainage should be provided through the wall so water will not accumulate behind

the wall. Lowering the grade on one side of the tree or group of trees can be accomplished by constructing only half of this system.




Figure PV- 3 Tree Well Detail




Figure PV- 4 Tree Wall Detail

Trenching and Tunneling

Trenching should be done as far away from the trunks of trees as possible, preferably outside the branches or crown spreads of trees, to reduce the amount of root area damaged or killed by trenching activities. When possible trenches should avoid large roots or root concentrations. This can be accomplished by curving the trench or by tunneling under large roots and areas of heavy root concentration. Tunneling under a species that does not have a large tap root may be preferable to trenching beside it as it has less impact on root systems (see Figure PV-5).

Roots should not be left exposed to the air but should be covered with soil as soon as possible or protected and kept moist with burlap or peat moss until the trench or tunnel can be filled. The ends of damaged and cut roots shall be cut off smoothly and moist peat moss, burlap or topsoil should be placed over the exposed area.

Trenches and tunnels shall be filled as soon as possible. Care should be taken to ensure that air spaces are not left in the soil. Peat moss or other organic matter shall be added to the fill material as an aid to inducing and developing root growth. The tree should be fertilized and mulched to stimulate new root growth and enhance general tree vigor. If a large part of the root system has been damaged the crown leaf surface area should be reduced in proportion to the root damage. This may be accomplished by pruning 20-30 percent of the crown foliage. If the roots are damaged during the winter the crown should be pruned before the next growing season. If roots are cut during the growing season, pruning should be done immediately.




Figure PV- 5 Trenching vs. Tunneling

Treating Damaged Trees

When trees are damaged during construction activities certain maintenance practices can be applied to protect the health of the tree.

Soil aeration may be needed if the soil has been compacted. The soil around trees can be aerated by punching holes 1 foot deep and 18" apart under the crown of trees with an iron pipe.

Damaged roots should be cut off cleanly and moist peat moss, burlap or topsoil should be placed over the exposed area. Bark damage should be treated by removing loose bark.

Tree limbs damaged during construction or removed for any other reason shall be cut off above the collar at the branch junction.

Trees that have been stressed or damaged should be fertilized to aid their recovery.

Trees should be fertilized in the spring or fall. Fall applications are preferred.

Fertilizer should be applied to the soil over the feeder roots. In no case should it be applied closer than 3 feet to the trunk. Root systems of trees extend some distance beyond the drip line. The area to be fertilized should be increased by $\frac{1}{4}$ the area of the crown. A soil test is the best way to determine what type of fertilizer to use. In the absence of a soil test, fertilizer should be applied at the rate of 1 to 2 pounds of 10-8-6 or 10-6-4 per inch of dbh for trees under 6" dbh and at the rate of 2 to 4 pounds of 10-8-6 or 10-6-4 per inch of dbh for trees over 6" dbh.

A ground cover or organic mulch layer should be maintained around trees to prevent erosion, protect roots and to conserve water.

Verification of Practice

Check to determine that specifications are met as the areas are identified for retention, as the plants are protected during construction and that damaged plants are treated or replaced.

Common Problems

Consult with a qualified design professional if any of the following occur:

Soil compaction appears to be retarding plant growth or affecting plant health.

Damage to plants appears to be severe and life threatening.

Plants appear to be of poor quality and are undesirable for retention.

Problems during construction that require remedial actions:

Erosion – eroded areas should be vegetated to grass or a suitable ground cover.

Severely damaged trees, shrubs or vines should be replaced.

Maintenance

Enhance and maintain plant growth and health according to the maintenance plan. This may involve applying fertilizer, spreading mulch and pruning trees and shrubs.

Replace dead plants as needed to maintain desired landscape cover. Additional information about plantings is found in practices *Permanent Seeding, Shrub, Vine and Groundcover Planting, and Tree Planting on Disturbed Areas*.

References

BMPs from Volume 1

Chapter 4

Land Grading (LG)	4-16
Permanent Seeding (PS)	4-53
Shrub, Vine, and Groundcover Planting (SVG)	4-80
Tree Planting on Disturbed Areas (TP)	4-110

Retaining Wall (RW)



Practice Description

A retaining wall is a constructed wall used to eliminate steep slopes between areas that have abrupt changes in grade. This practice is used to replace cut or fill slopes in confined areas or where a wall is necessary to achieve stable slopes. A retaining wall can be constructed of reinforced concrete, treated timbers, gabions, reinforced earth (a system of face panels and buried reinforcement strips), and other manufactured products such as interlocking concrete blocks.

Planning Considerations

Retaining walls should be used in conjunction with steep cut or fill slopes, that may be unstable due to steepness, space limitations, or poor soil conditions to stabilize the site. Retaining walls may be used to relieve the need to construct cuts into steep hillsides or on small lots where fill toe-outs or slope cut-outs would go off of the property being developed. Retaining walls may be required to achieve the best or intended use of the property.

Retaining walls can be constructed from the following materials:

- Reinforced concrete
- Concrete cribbing
- Geotextile-wrapped face wall
- Geotextile-reinforced steep slopes
- Modular blocks
- Treated timbers

Each case is different and the type of retaining wall to be used should be selected by a qualified design professional based on the particular site conditions and what best meets the needs of the site. In most cases, treated timber is the least desirable material because of its potential to decay.



Figure 1: Retaining wall made of gabions

Design Criteria and Construction

The design of a retaining wall is or can be a complicated engineering procedure. There are many factors to consider. Each case is different and requires a different set of considerations and a different design.

The qualified design professional should consider the stresses and forces outside and within the wall as well as allowable height and minimum thickness. Other considerations are foundation design with respect to loadings, bearing values of soils and footing dimensions. Additional design factors include safety hazards, drainage aspects and appearance.

Each retaining wall requires a specific engineering design which requires the capabilities of a competent qualified design professional. Retaining walls are engineering structures that affect public property, life and welfare of citizens. Mississippi law which regulates the practice of professional engineering in the State of Mississippi must be followed on structures such as retaining walls. The State Board of Registration for Professional Engineers and Land Surveyors in Jackson is responsible for administering the provisions of the law.

Site Preparation

At least 3 days prior to construction, contact the Mississippi One-Call System, Inc (1-800-227-6477) to identify, locate and mark all underground utilities within the project area. See **Appendix C** for more information about Mississippi One-Call and utility markings.

Clear installation area of debris and obstacles, such as tree and stumps, that might hinder grading and installation of the wall.

Grading

Grade existing embankments according to the design plan to provide a stable slope until construction of the retaining wall is complete.

Grade the top of the embankments according to the design plan to direct stormwater runoff around the area where retaining walls are being constructed.

Installation of Wall

Concrete Wall Installation

The placement of reinforcing steel, the construction of forms, concrete batching, mixing, placement, curing, and finishing should be in accordance with the project specifications and the American Concrete Institute (ACI) standards. The concrete mix quantities, air entrainment, slump, temperature, and compressive strength should be in accordance with the plans for the job.



Compressive strength of the concrete should be verified by laboratory tests on representative cylinders made during concrete placement.

Drains and weep holes should be installed as shown on the design plans.

Modular Block Wall Installation

Prepare a leveling pad of compacted, crushed rock (typically 6" thick and 18" wide). Place the first row of modular blocks on the leveling pad (not a footing, as the geosynthetic reinforcement will bear the weight of the block and the backfill). Install additional modular blocks and geosynthetic reinforcement (geogrid or geotextile) according to design plans.

Timber Wall Installation

Timbers should be new pressure-treated (usually 0.6 pcf for ground contact) members having a design life consistent with that of the project and free of splits and deep cracks.

Proper tiebacks are essential to the stability of timber retaining



walls. Install tiebacks according to design plans.

Manufactured Products Installation

Specifications for manufactured products should be provided by the manufacturer or in the design plan. Inspect all such materials for damage prior to installation.

Drain Installation

Install drains as specified in the design plans.

Backfill Installation

Backfill for all wall types should be placed carefully in layers not exceeding 8" (loose) and compacted with hand-operated tampers. The degree of compaction should be provided as specified in the design plans. Before compacting, the soil should be moistened or dried as necessary to obtain the optimum moisture content specified. Backfill should not be placed on surfaces that are muddy, frozen or contain frost or ice.

Backfill for retaining walls built of manufactured products such as reinforced earth or interlocking concrete blocks should be placed according to manufacturer's recommendations. Tiebacks or geosynthetic reinforcements should be placed as specified in the design plans.

Nonwoven geotextile fabric should be used behind timber or modular block walls to help keep soil in place.

Erosion Control

Stabilize all bare areas according to the vegetation plan.

Safety

Steep slopes are subject to collapse and can be a safety hazard to persons in the area. No person should work adjacent to steep slopes without shoring protection or properly sloping the embankment.

Construction Verification

Check finished retaining wall for conformance with design plans and specifications.

Check for cracks or movement of the retaining wall.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate retaining wall will not function as intended.

Seepage is encountered during construction. It may be necessary to install drains.

Poor foundation soils are encountered under the proposed wall location.

Design specifications for concrete, timbers, backfill or other materials cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

High soil and water pressures result in structural failure of the wall—consult qualified design professional and rebuild according to revised plan and specifications.

Maintenance

Inspect retaining walls periodically and after heavy rains for cracks, undercutting of the foundation, piping erosion, wetness or movement.

Repair problems determined during inspections. Repair cracks according to manufacturer's recommendations.

References

The following references may be useful in the application/installation of this practice.

BMPs from Volume 1

Chapter 4

Permanent Seeding (PS)

4-53

Appendices Volume

Appendix C

Mississippi One-Call & 811 Color Coding

C-1

Shrub, Vine, and Groundcover Planting (SVG)



Practice Description

Shrub, vine and groundcover planting is the practice of establishing shrubs, vines or groundcover to stabilize soil in areas where establishing grass is difficult and mowing is not feasible. The practice is especially suited for steep slopes where aesthetics are important. Incidental benefits include providing food and shelter for wildlife, windbreaks or screens and improved aesthetics.

Planning Considerations

Shrubs, vines and groundcovers provide alternatives to grasses and legumes as low-maintenance, long-term erosion control. However, they are normally planted only for special, high-value applications, or for aesthetic reasons, because there is additional cost and labor associated with their use.

Very few of these plants can be dependably planted from seed, and none are capable of providing the rapid cover possible with grasses. Consequently, short-term stabilization efforts must involve using dependable mulch along with special cultural practices to ensure establishment.

Shrubs vary in form and differ from most trees in that multiple stems arise from a common base.

Shrubs can be used to attain additional benefits including the following:

- Increase the aesthetic value of plantings
- Provide visual screening and protective barriers
- Enhance windbreaks
- Provide food and cover for wildlife
- Accelerate the transition to a diverse landscape
- Provide post-construction landscaping

Groundcovers differ in growth rate and shade tolerance. Some are suitable only as part of a high-maintenance landscape; others can be used to stabilize large areas with little maintenance.

Competition from volunteer plants inhibits development and maintenance of the groundcover. Thick durable mulch such as shredded bark (not chips) or pine straw can prevent erosion and reduce weed competition.

Mulch is beneficial to plants at most stages of development but is particularly important for new plantings.




Figure SVG-1 Sample Planting Design Plan

Design Criteria

Plant Selection

Specific characteristics and requirements of recommended species are given in Tables SVG-1 through SVG-5 *Plants Suitable for Shrub, Vine and Groundcover Planting* in Mississippi. Other suitable plants may be identified by qualified design professionals based on plant suitability information including plant adaptation zones (see Figure SVG-2). Exotic invasive species should not be planted!

Site Preparation

Remove debris and other undesirable objects and smooth the area to accommodate the planting and mulching. Sites should be prepared in strips along the contour or at individual spots. Additional preparation will vary according to the type of plant and is discussed later under *Planting*.

On steep slopes, till the soil in contour rows or dig single holes for each plant. Blend the needed lime, fertilizer, and organic material with the soil removed from each hole or furrow. Mix fertilizer thoroughly with the soil before planting, and use it sparingly to avoid burning roots. To eliminate harmful competition from weeds, an appropriate preemergent herbicide may be useful if weeding is not practical.

Soil Amendments

Fertilizer and lime requirements are plant specific and the prescription for a planting should be based on a soil test or a plan prepared by a qualified design professional.

Soils low in organic matter may be improved by incorporating peat, compost, aged sawdust or well-rotted manure.

To eliminate competition from weeds, an appropriate preemergent herbicide may be useful if mechanical weeding is not practical or desired.




Figure SVG-2 Plant Adaption Zones

Table SVG-1 Plants Suitable for Groundcover Planting in Mississippi

Botanical Name and Common Name	Size	Foliage	Exposure	Native/ Introduced
Bugleweed <i>Ajuga reptans</i>	3"-6"	Deciduous	Shade	Introduced
Cast iron plant <i>Aspidistra elatior</i>	30"-36"	Evergreen	Shade	Introduced
Holly fern <i>Cyrtomium falcatum</i>	24"-30"	Evergreen	Shade	Introduced
English ivy <i>Hedera helix</i>	30-40 ft.	Evergreen	Shade	Introduced (May be Invasive)
Liriope a.k.a. Lillyturf <i>Liriope muscari</i>	12"-18"	Evergreen	Sun/Shade	Introduced
Moneywort <i>Lysimachia nummularia</i>	3"-18"	Deciduous	Sun/Part Sun	Introduced
Monkey grass <i>Ophiopogon japonicus</i>	6"-8"	Evergreen	Sun/Shade	Introduced
Stonecrop <i>Sedum acre</i>	4"-12"	Evergreen	Sun	Introduced
Asian jasmine <i>Trachelospermum asiaticum</i>	12"-10'	Evergreen	Sun/Shade	Introduced
Periwinkle <i>Vinca major</i>	12"-3'	Evergreen	Part Shade	Introduced (May be Invasive)
Littleleaf periwinkle <i>Vinca minor</i>	10"-3'	Evergreen	Part Shade	Introduced (May be Invasive)
Daylily <i>Hemerocallis spp.</i>	30"-36"	Evergreen/ Deciduous	Sun	Introduced
Wild ginger <i>Asarum canadense</i>	4"-6"	Evergreen	Shade	Native
Confederate jasmine <i>Trachelospermum jasminoides</i>	12"-10'	Evergreen	Sun	Introduced
Ardisia <i>Ardisia crenata</i>	24"-24"	Evergreen	Shade	Introduced
Japanese ardisia <i>Ardisia japonica</i>	10"-10"	Evergreen	Shade	Introduced
Butterfly iris <i>Bietes vegeta</i>	24"-24"	Herbaceous	Sun	Introduced
Louisiana iris <i>Iris spp.</i>	36"-36"	Evergreen	Sun	Introduced
Indigo <i>Indigofera kirilowii</i>	24"-24"	Deciduous	Part Shade	Introduced

Table SVG-2 Plants Suitable for Vine Planting in Mississippi

Botanical Name and Common Name	Size	Foliage	Exposure	Support Needed	Native / Introduced
Coral vine <i>Antigonon leptopus</i>	Grows to 40'	Deciduous	Sun/Part sun	Yes	Introduced
Crossvine <i>Bignonia capreolata</i>	Grows to 60'	Evergreen	Sun/Shade	No	Native
Trumpet creeper <i>Campsis radicans</i>	Grows to 30'	Deciduous	Sun/part sun	No	Native
Autumn clematis <i>Clematis paniculata</i>	Grows to 30'	Deciduous	Sun	Yes	Introduced
Yellow jessamine <i>Gelsemium sempervirens</i>	Grows to 25'	Evergreen	Sun/Part sun	Yes	Native
Climbing hydrangea <i>Hydrangea petiolaris</i>	Grows to 50'	Deciduous	Sun/Part Shade	No	Native
Coral honeysuckle <i>Lonicera sempervirens</i>	Grows to 20'	Evergreen	Sun/ Part shade	Yes	Native
Lady banks' rose <i>Rosa banksiae</i>	Grows to 20'	Evergreen	Sun	Yes	Introduced
Confederate jasmine <i>Trachelospermum jasminoides</i>	Grows to 25'	Evergreen	Sun/Part sun	Yes	Introduced
Virginia creeper <i>Parthenocissus quinquefolia</i>	Grows to 40'	Deciduous	Sun/Shade	No	Native
Muscadine grape <i>Vitis rotundifolia</i>	Grows to 30'	Deciduous	Sun/Part sun	Yes	Native
American wisteria <i>Wisteria frutescens</i>	Grows to 30'	Deciduous	Sun/Part sun	Yes	Native (very aggressive)
Dutchman's pipe <i>Aristolochia macrophylla</i>	Grows to 30'	Deciduous	Shade	Yes	Native
Passion flower <i>Passiflora incarnate</i>	Grows to 20'	Deciduous	Sun/Part sun	Yes	Native

Table SVG-3 Plants Suitable for Small Shrub Planting in Mississippi

Botanical Name and Common Name	Normal Height	Foliage	Exposure
<i>Callicarpa Americana</i> American Beautyberry	4-6 ft.	Deciduous	Part Shade
<i>Calycanthus floridus</i> Sweetshrub	6-10 ft.	Deciduous	Full Sun to Shade
<i>Clethra alnifolia</i> Summersweet	2-4 ft.	Deciduous	Full Sun to Part Sun
<i>Fothergilla major</i> Witch Alder	6-10 ft.	Deciduous	Full Sun to Part Sun
<i>Gaylussacia dumosa</i> Dwarf Huckleberry	4-6 ft.	Deciduous	Full Sun to Part Sun
<i>Hydrangea quercifolia</i> Oakleaf Hydrangea	6 ft.	Deciduous	Part Sun to Shade
<i>Illicium floridanum</i> Star Anise	8 ft.	Evergreen	Shade to Part Sun
<i>Itea Virginica</i> Virginia Sweetspire	3-6 ft.	Deciduous	Full Sun to Part Sun
<i>Leucothoe axillaris</i> Leucothoe	3 ft.	Evergreen	Full Sun to Part Sun
<i>Lyonia lucida</i> Lyonia	3 ft.	Evergreen	Part Sun to Shade
<i>Sabal minor</i> Dwarf Palmetto	6 ft.	Evergreen	Full Sun to Part Sun
<i>Viburnum dentatum</i> Arrow-wood Virburnum	5-9 ft.	Deciduous	Full Sun to Part Sun

Table SVG-4 Plants Suitable for Medium Shrub Planting in Mississippi

Botanical Name and Common Name	Normal Height	Foliage	Exposure
<i>Aesculus pavia</i> Red Buckeye	10 ft.	Deciduous	Full Sun to Part Shade
<i>Baccharis halimifolia</i> Groundsel Bush	12 ft.	Evergreen	Part Shade
<i>Cephalanthus occidentalis</i> Buttonbush	10 ft.	Deciduous	Full Sun to Part Sun (needs a lot of water)
<i>Ilex verticillata</i> Winterberry Holly	6-10 ft.	Deciduous	Full Sun to Part Sun
<i>Rhododendron austrinum</i> Yellow Native Azalea	12 ft.	Deciduous	Part Sun to Shade
<i>Rhododendron canescens</i> Honeysuckle Azalea	12 ft.	Deciduous	Part Sun to Shade
<i>Styrax americana</i> Snowbell	10 ft.	Deciduous	Full Sun to Part Sun
<i>Vaccinium elliotii</i> Elliott's Blueberry	12 ft.	Deciduous	Full Sun to Part Sun

Table SVG-5 Plants Suitable for Large Shrub Planting in Mississippi

Botanical Name and Common Name	Normal Height	Foliage	Exposure
<i>Alnus serrulata</i> Tag Alder	15 ft.	Deciduous	Sun to shade
<i>Chionanthus virginicus</i> Fringe Tree	20 ft.	Deciduous	Full Sun to Part Sun
<i>Cliftonia monophylla</i> Buckwheat Tree	6-12 ft.	Evergreen	Full Sun to Part Sun
<i>Hamamelis virginiana</i> Witch Hazel	8-20 ft.	Deciduous	Full Sun to Shade
<i>Ilex coriacea</i> Bigleaf Gallberry Holly	15 ft.	Evergreen	Full Sun to Part Sun
<i>Kalmia latifolia</i> Mountain Laurel	5-10 ft.	Evergreen	Full Sun to Part Sun
<i>Osmanthus americanus</i> American Sweet Olive	20 ft.	Evergreen	Full Sun to Part Sun
<i>Rhododendron serrulatum</i> Summer Azalea	15 ft.	Deciduous	Part Sun to Shade
<i>Rhus typhina</i> Staghorn Sumac	20 ft.	Deciduous	Full Sun to Part Sun
<i>Vaccinium arboretum</i> Tree Huckleberry	20 ft.	Evergreen	Full Sun to Part Sun

Table SVG-6 Plants Suitable for Ornamental Grass Planting in Mississippi

Botanical Name and Common Name	Height and Spread	Exposure
Andropogon virginicus Broomsedge	2-3 ft. / 1-2 ft.	Sun to Part Sun
Carex sp. Carex	1-1.5 ft. / 1.5 ft.	Sun to Shade
Pennisetum alopecuroides Fountain Grass	3 ft. / 4 ft.	Full Sun
Miscanthus sinensis Miscanthus (maiden grass)	4-7 ft. / 4-5 ft.	Full Sun to Part Sun
Cortaderia selloana Pampass Grass (Not reliable in North MS)	12 ft. / 6 ft.	Full Sun to Light Shade
Chasmanthium latifolium River Oats	2-5 ft. / 2-3 ft.	Full Sun to Partial Shade
Phalaris arundinacea Variegated Ribbon Grass	3-4 ft. / 4 ft.	Full to Partial Sun

Planting

In the absence of a site-specific planting plan consider the following guidelines.

Shrubs

Late winter (before leaves emerge) is the best time for planting deciduous shrubs and early fall is the best for evergreens. Shrubs grown and marketed in containers can be planted anytime during the year except when the ground is frozen.

Individual Shrubs with Root Ball

Provide a relatively large area for initial root development. The hole should be dug to a depth that allows the root ball to extend 1" above the soil surface. The top diameter of the hole should be as big around as 2-3 times the diameter of the root ball. As soil is added the hole should be filled with water to moisten the soil until the filling of the hole is complete.

Shrubs in Prepared Beds

Till or spade a bed to a depth of 8" to 12". Contrary to the individual planting, soil amendments, such as peat or compost at a rate of 1 part amendment to 3 parts native soil, are beneficial to shrubs because they provide a uniform root environment across the bed area. Organic soil amendments enable plants to respond positively to water and fertilizers when they are applied. The hole for the shrub planted in a bed area should be a few inches wider in diameter than the root ball.

Plants in Containers

Remove container plants from their containers, cutting the container if necessary. If the plant is root-bound (roots circling the outside of the root ball), score the root-ball from top to bottom about 4 times, cutting about ¼ " deep with a knife, or gently massage the root ball until roots point outward. Place the shrub into the hole. Using only the native backfill, add soil back to the hole until it is ½ to ⅔ full. Water in the backfill soil around the root ball. Add soil to ground level and thoroughly water again. A small dike may be formed around the edge of the planting hole to hold water around the root ball if the plant is in sandy soils or on slopes. *Caution: in a dense clay soil, trapping additional water in the root zone can be detrimental because water drains poorly and creates an extended period of wetness.*

Bare Root Plants

Soak bare root plants in water. When planting, spread the roots in the hole and gradually add soil. Firm the soil, being careful to avoid breaking roots. Fill the hole with water, and allow it to drain. Then fill the hole with soil, and water again thoroughly.

Burlapped Plants

Cut any wire or string that is around plants stems. Do not remove the burlap. Fold the burlap back so it will be buried by soil. Burlap which is allowed to remain exposed after planting can act as a wick, causing the root ball to dry out. Follow the same procedure for filling the hole as that described for container plants.



Vine and Groundcovers

Most groundcovers are planted from container-grown nursery stock. Planting density determines how quickly full cover is achieved; a 1 foot spacing is often used for rapid cover. Large plants such as junipers can be spaced on 3 foot centers. Transplanting to the prepared seedbed can be done using a small trowel or a spade. Make a hole large enough to accommodate the roots and soil. Backfill and firm the soil around the plant, water immediately, and keep well watered until established. Water slowly and over longer periods to allow for infiltration and reduce runoff.

When to plant

Late winter (before leaves emerge) is the best time for planting deciduous shrubs and early fall is the best for evergreen shrubs. Assuming the plants are well-watered during the summer, shrubs grown in containers can be planted anytime during the year except when the ground is frozen.

Vines and groundcovers are best planted in early fall or early spring.

Mulching

Once plants are installed, add mulch. On steep slopes or highly erodible soils, install erosion control netting or matting prior to planting, and tuck plants into the soil through slits in the net. Plant in a staggered pattern (see *Mulching Practice* for more details on mulching).

Watering

Shrubs

Water shrubs immediately after planting and keep well watered for the first few weeks. Apply water weekly if rainfall does not supply 1" of water per week. Be conscious of plants that have been in the ground for less than 1 year and water them regularly and thoroughly during extended dry periods.

Vines and Groundcover

Water vines and groundcover immediately after planting and keep well watered until established. Vines and groundcover need about an inch of water a week for the first 2 years after planting.

Verification of Practice

Check all components of the practice during installation to ensure that specifications are being met.

Common Problems

Consult with a qualified design professional if any of the following occur:

Soil compaction at planting time appears so significant that it will prevent adequate plant growth. Compaction should be addressed during site preparation.

Design specifications for plants (species, variety, planting dates) and mulch cannot be met. Unapproved substitutions could lead to failure.

Problems that require remedial actions:

Erosion, washout and poor plant establishment – repair eroded surface, replant, reapply mulch and anchor.

Mulch is lost to wind or stormwater runoffs – reapply mulch and anchor.

Maintenance

Replant shrubs, vines or groundcovers where needed to maintain adequate cover for erosion control. Repair eroded surfaces by reapplying the previous treatment and determine if an additional practice is needed, i.e. installing erosion netting. Maintain shrubs, vines and ground covers with applications of fertilizer and mulching. Reapply mulch that is lost to wind, stormwater runoff or decomposition.

Shrubs, vines and groundcovers need about an inch of water a week for the first 2 years after planting. When rain does not supply this need, shrubs should be watered deeply not less than once a week.

Fertilization needs should be determined by a professional because different plants have different needs. In the absence of a recommendation from a landscape professional, a soil test is the best way to determine what nutrient elements are needed. Fertilizer formulations of 12-4-8 or 15-0-15 can be used in the absence of a soil test. Apply 2 lbs of fertilizer per 1000 ft² of area.

References

Volume 1

Chapter 2

Vegetation for Erosion and Sediment Control 2-10

Chapter 4

Land Grading (LG) 4-16

Topsoiling (TSG) 4-20

Mulching (MU) 4-48

Permanent Seeding (PS) 4-53

Temporary Seeding (TS) 4-103

Appendices Volume

Appendix G

MDOT Vegetation Schedule G-1

Sodding (SOD)



Practice Description

Sodding is the use of a transplanted vegetative cover to provide immediate erosion control in disturbed areas. Sodding is well suited for stabilizing erodible areas such as grass-lined channels, slopes around storm drain inlets and outlets, diversions, swales, and slopes and filter strips that cannot be established by seed or that need immediate cover.

Planning Considerations

Advantages of sod include immediate erosion control, nearly year-round establishment capability, less chance of failure than with seeding, and rapid stabilization of surfaces for traffic areas, channel linings, or critical areas.

Initially it is more costly to install sod than to plant seed; however, the higher cost may be justified for specific situations where sod performs better than a seeded cover. Sodding may be more cost-efficient in the long term.

Sod can be laid during the times of the year when seeded grasses may fail, provided there is adequate water available for irrigation in the early establishment period. Irrigation is essential at all times of the year to establish sod.

Sod placed around drop inlets can prevent erosion around the inlet and help maintain the necessary grade around the inlet.

The site to be sodded should be prepared for the sod before it is delivered so that the sod can be installed immediately. Leaving sod stacked or rolled can cause severe damage and loss of plant material.

Design Criteria and Installation

Prior to start of installation, design and installation guidelines should be specified by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the installation process.

Sod Selection

The species of sod selected should be adapted to both the site and the intended purpose. Species used in Mississippi include Bermuda, zoysia, centipede, St. Augustine, fescue, and Rye grass. Species selection is primarily determined by region, availability, and intended use. Use Tables SOD-1 and SOD-2 and Figure SOD-1 for guidance in selecting and maintaining sod.

Table SOD-1 Grasses Adapted for Sodding in Mississippi

Species	Variety	Applications
Warm Season Grasses		
Bermuda Grass	La Prima, Yukon	Full Sun
Centipede	No Improved Varieties	Mostly Sunny to Full Sun
Zoysia	Zenith, Compadre	Mostly Sunny to Full Sun
St. Augustine	Bitterblue, Raleigh, Common	Partial Sun, Wet Areas
Cool Season Grasses		
Fescue – Turf Type	Combat Extreme	Partial Sun
Rye Grass	OSP Ryegrass	Winter Overseed

Surface Preparation

Prior to laying sod, clear the soil surface of trash, debris, roots, branches, stones, and clods larger than 2" in diameter. Fill or level low spots in order to avoid standing water. Rake or harrow the site to achieve a smooth and mowable final grade. Apply appropriate soil amendments prior to final disking. Complete soil preparation by disking, chiseling or other appropriate means and then rolling or cultipacking to firm the soil. Limit the of heavy equipment on the area to be sodded, particularly when the soil is wet, as this may cause excessive compaction and make it difficult for the sod to penetrate the soil and develop the root system that it should attain.

Table SOD-2 Adaptation and Maintenance of Grasses Used for Sodding

Cool Season Grasses	Leaf Texture	Establish Rate	Nitrogen Use	Water Use	Drought Tolerance	Salinity Tolerance	Shade Tolerance	Fertility Needs	Wear Resistance	Mowing Height	Cold Tolerance	Acid Soil Tolerance	Thatching Tendency	Heat Tolerance
Bentgrass - Creeping	Fine	Moderate to Fast	Low to Moderate	High	Poor to Moderate	High	Poor to Moderate	High	Low	Low	Low	Medium to High	High	High
Bentgrass - Colonial	Fine	Moderate to Fast	Low	Moderate	Poor to Moderate	Moderate	Moderate	High	Low	Low	Low	Medium to High	High	High
Bluegrass - Kentucky	Moderate to Fine	Slow	Moderate to High	Moderate to High	Good	Moderate	Poor	Medium	Medium to High	Medium	High	Medium	Medium	Medium
Bluegrass - Rough	Moderate to Fine	Slow	Moderate to High	Moderate to High	Poor	Moderate	Excellent	Medium	Medium	Medium	High	Medium	Medium	Medium
Fescue - Chewings	Fine	Moderate	Moderate to Low	Moderate	Good to Excellent	Low	Excellent	Low	Low	Medium	Medium to High	Medium to High	Low to Medium	Low to Medium
Fescue - Hard	Fine	Slow to Moderate	Low to very Low	Moderate	Excellent	Low to Moderate	Excellent	Low	Low	Medium	Medium to High	Medium to High	Low to Medium	Low to Medium
Fescue - Creeping	Fine	Moderate	Low to Moderate	Moderate	Good	Low	Excellent	Low	Low	Medium	High	Medium to High	Low to Medium	Low to Medium
Fescue - Turf Type	Moderate to Coarse	Moderate	Moderate to High	Low to Moderate	Excellent	Low	Good to Excellent	Low to Medium	Medium to High	Medium to High	Medium	High	Low	High
Rye Grass - Perennial	Fine to Moderate	Very Fast	Moderate to High	Moderate to High	Good	Poor to Moderate	Poor to Moderate	Medium	Low to Medium	Low to Medium	Medium	Medium	Low	Medium to High
Warm Grasses	Leaf Texture	Establish Rate	Nitrogen Use	Water Use	Drought Tolerance	Salinity Tolerance	Shade Tolerance	Fertility Needs	Wear Resistance	Mowing Height	Cold Tolerance	Acid Soil Tolerance	Thatching Tendency	Heat Tolerance
Bahiagrass	Coarse to very Coarse	Slow to Moderate	Low	Low	Excellent	Excellent	Moderate to Good	Low	Medium to High	High	Low	Low	Medium to High	High
Bermudagrass	Fine to Moderate	Moderate to Fast	Moderate	Moderate to High	Excellent	Very Good	Poor	Medium	High	Low to Medium	Low to Medium	Medium	Medium	High
Blue Grama	Fine to Moderate	Slow to Moderate	Low	Low	Excellent	Moderate	Very Poor	Low	Low	High	High	Low	Low	High
Buffalograss	Moderate to Coarse	Slow to Moderate	Low	Low	Excellent	Moderate	Very Poor	Low	Low	High	High	Low	Low	High
St. Augustine Grass	Coarse	Moderate to Fast	Low	High	Low	Low	Excellent	Low	Medium to High	Low	Medium to High	Medium to High	High	Low
Centipedegrass	Moderate to Coarse	Slow	Low	Low	Good	Moderate	Moderate to Good	Low	Low	Medium to High	Medium to High	High	Medium	High
Seashore Paspalum	Moderate	Moderate	Moderate	Moderate	Excellent	Excellent	Good	Medium to High	Medium to High	Low	Medium	Low	Medium to High	High
Zoysia grass	Fine to Medium	Slow to Moderate	Moderate	Moderate	Excellent	Good	Moderate to Good	Low to Medium	Medium to High	Low to Medium	High	Low to Medium	Medium to High	High




Figure SOD-1 Geographical Areas for Species Adaptation

Soil Amendments

Test soil to determine the requirements for lime and fertilizer. Soil tests may be conducted by Mississippi State University Extension Service Soil Testing Laboratory or other laboratories that make recommendations based on soil analysis. When soil test recommendations are unavailable, the following soil amendments may be sufficient:

- Agricultural limestone at a rate of 2 tons per acres (90lbs per 1000 sq. ft.). Other liming materials that may be selected should be provided in amounts that provide equal value to agricultural lime.
- Fertilizer at a rate of 1000 lbs per acre (25 lbs per 1000 sq. ft.) of 10-10-10.
- Equivalent nutrients may be applied with other fertilizer formulations. The soil amendments should be spread evenly over the treatment area and incorporated into the top 6" of soil by disking, chiseling or other effective, means. If topsoil is applied, follow specifications given in the *Topsoiling Practice*. Minor surface smoothing may be necessary after incorporation of soil amendments.

Installing the Sod

A step-by-step procedure for installing sod is illustrated in Figure SOD-2 and described below.




Figure SOD-2 Typical Installation of Grass Sod

Moistening the sod after it is unrolled helps maintain its viability. Store it in the shade during installation.


Rake the soil surface to break the crust just before laying sod. During the summer, lightly irrigate the soil, immediately before laying the sod to cool the soil and reduce root burning and dieback.

Do not lay sod on gravel, frozen soils, or soils that have been recently sterilized or treated with herbicides.

Lay the first row of sod in a straight line with subsequent rows placed parallel to and butting tightly against each other. Stagger strips in a brick-like pattern. (see Figure SOD – 2). Be sure that the sod is not stretched or overlapped and that all joints are butted tightly to prevent voids. Use a knife or sharp spade to trim and fit irregularly shaped areas.

Install strips of sod with their longest dimension perpendicular to the slope/waterflow direction. On slopes 3:1 or greater, in grass swales or wherever erosion may be a problem, secure sod with pegs or staples. Jute or other netting material may be pegged over the sod for extra protection on critical areas (see Figure SOD – 3).

As sodding of clearly defined areas is completed, use a weighted roller on the sod to provide firm contact between roots and soil.



LAY SOD ACROSS THE DIRECTION OF FLOW. USE PEGS OR STAPLES TO FASTEN SOD FIRMLY AT THE CORNERS AND CENTER.

Figure SOD-3 Installation of Sod in Areas with Channel Flows

Irrigation

Immediately after laying the sod, roll or tamp it to provide firm contact between roots and soil, then irrigate sod deeply so that the underside of the sod pad and the soil 6" below the sod is thoroughly wet.

Keep sodden areas moist to a depth of 4" until the grass takes root. This can be determined by gently tugging on the sod. Resistance indicates that rooting has occurred.

Mowing should not be attempted until the sod is firmly rooted, usually in 2 to 3 weeks.

Construction Verification

Check materials and installation for compliance with specifications.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate the sodding materials will not function as intended; changes in plan may be needed.

Design specifications for sod variety cannot be met or irrigation is not possible; substitution or seeding may be required. Unapproved substitutions could result in erosion or sodding failure.

Sod laid on poorly prepared soil or unsuitable surface and grass dies because it is unable to develop a root system with the soil: remove dead sod, prepare surface properly and resod.

Sod not adequately irrigated after installation; may cause root dieback or grass does not root rapidly and is subject to drying out: irrigate sod and underlying soil to a depth of 4" and keep moist until roots are established.

Sod not anchored properly may be loosened by runoff: use guidance under Site Preparation to repair the damaged areas, lay healthy sod, anchor properly and irrigate as planned.

Slow growth due to lack of nitrogen: apply additional fertilizer.

Maintenance

- See Table SOD-2 for maintenance guidelines for sod.
- Keep sod moist until it is fully rooted.
- Mow to a height of 2" to 3" after sod is well-rooted, in 2 to 3 weeks. Do not remove more than 1/3 of the leaf blade in any mowing.
- Permanent, fine turf areas require yearly fertilization. Fertilize warm-season grass in late spring to early summer; cool-season grass in early fall and late winter.

References

BMPs from Volume 1

Land Grading (LG)

4-16

Surface Roughening (SR)



Practice Description

Roughening a sloping bare soil surface with horizontal depressions helps control erosion by aiding the establishment of vegetative cover with seed, reducing runoff velocity, and increasing infiltration. The depressions also trap sediment on the face of the slope. This practice is especially appropriate for soils that are frequently disturbed and on piles of excavated soils.

Roughening methods include stair-step grading, grooving and tracking. Equipment such as bulldozers with rippers or tractors with disks may be used. The final face of the slopes should not be bladed or scraped to give a smooth hard finish.

Planning Considerations

Surface roughening should be considered for all slopes. The amount of roughening required depends on the steepness of the slope and the type of soil. Stable sloping rocky faces may not require roughening or stabilization, while erodible slopes steeper than 3:1 require special surface roughening.

Design Criteria and Installation

Surface roughening is to be done only after cuts and fill are to final grade and shape.

Cut Slope Roughening (Areas not to be mowed)

Use stair-step grades or groove cut slopes with a gradient steeper than 3:1. Use stair-step grading on any erodible material soft enough to be ripped with a bulldozer. Do not make

individual vertical cuts more than 2 feet in soft materials or more than 3 feet in rocky materials.

Grooving

Grooving uses machinery to create a series of ridges and depressions that run across the slope (on the contour). Groove using any appropriate implement that can be safely operated on the slope, such as disks, tillers, spring harrows, or the teeth on a front-end loader bucket. Do not make such grooves less than 3 inches deep nor more than 15 inches apart.

Fill Slope Roughening (Areas not to be mowed)

Place fill slopes with a gradient steeper than 3:1 in lifts not to exceed 9 inches, and make sure each lift is properly compacted. Insure that the face of the slope consists of loose, uncompacted fill 4 to 6 inches deep. Use grooving, as described above, to roughen the face of the slopes, if necessary. Do not blade or scrape the final slopes face.



Cuts, Fills, and Graded Areas That Will Be Mowed

Make mowed slopes no steeper than 3:1. Roughen these areas to shallow grooves by normal tilling, dishing, harrowing, or use of cultipacker-seeder. Make the final pass of any such tillage implement on the contour. Make grooves formed by such implements close together (less than 10 inches) and not less than 1 inch deep. Excessive roughness is undesirable where mowing is planned.

Roughening with Tracked Machinery

Limit roughening with tracked machinery to sandy soils to avoid undue compacting of the soil surface. Tracking is generally not as effective as other roughening methods described. Operate tracked machinery up and down the slopes to leave horizontal depressions in the soil. Do not back-blade during the final grading operation.

Seeding

Immediately seed and mulch roughened areas to obtain optimum seed germination and growth.

Common Problems

Tracking in the wrong direction, perpendicular to the slope, can accelerate rill erosion.

Maintenance

Inspect roughened areas after storms to see if re-roughening is needed. Regular inspection should indicate where additional erosion and



Figure 3 Rill Erosion

sediment-control measures are needed. If rills appear, fill, regrade, and reseed them immediately. Use proper *Dust Control* methods.

References

BMPs from Volume 1

Dust Control (DC)	4-29
Erosion-Control Blanket (ECB)	4-33
Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103

Temporary Seeding (TS)

TS



Practice Description

Temporary seeding is the establishment of fast-growing annual vegetation from seed on disturbed areas. Temporary vegetation provides economical erosion control for up to a year and reduces the amount of sediment moving off the site.

This practice applies where short-lived vegetation can be established before final grading or in a season not suitable for planting the desired permanent species. It helps prevent costly maintenance operations on other practices such as sediment basins and sediment barriers. In addition, it reduces problems of mud and dust production from bare soil surfaces during construction. Temporary or permanent seeding is necessary to protect earthen structures such as dikes, diversions, grass-lined channels and the banks and dams of sediment basins.

Planning Considerations

Temporary vegetative cover can provide significant short-term erosion and sediment reduction before establishing perennial vegetation.

Temporary vegetation will reduce the amount of maintenance associated with sediment basins.

Temporary vegetation is used to provide cover for no more than 1 year. Permanent vegetation should be established at the proper planting time for permanent vegetative cover.

Certain plants species used for temporary vegetation will produce large quantities of residue which can provide mulch for establishment of the permanent vegetation.

Proper seedbed preparation and selection of appropriate species are important with this practice. Failure to follow establishment guidelines and recommendations carefully may result in an inadequate or short-lived stand of vegetation that will not control erosion.

The selection of plants for temporary vegetation must be site specific. Factors that should be considered are types of soils, climate, establishment rates, and management requirements of the vegetation. Other factors that may be important are wear, mowing tolerance, and salt tolerance of vegetation.

Seeding properly carried out within the optimum dates has a higher probability of success. It is also possible to have satisfactory establishment when seeding outside these dates. However, as plantings are deviated from the optimum dates, the probability of failure increases rapidly. Seeding dates should be taken into account in scheduling land-disturbing activities.

Site quality impacts both short-term and long-term plant success. Sites that have compacted soils should be modified whenever practical to improve the potential for plant growth.

The operation of equipment is restricted on slopes steeper than 3:1, severely limiting the quality of the seedbed that can be prepared. Provisions for establishment of vegetation on steep slopes can be made during final grading. In construction of fill slopes, for example, the last 4-6" might not be compacted. A loose, rough seedbed with irregularities that hold seeds and fertilizer is essential for hydroseeding. Cut slopes should be roughened (see practice *Land Grading*).

Good mulching practices are critical to protect against erosion on steep slopes. When using straw, anchor with netting or asphalt. On slopes steeper than 2:1, jute, excelsior, or synthetic matting may be required to protect the slope.

The use of irrigation (temporary or permanent) will greatly improve the success of vegetation establishment.

Design Criteria and Installation

Prior to start of installation, plant materials, seeding rates and planting dates should be specified by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the installation process.

Scheduling

Plantings should be made during the specified planting period if possible. When sites become available to plant outside of the recommended planting period, either temporary seeding, mulching or chemical stabilization will be more appropriate than leaving the surface bare for an extended period. If lime and fertilizer application rates are not specified, take soil samples during the final grading operation from the top 6" in each area to be seeded. Submit samples to a soil testing laboratory for lime and fertilizer recommendations.

Plant Selection

Select plants that can be expected to meet planting objectives. To simplify plant selection, use Table TS-1, *Commonly Used Plants for Temporary Cover* and Figure TS-1, *Geographical Areas for Species Adaptation and Seeding Dates*. Seeding mixtures commonly specified by the Mississippi Department of Transportation are an appropriate alternative for plantings on rights-of-ways. Additional information related to plantings in Mississippi is found in Chapter 2 in the section *Non-woody Vegetation for Erosion and Sediment Control*.

Table TS-1 Commonly Used Plants for Temporary Cover

Species	Seeding Rates/Ac	Planting Time	Desired pH Range	Fertilization Rate/Acre	Method of Establishment	Zone of Adaptability
Wheat	90 lbs. alone	9/1 – 11/30	6.0 – 7.0	600 lbs. 13-13-13	Seed	All
Ryegrass	30 lbs.	9/1 – 11/30	6.0 – 7.0	600 lbs. 13-13-13	Seed	All
White Clover	5 lbs	9/1 – 11/30	6.0 – 7.0	400 lbs. 13-13-13	Seed	All
Crimson Clover	25 lbs. alone 15 lbs. mix	9/1 – 11/30	6.0 – 7.0	400 lbs. 13-13-13	Seed	All
Hairy Vetch	30 lbs.	9/1 – 11/30	6.0 – 7.0	400 lbs. 13-13-13	Seed	All
Browntop Millet	40 lbs. alone 15 lbs. mix	4/1 – 8/30	6.0 – 7.0	600 lbs. 13-13-13	Seed	All




Figure TS- 1 Geographical Areas for Species Adaptation

Site Preparation and Soil Amendments

Complete grading and shaping before applying soil amendments, if needed, to provide a surface on which equipment can safely and efficiently be used to apply soil amendments and accomplish seedbed preparation and seeding. Incorporate lime and fertilizer into the top 6" of soil during seedbed preparation.

Lime

Apply lime according to soil-test recommendations. If a soil test is not available, use 1 ton of agricultural limestone or equivalent per acre on coarse-textured soils and 2 tons per acre on fine textured soils. Do not apply lime to alkaline soils or to areas that have been limed during the preceding 2 years. Other liming materials that may be selected should be provided in amounts that provide equal value to the criteria listed for agricultural lime or be used in combination with agricultural limestone or Selma chalk to provide equivalent values to agricultural limestone.

Fertilizer

Apply fertilizer according to soil-test results. If a soil test is not available, apply 8-24-24 fertilizer.

When vegetation has emerged in a stand and is growing, 30 to 40 lbs/acre (approximately 0.8 lbs/1000 ft²) of additional nitrogen fertilizer should be applied.

Note: Fertilizer can be blended to meet exact fertilizer recommendations. Take soil-test recommendations to local fertilizer dealer for bulk-fertilizer blends. This may be more economical than bagged fertilizer.

Seedbed Preparation

Good seedbed preparation is essential to successful plant establishment. A good seedbed is well pulverized, loose, and smooth. If soils become compacted during grading, loosen them to a depth of 6" to 8" using a ripper or chisel plow.

If rainfall has caused the surface to become sealed or crusted, loosen it just prior to seeding by disking, raking, harrowing, or other suitable methods. When hydroseeding methods are used, the surface should be left with a more irregular surface of clods.

Planting Methods

Seeding

Evenly apply seed using a cyclone seeder (broadcast), drill seeder, cultipacker seeder, or hydroseeder. Broadcast seeding and hydroseeding are appropriate for steep slopes where equipment cannot operate safely. Small grains should be planted no more than 1" deep, and grasses and legumes no more than ½" deep. Seed that are broadcast must be covered by raking or chain dragging, and then lightly firmed with a roller or cultipacker.

Hydroseeding

Surface roughening is particularly important when hydroseeding, as a roughened slope will provide some natural coverage for lime, fertilizer, and seed. The surface should not be compacted or left smooth. Fine seedbed preparation is not necessary

for hydroseeding operations; large clods, stones, and irregularities provide cavities in which seeds can lodge.

Mix seed, use an inoculant if required, and mix a seed carrier with water and apply as slurry uniformly over the area to be treated. The seed carrier should be a cellulose fiber, natural-wood fiber or other approved fiber-mulch material which is dyed an appropriate color to facilitate uniform application of seed. Use the correct legume inoculant at 4 times the recommended rate when adding inoculant to a hydroseeder slurry. The mixture should be applied within one hour after mixing to reduce damage to seed.

Fertilizer should not be mixed with the seed-inoculant mixture because fertilizer salts may damage seed and reduce germination and seedling vigor. Fertilizer may be applied with a hydroseeder as a separate operation after seedlings are established.

Mulching

The use of an appropriate mulch provides instant cover and helps ensure establishment of vegetative cover under normal conditions and is essential to seeding success under harsh site conditions (see the *Mulching Practice* for guidance). Harsh site conditions include the following: slopes steeper than 3:1 and adverse soils (soils that are shallow to rock, rocky, or high in clay or sand). Areas with concentrated flow should be treated differently and require a hydromulch formulated for channels or use of an appropriate erosion control blanket.

Verification of Installation

Check materials and installation for compliance with specifications during installation of products.

Common Problems

Consult with a qualified design professional if the following occurs:

Design specifications for seed variety, seeding dates or mulching cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Seeding outside of the recommendations results in an inadequate stand. Reseed according to specifications of a qualified design professional (see recommendations under Maintenance).

Maintenance

Reseeding

Inspect seedings weekly until a stand is established and at least monthly thereafter for stand survival and vigor. Also, inspect the site for erosion.

Eroded areas should be addressed appropriately by filling and/or smoothing, and a reapplication of lime, fertilizer, seed and mulch.

A stand should be uniform and dense for best results. Stand conditions, particularly the vegetative coverage, will determine the extent of remedial actions, such as seedbed preparation and reseeded. A qualified design professional should be consulted to advise on remedial actions. Consider no-till planting.

Fertilizing

If vegetation fails to grow, have the soil tested to determine whether its pH is in the correct range or whether nutrient deficiency is a problem.

Satisfactory establishment may require refertilizing the stand, especially if the planting is made early in the planting season. Follow soil-test recommendations or the specifications provided to establish the planting.

Mowing

Temporary plantings may be mowed and baled or simply mowed to complement the use of the site.

Millet, rye, and wheat may be mowed, but no lower than 6" (closer mowing may damage the stand).

Ryegrass is tolerant of most mowing regimes and may be mowed often and as close as 4" to 6" if this regime is started before it attains tall growth (over 8").

Bermuda grass is tolerant of most mowing regimes and can be mowed often and close, if so desired, during its growing season.

References

Volume 1

Chapter 2

Vegetation for Erosion and Sediment Control 2-10

Chapter 4

Land Grading (LG) 4-16

Topsoiling (TSG) 4-20

Mulching (MU) 4-48

Permanent Seeding (PS) 4-53

Appendices Volume

Appendix G

MDOT Vegetation Schedule G-1

Tree Planting On Disturbed Areas (TP)



Practice Description

Tree planting on disturbed areas is planting trees on construction sites or other disturbed areas to stabilize the soil. The practice reduces erosion and minimizes the maintenance requirements after a site is stabilized. The practice is applicable to those areas where tree cover is desired and is compatible with the planned use of the area, particularly on steep slopes and adjacent to streams. Tree planting is usually used with other cover practices such as permanent seeding or sodding.

Planning Considerations

Control grass and legume cover when seeded in combination with planted trees to reduce competition for moisture, nutrients and sunlight.

Select trees that are adapted to soil and climate.

Avoid planting species that are invasive or may become a nuisance.

Avoid trees that have undesirable characteristics.

Select trees that will improve aesthetics and provide food and cover for wildlife.

Design Criteria and Installation

Tree-planting requirements should be designed by a qualified design professional and plans and specifications should be made available to field personnel prior to start of planting.

Planting Bare-rooted Tree Seedlings

Site Preparation

Compacted soil should be ripped or chiseled on the contour to permit adequate root development and proper tree growth. Debris should be removed from the site to facilitate tree planting.

Planting Methods

Tree seedlings may be planted by hand or machine. Any tool or piece of equipment that gives satisfactory results may be used. Dibble bars, mattocks, augers, post-hole diggers and shovels may be used to plant trees by hand. Wildland tree-planting machines should be used on rough areas or areas with clayey or compacted soils. Old-field tree planters should be limited to areas with light soils that are not compacted. On sloping land, planting should be done on the contour. Bare-rooted tree-seedling planting techniques are outlined in Figure TP-1. Additional planting techniques for bare-root plants are available on MDOT drawing PD-1 found at the end of this practice.




Figure TP- 1 Planting Bare-Root Seedlings

When to Plant

Bare-root seedlings should be planted from December 1 to March 15. Planting should be done when the soil is neither too dry nor too wet. Planting should be avoided during freezing weather and when the ground is frozen.

Planting Rate

To control erosion, pines should be planted at a rate of 600 to 700 trees per acre and hardwoods should be planted at a rate of 300 to 500 trees per acre. Severely eroding areas should be planted at the rate of 600 to 900 trees per acre for both pine and hardwood species.

Depth of Planting

Trees should be planted deeper than they grew in the nursery. Plant small stock 1" deeper and medium to large stock ½" deeper. On most soils, longleaf pine seedlings should be planted ¼" deeper than they grew in the nursery.

Condition of Roots

Roots should be planted straight down and not twisted, balled, nor U-shaped. Soil should be packed firmly around the planted seedlings. No air pockets should be left in either machine furrows or holes made by planting tools.

Care of Seedlings

The roots of seedlings must be kept moist and cool at all times. After lifting, seedlings should not be exposed to sun, wind, heat, dry air or freezing cold before they are planted. Baled seedlings may be kept up to 3 weeks if they are properly stacked, watered, and kept in a cool place. When planting is delayed, the roots of seedlings should be covered with moist soil (heeled-in) or the seedlings should be placed in cold storage.

During planting, the roots of seedlings must be kept moist and only one seedling should be planted at a time. At the end of each day, loose seedlings should be either repacked in wet moss or heeled-in.

Mulching

Mulching may be necessary on sloping land to reduce erosion. Mulch with wood chips, bark, pine needles, peanut hulls, etc. to a depth of no more than 3". Mulch should not be placed against the trunk of the tree.

Planting Balled and Burlapped and Container-Grown Trees

The best time to plant hardwood trees is in late winter (before leaves emerge) and the best time to plant evergreens is in early fall. However, these plants may be planted anytime of the year except when the ground is frozen. Watering is essential during dry periods.

Site Preparation

The planting hole should be dug deep and wide enough to allow proper placement of the root ball. The final level of the root ball's top should be level with the ground surface (See Figure TP-2).

As the hole is dug, the topsoil should be kept separate from the subsoil. If possible, the subsoil should be replaced with topsoil. If topsoil is unavailable, the subsoil can be improved by mixing in ⅓ volume of peat moss or well-rotted manure.

Heavy or poorly drained soils are not good growth media for trees. When it is necessary to transplant trees into such soils, extra care should be taken.




Figure TP- 2 Tree Planting Diagram

Tree Preparation

The proper digging of a tree includes the conservation of as much of the root system as possible, particularly the fine roots. Soil adhering to the roots should be damp when the tree is dug, the tree roots should be kept moist until planting. The soil ball should be 12" in diameter for each inch of diameter of the trunk. The tree should be carefully excavated and the soil ball wrapped in burlap and tied with rope. Use of a mechanical tree spade is also acceptable.

Any trees that are to be transported for a long distance should have the branches bound with a soft rope to prevent damage.

Planting the Tree

Depth of planting must be close to the original depth. The tree may be set just a few inches higher than in its former location, especially if soil is poorly drained. Do not set the tree lower than before. Soil to be placed around the root ball should be moist but not wet.

Set the tree in the hole and if the tree is balled and burlapped, remove the rope which holds the burlap. Loosen the burlap and remove completely if practical. Do not break the soil of the root ball. Fill the hole with soil halfway and add water to settle the soil and eliminate air pockets. When the water has drained off, fill the hole the remainder of the way. Use extra soil to form a shallow basin around the tree. This will help retain water.

Newly planted trees may need artificial support to prevent excessive swaying. Stakes and guy wires may be used (see Figure TP-2). Guying should be loose enough to allow some movement of the tree. Planting and guying techniques for balled and burlapped and container plants are available on MDOT drawing PD-1 found at the end of this practice.

Mulching

Mulching may be necessary on sloping land to reduce erosion and should be used around balled and burlapped trees and container grown trees to help conserve soil moisture and reduce competition from weeds and grass. Apply mulch using wood chips, bark, pine needles, peanut hulls etc. to a depth of no more than 3". Mulch should not be placed against the trunk of the tree.

Verification of Installation

Check all components of the practice during installation to ensure that specifications are being met.

Common Problems

Consult with a qualified design professional if any of the following occur:

Soil compaction can prevent adequate tree growth. Compaction should be addressed during site preparation.

Design specifications for trees (species, planting dates) and mulch cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Problems that require remedial actions:

Erosion, washout and poor tree establishment – repair eroded surface, replant, reapply mulch and anchor.

Mulch is lost to wind or stormwater runoff – reapply mulch and anchor.

Maintenance

Replant dead trees where needed to maintain adequate cover for erosion control.

Periodic fertilization may be beneficial on poor sites to maintain satisfactory tree growth. Transplanted trees should be fertilized 1 year or so after planting. A soil test is the best way to determine what elements are needed. Fertilizer formulations of 10-8-6 or 10-6-4 can be used in the absence of a soil test. About 2 lbs. of fertilizer should be used for each inch of tree diameter measured at 4.5 feet above the ground.

Fertilizer must come in contact with the roots to benefit a tree. The easiest way to apply fertilizer is to simply broadcast it under the tree and over the root system. As a tree grows, the roots will grow well beyond the drip line. This should be taken into account when applying fertilizer by the broadcast method. Another way to apply fertilizer is to make holes in the tree's root area with a bar or auger. Holes should be 18" deep, spaced about 2 feet apart, and located around the drip line of the tree. Distribute the fertilizer evenly into these holes and close the holes with the heel of the shoe or by filling with topsoil or peat moss. Trees should be fertilized in late winter or early spring before leaves emerge.

References

BMPs from Volume 1

Chapter 4

Mulching (MU)



4-48

MDOT Drawing PD-1


Typical Planting Details for Trees and Shrubs

4-116





STATE	PROJECT NO.
MISS.	



NOTE: METHOD OF "HEELING-IN" BEFORE PLANTING CONSISTS OF PLACING THE PLANTS IN A TRENCH AND COVERING THE ROOTS WITH DIRT. THIS MAY BE DONE ON TRUCK FOR EASE OF MOVEMENT. SAW DUST OR OTHER APPROVED MATERIAL MAY BE USED. ROOTS MUST BE KEPT MOIST AT ALL TIMES.





ROOT PROTECTION ("HEELING-IN") DURING STORAGE



DOUBLE VERTICAL STAKING METHOD

NOTE: ALL TREES SHALL BE STAKED OR GUYED. THE TRUNK OF ALL SMOOTH BARKED TREES SHALL BE WRAPPED. LARGE SHRUBS TO BE STAKED AND WRAPPED WHEN SPECIFIED ON PLANS.

TREE AND SHRUB PLANTING (BARE ROOT)



GENERAL NOTES:

1. THE TYPE(S), RATE(S) OF APPLICATION AND PLACEMENT OF FERTILIZER AND MULCH SHALL BE IN ACCORDANCE WITH THE REQUIREMENTS OF THE PLANS AND SPECIFICATIONS.
2. TENSION IN GUY WIRES WILL BE SUCH AS TO ALLOW SOME SWAYING MOTION IN TREE.

DATE	DESIGNED BY	CHECKED BY	IN CHARGE	STATE	PROJECT NO.


MISSISSIPPI DEPARTMENT OF TRANSPORTATION
ROADWAY DESIGN DIVISION
STANDARD PLAN

TYPICAL PLANTING DATA
FOR TREES & SHRUBS

ISSUE DATE: OCTOBER 1, 1998

WORKING NUMBER: PD-1
SHEET NUMBER: 141

Check Dam (CD)



Practice Description

A check dam is a small barrier or dam constructed across a swale, drainage ditch or other area of concentrated flow for the purpose of reducing channel erosion. Channel erosion is reduced because check dams flatten the gradient of the flow channel and slow the velocity of channel flow. Most check dams are constructed of rock, but hay bales, logs and other materials may be acceptable. Contrary to popular opinion, most check dams trap an insignificant volume of sediment.

This practice applies in small open channels and drainageways, including temporary and permanent swales. It is not to be used in a live stream. Situations of use include areas in need of protection during establishment of grass and areas that cannot receive a temporary or permanent non-erodible lining for an extended period of time.

Planning Considerations

Check dams are used in concentrated flow areas to provide temporary channel stabilization during the intense runoff periods associated with construction disturbances. Check dams may be constructed of rock, logs, hay bales or other suitable material, including manufactured products. MDOT Drawing ECD-4 at the end of this practice shows the typical application of check dam structures. Most check dams are constructed of rock. Rock may not be acceptable in some installations because of aesthetics; therefore, alternative types of check dams need to be considered.

Rock check dams

Rock check dams (Figures CD-1 and CD-2) are usually installed with backhoes or other suitable equipment, but hand labor is likely needed to complete most installations to the quality needed. The rock is usually purchased, and some locations in the state may not have rock readily available. The use of rock should be considered carefully in areas to be

mowed. Some rock may be washed away during heavy rain events and should be removed before each mowing operation. Additional installation drawings are provided at the end of this practice as MDOT Drawings ECD-8 and ECD-9.

Log check dams

Log check dams (Figure CD-3) are more economical from a materials cost standpoint since logs can usually be salvaged from clearing operations. The time and labor required would be greater for log check dams. Increased labor costs would offset the reduced material costs. Log check dams would not be permanent but may last long enough to get grass linings established.

Hay bale check dams

Check dams constructed of hay bales (Figure CD-4) have the shortest life of the materials discussed and are only used as a temporary means to help establish a channel to vegetation. MDOT Drawing ECD-5 is provided at the end of this practice and shows more specifics for hay bale check dams. MDOT Drawing ECD-6 shows typical details for a straw wattle ditch check as an alternative to hay bale check dams. Hay bale check dams should not be used where permanent watercourse protection is needed and should be used only in concentrated-flow areas where only minimal runoff occurs.

Without proper installation, which is rarely done, hay bale check dams always fail.




Figure CD-1 Profile of Typical Rock Check Dams

Check dams should be planned to be compatible with the other features such as streets, walks, trails, sediment basins and rights-of-way or property lines. Check dams are normally constructed in series, and the dams should be located at a normal interval from other grade controls such as culverts or sediment basins.




Figure CD-2 Cross Section of Typical Rock Check Dam




Figure CD-3 Typical Log Check Dam




Figure CD-4 Typical Hay Bale Check Dam

(NOTE: Without proper installation, which is rarely done, hay bale check dams always fail.)

Design Criteria and Installation

Formal design is not required. The following limiting factors should be adhered to when designing check dams.

Drainage Area

Ten acres or less (rock or logs).

Maximum Height

Two feet when drainage area is less than 5 acres.

Three feet when drainage area is 5 to 10 acres.

Depth of Flow

Six inches when drainage area is less than 5 acres.

Twelve inches when drainage area is 5 to 10 acres.

The top of dam, perpendicular to flow, should be parabolic. The center of the dam should be constructed lower than the ends. The elevation of the center of the dam should be lower than the ends by the depth of flow listed above.

Side Slopes

2:1 or flatter.

Spacing

Elevation of the toe of the upstream dam is at or below elevation of the crest of the downstream dam.

Keyway

The rock or log check dam should be keyed into the channel bottom and abutments to a depth of 12 to 24". The keyway width should be at least 12". The keyway is to prevent erosion around the end of and beneath the dam. Hay bale check dams should be embedded into the soil at least 3".

Rock Check Dams

Rock check dams should be constructed of durable rock riprap. Rock material diameter should be 2" to 15".

In soils where failure by piping of soils into the rock is likely, a geotextile will be used as a filter to separate the soils from the rock. Geotextile should conform to the requirements of type I geotextile in Table CD-1.

Table CD-1 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTMD 4632	≥ 50	≥ 50	≥ 50	≥ 50
Puncture (pounds)	ASTMD 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD 4751	As specified max. no.40 ³			
Permittivity sec ⁻¹	ASTMD 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

- 1 Heat-bonded or resin-bonded geotextile may be used for Classes III and IV. They are particularly well suited to Class IV. Needle-punched geotextile is required for all other classes.
- 2 Minimum average roll value (weakest principal direction).
- 3 U.S. standard sieve size.

Site Preparation

Determine location of any underground utilities.

Locate and mark the site for each check dam in strategic locations (to avoid utilities and optimize effectiveness of each structure in flattening channel grade).

Remove debris and other unsuitable material that would interfere with proper placement of the check dam materials.

Excavate a shallow keyway (12"-24" deep and at least 12" wide) across the channel and into each abutment for each check dam.

Materials Installation

As specified, install a non-woven geotextile fabric in the keyway in sandy or silty soils. This may not be required in clayey soils.

Construct the dam with a minimum 2:1 side slope over the keyway and securely embed the dam into the channel banks. Position rock to form a parabolic top, perpendicular to channel flow, with the center portion at the elevation shown in the design so that the flow goes over the structure and not around the structure.

Erosion and Sediment Control

Install vegetation (temporary or permanent seeding) or mulching to stabilize other areas disturbed during the construction activities.

Construction Verification

Check finished size, grade and shape for compliance with standard drawings and materials list (check for compliance with specifications if included in contract specifications).

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate check dam will not function as intended. Change in plan will be needed.

Materials specified in the plan are not available.

Maintenance

Inspect the check dam for rock displacement and abutments for erosion around the ends of the dam after each significant rainfall event. If the rock appears too small, add additional stone and use a larger size.

Inspect the channel after each significant rainfall event. If channel erosion exceeds expectations, consult with the design professional and consider adding another check dam to reduce channel flow grade.

Sediment should be removed if it reaches a depth of ½ the original dam height. If the area behind the dam fills with sediment, there is a greater likelihood that water will flow around the end of the check dam and cause the practice to fail.

Check dams may be removed when their useful life has been completed. The area where check dams are removed should be seeded and mulched immediately unless a different treatment is prescribed. In some instances check dams should be left as a permanent measure to support channel stability.

References

BMPs from Volume 1

Chapter 4

Temporary Seeding (TS) 4-103

MDOT Drawing ECD-4

Ditch Check Structures, Typical Applications and Details 4-124

MDOT Drawing ECD-5

Temporary Erosion, Sediment and Water Pollution Control Measures, Silt Fence and Hay Bale Ditch Check 4-125

MDOT Drawing ECD-6

Details of Erosion Control Wattle Ditch Check 4-126

MDOT Drawing ECD-7

Details of Erosion Control Silt Dike Ditch Check 4-127

MDOT Drawing ECD-8

Rock Ditch Check 4-128

MDOT Drawing ECD-9



Rock Ditch Check with Sump Excavation 4-129

MDOT Drawing ECD-20

Details of Erosion Control Sandbag Ditch Check 4-130

STATE	PROJECT NO.
MISS.	

REFERENCE PROJECT NO.	FISCAL YEAR	SHEET NO.



EXAMPLE: HEIGHT OF STRUCTURE 1.5'
 GRADE 1%
 EXTEND VERTICALLY FROM 1.5' HEIGHT TO INTERSECT S = 1.0% GRADE
 EXTEND 90° TO THE LEFT TO DETERMINE SPACING (150'-0")


DITCH CHECK SPACING

NOTES:

1. THE DITCH CHECK PERSPECTIVE ILLUSTRATES A TOOL BOX OF TEMPORARY PRACTICES THAT MAY BE USED. DITCH CHECKS ARE INSTALLED TO CONTROL RUNOFF VELOCITY AND THUS REDUCE EROSION AND PROVIDE FOR TRAPPING OF SEDIMENTS.
2. SELECTION OF THE APPROPRIATE DITCH CHECK SHOULD BE A FUNCTION OF CONSTRUCTION PHASE, DRAINAGE AREA, DITCH GRADIENT, SOIL TYPE ECONOMY AND SAFETY.
3. DITCH CHECKS CAN BE REMOVED FOR MAINTENANCE AND/OR REPLACEMENT BUT MUST REMAIN IN PLACE UNTIL UPSLOPE AREAS HAVE BEEN PERMANENTLY STABILIZED. MAINTENANCE INCLUDES REMOVAL OF SEDIMENT BEGINNING WHEN SEDIMENT ACCUMULATION REACHES 1/3 THE CAPACITY OR HEIGHT OF THE STRUCTURE AND NEVER ALLOWING FOR SEDIMENT TO ACCUMULATE MORE THAN 1/2 THE VOLUME OR HEIGHT OF THE DITCH CHECK STRUCTURE.
4. HAY BALES ARE USED TO INTERCEPT LOW VOLUME FLOWS IN LOW TO MODERATE GRADIENT DITCHES.
5. SILT FENCE DITCH CHECKS ARE USED WHERE IT HAS BEEN DETERMINED THAT HAY BALE CHECKS ARE INADEQUATE. SILT FENCE DITCH CHECKS ARE USED TO INTERCEPT LOW VOLUME FLOWS IN LOW TO MODERATE GRADIENT DITCHES.
6. SAND BAG DITCH CHECKS ARE USED FOR VELOCITY REDUCTION AND MINIMAL SEDIMENT TRAPPING IN CONCRETE PAVED DITCHES OR IN DITCHES THAT HAVE ROCKY BOTTOMS.
7. WATTLE DITCH CHECKS ARE APPROPRIATE FOR VELOCITY REDUCTION AND CONTROL OF SEDIMENT TRANSPORT UNDER LOW TO MEDIUM FLOW CONDITIONS.
8. SILT DIKES CAN BE USED IN DITCHES WITH CONCENTRATED FLOWS WITHIN THE CLEAR ZONE WHERE RIPRAP CAN NOT BE USED, AS CONSTRUCTION PROGRESSES.
9. ROCK DITCH CHECK WITH SUMP EXCAVATION CAN BE PLACED IN DITCHES TO ASSURE ON-SITE SEDIMENT TRAPPING REQUIREMENTS ARE MET. DITCH CHECK WITH SUMP EXCAVATION IS USED WHEN DITCHES RECEIVE DRAINAGE FROM CUT OR FILL SLOPES OR OTHER CRITICAL AREAS WHERE SOIL EROSION IS EXPECTED. DRAINAGE AREA FOR A TEMPORARY SEDIMENT TRAP SHALL NOT EXCEED 3 ACRES. THEY CAN BE USED IN SERIES TO INCREASE ON-SITE SEDIMENT TRAPPING EFFICIENCY.
10. IN GENERAL, DITCH CHECKS SHOULD NOT BE PLACED IN LIVE STREAMS.
11. CONFIGURATION AND SPACING MAY BE ADJUSTED IF APPROVED BY THE ENGINEER TO ACCOMMODATE TRAVELWAY SAFETY, WATER FLOW, OR SOIL AND INSTALLATION CHALLENGES.

REVISIONS		MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
		DITCH CHECK STRUCTURES, TYPICAL APPLICATIONS AND DETAILS	
BY	DATE	WORKING NUMBER	ECD-4
BY	DATE	SHEET NUMBER	
FILENAME:	EROSTON CONTROL#ECD-4.DGN		
DESIGN TEAM:	CHECKED: BAK		

STATE	PROJECT NO.
MISS.	




PLAN VIEW


- NOTES:
1. ANCHOR AND INSTALL PER DETAILS FOR SILT FENCE SPACING GUIDELINES ON ECD-4
 2. A "W" SHAPE MAY BE USED FOR WIDER DITCHES.

SILT FENCE DITCH CHECK SELECTION GUIDELINES

SILT FENCE DITCH CHECKS ARE USED WHERE IT HAS BEEN DETERMINED THAT HAY BALE CHECKS ARE INADEQUATE. SILT FENCE DITCH CHECKS ARE USED TO INTERCEPT LOW VOLUME FLOWS IN LOW TO MODERATE GRADIENT DITCHES.



SECTION A-A




**PLAN VIEW
TRAPEZOIDAL DITCH**

- NOTES:
1. MINIMUM RECOMMENDED CHECK SPACING IS 100 FEET UNLESS SHOWN OTHERWISE ON THE PLANS OR EROSION CONTROL PLAN APPROVED BY THE ENGINEER. SEE SPACING GUIDANCE ON ECD-4.
 2. ANCHORING WOOD STAKES SHALL BE SIZED, SPACED, AND BE OF A MATERIAL THAT EFFECTIVELY SECURES THE CHECK. A MINIMUM OF TWO STAKES PER BALE IS REQUIRED. ALL NON-DEGRADABLE MATERIALS SHALL BE REMOVED WHEN NO LONGER NEEDED.
 3. BALES SHALL BE EMBEDDED IN THE SOIL A MIN. OF 4".
 4. BALES SHALL BE PLACED IN A ROW WITH ENDS TIGHTLY ABUTTING THE ADJACENT BALES. THE BALES SHALL BE PLACED WITH BINDINGS PARALLEL TO THE GROUND.
 5. SOIL IS COMPACTED ALONG THE BASE OF THE UPSTREAM FACE TO PREVENT PIPING.
 6. MULTIPLE ADJACENT ROWS OF BALES ARE REQUIRED AS SHOWN.

HAY BALE DITCH CHECK SELECTION GUIDELINES



HAY BALES ARE USED TO INTERCEPT LOW VOLUME FLOWS IN LOW TO MODERATE GRADIENT DITCHES.



**PROFILE VIEW
TRAPEZOIDAL DITCH**


DATE	BY	MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
		TEMPORARY EROSION, SEDIMENT AND WATER POLLUTION CONTROL MEASURES - SILT FENCE AND HAY BALE DITCH CHECKS	
DESIGN TEAM	CHECKED	DATE	WORKING NUMBER
			ECD-5
			SHEET NUMBER

STATE	PROJECT NO.
MSS.	



SECTION A-A

DETAIL (DITCH CHECK)



ELEVATION DETAIL


- NOTES:
1. MINIMUM RECOMMENDED PLACEMENT INTERVAL BETWEEN WATTLE DITCH CHECK IS 100' UNLESS SHOWN OTHERWISE ON THE PLANS OR EROSION CONTROL PLAN APPROVED BY THE ENGINEER. SEE SPACING GUIDANCE ON ECD-4
 2. ANCHORING WOOD STAKES SHALL BE SIZED, SPACED, DRIVEN, AND BE OF A MATERIAL THAT EFFECTIVELY SECURES THE CHECK. STAKE SPACING SHALL BE A MAXIMUM OF THREE FEET. ALL NON-DEGRADABLE MATERIALS SHALL BE REMOVED WHEN NO LONGER NEEDED.
 3. TRENCHING OF WATTLES MAY BE NECESSARY IF PIPING BECOMES EVIDENT.
 4. WATTLES SHOULD NOT BE USED IN HARD BOTTOM CHANNELS.

WATTLE DITCH CHECK SELECTION GUIDELINES

WATTLE DITCH CHECKS ARE APPROPRIATE FOR VELOCITY REDUCTION AND CONTROL OF SEDIMENT TRANSPORT UNDER LOW TO MEDIUM FLOW CONDITIONS.

BY		MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
DATE		DETAILS OF EROSION CONTROL WATTLE DITCH CHECK	
FILENAME:	EROSION_CONTROL-ECD-6.DGN	WORKING NUMBER	ECD-6
DESIGN TEAM:	CHECKED: JMT	SHEET NUMBER	

STATE	PROJECT NO.
MISS.	




SILT DIKE DITCH CHECK SELECTION GUIDELINES

SILT DIKES CAN BE USED IN DITCHES WITH CONCENTRATED FLOWS WITHIN THE CLEAR ZONE WHERE RIPRAP CAN NOT BE USED.


PLAN VIEW

- NOTE:**
1. MINIMUM RECOMMENDED PLACEMENT INTERVAL BETWEEN SILT DIKE DITCH CHECK IS 100' UNLESS SHOWN OTHERWISE ON THE PLANS OR EROSION CONTROL PLAN APPROVED BY THE ENGINEER. SEE SPACING GUIDANCE ON ECD-4
 2. INSTALLATION SHALL BE IN ACCORDANCE WITH MANUFACTURERS RECOMMENDATIONS.



POINT "A" MUST BE HIGHER THAN POINT "B" TO ENSURE THAT WATER FLOWS OVER THE DIKE AND NOT AROUND THE ENDS

SECTION B-B






NOTE: STAPLES SHALL BE PLACED WHERE THE UNITS OVERLAP AND IN THE CENTER OF THE UNIT

SECTION A-A

SILT DIKE INSTALLATION FOR ROADWAY DITCHES


DATE	BY	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
		DETAILS OF EROSION CONTROL SILT DIKE DITCH CHECK
FILENAME: EROSION_CONTROL\ECD-7.DGN	WORKING NUMBER ECD-7	SHEET NUMBER
DESIGN TEAM	CHECKED	

STATE	PROJECT NO.
MSS.	




TEMPORARY ROCK DITCH CHECKS IN ROADSIDE DITCHES

- NOTES:**
1. MINIMUM SPACING FOR ROCK DITCH CHECKS SHALL BE 100 FEET OR EROSION CONTROL PLAN APPROVED BY THE ENGINEER. SEE SPACING GUIDANCE ON ECD-4
 2. ROCK DITCH CHECKS MAY ALSO BE CHECKED WITH FABRIC.
 3. SIZE 300 LB RIP RAP MAY BE USED FOR SPECIFIED APPLICATIONS AS SHOWN ON EROSION CONTROL PLAN




BY: MISSISSIPPI DEPARTMENT OF TRANSPORTATION		WORKING NUMBER
ROCK DITCH CHECK		ECD-8
DATE:	FILENAME: EROSION_CONTROL/ECD-8.DWG	SHEET NUMBER
DESIGN TEAM:	CHECKED: DATE:	


STATE	PROJECT NO.
MISS.	



PLAN VIEW




SECTION A-A



PROFILE VIEW

BY:	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
REVISION:	ROCK DITCH CHECK WITH SUMP EXCAVATION
DATE:	FILENAME: EROSION CONTROL #ECD-9.DGN
DESIGN TEAM:	CHECKED: DATE:
	WORKING NUMBER ECD-9
	SHEET NUMBER

STATE	PROJECT NO.
MISS.	




DETAIL (DITCH CHECK)

- NOTES:
1. MINIMUM RECOMMENDED PLACEMENT INTERVAL BETWEEN SAND BAG DITCH CHECK IS 100' UNLESS SHOWN OTHERWISE ON THE PLANS OR APPROVED BY THE ENGINEER. SEE SPACING GUIDANCE ON ECD-4.
 2. PREVENTING SEDIMENT FROM ENTERING A PAVED DITCH IS PREFERABLE TO CAPTURING SEDIMENT WITHIN PAVED DITCH.

SAND BAG DITCH CHECK SELECTION GUIDELINES

SAND BAG DITCH CHECKS ARE USED FOR VELOCITY REDUCTION AND MINIMAL SEDIMENT TRAPPING IN CONCRETE PAVED DITCHES OR IN DITCHES THAT HAVE ROCKY BOTTOMS.



SECTION A-A

ELEVATION DETAIL

DATE	BY	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
		DETAILS OF EROSION CONTROL
		SANDBAG DITCH CHECK
FILENAME:	EROSION CONTROL/ECD-20.DGN	WORKING NUMBER
DESIGN TEAM		ECD-20
CHECKED	DATE	SHEET NUMBER

Diversion (DV)

→ D →



Practice Description

A diversion is a watercourse constructed across a slope consisting of an excavated channel, a compacted ridge, or a combination of both. Most diversions are constructed by excavating a channel and using the excavated material to construct a ridge on the downslope side of the channel. Right-of-way diversions and temporary diversions are sometimes constructed by making a ridge, often called a berm, from fill material.

This practice applies to sites where stormwater runoff can be redirected to permanently protect structures or areas downslope from erosion, sediment, and excessive wetness or localized flooding. Diversions may be used to temporarily divert stormwater runoff to protect disturbed areas and slopes or to retain sediment on-site during construction.

Perimeter protection is sometimes used to describe both permanent and temporary diversions used at either the upslope or downslope side of a construction area.

Right-of-way diversions, sometimes referred to as water bars, are used to shorten the flow length on a sloping right-of-way and reduce the erosion potential of the stormwater runoff.

Water Bar



Planning Considerations

Diversions are designed to intercept and carry excess water to a stable outlet.

Diversions can be useful tools for managing surface water flows and preventing soil erosion. On moderately sloping areas, they may be placed at intervals to trap and divert sheet flow before it has a chance to concentrate and cause rill and gully erosion. Simple water bars illustrate this concept (Figure DV-1).

Diversions may be placed at the top of cut or fill slopes to keep runoff from upgradient drainage areas off the slope. Diversions are also typically built at the base of steeper slopes to protect flatter developed areas that cannot withstand runoff water from outside areas. They can also be used to protect structures, parking lots, adjacent properties, and other special areas from flooding.

Diversions are preferable to other types of man-made stormwater conveyance systems because they more closely simulate natural flow patterns and characteristics. Flow velocities are generally kept to a minimum. When properly coordinated into the landscape design of a site, diversions can be visually pleasing as well as functional.

As with any earthen structure, it is very important to establish adequate vegetation as soon as possible after installation. It is usually important to stabilize the drainage area above the diversion so that sediment will not enter and accumulate in the diversion channel.




Figure DV-1 Water Bar

Design Considerations

Location

The location of the diversion should be determined by considering outlet conditions, topography, land use, soil type, length of slope, seepage (where seepage is a problem) and the development layout. Outlets must be stable after the diversion empties stormwater flow into it; therefore, care should be exercised in the location selection of the diversion and its outlet.

Capacity

The diversion channel must have a minimum capacity to carry the runoff expected from a storm frequency meeting the requirements of Table DV-1 with a freeboard of at least 0.3 foot (Figure DV-2).

The storm frequency should be used to determine the required channel capacity, Q (peak rate of runoff). The peak rate of runoff should be determined using the Natural Resources Conservation Service runoff curve number (RCN) method or other equivalent methods.

Table DV-1 Design Frequency

Diversion Type	Typical Area of Protection	24-Hour Design Storm Frequency
Temporary	Construction Areas	2-year
	Building Sites	5-year
Permanent	Agricultural Land	10-year
	Mined Reclamation Area	10-year
	Recreation Areas	10-year
	Isolated Buildings	25-year
	Urban areas, Residential, School, Industrial Areas, etc.	50-year

Diversions designed to protect homes, schools, industrial buildings, roads, parking lots, and comparable high-risk areas, and those designed to function in connection with other structures, should have sufficient capacity to carry peak runoff expected from a storm frequency consistent with the hazard involved.

Velocities

Diversions should be designed so that the design velocities are as high as will be safe for the planned type of protective vegetation and the expected maintenance, to minimize sediment deposition in the channel. Maximum permissible velocities are dependent upon the erosion resistance of the soil (Table DV-2) and the quality of the vegetation maintained.

Table DV-2 Permissible Velocities

Soil Texture	Velocity in Feet/Second		
	Conditions of Vegetation		
	Poor	Fair	Good
Sand, Silt, Sandy Loam, Silt Loam	1.5	2.0	3.0
Silty Clay Loam, Sandy Clay Loam	2.5	3.0	4.0
Clay	3.0	4.0	5.0

Channel Design

The diversion channel may be parabolic, trapezoidal or v-shaped, as shown in Figure DV-2 and should be designed in accordance with the procedure shown at the end of this practice. Land slope must be considered when choosing channel dimensions. On steeper slopes, narrow and deep channels may be required. On more gentle slopes, broad, shallow channels can be used to facilitate maintenance.

Ridge Design

The supporting ridge cross section should meet the configuration and requirements of Figure DV-2.

The side slopes should be no steeper than 2:1. Side slopes should be flatter, 5:1 to 10:1, when the diversion is to be permanent with mowing and other maintenance activities performed on or around it.

The width of the ridge at the design water elevation should be a minimum of 4 feet. The minimum freeboard should be 0.3 foot.

The design should include a 10% settlement factor.

Outlet

Diversions should have adequate outlets that will convey concentrated runoff without erosion. Acceptable outlets include practices such as *Grass Swale*, *Lined Swale*, *Drop Structure*, *Sediment Basin*, and *Stormwater Detention Basins*.

Stabilization

Unless otherwise stabilized, the ridge and channel should be seeded within 13 days of installation in accordance with the applicable seeding practice, *Permanent Seeding* or *Temporary Seeding*.

Disturbed areas draining into the diversion should be seeded and mulched prior to or at the time the diversion is constructed in accordance with the *Permanent Seeding*, *Temporary Seeding*, or *Mulching Practices* (whichever is applicable).




Figure DV-2 Typical Diversions Detail




Figure DV-3 Water Bar Detail

Design Criteria

Tables DV-1 through DV-16 may be used to facilitate the design of grass-lined diversions with parabolic cross sections. These tables are based on a retardance of “D” (vegetation newly cut) to determine V_1 for stability considerations. To determine channel capacity, choose a retardance of “C” when proper maintenance is expected; otherwise, design channel capacity based on retardance “B.” Refer to Table DV-2 for maximum permissible velocities. The permissible velocities guide the selection of V_1 and should not be exceeded. It is good practice to use a value for V_1 that is significantly less than the maximum allowable when choosing a design cross section. When velocities approach the

maximum allowable, flatter grades should be evaluated or a more erosion-resistant liner such as erosion control blanket or riprap should be considered. After the diversion dimensions are selected in the design tables, the top width should be increased by 4 feet and the depth by 0.3 foot for freeboard.

Example Problem

Given

Q: 30 cfs
Grade: 1%
Soil: Sandy clay loam
Condition of vegetation expected: fair
Maintenance: low; will be cut only twice a year.
Site will allow a top width of 26 feet.

Find

Diversion top width and depth that will be stable and fit site conditions.

Solution

From Table DV-2, use maximum permissible velocity of 3.0 ft/sec.

Since maintenance will be low, use “B” retardance for capacity.

From Table DV-4, use retardance “D” and “B”;
Grade 1.00 Percent Top width = 21.0 feet + 4 feet = 25.0 feet.

Depth = 1.6 feet + 0.3 foot = 1.9 feet.

$V_2 = 1.3$ ft/sec.

Note: $V_1 < 3.0$ ft/sec.; Top width < 26 feet, design O.K.

Note: It is good practice to select a cross section that will give a velocity, V_1 , well below the maximum allowable whenever site conditions permit. Wide, shallow cross sections are more stable and require less maintenance. It is always prudent to evaluate flatter design grades in order to best fit diversions to the site and keep velocities well below maximum allowable.

Table DV-3 Parabolic Diversion Design Chart (Retardance "D" and "B," Grade 0.50%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "B"

Grade 0.50 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0			
	T	D	V2	T	D	V2	T	D	V2																			
5																												
10																												
15	10.0	2.2	1.0																									
20	13.7	2.1	1.0	8.4	2.7	1.3																						
25	17.4	2.1	1.0	11.3	2.4	1.4																						
30	21.0	2.0	1.0	13.9	2.3	1.4																						
35	24.6	2.0	1.1	16.4	2.3	1.4	10.7	2.8	1.8																			
40	28.5	2.0	1.0	18.9	2.3	1.4	12.6	2.7	1.8																			
45	31.9	2.0	1.1	21.4	2.3	1.4	14.4	2.6	1.8																			
50	35.5	2.0	1.1	23.9	2.2	1.4	16.2	2.5	1.8	9.9	3.4	2.2																
55	39.0	2.0	1.1	26.3	2.2	1.4	17.9	2.5	1.8	11.9	3.1	2.3																
60	42.5	2.0	1.1	28.8	2.2	1.4	19.7	2.5	1.8	13.2	3.0	2.3																
65	46.1	2.0	1.1	31.6	2.2	1.4	21.4	2.5	1.8	14.5	2.9	2.3																
70	49.6	2.0	1.1	34.0	2.2	1.4	23.1	2.5	1.8	15.8	2.9	2.3	11.0	3.6	2.6													
75	53.1	2.0	1.1	36.4	2.2	1.4	24.9	2.5	1.8	17.1	2.8	2.3	12.7	3.4	2.7													
80	56.6	2.0	1.1	38.8	2.2	1.4	26.6	2.5	1.8	18.4	2.8	2.3	13.7	3.3	2.7													
85	60.2	2.0	1.1	41.2	2.2	1.4	28.3	2.5	1.8	19.7	2.8	2.3	14.8	3.2	2.7													
90	63.7	2.0	1.1	43.6	2.2	1.4	30.0	2.4	1.8	20.9	2.8	2.3	15.9	3.2	2.7													
95	67.2	2.0	1.1	46.1	2.2	1.4	31.7	2.4	1.8	22.1	2.8	2.3	16.9	3.1	2.7													
100	70.8	2.0	1.1	48.5	2.2	1.4	33.7	2.4	1.8	23.4	2.8	2.3	17.9	3.1	2.7	12.3	3.9	3.1										
105	74.3	2.0	1.1	50.9	2.2	1.4	35.4	2.4	1.8	24.5	2.7	2.4	18.9	3.1	2.7	13.7	3.7	3.1										
110	77.8	2.0	1.1	53.3	2.2	1.4	37.1	2.4	1.8	25.8	2.7	2.4	19.9	3.1	2.7	14.6	3.6	3.1										
115	81.4	2.0	1.1	55.7	2.2	1.4	38.7	2.4	1.8	27.0	2.7	2.4	20.8	3.0	2.7	15.4	3.6	3.1										
120	84.9	2.0	1.1	58.1	2.2	1.4	40.4	2.4	1.9	28.2	2.7	2.4	21.8	3.0	2.7	16.3	3.5	3.1										
125	88.4	2.0	1.1	60.6	2.2	1.4	42.1	2.4	1.9	29.4	2.7	2.4	22.8	3.0	2.7	17.1	3.5	3.1										
130	92.0	2.0	1.1	63.0	2.2	1.4	43.8	2.4	1.9	30.6	2.7	2.4	23.8	3.0	2.7	17.9	3.5	3.1										
135	95.5	2.0	1.1	65.4	2.2	1.4	45.4	2.4	1.9	31.8	2.7	2.4	24.8	3.0	2.7	18.7	3.4	3.2										
140	99.0	2.0	1.1	67.8	2.2	1.4	47.1	2.4	1.9	33.1	2.7	2.4	25.7	3.0	2.8	19.4	3.4	3.2										
145	102.5	2.0	1.1	70.2	2.2	1.4	48.8	2.4	1.9	34.3	2.7	2.4	26.7	3.0	2.8	20.2	3.4	3.2	13.5	4.4	3.6							
150	106.1	2.0	1.1	72.6	2.2	1.4	50.5	2.4	1.9	35.5	2.7	2.4	27.7	3.0	2.8	21.0	3.4	3.2	14.4	4.3	3.6							

RETARDANCE "D" AND "B"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-4 Parabolic Diversion Design Char (Retardance "D" and "B," Grade 1.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "B"																													
Grade 1.00 Percent																													
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0				
	T	D	V2	T	D																								
5																													
10	9.7	1.6	1.0	6.2	2.0	1.2																							
15	14.8	1.5	1.0	10.2	1.7	1.3	6.5	2.2	1.5																				
20	20.2	1.5	1.0	13.8	1.7	1.3	9.6	1.9	1.6																				
25	25.1	1.5	1.0	17.4	1.7	1.3	12.2	1.9	1.6	8.5	2.2	2.0																	
30	30.1	1.5	1.0	21.0	1.6	1.3	14.9	1.8	1.7	10.6	2.1	2.1																	
35	35.1	1.5	1.0	24.7	1.6	1.3	17.5	1.8	1.7	12.6	2.0	2.1	8.9	2.4	2.5														
40	40.1	1.5	1.0	28.2	1.6	1.3	20.0	1.8	1.7	14.5	2.0	2.1	10.5	2.3	2.5														
45	45.1	1.5	1.0	31.7	1.6	1.3	22.5	1.8	1.7	16.4	2.0	2.1	12.1	2.2	2.5	8.2	2.8	2.9											
50	50.2	1.5	1.0	35.2	1.6	1.3	25.4	1.8	1.7	18.3	2.0	2.1	13.6	2.2	2.5	10.0	2.6	2.9											
55	55.2	1.5	1.0	38.8	1.6	1.3	27.9	1.8	1.7	20.3	1.9	2.1	15.1	2.2	2.5	11.2	2.5	3.0											
60	60.2	1.5	1.0	42.3	1.6	1.3	30.4	1.8	1.7	22.2	1.9	2.1	16.6	2.1	2.5	12.4	2.4	3.0											
65	65.2	1.5	1.0	45.8	1.6	1.3	32.9	1.8	1.7	24.0	1.9	2.1	18.0	2.1	2.5	13.6	2.4	3.0	8.9	3.1	3.5								
70	70.2	1.5	1.0	49.3	1.6	1.3	35.5	1.8	1.7	25.9	1.9	2.1	19.5	2.1	2.6	14.8	2.4	3.0	10.6	2.8	3.5								
75	75.2	1.5	1.0	52.8	1.6	1.3	38.0	1.8	1.7	28.2	1.9	2.1	20.9	2.1	2.6	16.0	2.3	3.0	11.5	2.8	3.5								
80	80.2	1.5	1.0	56.3	1.6	1.3	40.5	1.8	1.7	30.0	1.9	2.1	22.3	2.1	2.6	17.1	2.3	3.0	12.5	2.7	3.5								
85	85.2	1.5	1.0	59.8	1.6	1.3	43.0	1.8	1.7	31.9	1.9	2.1	23.7	2.1	2.6	18.3	2.3	3.0	13.5	2.7	3.6	9.8	3.3	3.9					
90	90.2	1.5	1.0	63.3	1.6	1.3	45.6	1.8	1.7	33.6	1.9	2.1	25.2	2.1	2.6	19.4	2.3	3.1	14.4	2.6	3.6	10.9	3.1	3.9					
95	95.2	1.5	1.0	66.9	1.6	1.3	48.1	1.8	1.7	35.5	1.9	2.1	26.6	2.1	2.6	20.5	2.3	3.1	15.3	2.6	3.6	12.0	3.0	3.9					
100	100.2	1.5	1.0	70.4	1.6	1.3	50.6	1.8	1.7	37.4	1.9	2.1	28.0	2.1	2.6	21.6	2.3	3.1	16.2	2.6	3.6	12.9	2.9	4.0					
105	105.3	1.5	1.0	73.9	1.6	1.3	53.1	1.8	1.7	39.2	1.9	2.1	29.8	2.1	2.6	22.8	2.3	3.1	17.1	2.6	3.6	13.7	2.9	4.0	10.8	3.4	4.3		
110	110.3	1.5	1.0	77.4	1.6	1.3	55.7	1.8	1.7	41.1	1.9	2.1	31.3	2.1	2.6	23.9	2.3	3.1	18.0	2.6	3.6	14.4	2.9	4.0	12.0	3.2	4.3		
115	115.3	1.5	1.0	80.9	1.6	1.3	58.2	1.8	1.7	42.9	1.9	2.1	32.7	2.1	2.6	25.0	2.3	3.1	18.9	2.5	3.6	15.2	2.8	4.0	12.7	3.2	4.3		
120	120.3	1.5	1.0	84.4	1.6	1.3	60.7	1.8	1.7	44.8	1.9	2.1	34.1	2.1	2.6	26.1	2.2	3.1	19.7	2.5	3.6	16.0	2.8	4.0	13.4	3.1	4.3		
125	125.3	1.5	1.0	88.0	1.6	1.3	63.2	1.8	1.7	46.7	1.9	2.1	35.5	2.1	2.6	27.2	2.2	3.1	20.6	2.5	3.6	16.8	2.8	4.0	14.1	3.1	4.3		
130	130.3	1.5	1.0	91.5	1.6	1.3	65.8	1.8	1.7	48.5	1.9	2.1	36.9	2.1	2.6	28.4	2.2	3.1	21.5	2.5	3.6	17.4	2.8	4.0	14.8	3.1	4.3		
135	135.3	1.5	1.0	95.0	1.6	1.3	68.3	1.8	1.7	50.4	1.9	2.1	38.3	2.1	2.6	29.5	2.2	3.1	22.4	2.5	3.6	18.2	2.8	4.0	15.5	3.0	4.3		
140	140.3	1.5	1.0	98.5	1.6	1.3	70.8	1.8	1.7	52.2	1.9	2.1	39.7	2.0	2.6	30.6	2.2	3.1	23.2	2.5	3.6	18.9	2.7	4.0	16.1	3.0	4.4		
145	145.3	1.5	1.0	102.0	1.6	1.3	73.3	1.8	1.7	54.1	1.9	2.1	41.1	2.0	2.6	32.1	2.2	3.0	24.1	2.5	3.6	19.7	2.7	4.0	16.8	3.0	4.4		
150	150.3	1.5	1.0	105.5	1.6	1.3	75.9	1.8	1.7	56.0	1.9	2.1	42.5	2.0	2.6	33.2	2.2	3.0	25.0	2.5	3.6	20.4	2.7	4.1	17.5	2.9	4.4		

RETARDANCE "D" AND "B"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-5 Parabolic Diversion Design Chart (Retardance "D" and "B," Grade 2.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "B"

Grade 2.00 Percent

Q CFS	V1=2.0			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																					
5	7.1	1.2	0.9																					
10	14.7	1.2	0.9	9.5	1.3	1.2	7.0	1.4	1.5															
15	22.0	1.2	0.9	14.5	1.3	1.2	10.9	1.4	1.5	8.0	1.5	1.6	5.5	1.9	2.1									
20	29.3	1.2	0.9	19.6	1.2	1.2	14.8	1.3	1.5	10.9	1.5	1.9	8.1	1.8	2.3	5.5	2.1	2.8						
25	36.6	1.2	0.9	24.4	1.2	1.2	18.5	1.3	1.5	13.8	1.4	1.9	10.4	1.6	2.3	7.9	1.9	2.7						
30	43.9	1.2	0.9	29.3	1.2	1.2	22.2	1.3	1.6	16.6	1.4	1.9	12.7	1.5	2.3	9.7	1.7	2.7						
35	51.2	1.2	0.9	34.2	1.2	1.2	25.8	1.3	1.6	19.6	1.4	1.9	14.9	1.5	2.3	11.5	1.7	2.7	8.9	1.9	3.2			
40	58.5	1.2	0.9	39.0	1.2	1.2	29.5	1.3	1.6	22.4	1.4	1.9	17.1	1.5	2.3	13.3	1.6	2.8	10.4	1.8	3.2	8.0	2.1	3.8
45	65.8	1.2	0.9	43.9	1.2	1.2	33.2	1.3	1.6	25.2	1.4	1.9	19.3	1.5	2.3	15.0	1.6	2.8	11.8	1.8	3.2	9.2	2.0	3.7
50	73.1	1.2	0.9	48.8	1.2	1.2	38.8	1.3	1.6	28.0	1.4	1.9	21.7	1.5	2.3	16.7	1.6	2.8	13.2	1.8	3.2	10.8	1.9	3.7
55	80.4	1.2	0.9	53.8	1.2	1.2	40.5	1.3	1.6	30.7	1.4	1.9	23.9	1.5	2.3	18.5	1.6	2.8	14.6	1.7	3.2	11.7	1.9	3.7
60	87.7	1.2	0.9	58.5	1.2	1.2	44.2	1.3	1.6	33.5	1.4	1.9	26.0	1.5	2.3	20.2	1.6	2.8	16.0	1.7	3.2	12.8	1.9	3.7
65	95.0	1.2	0.9	63.4	1.2	1.2	47.9	1.3	1.6	36.3	1.4	1.9	28.2	1.5	2.3	22.1	1.6	2.8	17.4	1.7	3.2	14.0	1.9	3.7
70	102.3	1.2	0.9	68.2	1.2	1.2	51.6	1.3	1.6	39.1	1.4	1.9	30.3	1.5	2.3	23.8	1.6	2.8	18.8	1.7	3.2	15.2	1.9	3.7
75	109.6	1.2	0.9	73.1	1.2	1.2	55.2	1.3	1.6	41.9	1.4	1.9	32.5	1.5	2.3	25.5	1.6	2.8	20.1	1.7	3.2	16.2	1.8	3.7
80	116.9	1.2	0.9	78.0	1.2	1.2	58.9	1.3	1.6	44.7	1.4	1.9	34.6	1.5	2.3	27.2	1.6	2.8	21.5	1.7	3.2	17.4	1.8	3.6
85	124.2	1.2	0.9	82.9	1.2	1.2	62.6	1.3	1.6	47.4	1.4	1.9	36.8	1.5	2.3	28.8	1.6	2.8	22.9	1.7	3.2	18.6	1.8	3.6
90	131.5	1.2	0.9	87.7	1.2	1.2	66.3	1.3	1.6	50.2	1.4	1.9	39.0	1.5	2.3	30.8	1.6	2.8	24.6	1.7	3.2	19.8	1.8	3.6
95	138.8	1.2	0.9	92.6	1.2	1.2	69.9	1.3	1.6	53.0	1.4	1.9	41.1	1.5	2.3	32.3	1.6	2.8	25.9	1.7	3.2	20.8	1.8	3.6
100	146.1	1.2	0.9	97.5	1.2	1.2	73.6	1.3	1.6	55.8	1.4	1.9	43.3	1.5	2.3	34.0	1.6	2.8	27.3	1.7	3.2	21.9	1.8	3.6
105	153.4	1.2	0.9	102.3	1.2	1.2	77.3	1.3	1.6	58.6	1.4	1.9	45.4	1.5	2.3	35.7	1.6	2.8	28.6	1.7	3.2	23.0	1.8	3.6
110	160.7	1.2	0.9	107.2	1.2	1.2	81.0	1.3	1.6	61.4	1.4	1.9	47.6	1.5	2.3	37.3	1.6	2.8	30.0	1.7	3.2	24.1	1.8	3.6
115	168.0	1.2	0.9	112.1	1.2	1.2	84.7	1.3	1.6	64.2	1.4	1.9	49.8	1.5	2.3	39.0	1.6	2.8	31.3	1.7	3.2	25.3	1.8	3.6
120	175.3	1.2	0.9	117.0	1.2	1.2	88.3	1.3	1.6	67.0	1.4	1.9	51.9	1.5	2.3	40.7	1.6	2.8	32.7	1.7	3.2	26.7	1.8	3.7
125	182.6	1.2	0.9	121.8	1.2	1.2	92.0	1.3	1.6	69.7	1.4	1.9	54.1	1.5	2.3	42.4	1.6	2.8	34.1	1.7	3.2	27.8	1.8	3.7
130	189.9	1.2	0.9	126.7	1.2	1.2	95.7	1.3	1.6	72.5	1.4	1.9	56.2	1.5	2.3	44.1	1.6	2.8	35.4	1.7	3.2	28.9	1.8	3.7
135	197.3	1.2	0.9	131.6	1.2	1.2	99.4	1.3	1.6	75.3	1.4	1.9	58.4	1.5	2.3	45.8	1.6	2.8	36.8	1.7	3.2	30.0	1.8	3.7
140	204.6	1.2	0.9	136.5	1.2	1.2	103.1	1.3	1.6	78.1	1.4	1.9	60.6	1.5	2.3	47.5	1.6	2.8	38.1	1.7	3.2	31.1	1.8	3.7
145	211.9	1.2	0.9	141.3	1.2	1.2	106.7	1.3	1.6	80.9	1.4	1.9	62.7	1.5	2.3	49.2	1.6	2.8	39.5	1.7	3.2	32.3	1.8	3.7
150	219.2	1.2	0.9	146.2	1.2	1.2	110.4	1.3	1.6	83.7	1.4	1.9	64.9	1.5	2.3	50.9	1.6	2.8	40.8	1.7	3.2	33.4	1.8	3.7

RETARDANCE "D" AND "B"

NOTE: Width and Depth dimensions are in feet. Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-6 Parabolic Diversion Design Chart (Retardance "D" and "B," Grade 4.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "B"
Grade 4.00 Percent

Q CFE	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	10.1	0.9	0.8	7.9	1.0	1.1	4.9	1.1	1.4																		
10	20.8	0.9	0.8	14.4	0.9	1.1	10.3	1.0	1.4	7.9	1.1	1.2	5.1	1.2	2.1	4.5	1.4	2.4									
15	30.7	0.9	0.8	21.5	0.9	1.1	15.7	1.0	1.4	12.0	1.1	1.2	9.4	1.1	2.1	7.4	1.2	2.5	6.8	1.4	2.8						
20	40.9	0.9	0.8	28.6	0.9	1.1	20.9	1.0	1.4	16.3	1.0	1.2	12.8	1.1	2.1	10.1	1.2	2.5	8.0	1.3	2.9	8.3	1.4	3.3			
25	51.1	0.9	0.8	35.8	0.9	1.1	26.1	1.0	1.4	20.3	1.0	1.2	18.0	1.1	2.1	12.7	1.2	2.5	10.2	1.3	2.9	8.2	1.4	3.4	8.5	1.5	3.8
30	61.3	0.9	0.8	42.9	0.9	1.1	31.4	1.0	1.4	24.4	1.0	1.2	19.2	1.1	2.1	15.2	1.2	2.5	12.3	1.3	2.9	10.0	1.3	3.4	8.1	1.5	3.8
35	71.5	0.9	0.8	50.1	0.9	1.1	36.6	1.0	1.4	28.3	1.0	1.2	22.4	1.1	2.1	18.0	1.2	2.5	14.4	1.2	2.9	11.7	1.3	3.4	8.8	1.4	3.8
40	81.8	0.9	0.8	57.2	0.9	1.1	41.8	1.0	1.5	32.4	1.0	1.2	25.6	1.1	2.1	20.6	1.2	2.8	16.5	1.2	2.9	13.5	1.3	3.4	11.1	1.4	3.8
45	92.0	0.9	0.8	64.4	0.9	1.1	47.0	1.0	1.5	36.4	1.0	1.2	28.8	1.1	2.1	23.1	1.2	2.8	18.8	1.2	2.9	15.2	1.3	3.4	12.8	1.4	3.9
50	102.2	0.9	0.8	71.5	0.9	1.1	52.2	1.0	1.5	40.5	1.0	1.2	32.0	1.1	2.1	25.7	1.2	2.8	20.9	1.2	2.9	17.0	1.3	3.4	14.0	1.4	3.9
55	112.4	0.9	0.8	78.7	0.9	1.1	57.5	1.0	1.5	44.5	1.0	1.2	35.2	1.1	2.1	28.2	1.2	2.8	23.0	1.2	2.9	18.9	1.3	3.4	15.4	1.4	3.9
60	122.6	0.9	0.8	85.8	0.9	1.1	62.7	1.0	1.5	48.5	1.0	1.2	38.4	1.1	2.2	30.8	1.2	2.8	25.1	1.2	2.9	20.8	1.3	3.4	16.9	1.4	3.9
65	132.8	0.9	0.8	93.0	0.9	1.1	67.9	1.0	1.5	52.8	1.0	1.2	41.5	1.1	2.2	33.4	1.2	2.8	27.2	1.2	2.9	22.3	1.3	3.4	18.3	1.4	3.9
70	143.1	0.9	0.8	100.1	0.9	1.1	73.1	1.0	1.5	56.8	1.0	1.2	44.7	1.1	2.2	35.9	1.2	2.8	29.2	1.2	2.9	24.0	1.3	3.4	20.0	1.4	3.9
75	153.3	0.9	0.8	107.3	0.9	1.1	78.3	1.0	1.5	60.7	1.0	1.2	47.9	1.1	2.2	38.5	1.2	2.8	31.3	1.2	2.9	25.7	1.3	3.4	21.4	1.4	3.9
80	163.5	0.9	0.8	114.4	0.9	1.1	83.5	1.0	1.5	64.7	1.0	1.2	51.1	1.1	2.2	41.0	1.2	2.8	33.4	1.2	2.9	27.4	1.3	3.4	22.8	1.4	3.9
85	173.7	0.9	0.8	121.6	0.9	1.1	88.5	1.0	1.5	68.8	1.0	1.2	54.3	1.1	2.2	43.6	1.2	2.8	35.5	1.2	2.9	29.1	1.3	3.4	24.2	1.4	3.9
90	183.9	0.9	0.8	128.7	0.9	1.1	94.0	1.0	1.5	72.8	1.0	1.2	57.5	1.1	2.2	46.2	1.2	2.8	37.6	1.2	2.9	30.8	1.3	3.4	25.7	1.4	3.9
95	194.1	0.9	0.8	135.9	0.9	1.1	99.2	1.0	1.5	76.8	1.0	1.2	60.7	1.1	2.2	48.7	1.2	2.8	39.7	1.2	2.9	32.5	1.3	3.4	27.1	1.4	3.9
100	204.4	0.9	0.8	143.0	0.9	1.1	104.4	1.0	1.5	80.9	1.0	1.2	63.9	1.1	2.2	51.3	1.2	2.8	41.7	1.2	2.9	34.2	1.3	3.4	28.5	1.3	3.9
105	214.6	0.9	0.8	150.2	0.9	1.1	109.7	1.0	1.5	84.9	1.0	1.2	67.1	1.1	2.2	53.9	1.2	2.8	43.8	1.2	2.9	35.9	1.3	3.4	29.9	1.3	3.9
110	224.8	0.9	0.8	157.4	0.9	1.1	114.9	1.0	1.5	89.0	1.0	1.2	70.3	1.1	2.2	56.4	1.2	2.8	45.9	1.2	2.9	37.6	1.3	3.4	31.3	1.3	3.9
115	235.0	0.9	0.8	164.5	0.9	1.1	120.1	1.0	1.5	93.0	1.0	1.2	73.5	1.1	2.2	59.0	1.2	2.8	48.0	1.2	2.9	39.3	1.3	3.4	32.7	1.3	3.9
120	245.2	0.9	0.8	171.7	0.9	1.1	125.3	1.0	1.5	97.1	1.0	1.2	76.7	1.1	2.2	61.5	1.2	2.8	49.9	1.2	3.0	41.0	1.3	3.4	34.2	1.3	3.9
125	255.5	0.9	0.8	178.8	0.9	1.1	130.5	1.0	1.5	101.1	1.0	1.2	79.9	1.1	2.2	64.1	1.2	2.8	52.0	1.2	3.0	42.7	1.3	3.4	35.6	1.3	3.9
130	265.7	0.9	0.8	186.0	0.9	1.1	135.8	1.0	1.5	105.1	1.0	1.2	83.0	1.1	2.2	66.7	1.2	2.8	54.1	1.2	3.0	44.4	1.3	3.4	37.0	1.3	3.9
135	275.9	0.9	0.8	193.1	0.9	1.1	141.0	1.0	1.5	109.2	1.0	1.2	86.2	1.1	2.2	69.2	1.2	2.8	56.1	1.2	3.0	46.1	1.3	3.4	38.4	1.3	3.9
140	286.1	0.9	0.8	200.3	0.9	1.1	146.2	1.0	1.5	113.2	1.0	1.2	89.4	1.1	2.2	71.8	1.2	2.8	58.2	1.2	3.0	47.8	1.3	3.4	39.9	1.3	3.9
145	296.3	0.9	0.8	207.4	0.9	1.1	151.4	1.0	1.5	117.3	1.0	1.2	92.6	1.1	2.2	74.4	1.2	2.8	60.3	1.2	3.0	49.6	1.3	3.4	41.3	1.3	3.9
150	306.5	0.9	0.8	214.6	0.9	1.1	156.7	1.0	1.5	121.5	1.0	1.2	95.8	1.1	2.2	76.9	1.2	2.8	62.4	1.2	3.0	51.3	1.3	3.4	42.7	1.3	3.9

RETARDANCE "D" AND "B"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
 Depth "D" does not include allowance for freeboard or settlement.

Table DV-7 Parabolic Diversion Design Chart (Retardance "D" and "B," Grade 6.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "B"
Grade 6.00 Percent

Q CFB	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	12.4	0.7	0.8	8.7	0.8	1.0	6.2	0.9	1.4	4.7	1.0	1.8	3.5	1.2	1.9												
10	24.7	0.7	0.8	17.6	0.8	1.0	12.8	0.9	1.4	9.8	0.9	1.7	7.8	1.0	2.0	5.2	1.0	2.3	4.9	1.1	2.7						
15	37.1	0.7	0.8	26.4	0.9	1.1	19.2	0.8	1.4	15.0	0.9	1.7	11.8	0.9	2.0	9.5	1.0	2.4	7.7	1.1	2.7	6.2	1.2	3.1	5.0	1.3	3.5
20	49.4	0.7	0.8	35.1	0.8	1.1	25.8	0.8	1.4	19.0	0.9	1.7	16.0	0.9	2.0	12.9	1.0	2.4	10.4	1.0	2.8	8.5	1.1	3.2	7.0	1.2	3.6
25	61.8	0.7	0.8	43.9	0.8	1.1	32.0	0.8	1.4	24.9	0.9	1.7	18.9	0.9	2.0	16.1	1.0	2.4	13.1	1.0	2.8	10.8	1.1	3.2	10.8	1.1	3.6
30	74.1	0.7	0.8	52.7	0.8	1.1	38.4	0.8	1.4	29.9	0.9	1.7	23.8	0.9	2.1	19.3	1.0	2.4	15.9	1.0	2.8	13.0	1.1	3.2	10.8	1.1	3.6
35	86.5	0.7	0.8	61.5	0.8	1.1	44.8	0.8	1.4	34.8	0.9	1.7	27.8	0.9	2.1	22.5	1.0	2.4	18.5	1.0	2.8	15.4	1.1	3.2	12.7	1.1	3.6
40	98.9	0.7	0.8	70.2	0.8	1.1	51.2	0.8	1.4	38.6	0.9	1.7	31.8	0.9	2.1	25.7	1.0	2.4	21.2	1.0	2.8	17.8	1.1	3.2	14.5	1.1	3.6
45	111.2	0.7	0.8	79.0	0.8	1.1	57.8	0.8	1.4	44.8	0.9	1.7	35.7	0.9	2.1	29.0	1.0	2.4	23.8	1.0	2.8	19.8	1.1	3.2	16.6	1.1	3.6
50	123.6	0.7	0.8	87.8	0.8	1.1	64.0	0.8	1.4	48.7	0.9	1.7	39.7	0.9	2.1	32.2	1.0	2.4	26.4	1.0	2.8	22.0	1.1	3.2	18.4	1.1	3.6
55	136.0	0.7	0.8	96.6	0.8	1.1	70.4	0.8	1.4	54.7	0.9	1.7	43.6	0.9	2.1	36.4	1.0	2.4	29.1	1.0	2.8	24.2	1.1	3.2	20.2	1.1	3.7
60	148.3	0.7	0.8	105.3	0.8	1.1	76.8	0.8	1.4	59.7	0.9	1.7	47.6	0.9	2.1	38.9	1.0	2.4	31.7	1.0	2.8	26.3	1.1	3.2	22.0	1.1	3.7
65	160.6	0.7	0.8	114.1	0.8	1.1	83.2	0.8	1.4	64.7	0.9	1.7	51.6	0.9	2.1	41.8	1.0	2.4	34.3	1.0	2.8	28.5	1.1	3.2	23.8	1.1	3.7
70	173.0	0.7	0.8	122.9	0.8	1.1	89.6	0.8	1.4	69.8	0.9	1.7	55.5	0.9	2.1	45.0	1.0	2.4	37.0	1.0	2.8	30.7	1.1	3.2	25.6	1.1	3.7
75	185.4	0.7	0.8	131.7	0.8	1.1	96.0	0.8	1.4	74.8	0.9	1.7	59.5	0.9	2.1	48.2	1.0	2.4	39.8	1.0	2.8	32.9	1.1	3.2	27.4	1.1	3.7
80	197.7	0.7	0.8	140.4	0.8	1.1	102.3	0.8	1.4	79.8	0.9	1.7	63.5	0.9	2.1	51.4	1.0	2.4	42.2	1.0	2.8	35.1	1.1	3.2	29.3	1.1	3.7
85	210.1	0.7	0.8	149.2	0.8	1.1	108.7	0.8	1.4	84.5	0.9	1.7	67.4	0.9	2.1	54.7	1.0	2.4	44.9	1.0	2.8	37.3	1.1	3.2	31.1	1.1	3.7
90	222.4	0.7	0.8	158.0	0.8	1.1	115.1	0.8	1.4	89.5	0.9	1.7	71.4	0.9	2.1	57.9	1.0	2.4	47.5	1.0	2.8	39.5	1.1	3.2	32.9	1.1	3.7
95	234.8	0.7	0.8	166.8	0.8	1.1	121.5	0.8	1.4	94.5	0.9	1.7	75.4	0.9	2.1	61.1	1.0	2.4	50.2	1.0	2.8	41.7	1.1	3.2	34.7	1.1	3.7
100	247.1	0.7	0.8	175.5	0.8	1.1	127.9	0.8	1.4	99.5	0.9	1.7	79.3	0.9	2.1	64.3	1.0	2.4	52.8	1.0	2.8	43.9	1.1	3.2	36.6	1.1	3.7
105	259.5	0.7	0.8	184.3	0.8	1.1	134.3	0.8	1.4	104.4	0.9	1.7	83.3	0.9	2.1	67.5	1.0	2.4	55.4	1.0	2.8	46.1	1.1	3.2	38.4	1.1	3.7
110	271.8	0.7	0.8	193.1	0.8	1.1	140.7	0.8	1.4	109.4	0.9	1.7	87.3	0.9	2.1	70.7	1.0	2.4	58.1	1.0	2.8	48.2	1.1	3.2	40.2	1.1	3.7
115	284.2	0.7	0.8	201.9	0.8	1.1	147.1	0.8	1.4	114.4	0.9	1.7	91.2	0.9	2.1	73.9	1.0	2.4	60.7	1.0	2.8	50.4	1.1	3.2	42.0	1.1	3.7
120	296.6	0.7	0.8	210.7	0.8	1.1	153.5	0.8	1.4	119.3	0.9	1.7	95.2	0.9	2.1	77.2	1.0	2.4	63.3	1.0	2.8	52.6	1.1	3.2	43.9	1.1	3.7
125	308.9	0.7	0.8	219.4	0.8	1.1	159.8	0.8	1.4	124.3	0.9	1.7	99.2	0.9	2.1	80.4	1.0	2.4	66.0	1.0	2.8	54.8	1.1	3.2	45.7	1.1	3.7
130	321.3	0.7	0.8	228.2	0.8	1.1	166.2	0.8	1.4	129.3	0.9	1.7	103.1	0.9	2.1	83.6	1.0	2.4	68.8	1.0	2.8	57.0	1.1	3.2	47.5	1.1	3.7
135	333.6	0.7	0.8	237.0	0.8	1.1	172.7	0.8	1.4	134.3	0.9	1.7	107.1	0.9	2.1	86.8	1.0	2.4	71.3	1.0	2.8	59.2	1.1	3.2	49.3	1.1	3.7
140	346.0	0.7	0.8	245.8	0.8	1.1	179.1	0.8	1.4	139.2	0.9	1.7	111.0	0.9	2.1	90.0	1.0	2.4	73.9	1.0	2.8	61.4	1.1	3.2	51.2	1.1	3.7
145	358.3	0.7	0.8	254.5	0.8	1.1	185.5	0.8	1.4	144.2	0.9	1.7	115.0	0.9	2.1	93.2	1.0	2.4	76.5	1.0	2.8	63.6	1.1	3.2	53.0	1.1	3.7
150	370.7	0.7	0.8	263.3	0.8	1.1	191.9	0.8	1.4	149.2	0.9	1.7	119.0	0.9	2.1	96.4	1.0	2.4	79.2	1.0	2.8	65.8	1.1	3.2	54.8	1.1	3.7

RETARDANCE "D" AND "B"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second.
Depth "D" does not include allowances for freeboard or settlement.

Table DV-8 Parabolic Diversion Design Chart (Retardance "D" and "B," Grade 8.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "B"
Grade 8.00 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0			
	T	D	V2																									
5	14.0	0.7	0.8	10.1	0.7	1.0	7.4	0.6	1.3	5.5	0.6	1.8	4.4	0.6	1.9	3.4	1.0	2.1										
10	26.0	0.7	0.8	20.1	0.7	1.0	15.0	0.6	1.3	11.3	0.6	1.7	8.1	0.6	2.0	7.4	0.9	2.3	6.0	0.9	2.6	4.9	1.0	3.0	3.6	1.2	3.3	
15	41.9	0.7	0.8	30.1	0.7	1.0	22.4	0.6	1.3	17.0	0.6	1.7	13.9	0.6	2.0	11.4	0.9	2.3	9.2	0.9	2.7	7.8	1.0	3.0	6.3	1.0	3.4	
20	65.8	0.7	0.8	40.1	0.7	1.0	29.0	0.6	1.3	22.6	0.6	1.7	18.5	0.6	2.0	15.1	0.9	2.3	12.5	0.9	2.7	10.2	1.0	3.1	8.5	1.0	3.5	
25	89.9	0.7	0.8	50.1	0.7	1.0	37.3	0.6	1.3	28.2	0.6	1.7	23.1	0.6	2.0	18.8	0.9	2.3	15.6	0.9	2.7	13.0	0.9	3.1	10.8	1.0	3.5	
30	113.9	0.7	0.8	60.1	0.7	1.0	44.8	0.6	1.3	33.9	0.6	1.7	27.7	0.6	2.0	22.0	0.9	2.3	18.8	0.9	2.7	15.9	0.9	3.1	13.0	1.0	3.5	
35	137.9	0.7	0.8	70.1	0.7	1.0	52.3	0.6	1.3	39.5	0.6	1.7	32.3	0.6	2.0	26.3	0.9	2.3	21.7	0.9	2.7	18.2	0.9	3.1	15.3	1.0	3.5	
40	161.8	0.7	0.8	80.2	0.7	1.0	60.7	0.6	1.3	45.1	0.6	1.7	36.9	0.6	2.0	30.1	0.9	2.3	24.8	0.9	2.7	20.8	0.9	3.1	17.5	1.0	3.5	
45	185.8	0.7	0.8	90.2	0.7	1.0	67.2	0.6	1.3	50.6	0.6	1.7	41.5	0.6	2.0	33.6	0.9	2.3	27.9	0.9	2.7	23.3	0.9	3.1	19.7	1.0	3.5	
50	209.8	0.7	0.8	100.2	0.7	1.0	74.7	0.6	1.3	56.4	0.6	1.7	46.1	0.6	2.0	37.6	0.9	2.3	31.0	0.9	2.7	25.9	0.9	3.1	21.9	1.0	3.5	
55	233.8	0.7	0.8	110.2	0.7	1.0	82.1	0.6	1.3	62.1	0.6	1.7	50.7	0.6	2.0	41.3	0.9	2.3	34.1	0.9	2.7	28.5	0.9	3.1	24.0	1.0	3.5	
60	257.8	0.7	0.8	120.2	0.7	1.0	89.6	0.6	1.3	67.7	0.6	1.7	55.3	0.6	2.0	45.1	0.9	2.3	37.2	0.9	2.7	31.1	0.9	3.1	26.2	1.0	3.5	
65	281.7	0.7	0.8	130.3	0.7	1.0	97.0	0.6	1.3	73.3	0.6	1.7	60.0	0.6	2.0	48.8	0.9	2.3	40.3	0.9	2.7	33.7	0.9	3.1	28.4	1.0	3.5	
70	305.7	0.7	0.8	140.3	0.7	1.0	104.5	0.6	1.3	79.0	0.6	1.7	64.6	0.6	2.0	52.8	0.9	2.3	43.4	0.9	2.7	36.3	0.9	3.1	30.6	1.0	3.5	
75	329.7	0.7	0.8	150.3	0.7	1.0	112.0	0.6	1.3	84.8	0.6	1.7	69.2	0.6	2.0	56.3	0.9	2.3	46.6	0.9	2.7	38.9	0.9	3.1	32.8	1.0	3.5	
80	353.7	0.7	0.8	160.3	0.7	1.0	119.4	0.6	1.3	90.3	0.6	1.7	73.8	0.6	2.0	60.1	0.9	2.3	49.8	0.9	2.7	41.4	0.9	3.1	36.0	1.0	3.5	
85	377.7	0.7	0.8	170.3	0.7	1.0	126.9	0.6	1.3	95.9	0.6	1.7	78.4	0.6	2.0	63.8	0.9	2.3	52.7	0.9	2.7	44.0	0.9	3.1	37.1	1.0	3.5	
90	401.8	0.7	0.8	180.3	0.7	1.0	134.4	0.6	1.3	101.8	0.6	1.7	83.0	0.6	2.0	67.6	0.9	2.3	55.6	0.9	2.7	46.6	0.9	3.1	39.3	1.0	3.5	
95	425.8	0.7	0.8	190.4	0.7	1.0	141.8	0.6	1.3	107.2	0.6	1.7	87.6	0.6	2.0	71.5	0.9	2.3	58.8	0.9	2.7	49.2	0.9	3.1	41.5	1.0	3.5	
100	449.8	0.7	0.8	200.4	0.7	1.0	149.3	0.6	1.3	112.6	0.6	1.7	92.2	0.6	2.0	75.1	0.9	2.3	62.0	0.9	2.7	51.8	0.9	3.1	43.7	1.0	3.5	
105	473.8	0.7	0.8	210.4	0.7	1.0	156.8	0.6	1.3	118.5	0.6	1.7	96.8	0.6	2.0	78.9	0.9	2.3	65.1	0.9	2.7	54.4	0.9	3.1	45.9	1.0	3.5	
110	497.8	0.7	0.8	220.4	0.7	1.0	164.2	0.6	1.3	124.1	0.6	1.7	101.4	0.6	2.0	82.6	0.9	2.3	68.2	0.9	2.7	57.0	0.9	3.1	48.0	1.0	3.5	
115	521.8	0.7	0.8	230.4	0.7	1.0	171.7	0.6	1.3	129.8	0.6	1.7	106.1	0.6	2.0	86.4	0.9	2.3	71.3	0.9	2.7	59.6	0.9	3.1	50.2	1.0	3.5	
120	545.8	0.7	0.8	240.5	0.7	1.0	179.1	0.6	1.3	135.4	0.6	1.7	110.7	0.6	2.0	90.1	0.9	2.3	74.4	0.9	2.7	62.2	0.9	3.1	52.4	1.0	3.5	
125	569.8	0.7	0.8	250.5	0.7	1.0	186.6	0.6	1.3	141.0	0.6	1.7	115.3	0.6	2.0	93.9	0.9	2.3	77.5	0.9	2.7	64.7	0.9	3.1	54.6	1.0	3.5	
130	593.8	0.7	0.8	260.6	0.7	1.0	194.1	0.6	1.3	146.7	0.6	1.7	119.9	0.6	2.0	97.6	0.9	2.3	80.6	0.9	2.7	67.3	0.9	3.1	56.8	1.0	3.5	
135	617.8	0.7	0.8	270.5	0.7	1.0	201.5	0.6	1.3	152.3	0.6	1.7	124.5	0.6	2.0	101.4	0.9	2.3	83.7	0.9	2.7	70.9	0.9	3.1	59.0	1.0	3.5	
140	641.8	0.7	0.8	280.5	0.7	1.0	208.0	0.6	1.3	158.0	0.6	1.7	129.1	0.6	2.0	105.1	0.9	2.3	86.8	0.9	2.7	72.5	0.9	3.1	61.1	1.0	3.5	
145	665.8	0.7	0.8	290.6	0.7	1.0	216.5	0.6	1.3	163.5	0.6	1.7	133.7	0.6	2.0	108.9	0.9	2.3	89.9	0.9	2.7	75.1	0.9	3.1	63.3	1.0	3.5	
150	689.8	0.7	0.8	300.6	0.7	1.0	223.9	0.6	1.3	169.3	0.6	1.7	138.3	0.6	2.0	112.6	0.9	2.3	93.0	0.9	2.7	77.7	0.9	3.1	65.5	1.0	3.5	

RETARDANCE "D" AND "B"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-9 Parabolic Diversion Design Chart (Retardance "D" and "B," Grade 10.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "B"
Grade 10.00 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	15.3	0.6	0.8	11.1	0.7	1.0	8.1	0.7	1.3	6.3	0.7	1.6	4.6	0.8	1.9	4.0	0.8	2.2	3.1	1.0	2.4						
10	30.6	0.6	0.8	22.1	0.7	1.0	16.5	0.7	1.3	12.8	0.7	1.6	10.0	0.8	2.0	8.4	0.8	2.2	6.9	0.8	2.6	5.7	0.9	2.9	4.7	1.0	3.3
15	46.9	0.6	0.8	33.2	0.7	1.0	24.7	0.7	1.3	19.2	0.7	1.6	15.0	0.8	2.0	12.7	0.8	2.2	10.5	0.8	2.8	8.7	0.9	3.0	7.3	0.9	3.3
20	61.2	0.6	0.8	44.2	0.7	1.0	32.0	0.7	1.3	25.6	0.7	1.6	20.0	0.8	2.0	17.0	0.8	2.2	14.1	0.8	2.8	11.8	0.9	3.0	9.8	0.9	3.4
25	75.5	0.6	0.8	55.3	0.7	1.0	41.1	0.7	1.3	32.0	0.7	1.6	25.0	0.8	2.0	21.3	0.8	2.3	17.9	0.8	2.8	14.7	0.9	3.0	12.6	0.9	3.4
30	91.8	0.6	0.8	63.3	0.7	1.0	49.3	0.7	1.3	38.3	0.7	1.6	29.9	0.8	2.0	28.4	0.8	2.3	21.1	0.8	2.8	17.7	0.8	3.0	15.0	0.9	3.3
35	107.1	0.6	0.8	77.4	0.7	1.0	57.5	0.7	1.3	44.7	0.7	1.6	34.9	0.8	2.0	29.7	0.8	2.3	24.5	0.8	2.8	20.6	0.8	3.0	17.5	0.9	3.4
40	122.4	0.6	0.8	88.4	0.7	1.0	66.7	0.7	1.3	51.1	0.7	1.6	38.8	0.8	2.0	33.9	0.8	2.3	26.1	0.8	2.6	23.5	0.8	3.0	20.0	0.9	3.4
45	137.8	0.6	0.8	99.5	0.7	1.0	73.9	0.7	1.3	57.8	0.7	1.6	44.9	0.8	2.0	38.0	0.8	2.3	31.5	0.8	2.6	28.5	0.8	3.0	22.5	0.9	3.4
50	153.1	0.6	0.8	110.6	0.7	1.0	82.1	0.7	1.3	63.9	0.7	1.6	48.9	0.8	2.0	42.2	0.8	2.3	35.1	0.8	2.8	29.4	0.8	3.0	25.0	0.9	3.4
55	168.4	0.6	0.8	121.8	0.7	1.0	90.3	0.7	1.3	70.3	0.7	1.6	54.9	0.8	2.0	48.4	0.8	2.3	38.6	0.8	2.6	32.3	0.8	3.0	27.5	0.9	3.4
60	183.7	0.6	0.8	132.7	0.7	1.0	98.6	0.7	1.3	76.7	0.7	1.6	59.9	0.8	2.0	53.7	0.8	2.3	42.1	0.8	2.6	35.3	0.8	3.0	30.0	0.9	3.4
65	199.0	0.6	0.8	143.7	0.7	1.0	106.7	0.7	1.3	83.1	0.7	1.6	64.8	0.8	2.0	54.9	0.8	2.3	45.6	0.8	2.6	38.2	0.8	3.0	32.5	0.9	3.4
70	214.3	0.6	0.8	154.8	0.7	1.0	115.0	0.7	1.3	89.4	0.7	1.6	69.8	0.8	2.0	59.1	0.8	2.3	48.1	0.8	2.6	41.2	0.8	3.0	35.0	0.9	3.4
75	229.6	0.6	0.8	165.8	0.7	1.0	123.2	0.7	1.3	95.8	0.7	1.6	74.8	0.8	2.0	63.3	0.8	2.3	52.6	0.8	2.8	44.1	0.8	3.0	37.4	0.9	3.4
80	244.9	0.6	0.8	176.9	0.7	1.0	131.4	0.7	1.3	102.2	0.7	1.6	79.8	0.8	2.0	67.6	0.8	2.3	56.1	0.8	2.8	47.0	0.8	3.0	39.9	0.9	3.4
85	260.2	0.6	0.8	187.9	0.7	1.0	139.6	0.7	1.3	108.6	0.7	1.6	84.8	0.8	2.0	71.8	0.8	2.3	59.5	0.8	2.8	50.0	0.8	3.0	42.3	0.9	3.4
90	275.5	0.6	0.8	199.0	0.7	1.0	147.8	0.7	1.3	115.0	0.7	1.6	89.8	0.8	2.0	76.0	0.8	2.3	63.1	0.8	2.6	52.9	0.8	3.0	44.8	0.9	3.4
95	290.8	0.6	0.8	210.0	0.7	1.0	156.0	0.7	1.3	121.4	0.7	1.6	94.8	0.8	2.0	80.2	0.8	2.3	66.6	0.8	2.6	55.8	0.8	3.0	47.3	0.9	3.4
100	306.1	0.6	0.8	221.1	0.7	1.0	164.2	0.7	1.3	127.8	0.7	1.6	99.8	0.8	2.0	84.4	0.8	2.3	70.1	0.8	2.8	58.8	0.8	3.0	49.7	0.9	3.4
105	321.4	0.6	0.8	232.2	0.7	1.0	172.4	0.7	1.3	134.2	0.7	1.6	104.7	0.8	2.0	88.7	0.8	2.3	73.6	0.8	2.8	61.7	0.8	3.0	52.2	0.9	3.4
110	336.7	0.6	0.8	243.2	0.7	1.0	180.6	0.7	1.3	140.5	0.7	1.6	109.7	0.8	2.0	92.9	0.8	2.3	77.1	0.8	2.8	64.7	0.8	3.0	54.7	0.9	3.4
115	352.0	0.6	0.8	254.3	0.7	1.0	188.8	0.7	1.3	146.9	0.7	1.6	114.7	0.8	2.0	97.1	0.8	2.3	80.6	0.8	2.6	67.5	0.8	3.0	57.2	0.9	3.4
120	367.3	0.6	0.8	265.3	0.7	1.0	197.1	0.7	1.3	153.3	0.7	1.6	119.7	0.8	2.0	101.3	0.8	2.3	84.1	0.8	2.8	70.5	0.8	3.0	59.7	0.9	3.4
125	382.6	0.6	0.8	276.4	0.7	1.0	205.3	0.7	1.3	159.7	0.7	1.6	124.7	0.8	2.0	105.0	0.8	2.3	87.6	0.8	2.8	73.5	0.8	3.0	62.2	0.9	3.4
130	397.9	0.6	0.8	287.4	0.7	1.0	213.5	0.7	1.3	166.1	0.7	1.6	129.7	0.8	2.0	109.0	0.8	2.3	91.1	0.8	2.8	76.4	0.8	3.0	64.7	0.9	3.4
135	413.2	0.6	0.8	298.5	0.7	1.0	221.7	0.7	1.3	172.5	0.7	1.6	134.7	0.8	2.0	114.0	0.8	2.3	94.6	0.8	2.8	79.3	0.8	3.0	67.2	0.9	3.4
140	428.5	0.6	0.8	308.5	0.7	1.0	229.9	0.7	1.3	178.9	0.7	1.6	139.7	0.8	2.0	118.2	0.8	2.3	98.1	0.8	2.8	82.3	0.8	3.0	69.8	0.9	3.4
145	443.9	0.6	0.8	320.6	0.7	1.0	238.1	0.7	1.3	185.3	0.7	1.6	144.8	0.8	2.0	122.4	0.8	2.3	101.7	0.8	2.8	85.2	0.8	3.0	72.1	0.9	3.4
150	458.2	0.6	0.8	331.7	0.7	1.0	246.3	0.7	1.3	191.8	0.7	1.6	149.6	0.8	2.0	126.7	0.8	2.3	105.2	0.8	2.8	88.2	0.9	3.0	74.6	0.9	3.4

RETARDANCE "D" AND "B"

NOTE: Width and Depth dimensions are in feet. Velocity measurements are in feet per second.
 Depth "D" does not include allowance for freeboard or settlement.

Table DV-10 Parabolic Diversion Design Chart (Retardance "D" and "C," Grade .50%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"
Grade 0.50 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0			
	T	D	V2	T	D	V2	T	D	V2																			
5																												
10																												
15	8.4	1.6	1.7																									
20	11.7	1.5	1.7	7.1	2.0	2.2																						
25	14.9	1.5	1.7	9.7	1.8	2.2																						
30	18.0	1.5	1.7	12.0	1.7	2.2																						
35	21.0	1.5	1.7	14.2	1.7	2.2	9.3	2.1	2.7																			
40	24.4	1.5	1.7	16.3	1.7	2.2	10.9	2.0	2.7																			
45	27.4	1.5	1.7	18.5	1.7	2.2	12.5	2.0	2.7																			
50	30.5	1.5	1.7	20.6	1.7	2.2	14.1	1.9	2.7	8.7	2.6	3.3																
55	33.5	1.5	1.7	22.7	1.7	2.2	15.7	1.9	2.7	10.4	2.4	3.3																
60	36.6	1.5	1.7	24.8	1.7	2.2	17.2	1.9	2.7	11.7	2.3	3.3																
65	39.6	1.5	1.7	27.3	1.7	2.2	18.8	1.9	2.7	12.9	2.3	3.3																
70	42.6	1.5	1.7	29.4	1.7	2.2	20.3	1.9	2.7	14.0	2.2	3.3	9.8	2.8	3.8													
75	45.7	1.5	1.7	31.4	1.7	2.2	21.8	1.9	2.7	15.2	2.2	3.3	11.3	2.7	3.8													
80	48.7	1.5	1.7	33.5	1.7	2.2	23.3	1.9	2.7	16.3	2.2	3.3	12.2	2.6	3.8													
85	51.7	1.5	1.7	35.6	1.6	2.2	24.8	1.9	2.7	17.4	2.2	3.3	13.2	2.5	3.8													
90	54.8	1.5	1.7	37.7	1.6	2.2	26.3	1.9	2.7	18.5	2.2	3.3	14.2	2.5	3.8													
95	57.8	1.5	1.7	39.8	1.6	2.2	27.8	1.9	2.7	19.6	2.2	3.3	15.1	2.5	3.8													
100	60.9	1.5	1.7	41.9	1.6	2.2	29.7	1.9	2.7	20.7	2.2	3.3	16.0	2.5	3.8	11.0	3.2	4.3										
105	63.9	1.5	1.7	44.0	1.6	2.2	31.2	1.9	2.7	21.8	2.2	3.3	16.9	2.5	3.8	12.3	3.0	4.3										
110	66.9	1.5	1.7	46.1	1.6	2.2	32.6	1.9	2.7	22.9	2.2	3.3	17.8	2.4	3.8	13.1	2.9	4.3										
115	70.0	1.5	1.7	48.1	1.6	2.2	34.1	1.9	2.7	24.0	2.1	3.3	18.7	2.4	3.8	13.9	2.9	4.3										
120	73.0	1.5	1.7	50.2	1.6	2.2	35.6	1.9	2.7	25.1	2.1	3.3	19.6	2.4	3.8	14.6	2.9	4.3										
125	76.1	1.5	1.7	52.3	1.6	2.2	37.1	1.9	2.7	26.2	2.1	3.3	20.5	2.4	3.8	15.4	2.8	4.3										
130	79.1	1.5	1.7	54.4	1.6	2.2	38.5	1.9	2.7	27.3	2.1	3.3	21.3	2.4	3.8	16.1	2.8	4.3										
135	82.1	1.5	1.7	56.5	1.6	2.2	40.0	1.9	2.7	28.4	2.1	3.3	22.2	2.4	3.8	16.9	2.8	4.3										
140	85.2	1.5	1.7	58.6	1.6	2.2	41.5	1.9	2.7	29.4	2.1	3.3	23.1	2.4	3.8	17.6	2.8	4.3										
145	88.2	1.5	1.7	60.7	1.6	2.2	43.0	1.9	2.7	30.5	2.1	3.3	24.0	2.4	3.8	18.3	2.8	4.3	12.3	3.7	4.9							
150	91.3	1.5	1.7	62.8	1.6	2.2	44.5	1.9	2.7	31.6	2.1	3.3	24.8	2.4	3.8	19.0	2.7	4.3	13.1	3.5	4.9							

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-10

Table DV-11 Parabolic Diversion Design Chart (Retardance "D" and "C," Grade 1.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"
Grade 1.00 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5																											
10	8.2	1.2	1.6	5.2	1.4	2.0																					
15	12.6	1.1	1.6	8.7	1.3	2.1	5.5	1.6	2.6																		
20	17.1	1.1	1.6	11.8	1.2	2.1	8.2	1.4	2.6																		
25	21.4	1.1	1.6	14.9	1.2	2.1	10.5	1.4	2.6	7.3	1.6	3.1															
30	25.7	1.1	1.6	18.0	1.2	2.1	12.8	1.4	2.6	9.1	1.6	3.2															
35	29.9	1.1	1.6	21.2	1.2	2.1	15.0	1.3	2.6	10.9	1.5	3.1	7.8	1.8	3.7												
40	34.2	1.1	1.6	24.3	1.2	2.1	17.3	1.3	2.6	12.6	1.5	3.1	9.2	1.7	3.7												
45	38.5	1.1	1.6	27.3	1.2	2.1	19.5	1.3	2.6	14.3	1.5	3.1	10.6	1.7	3.7	7.2	2.2	4.3									
50	42.7	1.1	1.6	30.3	1.2	2.1	21.9	1.3	2.6	16.0	1.5	3.2	11.9	1.7	3.7	8.8	2.0	4.3									
55	47.0	1.1	1.6	33.3	1.2	2.1	24.1	1.3	2.6	17.7	1.5	3.2	13.3	1.7	3.7	9.9	1.9	4.3									
60	51.3	1.1	1.6	36.3	1.2	2.1	26.3	1.3	2.6	19.3	1.5	3.2	14.6	1.7	3.7	11.0	1.9	4.3									
65	55.5	1.1	1.6	39.4	1.2	2.1	28.5	1.3	2.6	21.0	1.5	3.2	15.9	1.6	3.7	12.1	1.9	4.3	8.0	2.5	4.9						
70	59.8	1.1	1.6	42.4	1.2	2.1	30.7	1.3	2.6	22.7	1.5	3.2	17.1	1.6	3.7	13.2	1.9	4.3	9.5	2.3	4.8						
75	64.1	1.1	1.6	45.4	1.2	2.1	32.9	1.3	2.6	24.6	1.5	3.1	18.5	1.6	3.7	14.2	1.8	4.3	10.4	2.2	4.9						
80	68.3	1.1	1.6	48.4	1.2	2.1	35.0	1.3	2.6	26.2	1.5	3.1	19.8	1.6	3.7	15.2	1.8	4.3	11.3	2.2	4.9						
85	72.6	1.1	1.6	51.5	1.2	2.1	37.2	1.3	2.6	27.9	1.5	3.1	21.0	1.6	3.7	16.3	1.8	4.3	12.1	2.2	4.9	8.8	2.7	5.4			
90	76.9	1.1	1.6	54.5	1.2	2.1	39.4	1.3	2.6	29.5	1.5	3.1	22.3	1.6	3.7	17.3	1.8	4.3	13.0	2.1	4.9	9.8	2.6	5.4			
95	81.1	1.1	1.6	57.5	1.2	2.1	41.6	1.3	2.6	31.1	1.5	3.1	23.6	1.6	3.7	18.3	1.8	4.3	13.8	2.1	4.9	10.9	2.5	5.3			
100	85.4	1.1	1.6	60.5	1.2	2.1	43.8	1.3	2.6	32.7	1.5	3.1	24.9	1.6	3.7	19.3	1.8	4.3	14.6	2.1	4.9	11.6	2.4	5.4			
105	89.7	1.1	1.6	63.6	1.2	2.1	46.0	1.3	2.6	34.4	1.5	3.1	26.5	1.6	3.7	20.3	1.8	4.3	15.4	2.1	4.9	12.4	2.4	5.4	9.7	2.8	5.8
110	94.0	1.1	1.6	66.6	1.2	2.1	48.2	1.3	2.6	36.0	1.5	3.1	27.7	1.6	3.7	21.3	1.8	4.3	16.2	2.1	4.9	13.1	2.4	5.4	10.8	2.6	5.8
115	98.2	1.1	1.6	69.6	1.2	2.1	50.4	1.3	2.6	37.6	1.5	3.1	29.0	1.6	3.7	22.3	1.8	4.3	17.0	2.1	4.9	13.8	2.3	5.4	11.5	2.6	5.8
120	102.5	1.1	1.6	72.6	1.2	2.1	52.5	1.3	2.6	39.3	1.5	3.1	30.2	1.6	3.7	23.3	1.8	4.3	17.9	2.1	4.9	14.5	2.3	5.4	12.2	2.6	5.8
125	106.8	1.1	1.6	75.7	1.2	2.1	54.7	1.3	2.6	40.9	1.5	3.1	31.5	1.6	3.7	24.3	1.8	4.3	18.7	2.1	4.9	15.2	2.3	5.4	12.8	2.5	5.8
130	111.0	1.1	1.6	78.7	1.2	2.1	56.9	1.3	2.6	42.5	1.5	3.1	32.7	1.6	3.7	25.3	1.8	4.3	19.4	2.1	4.9	15.9	2.3	5.4	13.4	2.5	5.8
135	115.3	1.1	1.6	81.7	1.2	2.1	59.1	1.3	2.6	44.2	1.5	3.1	34.0	1.6	3.7	26.3	1.8	4.3	20.2	2.0	4.9	16.6	2.3	5.4	14.1	2.5	5.8
140	119.6	1.1	1.6	84.7	1.2	2.1	61.3	1.3	2.6	45.8	1.5	3.1	35.2	1.6	3.7	27.3	1.8	4.3	21.0	2.0	4.9	17.2	2.3	5.4	14.7	2.5	5.8
145	123.8	1.1	1.6	87.8	1.2	2.1	63.5	1.3	2.6	47.5	1.5	3.1	36.5	1.6	3.7	28.7	1.8	4.3	21.8	2.0	4.9	17.9	2.3	5.4	15.3	2.5	5.8
150	128.1	1.1	1.6	90.8	1.2	2.1	65.7	1.3	2.6	49.1	1.5	3.1	37.8	1.6	3.7	29.7	1.8	4.3	22.6	2.0	4.9	18.6	2.3	5.4	15.9	2.4	5.8

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-12 Parabolic Diversion Design Chart (Retardance "D" and "C," Grade 2.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"
Grade 2.00 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	5.9	0.9	1.5																								
10	12.4	0.8	1.5	8.1	0.9	2.0	5.9	1.0	2.5																		
15	18.5	0.8	1.5	12.3	0.9	2.0	9.3	1.0	2.5	6.8	1.1	3.0	4.7	1.4	3.5												
20	24.7	0.8	1.5	16.7	0.9	2.0	12.5	1.0	2.5	9.4	1.1	3.0	7.0	1.2	3.6	4.7	1.5	4.1									
25	30.8	0.8	1.5	20.8	0.9	2.0	15.9	1.0	2.4	11.8	1.1	3.0	9.0	1.2	3.5	6.8	1.3	4.1									
30	37.0	0.8	1.5	25.0	0.9	2.0	19.0	1.0	2.5	14.3	1.1	3.0	11.0	1.2	3.5	8.5	1.3	4.1	6.4	1.5	4.7						
35	43.2	0.8	1.5	29.1	0.9	2.0	22.2	1.0	2.5	16.9	1.0	3.0	12.9	1.1	3.5	10.1	1.3	4.1	7.8	1.4	4.7						
40	49.3	0.8	1.5	33.3	0.9	2.0	25.3	1.0	2.5	19.3	1.0	3.0	14.8	1.1	3.5	11.6	1.3	4.1	9.1	1.4	4.7	7.1	1.6	5.2			
45	55.5	0.8	1.5	37.4	0.9	2.0	28.5	1.0	2.5	21.7	1.0	3.0	16.7	1.1	3.5	13.1	1.3	4.1	10.4	1.4	4.7	8.2	1.6	5.2			
50	61.7	0.8	1.5	41.6	0.9	2.0	31.7	1.0	2.5	24.1	1.0	3.0	18.8	1.1	3.5	14.7	1.2	4.1	11.7	1.4	4.7	9.3	1.5	5.3	7.1	1.8	5.8
55	67.8	0.8	1.5	45.7	0.9	2.0	34.8	1.0	2.5	26.5	1.0	3.0	20.7	1.1	3.5	16.2	1.2	4.1	12.9	1.4	4.7	10.4	1.5	5.3	8.2	1.7	5.8
60	74.0	0.8	1.5	49.9	0.9	2.0	38.0	1.0	2.5	28.9	1.0	3.0	22.6	1.1	3.5	17.7	1.2	4.1	14.1	1.4	4.7	11.4	1.5	5.3	9.2	1.7	5.8
65	80.2	0.8	1.5	54.0	0.9	2.0	41.1	1.0	2.5	31.4	1.0	3.0	24.5	1.1	3.5	19.5	1.2	4.1	15.4	1.3	4.7	12.4	1.5	5.3	10.1	1.7	5.8
70	86.3	0.8	1.5	58.2	0.9	2.0	44.3	1.0	2.5	33.8	1.0	3.0	26.3	1.1	3.5	21.0	1.2	4.1	16.6	1.3	4.7	13.5	1.5	5.3	11.0	1.6	5.8
75	92.5	0.8	1.5	62.3	0.9	2.0	47.5	1.0	2.5	36.2	1.0	3.0	28.2	1.1	3.5	22.4	1.2	4.1	17.8	1.3	4.7	14.5	1.5	5.3	11.8	1.6	5.8
80	98.7	0.8	1.5	66.5	0.9	2.0	50.6	1.0	2.5	38.8	1.0	3.0	30.1	1.1	3.5	23.9	1.2	4.1	19.0	1.3	4.7	15.5	1.5	5.3	12.7	1.6	5.8
85	104.8	0.8	1.5	70.6	0.9	2.0	53.8	1.0	2.5	41.0	1.0	3.0	32.0	1.1	3.5	25.4	1.2	4.1	20.3	1.3	4.7	16.5	1.5	5.3	13.6	1.6	5.8
90	111.0	0.8	1.5	74.8	0.9	2.0	57.0	1.0	2.5	43.4	1.0	3.0	33.8	1.1	3.5	26.9	1.2	4.1	21.8	1.3	4.6	17.5	1.5	5.3	14.4	1.6	5.8
95	117.2	0.8	1.5	78.9	0.9	2.0	60.1	1.0	2.5	45.8	1.0	3.0	35.7	1.1	3.5	28.4	1.2	4.1	23.0	1.3	4.6	18.6	1.5	5.3	15.3	1.6	5.8
100	123.3	0.8	1.5	83.1	0.9	2.0	63.3	1.0	2.5	48.2	1.0	3.0	37.6	1.1	3.5	29.9	1.2	4.1	24.2	1.3	4.6	19.6	1.5	5.3	16.2	1.6	5.8
105	129.5	0.8	1.5	87.3	0.9	2.0	66.4	1.0	2.5	50.6	1.0	3.0	39.5	1.1	3.5	31.4	1.2	4.1	25.4	1.3	4.6	20.6	1.5	5.3	17.0	1.6	5.8
110	135.7	0.8	1.5	91.4	0.9	2.0	69.6	1.0	2.5	53.0	1.0	3.0	41.3	1.1	3.5	32.9	1.2	4.1	26.6	1.3	4.7	21.6	1.4	5.3	17.9	1.6	5.8
115	141.8	0.8	1.5	95.6	0.9	2.0	72.8	1.0	2.5	55.4	1.0	3.0	43.2	1.1	3.5	34.4	1.2	4.1	27.9	1.3	4.7	22.6	1.4	5.3	18.7	1.6	5.8
120	148.0	0.8	1.5	99.7	0.9	2.0	75.9	1.0	2.5	57.9	1.0	3.0	45.1	1.1	3.5	35.9	1.2	4.1	29.1	1.3	4.7	23.9	1.4	5.2	19.5	1.6	5.8
125	154.1	0.8	1.5	103.9	0.9	2.0	79.1	1.0	2.5	60.3	1.0	3.0	47.0	1.1	3.5	37.4	1.2	4.1	30.3	1.3	4.7	24.8	1.4	5.2	20.4	1.6	5.8
130	160.3	0.8	1.5	108.0	0.9	2.0	82.3	1.0	2.5	62.7	1.0	3.0	48.8	1.1	3.5	38.9	1.2	4.1	31.5	1.3	4.7	25.8	1.4	5.3	21.2	1.6	5.8
135	166.5	0.8	1.5	112.2	0.9	2.0	85.4	1.0	2.5	65.1	1.0	3.0	50.7	1.1	3.5	40.3	1.2	4.1	32.7	1.3	4.7	26.8	1.4	5.3	22.1	1.6	5.8
140	172.6	0.8	1.5	116.3	0.9	2.0	88.6	1.0	2.5	67.5	1.0	3.0	52.6	1.1	3.5	41.8	1.2	4.1	33.9	1.3	4.7	27.8	1.4	5.3	22.9	1.6	5.8
145	178.8	0.8	1.5	120.5	0.9	2.0	91.8	1.0	2.5	69.9	1.0	3.0	54.5	1.1	3.5	43.3	1.2	4.1	35.1	1.3	4.7	28.8	1.4	5.3	23.7	1.6	5.8
150	185.0	0.8	1.5	124.6	0.9	2.0	94.9	1.0	2.5	72.3	1.0	3.0	56.4	1.1	3.5	44.8	1.2	4.1	36.3	1.3	4.7	29.8	1.4	5.3	24.6	1.6	5.8

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-13 Parabolic Diversion Design Chart (Retardance "D" and "C," Grade 4.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																											
Grade 4.00 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	8.5	0.6	1.4	5.9	0.7	1.8	4.1	0.8	2.3																		
10	17.2	0.6	1.4	12.1	0.7	1.8	8.8	0.7	2.3	6.7	0.8	2.8	5.2	0.9	3.3	3.8	1.0	3.9									
15	25.8	0.6	1.4	18.1	0.7	1.8	13.4	0.7	2.3	10.3	0.8	2.8	8.1	0.8	3.4	6.4	0.9	3.9	4.9	1.0	4.5						
20	34.4	0.6	1.4	24.2	0.7	1.8	17.8	0.7	2.3	13.9	0.8	2.8	10.9	0.8	3.4	8.7	0.9	3.9	6.9	1.0	4.5	5.5	1.1	5.0			
25	43.0	0.6	1.4	30.2	0.7	1.9	22.3	0.7	2.3	17.4	0.8	2.8	13.8	0.8	3.3	10.9	0.9	3.9	8.8	1.0	4.5	7.1	1.0	5.1	5.7	1.2	5.6
30	51.6	0.6	1.4	36.3	0.7	1.9	26.7	0.7	2.3	20.8	0.8	2.8	16.5	0.8	3.3	13.2	0.9	3.9	10.7	0.9	4.5	8.7	1.0	5.1	7.1	1.1	5.6
35	60.2	0.6	1.4	42.3	0.7	1.9	31.1	0.7	2.3	24.3	0.8	2.8	19.3	0.8	3.4	15.6	0.9	3.9	12.5	0.9	4.5	10.3	1.0	5.0	8.4	1.1	5.6
40	68.8	0.6	1.4	48.3	0.7	1.9	35.6	0.7	2.3	27.8	0.8	2.8	22.0	0.8	3.4	17.8	0.9	3.9	14.4	0.9	4.5	11.8	1.0	5.0	9.8	1.1	5.7
45	77.4	0.6	1.4	54.4	0.7	1.9	40.0	0.7	2.4	31.2	0.8	2.8	24.8	0.8	3.4	20.0	0.9	3.9	16.4	0.9	4.4	13.3	1.0	5.0	11.1	1.1	5.7
50	86.0	0.6	1.4	60.4	0.7	1.9	44.5	0.7	2.4	34.7	0.8	2.8	27.5	0.8	3.4	22.2	0.9	3.9	18.2	0.9	4.4	14.9	1.0	5.0	12.3	1.1	5.7
55	94.6	0.6	1.4	66.5	0.7	1.9	48.9	0.7	2.4	38.2	0.8	2.8	30.3	0.8	3.4	24.4	0.9	3.9	20.0	0.9	4.4	16.6	1.0	5.0	13.6	1.1	5.7
60	103.2	0.6	1.4	72.5	0.7	1.9	53.4	0.7	2.4	41.7	0.8	2.8	33.0	0.8	3.4	26.6	0.9	3.9	21.8	0.9	4.5	18.1	1.0	5.0	14.9	1.1	5.7
65	111.8	0.6	1.4	78.5	0.7	1.9	57.8	0.7	2.4	45.1	0.8	2.8	35.8	0.8	3.4	28.9	0.9	3.9	23.6	0.9	4.5	19.6	1.0	5.0	16.2	1.1	5.7
70	120.4	0.6	1.4	84.6	0.7	1.9	62.3	0.7	2.4	48.6	0.8	2.8	38.6	0.8	3.4	31.1	0.9	3.9	25.4	0.9	4.5	21.1	1.0	5.0	17.7	1.1	5.6
75	129.0	0.6	1.4	90.6	0.7	1.9	66.7	0.7	2.4	52.1	0.8	2.8	41.3	0.8	3.4	33.3	0.9	3.9	27.2	0.9	4.5	22.6	1.0	5.0	19.0	1.1	5.6
80	137.6	0.6	1.4	96.7	0.7	1.9	71.2	0.7	2.4	55.5	0.8	2.8	44.1	0.8	3.4	35.5	0.9	3.9	29.1	0.9	4.5	24.1	1.0	5.0	20.2	1.1	5.6
85	146.2	0.6	1.4	102.7	0.7	1.9	75.6	0.7	2.4	59.0	0.8	2.8	46.8	0.8	3.4	37.7	0.9	3.9	30.9	0.9	4.5	25.6	1.0	5.0	21.5	1.1	5.6
90	154.8	0.6	1.4	108.7	0.7	1.9	80.0	0.7	2.4	62.5	0.8	2.8	49.6	0.8	3.4	39.9	0.9	3.9	32.7	0.9	4.5	27.1	1.0	5.0	22.8	1.1	5.6
95	163.4	0.6	1.4	114.8	0.7	1.9	84.5	0.7	2.4	65.9	0.8	2.8	52.3	0.8	3.4	42.2	0.9	3.9	34.5	0.9	4.5	28.6	1.0	5.0	24.0	1.1	5.6
100	172.0	0.6	1.4	120.8	0.7	1.9	88.9	0.7	2.4	69.4	0.8	2.8	55.1	0.8	3.4	44.4	0.9	3.9	36.3	0.9	4.5	30.1	1.0	5.0	25.3	1.1	5.6
105	180.6	0.6	1.4	126.9	0.7	1.9	93.4	0.7	2.4	72.9	0.8	2.8	57.8	0.8	3.4	46.6	0.9	3.9	38.1	0.9	4.5	31.6	1.0	5.0	26.5	1.1	5.6
110	189.2	0.6	1.4	132.9	0.7	1.9	97.8	0.7	2.4	76.3	0.8	2.8	60.6	0.8	3.4	48.8	0.9	3.9	39.9	0.9	4.5	33.1	1.0	5.0	27.8	1.1	5.6
115	197.8	0.6	1.4	138.9	0.7	1.9	102.3	0.7	2.4	79.8	0.8	2.8	63.3	0.8	3.4	51.0	0.9	3.9	41.7	0.9	4.5	34.6	1.0	5.0	29.0	1.1	5.6
120	206.4	0.6	1.4	145.0	0.7	1.9	106.7	0.7	2.4	83.3	0.8	2.8	66.1	0.8	3.4	53.3	0.9	3.9	43.6	0.9	4.5	36.1	1.0	5.0	30.2	1.1	5.7
125	215.0	0.6	1.4	151.0	0.7	1.9	111.2	0.7	2.4	86.8	0.8	2.8	68.8	0.8	3.4	55.5	0.9	3.9	45.4	0.9	4.5	37.6	1.0	5.0	31.5	1.1	5.7
130	223.7	0.6	1.4	157.1	0.7	1.9	115.6	0.7	2.4	90.2	0.8	2.8	71.6	0.8	3.4	57.7	0.9	3.9	47.2	0.9	4.5	39.1	1.0	5.0	32.7	1.1	5.7
135	232.3	0.6	1.4	163.1	0.7	1.9	120.1	0.7	2.4	93.7	0.8	2.8	74.3	0.8	3.4	59.9	0.9	3.9	49.0	0.9	4.5	40.6	1.0	5.0	34.0	1.1	5.7
140	240.9	0.6	1.4	169.1	0.7	1.9	124.5	0.7	2.4	97.2	0.8	2.8	77.1	0.8	3.4	62.1	0.9	3.9	50.8	0.9	4.5	42.1	1.0	5.0	35.2	1.1	5.7
145	249.5	0.6	1.4	175.2	0.7	1.9	129.0	0.7	2.4	100.6	0.8	2.8	79.8	0.8	3.4	64.3	0.9	3.9	52.6	0.9	4.5	43.6	1.0	5.0	36.5	1.1	5.7
150	258.1	0.6	1.4	181.2	0.7	1.9	133.4	0.7	2.4	104.1	0.8	2.8	82.6	0.8	3.4	66.6	0.9	3.9	54.4	0.9	4.5	45.1	1.0	5.0	37.8	1.1	5.7

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-14 Parabolic Diversion Design Chart (Retardance "D" and "C," Grade 6.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																											
Grade 6.00 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	10.6	0.5	1.3	7.3	0.6	1.8	5.3	0.6	2.3	4.0	0.7	2.8	2.9	0.8	3.2												
10	21.1	0.5	1.3	14.7	0.6	1.8	10.9	0.6	2.3	8.4	0.7	2.8	6.6	0.7	3.2	5.3	0.8	3.8	4.2	0.8	4.3						
15	31.6	0.5	1.3	22.1	0.6	1.8	16.3	0.6	2.3	12.7	0.6	2.7	10.1	0.7	3.3	8.2	0.7	3.8	6.6	0.8	4.3	5.4	0.9	4.9	4.3	1.0	5.5
20	42.1	0.5	1.3	29.5	0.6	1.8	21.7	0.6	2.3	17.0	0.6	2.7	13.6	0.7	3.2	11.1	0.7	3.7	9.0	0.8	4.3	7.4	0.8	4.9	6.1	0.9	5.5
25	52.7	0.5	1.3	36.8	0.6	1.8	27.1	0.6	2.3	21.2	0.6	2.8	17.0	0.7	3.2	13.9	0.7	3.8	11.3	0.8	4.3	9.3	0.8	4.9	7.8	0.9	5.5
30	63.2	0.5	1.3	44.2	0.6	1.8	32.5	0.6	2.3	25.4	0.6	2.8	20.4	0.7	3.2	16.6	0.7	3.8	13.7	0.8	4.3	11.3	0.8	4.9	9.4	0.9	5.5
35	73.7	0.5	1.3	51.6	0.6	1.8	38.0	0.6	2.3	29.7	0.6	2.8	23.8	0.7	3.2	19.4	0.7	3.8	16.0	0.8	4.3	13.4	0.8	4.9	11.1	0.9	5.5
40	84.2	0.5	1.3	58.9	0.6	1.8	43.4	0.6	2.3	33.9	0.6	2.8	27.2	0.7	3.3	22.2	0.7	3.8	18.3	0.8	4.3	15.3	0.8	4.9	12.7	0.9	5.5
45	94.8	0.5	1.3	66.3	0.6	1.8	48.8	0.6	2.3	38.2	0.6	2.8	30.7	0.7	3.3	24.9	0.7	3.8	20.6	0.8	4.3	17.2	0.8	4.9	14.5	0.9	5.4
50	105.3	0.5	1.3	73.6	0.6	1.8	54.2	0.6	2.3	42.4	0.6	2.8	34.1	0.7	3.3	27.7	0.7	3.8	22.8	0.8	4.3	19.1	0.8	4.9	16.1	0.9	5.4
55	115.8	0.5	1.3	81.0	0.6	1.8	59.7	0.6	2.3	46.6	0.6	2.8	37.5	0.7	3.3	30.5	0.7	3.8	25.1	0.8	4.3	21.0	0.8	4.9	17.7	0.9	5.4
60	126.4	0.5	1.3	88.4	0.6	1.8	65.1	0.6	2.3	50.9	0.6	2.8	40.9	0.7	3.3	33.3	0.7	3.8	27.4	0.8	4.3	22.9	0.8	4.9	19.3	0.9	5.4
65	136.9	0.5	1.3	95.7	0.6	1.8	70.5	0.6	2.3	55.1	0.6	2.8	44.3	0.7	3.3	36.0	0.7	3.8	29.7	0.8	4.3	24.8	0.8	4.9	20.9	0.9	5.4
70	147.4	0.5	1.3	103.1	0.6	1.8	75.9	0.6	2.3	59.3	0.6	2.8	47.7	0.7	3.3	38.8	0.7	3.8	32.0	0.8	4.3	26.7	0.8	4.9	22.5	0.9	5.4
75	158.0	0.5	1.3	110.5	0.6	1.8	81.3	0.6	2.3	63.6	0.6	2.8	51.1	0.7	3.3	41.6	0.7	3.8	34.3	0.8	4.3	28.6	0.8	4.9	24.1	0.9	5.4
80	168.5	0.5	1.3	117.8	0.6	1.8	86.8	0.6	2.3	67.8	0.6	2.8	54.5	0.7	3.3	44.3	0.7	3.8	36.5	0.8	4.3	30.5	0.8	4.9	25.7	0.9	5.5
85	179.0	0.5	1.3	125.2	0.6	1.8	92.2	0.6	2.3	72.0	0.6	2.8	57.9	0.7	3.3	47.1	0.7	3.8	38.8	0.8	4.3	32.4	0.8	4.9	27.3	0.9	5.5
90	189.6	0.5	1.3	132.6	0.6	1.8	97.6	0.6	2.3	76.3	0.6	2.8	61.3	0.7	3.3	49.9	0.7	3.8	41.1	0.8	4.3	34.3	0.8	4.9	28.9	0.9	5.5
95	200.1	0.5	1.3	139.9	0.6	1.8	103.0	0.6	2.3	80.5	0.6	2.8	64.7	0.7	3.3	52.6	0.7	3.8	43.4	0.8	4.3	36.2	0.8	4.9	30.5	0.9	5.5
100	210.6	0.5	1.3	147.3	0.6	1.8	108.5	0.6	2.3	84.8	0.6	2.8	68.1	0.7	3.3	55.4	0.7	3.8	45.7	0.8	4.3	38.1	0.8	4.9	32.1	0.9	5.5
105	221.1	0.5	1.3	154.6	0.6	1.8	113.9	0.6	2.3	89.0	0.6	2.8	71.5	0.7	3.3	58.2	0.7	3.8	47.9	0.8	4.3	40.0	0.8	4.9	33.7	0.9	5.5
110	231.7	0.5	1.3	162.0	0.6	1.8	119.3	0.6	2.3	93.2	0.6	2.8	74.9	0.7	3.3	60.9	0.7	3.8	50.2	0.8	4.3	41.9	0.8	4.9	35.3	0.9	5.5
115	242.2	0.5	1.3	169.4	0.6	1.8	124.7	0.6	2.3	97.5	0.6	2.8	78.3	0.7	3.3	63.7	0.7	3.8	52.5	0.8	4.3	43.8	0.8	4.9	36.9	0.9	5.5
120	252.7	0.5	1.3	176.7	0.6	1.8	130.2	0.6	2.3	101.7	0.6	2.8	81.7	0.7	3.3	66.5	0.7	3.8	54.8	0.8	4.3	45.7	0.8	4.9	38.5	0.9	5.5
125	263.3	0.5	1.3	184.1	0.6	1.8	135.6	0.6	2.3	106.0	0.6	2.8	85.1	0.7	3.3	69.3	0.7	3.8	57.1	0.8	4.3	47.6	0.8	4.9	40.1	0.9	5.5
130	273.8	0.5	1.3	191.5	0.6	1.8	141.0	0.6	2.3	110.2	0.6	2.8	88.5	0.7	3.3	72.0	0.7	3.8	59.4	0.8	4.3	49.5	0.8	4.9	41.7	0.9	5.5
135	284.3	0.5	1.3	198.8	0.6	1.8	146.4	0.6	2.3	114.4	0.6	2.8	91.9	0.7	3.3	74.8	0.7	3.8	61.6	0.8	4.3	51.4	0.8	4.9	43.3	0.9	5.5
140	294.9	0.5	1.3	206.2	0.6	1.8	151.8	0.6	2.3	118.7	0.6	2.8	95.3	0.7	3.3	77.6	0.7	3.8	63.9	0.8	4.3	53.3	0.8	4.9	44.9	0.9	5.5
145	305.4	0.5	1.3	213.6	0.6	1.8	157.3	0.6	2.3	122.9	0.6	2.8	98.7	0.7	3.3	80.3	0.7	3.8	66.2	0.8	4.3	55.2	0.8	4.9	46.5	0.9	5.5
150	315.9	0.5	1.3	220.9	0.6	1.8	162.7	0.6	2.3	127.1	0.6	2.8	102.1	0.7	3.3	83.1	0.7	3.8	68.5	0.8	4.3	57.1	0.8	4.9	48.1	0.9	5.5

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table DV-15 Parabolic Diversion Design Chart (Retardance "D" and "C," Grade 8.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH' (D), AND V2 FOR RETARDANCE "C"																											
Grade 8.00 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	12.0	0.5	1.3	8.5	0.5	1.7	6.2	0.5	2.2	4.6	0.6	2.7	3.7	0.6	3.2	2.9	0.7	3.6									
10	24.1	0.5	1.3	16.9	0.5	1.7	12.6	0.5	2.2	9.6	0.6	2.7	7.8	0.6	3.2	6.3	0.6	3.7	5.1	0.7	4.2	4.2	0.8	4.8	3.2	0.9	5.3
15	36.1	0.5	1.3	25.3	0.5	1.7	18.9	0.5	2.2	14.4	0.6	2.7	11.8	0.6	3.2	9.7	0.6	3.7	7.9	0.7	4.2	6.5	0.7	4.8	5.4	0.8	5.3
20	48.1	0.5	1.3	33.8	0.5	1.7	25.2	0.5	2.2	19.2	0.6	2.7	15.8	0.6	3.2	12.9	0.6	3.7	10.7	0.7	4.2	8.8	0.7	4.8	7.4	0.8	5.3
25	60.1	0.5	1.3	42.2	0.5	1.7	31.5	0.5	2.2	24.0	0.6	2.7	19.7	0.6	3.2	16.2	0.6	3.7	13.4	0.7	4.2	11.2	0.7	4.7	9.3	0.8	5.3
30	72.1	0.5	1.3	50.6	0.5	1.7	37.8	0.5	2.2	28.8	0.6	2.7	23.6	0.6	3.2	19.4	0.6	3.7	16.1	0.7	4.2	13.5	0.7	4.8	11.3	0.7	5.3
35	84.1	0.5	1.3	59.1	0.5	1.7	44.1	0.5	2.2	33.6	0.6	2.7	27.6	0.6	3.2	22.6	0.6	3.7	18.7	0.7	4.2	15.7	0.7	4.8	13.3	0.7	5.3
40	96.2	0.5	1.3	67.5	0.5	1.7	50.4	0.5	2.2	38.4	0.6	2.7	31.5	0.6	3.2	25.8	0.6	3.7	21.4	0.7	4.2	17.9	0.7	4.8	15.2	0.7	5.3
45	108.2	0.5	1.3	76.0	0.5	1.7	56.7	0.5	2.2	43.2	0.6	2.7	35.4	0.6	3.2	29.0	0.6	3.7	24.1	0.7	4.2	20.2	0.7	4.8	17.1	0.7	5.3
50	120.2	0.5	1.3	84.4	0.5	1.7	63.0	0.5	2.2	48.0	0.6	2.7	39.4	0.6	3.2	32.3	0.6	3.7	26.8	0.7	4.2	22.4	0.7	4.8	19.0	0.7	5.3
55	132.2	0.5	1.3	92.8	0.5	1.7	69.3	0.5	2.2	52.8	0.6	2.7	43.3	0.6	3.2	35.5	0.6	3.7	29.4	0.7	4.2	24.7	0.7	4.8	20.9	0.7	5.3
60	144.2	0.5	1.3	101.3	0.5	1.7	75.6	0.5	2.2	57.6	0.6	2.7	47.2	0.6	3.2	38.7	0.6	3.7	32.1	0.7	4.2	26.9	0.7	4.8	22.8	0.7	5.3
65	156.3	0.5	1.3	109.7	0.5	1.7	81.8	0.5	2.2	62.4	0.6	2.7	51.2	0.6	3.2	41.9	0.6	3.7	34.8	0.7	4.2	29.1	0.7	4.8	24.7	0.7	5.3
70	168.3	0.5	1.3	118.2	0.5	1.7	88.1	0.5	2.2	67.2	0.6	2.7	55.1	0.6	3.2	45.2	0.6	3.7	37.5	0.7	4.2	31.4	0.7	4.8	26.6	0.7	5.3
75	180.3	0.5	1.3	126.6	0.5	1.7	94.4	0.5	2.2	72.0	0.6	2.7	59.0	0.6	3.2	48.4	0.6	3.7	40.1	0.7	4.2	33.6	0.7	4.8	28.5	0.7	5.3
80	192.3	0.5	1.3	135.0	0.5	1.7	100.7	0.5	2.2	76.8	0.6	2.7	63.0	0.6	3.2	51.6	0.6	3.7	42.8	0.7	4.2	35.9	0.7	4.8	30.3	0.7	5.3
85	204.3	0.5	1.3	143.5	0.5	1.7	107.0	0.5	2.2	81.6	0.6	2.7	66.9	0.6	3.2	54.9	0.6	3.7	45.5	0.7	4.2	38.1	0.7	4.8	32.2	0.7	5.3
90	216.4	0.5	1.3	151.9	0.5	1.7	113.3	0.5	2.2	86.4	0.6	2.7	70.8	0.6	3.2	58.1	0.6	3.7	48.1	0.7	4.2	40.3	0.7	4.8	34.1	0.7	5.3
95	228.4	0.5	1.3	160.3	0.5	1.7	119.6	0.5	2.2	91.2	0.6	2.7	74.8	0.6	3.2	61.3	0.6	3.7	50.8	0.7	4.2	42.6	0.7	4.8	36.0	0.7	5.3
100	240.4	0.5	1.3	168.8	0.5	1.7	125.9	0.5	2.2	96.0	0.6	2.7	78.7	0.6	3.2	64.5	0.6	3.7	53.5	0.7	4.2	44.8	0.7	4.8	37.9	0.7	5.3
105	252.4	0.5	1.3	177.2	0.5	1.7	132.2	0.5	2.2	100.8	0.6	2.7	82.6	0.6	3.2	67.8	0.6	3.7	56.2	0.7	4.2	47.1	0.7	4.8	39.8	0.7	5.3
110	264.4	0.5	1.3	185.7	0.5	1.7	138.5	0.5	2.2	105.6	0.6	2.7	86.6	0.6	3.2	71.0	0.6	3.7	58.8	0.7	4.2	49.3	0.7	4.8	41.7	0.7	5.3
115	276.5	0.5	1.3	194.1	0.5	1.7	144.8	0.5	2.2	110.4	0.6	2.7	90.5	0.6	3.2	74.2	0.6	3.7	61.5	0.7	4.2	51.5	0.7	4.8	43.6	0.7	5.3
120	288.5	0.5	1.3	202.5	0.5	1.7	151.1	0.5	2.2	115.2	0.6	2.7	94.4	0.6	3.2	77.4	0.6	3.7	64.2	0.7	4.2	53.8	0.7	4.8	45.5	0.7	5.3
125	300.5	0.5	1.3	211.0	0.5	1.7	157.4	0.5	2.2	120.0	0.6	2.7	98.4	0.6	3.2	80.7	0.6	3.7	66.9	0.7	4.2	56.0	0.7	4.8	47.4	0.7	5.3
130	312.5	0.5	1.3	219.4	0.5	1.7	163.7	0.5	2.2	124.8	0.6	2.7	102.3	0.6	3.2	83.9	0.6	3.7	69.5	0.7	4.2	58.3	0.7	4.8	49.3	0.7	5.3
135	324.5	0.5	1.3	227.9	0.5	1.7	170.0	0.5	2.2	129.6	0.6	2.7	106.2	0.6	3.2	87.1	0.6	3.7	72.2	0.7	4.2	60.5	0.7	4.8	51.2	0.7	5.3
140	336.6	0.5	1.3	236.3	0.5	1.7	176.3	0.5	2.2	134.4	0.6	2.7	110.2	0.6	3.2	90.3	0.6	3.7	74.9	0.7	4.2	62.7	0.7	4.8	53.1	0.7	5.3
145	348.6	0.5	1.3	244.7	0.5	1.7	182.6	0.5	2.2	139.2	0.6	2.7	114.1	0.6	3.2	93.6	0.6	3.7	77.6	0.7	4.2	65.0	0.7	4.8	55.0	0.7	5.3
150	360.6	0.5	1.3	253.2	0.5	1.7	188.9	0.5	2.2	144.0	0.6	2.7	118.0	0.6	3.2	96.8	0.6	3.7	80.2	0.7	4.2	67.2	0.7	4.8	56.9	0.7	5.3

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second
Depth "D" does not include allowance for freeboard or settlement

Table DV-16 Parabolic Diversion Design Chart (Retardance "D" and "C," Grade 10.00%)

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																														
Grade 10.00 Percent																														
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0					
	T	D	V2	T	D	V2																								
5	13.3	0.4	1.3	9.4	0.5	1.7	6.8	0.5	2.2	5.3	0.5	2.6	4.1	0.6	3.2	3.4	0.6	3.6	2.6	0.7	4.1									
10	26.6	0.4	1.3	18.7	0.5	1.7	13.8	0.5	2.2	10.9	0.5	2.6	8.5	0.6	3.2	7.1	0.6	3.6	5.9	0.6	4.1	4.9	0.7	4.7	4.0	0.7	5.3			
15	39.9	0.4	1.3	28.0	0.5	1.7	20.7	0.5	2.2	16.3	0.5	2.6	12.8	0.6	3.2	10.9	0.6	3.6	9.0	0.6	4.1	7.5	0.6	4.7	6.3	0.7	5.2			
20	53.2	0.4	1.3	37.4	0.5	1.7	27.6	0.5	2.2	21.7	0.5	2.7	17.0	0.6	3.2	14.5	0.6	3.6	12.1	0.6	4.1	10.2	0.6	4.6	8.5	0.7	5.2			
25	66.5	0.4	1.3	46.7	0.5	1.7	34.5	0.5	2.2	27.1	0.5	2.7	21.3	0.6	3.2	18.1	0.6	3.6	15.1	0.6	4.1	12.7	0.6	4.7	10.8	0.7	5.2			
30	79.8	0.4	1.3	56.1	0.5	1.7	41.4	0.5	2.2	32.5	0.5	2.7	25.5	0.6	3.2	21.7	0.6	3.6	18.1	0.6	4.1	15.2	0.6	4.7	12.9	0.7	5.2			
35	93.1	0.4	1.3	65.4	0.5	1.7	48.3	0.5	2.2	37.9	0.5	2.7	29.8	0.6	3.2	25.3	0.6	3.6	21.1	0.6	4.1	17.8	0.6	4.7	15.1	0.7	5.2			
40	106.4	0.4	1.3	74.7	0.5	1.7	55.2	0.5	2.2	43.3	0.5	2.7	34.0	0.6	3.2	29.0	0.6	3.6	24.1	0.6	4.1	20.3	0.6	4.7	17.2	0.7	5.2			
45	119.7	0.4	1.3	84.1	0.5	1.7	62.1	0.5	2.2	48.8	0.5	2.7	38.3	0.6	3.2	32.6	0.6	3.6	27.2	0.6	4.1	22.8	0.6	4.7	19.4	0.7	5.2			
50	133.0	0.4	1.3	93.4	0.5	1.7	69.0	0.5	2.2	54.2	0.5	2.7	42.5	0.6	3.2	36.2	0.6	3.6	30.2	0.6	4.1	25.4	0.6	4.7	21.5	0.7	5.2			
55	146.3	0.4	1.3	102.8	0.5	1.7	75.9	0.5	2.2	59.6	0.5	2.7	46.8	0.6	3.2	39.8	0.6	3.6	33.2	0.6	4.1	27.9	0.6	4.7	23.7	0.7	5.2			
60	159.6	0.4	1.3	112.1	0.5	1.7	82.8	0.5	2.2	65.0	0.5	2.7	51.0	0.6	3.2	43.4	0.6	3.6	36.2	0.6	4.1	30.5	0.6	4.7	25.9	0.7	5.2			
65	172.9	0.4	1.3	121.4	0.5	1.7	89.7	0.5	2.2	70.4	0.5	2.7	55.3	0.6	3.2	47.1	0.6	3.6	39.2	0.6	4.1	33.0	0.6	4.7	28.0	0.7	5.2			
70	186.2	0.4	1.3	130.8	0.5	1.7	96.6	0.5	2.2	75.8	0.5	2.7	59.5	0.6	3.2	50.7	0.6	3.6	42.2	0.6	4.1	35.5	0.6	4.7	30.2	0.7	5.2			
75	199.5	0.4	1.3	140.1	0.5	1.7	103.5	0.5	2.2	81.2	0.5	2.7	63.8	0.6	3.2	54.3	0.6	3.6	45.2	0.6	4.1	38.1	0.6	4.7	32.3	0.7	5.2			
80	212.8	0.4	1.3	149.5	0.5	1.7	110.5	0.5	2.2	86.7	0.5	2.7	68.0	0.6	3.2	57.9	0.6	3.6	48.3	0.6	4.1	40.6	0.6	4.7	34.5	0.7	5.2			
85	226.1	0.4	1.3	158.8	0.5	1.7	117.4	0.5	2.2	92.1	0.5	2.7	72.3	0.6	3.2	61.5	0.6	3.6	51.3	0.6	4.1	43.1	0.6	4.7	36.6	0.7	5.2			
90	239.4	0.4	1.3	168.1	0.5	1.7	124.3	0.5	2.2	97.5	0.5	2.7	76.5	0.6	3.2	65.2	0.6	3.6	54.3	0.6	4.1	45.7	0.6	4.7	38.8	0.7	5.2			
95	252.7	0.4	1.3	177.5	0.5	1.7	131.2	0.5	2.2	102.9	0.5	2.7	80.8	0.6	3.2	68.8	0.6	3.6	57.3	0.6	4.1	48.2	0.6	4.7	40.9	0.7	5.2			
100	266.0	0.4	1.3	186.8	0.5	1.7	138.1	0.5	2.2	108.3	0.5	2.7	85.0	0.6	3.2	72.4	0.6	3.6	60.3	0.6	4.1	50.7	0.6	4.7	43.1	0.7	5.2			
105	279.3	0.4	1.3	196.2	0.5	1.7	145.0	0.5	2.2	113.7	0.5	2.7	89.3	0.6	3.2	76.0	0.6	3.6	63.3	0.6	4.1	53.3	0.6	4.7	45.2	0.7	5.2			
110	292.6	0.4	1.3	205.5	0.5	1.7	151.9	0.5	2.2	119.2	0.5	2.7	93.5	0.6	3.2	79.6	0.6	3.6	66.4	0.6	4.1	55.8	0.6	4.7	47.4	0.7	5.2			
115	305.9	0.4	1.3	214.9	0.5	1.7	158.8	0.5	2.2	124.6	0.5	2.7	97.8	0.6	3.2	83.3	0.6	3.6	69.4	0.6	4.1	58.3	0.6	4.7	49.5	0.7	5.3			
120	319.2	0.4	1.3	224.2	0.5	1.7	165.7	0.5	2.2	130.0	0.5	2.7	102.0	0.6	3.2	86.9	0.6	3.6	72.4	0.6	4.1	60.9	0.6	4.7	51.7	0.7	5.3			
125	332.5	0.4	1.3	233.5	0.5	1.7	172.6	0.5	2.2	135.4	0.5	2.7	106.3	0.6	3.2	90.5	0.6	3.6	75.4	0.6	4.1	63.4	0.6	4.7	53.8	0.7	5.3			
130	345.8	0.4	1.3	242.9	0.5	1.7	179.5	0.5	2.2	140.8	0.5	2.7	110.5	0.6	3.2	94.1	0.6	3.6	78.4	0.6	4.1	66.0	0.6	4.7	56.0	0.7	5.3			
135	359.1	0.4	1.3	252.2	0.5	1.7	186.4	0.5	2.2	146.2	0.5	2.7	114.8	0.6	3.2	97.7	0.6	3.6	81.4	0.6	4.1	68.5	0.6	4.7	58.1	0.7	5.3			
140	372.4	0.4	1.3	261.6	0.5	1.7	193.3	0.5	2.2	151.7	0.5	2.7	119.0	0.6	3.2	101.3	0.6	3.6	84.4	0.6	4.1	71.0	0.6	4.7	60.3	0.7	5.3			
145	385.7	0.4	1.3	270.9	0.5	1.7	200.2	0.5	2.2	157.1	0.5	2.7	123.3	0.6	3.2	105.0	0.6	3.6	87.5	0.6	4.1	73.6	0.6	4.7	62.5	0.7	5.3			
150	399.0	0.4	1.3	280.2	0.5	1.7	207.1	0.5	2.2	162.5	0.5	2.7	127.5	0.6	3.2	108.6	0.6	3.6	90.5	0.6	4.1	76.1	0.6	4.7	64.6	0.7	5.3			

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Construction

Prior to start of construction, diversions should be designed by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the construction process. A diversion should be built according to planned alignment, grade and cross section. Typically, a diversion is constructed with the following activities.

Site Preparation

Determine exact location of any underground utilities (see Appendix C: MS One-Call and 811 Color Coding).

Locate and mark the alignment of the diversion as shown on the plans. Minor adjustments to the grade and alignment may be required to meet site conditions. The alignment should maintain a positive grade toward the outlet and end in a stable outlet or an area that can be stabilized.

Clear the construction area of trees, stumps, brush, sod and other unsuitable material which would interfere with compaction of the ridge.

Disk or scarify the area where the ridge is to be installed before placing the fill.

Clean out and refill with compacted earth fill all ditches, swales or gullies to be crossed.

Apply gravel or hard surface protection at vehicle crossings to prevent rutting.

Install stable outlets prior to construction. Adequate vegetation should be established in the outlet channel. If vegetation cannot be established, use *Erosion Control Blankets* and/or *Rock Outlets* or *Outlet Protection*.

Grading

Excavate, fill and shape the diversion to planned alignment, grade and cross section. The channel should have a positive grade toward the outlet to avoid ponding. Where possible, blend diversion into the surrounding landscape.

Overfill and compact the ridge, allowing for 10% settlement. Fill should be placed in lifts of no more than 6" to 8" in depth. Compaction may be achieved by driving wheeled equipment along the ridge as lifts are added. The settled ridge top must be at or above design elevation at all points.

All earth removed and not needed for the practice should be spread or disposed of so that it will not interfere with the functioning of the diversion.

Erosion and Sediment Control

Control sediment along grading limits with sediment control measures.

Leave sufficient area adjacent to the diversion to permit clean-out and regrading.

Immediately after installation, install vegetation treatment or other means to stabilize the diversion in accordance with plans.

Install gravel or hard surface protection at vehicle crossings.

Stabilize diversion outlets in accordance with plans.

Construction Verification

Check finished grades and cross section of diversions to eliminate constrictions to flow.
Check all ridges for low spots and stability.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate diversion will not function as intended.
Changes in plans will be needed.

Design specifications for seed variety or seeding cannot be met. Substitutions not approved by the design professional could result in erosion and lead to diversion failure.

Seepage is encountered during construction. It may be necessary to install drains.

Maintenance

Inspect weekly and following each storm event for erosion until the diversion is vegetated.

Remove debris and sediment from the channel, and rebuild the ridge to design elevation where needed.

Check diversion outlet for erosion and repair if area becomes unstable. Maintain vegetation with periodic fertilization and mowing to keep vegetation in a vigorous, healthy condition. Mow for weed and brush control during the first year and as needed to prevent brush and tree seedlings from becoming established after the first year of installation.

When the work area has been stabilized, remove temporary diversions, sediment barriers and traps, and repair bare or damaged areas in the vegetation by planting and mulching or sodding.

Stabilize all eroded, rutted or disturbed areas as soon as possible with vegetation or synthetic erosion control measures as specified in the design.

References

BMPs from Volume 1


Chapter 4

Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103
Drop Structure (DS)	4-156
Grass Swale (GS)	4-162
Lined Swale (LS)	4-190
Sediment Basin (SBN)	4-298


MDOT Drawing TEC-2

Typical Temporary Erosion Control Measures (Temporary Shoulder Berm)	4-155
---	-------

STATE	PROJECT NO.
MISS.	




TEMPORARY SHOULDER BERM




TEMPORARY SLOPE DRAIN

NOTE: TEMPORARY SLOPE DRAINS TO BE PLACED AT LOW POINT OF ALL SAG VERTICAL CURVES. INTERMEDIATE LOCATIONS TO BE PLACED AS DESIGNATED OR DEEMED APPROPRIATE BY THE CONTRACTOR AND APPROVED BY THE ENGINEER.



TEMPORARY MEDIAN SILT BASIN (TYPE A)



TEMPORARY SILT BASIN (TYPE A)

NOTE: TEMPORARY SILT BASIN (TYPE A) TO BE PLACED IN SURFACE DRAIN DITCHES AND SOOT DITCHES AT THE END OF CUT SECTIONS IMMEDIATELY PRECEDING DITCH INLETS AND JUST BEFORE THE WATER RUNOFF LEAVES THE RIGHT-OF-WAY OR ENTERS A WATER COURSE. LOCATION AND SIZE (OTHER THAN AS SHOWN) MAY BE REQUIRED AS DIRECTED BY THE ENGINEER.

GENERAL NOTES:

1. THE CONTRACTOR SHALL BE REQUIRED TO FURNISH ALL MATERIALS AND PERFORM ALL WORK FOR THE PROPER INSTALLATION, MAINTENANCE AND REMOVAL OF TEMPORARY EROSION CONTROL MEASURES NECESSARY TO CONTROL SILTATION.

BY	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
DATE	
DESIGN TEAM	
OFFICE	
DATE	
TYPICAL TEMPORARY EROSION CONTROL MEASURES (SLOPE DRAIN AND TYPE A SILT BASIN)	
FILENAME: EROSION_CONTROL\TEC-2.DGN	WORKING NUMBER
	TEC-2
	SHEET NUMBER

Drop Structure (DS)



Practice Description

A drop structure is an erosion-control structure created by constructing a barrier across a drainageway or installing a permanent manufactured product down a slope. The purpose of a drop structure is to convey concentrated flow storm runoff from the top to the bottom of a slope or to lower water from a grassed swale into an open channel such as an intermittent or perennial stream. This practice applies where other erosion-control measures are insufficient to prevent excessive erosion and off-site sedimentation.

Planning Considerations

This practice applies to the following sites: 1) where earth and vegetation cannot safely handle water at permissible velocities; 2) where excessive grades or over-fall conditions are encountered; and/or 3) where water is to be structurally lowered from one elevation to another. These structures should be planned and installed as a part of an overall surface-water disposal system. This practice does not apply to storm sewers, concrete over-fall structures, in-channel grade-control structures, or road culverts.

Design Criteria and Construction

Design and specifications shall be prepared for each structure on an individual job basis depending on its purpose and site conditions.

Capacity

The minimum design capacity for pipe structures shall be as required to pass the peak runoff expected from a 2-year frequency, 24-hour duration storm. Peak rates of runoff values used to determine the capacity requirements should be calculated using accepted engineering methods. Some accepted methods are:

- Natural Resources Conservation Service, National Engineering Handbook Series, Part 650, Engineering Field Handbook, Chapter 2, Estimating Runoff.
- Natural Resources Conservation Service (formerly Soil Conservation Service), Technical Release 55, Urban Hydrology for Small Watersheds.
- Other comparable methods – See *Appendix A: Erosion and Stormwater Runoff Calculations* found in the Appendices Volume.

Runoff computation will be based upon the most severe soil and cover conditions that will exist in the area draining into the pipe structures during the planned life of the structure.

All pipe structures should be designed as island type with an emergency spillway to safely pass storm runoff greater than the structure design storm. The minimum total capacity of the principal and emergency spillways shall be that required to handle the 25-year 24-hour duration storm, or the peak rate of flow from the contributing structure, whichever is greater.

General

The planning and design of antivortex devices, trash racks, and anti-seep collars should be in accordance with the requirements for principal spillway pipe design in the *Sediment Basin Practice*. Outlet protection should be designed according to the *Outlet Protection Practice*.

The crest elevation for the emergency spillway shall be set at the minimum level necessary to ensure full pipe flow of the principal spillway. The top of the settled embankment shall be based on 1 foot of freeboard above the design flow depth in the emergency spillway.

Straight pipe structures should be built in accordance with Figure DS-1.

Pipe drop structures should be built in accordance with Figure DS-2.




Figure DS-1 Straight Pipe Structure




Figure DS-2 Pipe Drop Structure

Construction

Prior to the start of construction, drop structures should be designed by a qualified design professional.

Plans and specifications should be referred to by field personnel throughout the construction process. The drop structure should be built according to planned grades and dimensions.

Note: Construction of an embankment with spillways is the only type of drop structure covered in this edition of the manual.

Consider the following guidance as construction proceeds:

Site Preparation

Locate all utilities at the site to ensure avoidance (See Appendix C: MS One-Call and 811 Color Coding).

Clear, grub, and strip the dam foundation and emergency spillway area, removing all woody vegetation, rocks and other objectionable material. Dispose of trees, limbs, logs, and other debris in designated disposal areas.

Stockpile surface soil for use later during topsoiling.

Clear the sediment pool to facilitate sediment clean-out and dispose of trees, limbs, logs, and other debris in designated disposal areas.

Principal Spillway

Prepare the pipe bedding and situate the spillway barrel (pipe) on a firm, even foundation.

Install anti-seep collars according to the design plan.

Place around the barrel 4" layers of moist, clayey, workable soil (not pervious material such as sand, gravel or silt), and compact with hand tampers to at least the density of the foundation soil. (Do not raise the pipe from the foundation when compacting under the pipe haunches.)

At the pipe inlet, install *Inlet Protection* according to the design plan.

At the pipe outlet, install *Outlet Protection* according to the design plan (if not specific, use a riprap apron at least 5 feet wide to a stable grade).

Embankment

Scarify the foundation of the dam before placing fill. Use fill from predetermined borrow areas. It should be clean, stable soil free of roots, woody vegetation, rocks and other debris, and must be wet enough to form a ball without crumbling, yet not so wet that water can be squeezed out.

Place the most permeable soil in the downstream toe and the least permeable in the center portion of the dam.

Protect the spillway barrel with 2 feet of fill that has been compacted with hand tampers before traversing over the pipe with equipment.

Compact the fill material in 6" to 8" continuous layers over the length of the embankment. One way is by routing construction equipment so that each layer is traversed by at least one wheel of the equipment.

Construct and compact the embankment to an elevation 10% above the design height to allow for settling. The embankment should have a minimum 8-foot top width and 3:1 (Horizontal: Vertical) side slopes, but the design may specify additional width and gentler side slopes.

Emergency Spillway

Construct the spillway at the site located by the qualified design professional according to the plan design (in undisturbed soil around one end of the embankment, and so that any flow will return to the receiving channel without damaging the embankment).

Erosion Control

Minimize the size of all disturbed areas.

Use temporary diversions to prevent surface water from running onto disturbed areas.

Vegetate and stabilize the embankment, the emergency spillway and all disturbed areas immediately after construction.

Construction Verification

Check the finished grades and configuration for all earthwork. Check elevations and dimensions of all pipes and structures.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate drop structure will not function as intended.

Seepage is encountered during construction; it may be necessary to install drains.

Design specifications for fill, pipe, seed variety or seeding dates cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Maintenance

Inspect the drop structure after each storm event until it is completely stabilized with vegetation.

Periodically check the embankment, emergency spillway and outlet for erosion damage, piping, settling, seepage or slumping along the toe or around the barrel and repair immediately.

References

BMPs from Volume 1

Chapter 4

Outlet Protection (OP)	4-199
Block and Gravel Inlet Protection (BIP)	4-233
Excavated Inlet Protection (EIP)	4-239
Fabric Drop Inlet Protection (FIP)	4-243
Straw Bale Inlet Protection (SBIP)	4-249

Grass Swale (GS)



Practice Description

A grass swale is a natural or constructed channel that is shaped or graded to required dimensions and established with suitable vegetation for the stable conveyance of runoff without causing damage to the channel by erosion. This practice applies to the following sites: 1) where concentrated runoff will cause erosion damage; 2) a vegetative lining provides sufficient stability for the channel as designed; and/or 3) space is available for a relatively large cross section. Typical situations where concentrated-flow areas are addressed with a grass swale include roadside ditches, channels at property boundaries, outlets for diversions and other concentrated-flow areas subject to channel erosion. Grassed swales are generally considered permanent structures but may be used as a temporary measure. Grassed swales as permanent structures are discussed further in Chapter 4 of Volume 2 - *Stormwater Management Manual*.

Planning Considerations

Grass swales should be carefully built to the design cross section, shape, and dimensions specified. Swales are hydraulic structures and as such depend upon the hydraulic parameters to function satisfactorily. Vegetated swales should be well established before large flows are permitted in the channel.

The design of a channel cross section and lining is based primarily upon the volume and velocity of flow expected in the channel. This practice covers grassed swales with low-velocity flows (generally less than 5 ft/sec). Where high velocities are anticipated, lined swales should be used (see *Lined Swale Practice* or *Riprap-lined Swale Practice*). Lined swales should also be used where there is continuous flow in the swale, which would prevent establishment of vegetation within the flow area.

Besides the primary design considerations of capacity and velocity, a number of other important factors should be taken into account when selecting a cross section (Figure GS-1). These factors include land availability, compatibility with land use and surrounding environment, safety, maintenance requirements outlet conditions, etc.




Figure GS-1 Typical Grass Swale Cross Section

Triangular Shaped Ditches

Triangular-shaped ditches are generally used where the quantity of water to be handled is relatively small, such as along roadsides. A triangular grass swale will suffice where velocities in the ditch are low.

Parabolic Channels

Parabolic channels are often used where the quantity of water to be handled is larger and where space is available for a wide, shallow channel with low-velocity flow.

Trapezoidal Channels

Trapezoidal channels are often used where the quantity of water to be carried is large and conditions require that it be carried at a relatively high velocity. Trapezoidal ditches are

generally lined with concrete or riprap, but in some cases can be grassed swales, if lined with erosion control blankets (see *Erosion Control Blanket Practice*).

Other Considerations

Outlet conditions for all channels should be considered. Appropriate measures must be taken to dissipate the energy of the flow to prevent scour at the outlet of the swale.

Grass swales should be protected from erosion by concentrated flows. The methods of protecting grass swales would include, but not be limited to, the following:

- Vegetation.
- A combination of biodegradable linings and vegetation.

The type and intensity of the protective linings will determine the design of the grass swale.

If velocities exceed stable velocities, for vegetated swales or vegetation with biodegradable linings, then other linings should be used (see *Lined Swale or Riprap-lined Swale Practice*).

The time of the year should be considered when planning grass swales. Grass swales that are seeded to establish vegetation should not be planned for construction during late fall, winter or early spring. Grass swales constructed during mid-summer to early fall may need temporary seeding followed by permanent seeding at the recommended times. The vegetation species should be recommended for the area of the state that it is planned.

Design Criteria

Capacity

Grass swales shall be designed to convey the peak rate of runoff as shown in Table GS-1. Adjustments should be made for release rates from structures and other drainage facilities. Grass swales shall also be designed to comply with local stormwater ordinances. Grass swales should be designed for greater capacity whenever there is danger of flooding or out-of-bank flow cannot be tolerated.

Table GS-1 Design Frequency for Grassed Swale

Grass Swale Type	Typical Area of Protection	24-Hour Design Storm Frequency
Temporary	Construction Areas	2-year
	Building Sites	5-year
Permanent	Agricultural Land	10-year
	Mined Reclamation Area	10-year
	Recreation Areas	10-year
	Isolated Buildings	10-year
	Urban areas, Residential, School, Industrial Areas, etc.	10-year

Peak rates of runoff values used to determine the capacity requirements should be calculated using accepted engineering methods. Some accepted methods are:

- Natural Resources Conservation Service, National Engineering Handbook Series, Part 650, Engineering Field Handbook, Chapter 2, Estimating Runoff.
- Natural Resources Conservation Service (formerly Soil Conservation Service), Technical Release 55, Urban Hydrology for Small Watersheds.
- Other comparable methods – See Appendix A: Erosion and Stormwater Runoff Calculations found in the Appendices Volume.

Grade of Grass Swale

After selecting a location for the grassed swale that will minimize the impacts to the site and maximize the intended use, the grade in the grass swales should be determined. The grade in feet per 100 feet of length can be determined from a topographic map of the site or from a detailed survey of the planned grassed swale location.

Retardance

The type grass used to vegetate the grassed swale and the degree of maintenance planned for the vegetation determine the retardance of the swale (see Table GS-2).

Generally, the retardance used for the design of grassed swales should be “D” and “C” to produce a stable velocity and adequate capacity to carry the design storm.

Table GS-2 Retardance for Grassed Swales

Retardance	Species	Cover Condition
A	Reed Canarygrass	Excellent stand, tall (average 36")
	Yellow Bluestem <i>Ischaemum</i>	Excellent stand, tall (average 36")
B	Smooth Bromegrass	Good stand, mowed (average 12 to 15")
	Bermuda Grass	Good stand, tall (average 12")
	Native Grass Mixture (Little Bluestem, Blue Grama, and other long and short Midwest Grasses)	Good stand, unmowed
	Tall Fescue	Good stand, unmowed (average 18")
	<i>Lespedeza sericea</i>	Good stand, not woody, tall (average 19")
	Grass-Legume mixture-Timothy, Smooth Bromegrass, or Orchardgrass	Good stand, uncut (average 20")
	Reed Canarygrass	Good stand, mowed (average 12 to 15")
	Tall Fescue, with Bird's Foot Trefoil or Ladino Clover	Good stand, uncut (average 18")
	Blue Grama	Good stand, uncut (average 13")
	C	Bahiagrass
Bermuda Grass		Good stand, mowed (average 6")
Redtop		Good stand, headed (15 to 20")
Grass-Legume Mixture-Summer (Orchardgrass, Redtop, Italian Ryegrass, and Common <i>Lespedeza</i>)		Good stand, uncut (6 to 8")
Centipede grass		Very dense cover (average 6")
Kentucky Bluegrass		Good stand, headed (6 to 12")
D	Bermuda Grass	Good stand, cut to 2.5" height
	Red Fescue	Good stand, headed (12 to 18")
	Buffalo Grass	Good stand, uncut (3 to 6")
	Grass-Legume Mixture-fall, spring (Orchard Grass, Redtop, Italian Ryegrass, and Common <i>Lespedeza</i>)	Good stand, uncut (4 to 5")
	<i>Lespedeza sericea</i>	After cutting to 2" height. Very good stand before cutting
	E	Bermuda Grass
Bermuda Grass		Burned stubble

Velocities

Classify the soil where the swale is to be constructed into erosion-resistant cohesive (clayey) fine and coarse-grained soils or easily eroded noncohesive silt, clays and sands.

Determine the type of vegetative cover to be established in the swale.

Use the swale grade, cover, and soil erodibility to determine permissible velocity using Table GS-3.

Swale Dimensions

The swale may be triangular shaped, parabolic or trapezoidal, as discussed in the planning considerations of this practice and shown in Figure GS-1.

Using the peak discharge, swale grade, permissible velocity and retardance, the parabolic dimensions can be determined using Table GS-4 (Sheets 1 through 14).

Table GS-3 Permissible Velocities in Grassed Swales

Cover	Slope Range ² <i>percent</i>	Permissible Velocity ¹	
		Erosion-Resistant Soils ³ (clayey) ft/sec	Easily Eroded Soils ⁴ (sandy) ft/sec
Bermuda Grass	<5	8	6
	5-10	7	4
	over 10	6	3
Bahiagrass Tall Fescue	<5	7	5
	5-10	6	4
	over 10	5	3
sericea lespedeza Weeping Lovegrass	<5 ⁵	3.5	2.5

¹ Use velocities exceeding (5ft/sec) only where good covers and proper maintenance can be obtained.

² Do not use on slopes steeper than 10 percent except for vegetated side slopes in combination with a stone, concrete, or highly resistant vegetative center section.

³ Cohesive (clayey) fine-grain soils and coarse-grain soils with cohesive fines with a plasticity index of 10 to 40 (CL, CH, SC, and CG).

⁴ Soils that do not meet requirements for erosion-resistant soils.

⁵ Do not use on slopes steeper than 5 percent except for vegetated side slopes in combination with a stone, concrete, or highly resistant vegetative center section.

Design dimensions for triangular-shaped and trapezoidal-shaped swales can be determined using Manning's equation or other accepted engineering designs. (See Appendix A: *Channel Geometry*.)

The design water surface elevation of a channel receiving water from other tributary sources shall be equal to or less than the design water surface elevation of the contributing source. The design water surface elevation of contributing and receiving waters should be the same, whenever practical.

A minimum depth may be necessary to provide adequate outlets for subsurface drains and tributary channels.

Drainage

Polyethylene drainage tubing, tile, or other suitable subsurface drainage measures shall be provided for sites having high water tables or seepage problems.

Freeboard

The minimum freeboard is 0.25 foot in depth. Freeboard is not required on grass swales with less than 1% slope and where out-of-bank flow will not be damaging and can be tolerated in the normal operation at the site.

Table GS-4 Parabolic Grass Swale Design Sheet 1 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"
Grade 0.25 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2	T	D	V2	T	D	V2	T	D	V2	T	D	V2	T	D	V2									
5																											
10																											
15																											
20																											
25	9.3	2.3	1.7																								
30	11.7	2.2	1.8																								
35	14.1	2.1	1.7																								
40	16.3	2.1	1.8																								
45	18.5	2.1	1.8	10.4	2.8	2.3																					
50	20.7	2.1	1.8	12.3	2.6	2.3																					
55	22.9	2.1	1.8	13.8	2.6	2.3																					
60	25.0	2.0	1.8	15.3	2.5	2.3																					
65	27.2	2.0	1.8	16.8	2.5	2.3	10.4	3.4	2.8																		
70	29.3	2.0	1.8	18.2	2.5	2.3	12.1	3.1	2.8																		
75	31.9	2.0	1.7	19.7	2.4	2.3	13.5	3.0	2.8																		
80	34.0	2.0	1.7	21.1	2.4	2.3	14.7	2.9	2.8																		
85	36.1	2.0	1.7	22.5	2.4	2.3	15.8	2.9	2.8																		
90	38.2	2.0	1.7	23.9	2.4	2.3	16.9	2.8	2.8																		
95	40.3	2.0	1.7	25.3	2.4	2.3	18.0	2.8	2.8																		
100	42.4	2.0	1.7	26.7	2.4	2.3	19.1	2.8	2.8																		
105	44.6	2.0	1.7	28.1	2.4	2.3	20.2	2.8	2.8																		
110	46.7	2.0	1.7	29.5	2.4	2.3	21.3	2.8	2.8	12.9	3.8	3.4															
115	48.8	2.0	1.7	30.8	2.4	2.3	22.3	2.8	2.8	14.0	3.7	3.4															
120	50.9	2.0	1.7	32.2	2.4	2.3	23.4	2.8	2.8	15.3	3.5	3.4															
125	53.0	2.0	1.8	33.6	2.4	2.3	24.4	2.8	2.8	16.1	3.5	3.4															
130	55.1	2.0	1.8	35.0	2.4	2.3	25.5	2.8	2.8	16.9	3.4	3.4															
135	57.3	2.0	1.8	36.4	2.4	2.3	26.5	2.7	2.8	17.7	3.4	3.4															
140	59.4	2.0	1.8	38.3	2.4	2.3	27.6	2.7	2.8	18.5	3.4	3.4															
145	61.5	2.0	1.8	39.7	2.4	2.3	28.6	2.7	2.8	19.3	3.3	3.4															
150	63.6	2.0	1.8	41.1	2.4	2.3	29.6	2.7	2.8	20.1	3.3	3.4															

T = Top width, tall vegetation
 D = Depth, tall vegetation
 V2 = Design velocity, tall vegetation
 V1 = Permissible velocity, short vegetation

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 2 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"
Grade 0.50 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2	T	D	V2	T	D	V2																		
5																											
10																											
15	8.4	1.6	1.7																								
20	11.7	1.5	1.7	7.1	2.0	2.2																					
25	14.9	1.5	1.7	9.7	1.8	2.2																					
30	18.0	1.5	1.7	12.0	1.7	2.2																					
35	21.0	1.5	1.7	14.2	1.7	2.2	9.3	2.1	2.7																		
40	24.4	1.5	1.7	16.3	1.7	2.2	10.9	2.0	2.7																		
45	27.4	1.5	1.7	18.5	1.7	2.2	12.5	2.0	2.7																		
50	30.5	1.5	1.7	20.6	1.7	2.2	14.1	1.9	2.7	8.7	2.6	3.3															
55	33.5	1.5	1.7	22.7	1.7	2.2	15.7	1.9	2.7	10.4	2.4	3.3															
60	36.6	1.5	1.7	24.8	1.7	2.2	17.2	1.9	2.7	11.7	2.3	3.3															
65	39.6	1.5	1.7	27.3	1.7	2.2	18.8	1.9	2.7	12.9	2.3	3.3															
70	42.6	1.5	1.7	29.4	1.7	2.2	20.3	1.9	2.7	14.0	2.2	3.3	9.8	2.8	3.8												
75	45.7	1.5	1.7	31.4	1.7	2.2	21.8	1.9	2.7	15.2	2.2	3.3	11.3	2.7	3.8												
80	48.7	1.5	1.7	33.5	1.7	2.2	23.3	1.9	2.7	16.3	2.2	3.3	12.2	2.6	3.8												
85	51.7	1.5	1.7	35.6	1.6	2.2	24.8	1.9	2.7	17.4	2.2	3.3	13.2	2.5	3.8												
90	54.8	1.5	1.7	37.7	1.6	2.2	26.3	1.9	2.7	18.5	2.2	3.3	14.2	2.5	3.8												
95	57.8	1.5	1.7	39.8	1.6	2.2	27.8	1.9	2.7	19.6	2.2	3.3	15.1	2.5	3.8												
100	60.9	1.5	1.7	41.9	1.6	2.2	29.7	1.9	2.7	20.7	2.2	3.3	16.0	2.5	3.8	11.0	3.2	4.3									
105	63.9	1.5	1.7	44.0	1.6	2.2	31.2	1.9	2.7	21.8	2.2	3.3	16.9	2.5	3.8	12.3	3.0	4.3									
110	66.9	1.5	1.7	46.1	1.6	2.2	32.6	1.9	2.7	22.9	2.2	3.3	17.8	2.4	3.8	13.1	2.9	4.3									
115	70.0	1.5	1.7	48.1	1.6	2.2	34.1	1.9	2.7	24.0	2.1	3.3	18.7	2.4	3.8	13.9	2.9	4.3									
120	73.0	1.5	1.7	50.2	1.6	2.2	35.6	1.9	2.7	25.1	2.1	3.3	19.6	2.4	3.8	14.6	2.9	4.3									
125	76.1	1.5	1.7	52.3	1.6	2.2	37.1	1.9	2.7	26.2	2.1	3.3	20.5	2.4	3.8	15.4	2.8	4.3									
130	79.1	1.5	1.7	54.4	1.6	2.2	38.5	1.9	2.7	27.3	2.1	3.3	21.3	2.4	3.8	16.1	2.8	4.3									
135	82.1	1.5	1.7	56.5	1.6	2.2	40.0	1.9	2.7	28.4	2.1	3.3	22.2	2.4	3.8	16.9	2.8	4.3									
140	85.2	1.5	1.7	58.6	1.6	2.2	41.5	1.9	2.7	29.4	2.1	3.3	23.1	2.4	3.8	17.6	2.8	4.3									
145	88.2	1.5	1.7	60.7	1.6	2.2	43.0	1.9	2.7	30.5	2.1	3.3	24.0	2.4	3.8	18.3	2.8	4.3	12.3	3.7	4.9						
150	91.3	1.6	1.7	62.8	1.6	2.2	44.5	1.9	2.7	31.6	2.1	3.3	24.8	2.4	3.8	19.0	2.7	4.3	13.1	3.5	4.9						

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 3 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																													
Grade 0.75 Percent																													
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0				
	T	D	V2	T	D	V2	T	D																					
5																													
10	7.0	1.3	1.6																										
15	11.0	1.3	1.6	7.1	1.5	2.1																							
20	14.9	1.3	1.6	9.9	1.4	2.1	6.1	1.9	2.6																				
25	18.9	1.2	1.6	12.7	1.4	2.1	8.6	1.6	2.7																				
30	22.7	1.2	1.6	15.3	1.4	2.1	10.6	1.6	2.6	6.7	2.1	3.2																	
35	26.5	1.2	1.6	18.0	1.4	2.1	12.6	1.6	2.7	8.7	1.9	3.2																	
40	30.2	1.2	1.6	20.6	1.4	2.1	14.5	1.6	2.7	10.3	1.8	3.2																	
45	34.0	1.2	1.6	23.5	1.4	2.1	16.4	1.5	2.7	11.8	1.8	3.2	7.8	2.3	3.8														
50	37.8	1.2	1.6	26.1	1.4	2.1	18.3	1.5	2.7	13.2	1.8	3.2	9.5	2.1	3.8														
55	41.5	1.2	1.6	28.7	1.4	2.1	20.2	1.5	2.7	14.7	1.7	3.2	10.7	2.0	3.8														
60	45.3	1.2	1.6	31.3	1.4	2.1	22.1	1.5	2.7	16.1	1.7	3.2	11.8	2.0	3.8														
65	49.1	1.2	1.6	33.9	1.4	2.1	24.3	1.5	2.6	17.6	1.7	3.2	13.0	2.0	3.8	8.5	2.6	4.4											
70	52.9	1.2	1.6	36.5	1.4	2.1	26.2	1.5	2.6	19.0	1.7	3.2	14.1	2.0	3.8	10.0	2.4	4.3											
75	56.6	1.2	1.6	39.1	1.4	2.1	28.0	1.5	2.6	20.4	1.7	3.2	15.2	2.0	3.8	11.0	2.4	4.4											
80	60.4	1.2	1.6	41.7	1.4	2.1	29.9	1.5	2.6	21.8	1.7	3.2	16.3	1.9	3.8	11.9	2.3	4.4											
85	64.2	1.2	1.6	44.3	1.4	2.1	31.8	1.5	2.6	23.2	1.7	3.2	17.4	1.9	3.8	12.8	2.3	4.4	9.1	2.9	4.8								
90	67.9	1.2	1.6	46.9	1.4	2.1	33.6	1.5	2.6	24.6	1.7	3.2	18.5	1.9	3.8	13.7	2.3	4.4	10.3	2.7	4.8								
95	71.7	1.2	1.6	49.5	1.4	2.1	35.5	1.5	2.6	26.0	1.7	3.2	19.6	1.9	3.8	14.6	2.2	4.4	11.4	2.6	4.8								
100	75.5	1.2	1.6	52.1	1.4	2.1	37.3	1.5	2.6	27.8	1.7	3.2	20.7	1.9	3.8	15.4	2.2	4.4	12.2	2.6	4.8								
105	79.3	1.2	1.6	54.7	1.4	2.1	39.2	1.5	2.6	29.1	1.7	3.2	21.8	1.9	3.8	16.3	2.2	4.4	12.9	2.5	4.8								
110	83.0	1.2	1.6	57.3	1.4	2.1	41.1	1.5	2.6	30.5	1.7	3.2	22.8	1.9	3.8	17.2	2.2	4.4	13.7	2.5	4.8								
115	86.8	1.2	1.6	59.9	1.4	2.1	42.9	1.5	2.6	31.9	1.7	3.2	23.9	1.9	3.8	18.0	2.2	4.4	14.4	2.5	4.8	10.5	3.1	5.3					
120	90.6	1.2	1.6	62.5	1.4	2.1	44.8	1.5	2.7	33.3	1.7	3.2	25.0	1.9	3.8	18.9	2.2	4.4	15.2	2.5	4.8	11.4	3.0	5.3					
125	94.3	1.2	1.6	65.1	1.4	2.1	46.7	1.5	2.7	34.7	1.7	3.2	26.0	1.9	3.8	19.7	2.2	4.4	15.9	2.4	4.8	12.4	2.9	5.3					
130	98.1	1.2	1.6	67.7	1.4	2.1	48.5	1.5	2.7	36.0	1.7	3.2	27.1	1.9	3.8	20.5	2.2	4.4	16.6	2.4	4.8	13.0	2.8	5.3					
135	101.9	1.2	1.6	70.3	1.4	2.1	50.4	1.5	2.7	37.4	1.7	3.2	28.2	1.9	3.8	21.4	2.2	4.4	17.3	2.4	4.8	13.7	2.8	5.3					
140	105.7	1.2	1.6	72.9	1.4	2.1	52.2	1.5	2.7	38.8	1.7	3.2	29.3	1.9	3.8	22.2	2.2	4.4	18.0	2.4	4.9	14.3	2.8	5.3					
145	109.4	1.2	1.6	75.5	1.4	2.1	54.1	1.5	2.7	40.2	1.7	3.2	30.8	1.9	3.7	23.1	2.2	4.4	18.7	2.4	4.9	14.9	2.7	5.3					
150	113.2	1.2	1.6	78.1	1.4	2.1	56.0	1.5	2.7	41.6	1.7	3.2	31.9	1.9	3.7	23.9	2.1	4.4	19.4	2.4	4.9	15.5	2.7	5.3					

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 4 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"

Grade 1.00 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0					
	T	D	V2	T	D	V2																								
5																														
10	8.2	1.2	1.6	5.2	1.4	2.0																								
15	12.6	1.1	1.6	8.7	1.3	2.1	5.5	1.6	2.6																					
20	17.1	1.1	1.6	11.8	1.2	2.1	8.2	1.4	2.6																					
25	21.4	1.1	1.6	14.9	1.2	2.1	10.5	1.4	2.6	7.3	1.6	3.1																		
30	25.7	1.1	1.6	18.0	1.2	2.1	12.8	1.4	2.6	9.1	1.6	3.2																		
35	29.9	1.1	1.6	21.2	1.2	2.1	15.0	1.3	2.6	10.9	1.5	3.1	7.8	1.8	3.7															
40	34.2	1.1	1.6	24.3	1.2	2.1	17.3	1.3	2.6	12.6	1.5	3.1	9.2	1.7	3.7															
45	38.5	1.1	1.6	27.3	1.2	2.1	19.5	1.3	2.6	14.3	1.5	3.1	10.6	1.7	3.7	7.2	2.2	4.3												
50	42.7	1.1	1.6	30.3	1.2	2.1	21.9	1.3	2.6	16.0	1.5	3.2	11.9	1.7	3.7	8.8	2.0	4.3												
55	47.0	1.1	1.6	33.3	1.2	2.1	24.1	1.3	2.6	17.7	1.5	3.2	13.3	1.7	3.7	9.9	1.9	4.3												
60	51.3	1.1	1.6	36.3	1.2	2.1	26.3	1.3	2.6	19.3	1.5	3.2	14.6	1.7	3.7	11.0	1.9	4.3												
65	55.5	1.1	1.6	39.4	1.2	2.1	28.5	1.3	2.6	21.0	1.5	3.2	15.9	1.6	3.7	12.1	1.9	4.3	8.0	2.5	4.9									
70	59.8	1.1	1.6	42.4	1.2	2.1	30.7	1.3	2.6	22.7	1.5	3.2	17.1	1.6	3.7	13.2	1.9	4.3	9.5	2.3	4.8									
75	64.1	1.1	1.6	45.4	1.2	2.1	32.9	1.3	2.6	24.6	1.5	3.1	18.5	1.6	3.7	14.2	1.8	4.3	10.4	2.2	4.9									
80	68.3	1.1	1.6	48.4	1.2	2.1	35.0	1.3	2.6	26.2	1.5	3.1	19.8	1.6	3.7	15.2	1.8	4.3	11.3	2.2	4.9									
85	72.6	1.1	1.6	51.5	1.2	2.1	37.2	1.3	2.6	27.9	1.5	3.1	21.0	1.6	3.7	16.3	1.8	4.3	12.1	2.2	4.9	8.8	2.7	5.4						
90	76.9	1.1	1.6	54.5	1.2	2.1	39.4	1.3	2.6	29.5	1.5	3.1	22.3	1.6	3.7	17.3	1.8	4.3	13.0	2.1	4.9	9.8	2.6	5.4						
95	81.1	1.1	1.6	57.5	1.2	2.1	41.6	1.3	2.6	31.1	1.5	3.1	23.6	1.6	3.7	18.3	1.8	4.3	13.8	2.1	4.9	10.9	2.5	5.3						
100	85.4	1.1	1.6	60.5	1.2	2.1	43.8	1.3	2.6	32.7	1.5	3.1	24.9	1.6	3.7	19.3	1.8	4.3	14.6	2.1	4.9	11.6	2.4	5.4						
105	89.7	1.1	1.6	63.6	1.2	2.1	46.0	1.3	2.6	34.4	1.5	3.1	26.5	1.6	3.7	20.3	1.8	4.3	15.4	2.1	4.9	12.4	2.4	5.4	9.7	2.8	5.8			
110	94.0	1.1	1.6	66.6	1.2	2.1	48.2	1.3	2.6	36.0	1.5	3.1	27.7	1.6	3.7	21.3	1.8	4.3	16.2	2.1	4.9	13.1	2.4	5.4	10.8	2.6	5.8			
115	98.2	1.1	1.6	69.6	1.2	2.1	50.4	1.3	2.6	37.6	1.5	3.1	29.0	1.6	3.7	22.3	1.8	4.3	17.0	2.1	4.9	13.8	2.3	5.4	11.5	2.6	5.8			
120	102.5	1.1	1.6	72.6	1.2	2.1	52.5	1.3	2.6	39.3	1.5	3.1	30.2	1.6	3.7	23.3	1.8	4.3	17.9	2.1	4.9	14.5	2.3	5.4	12.2	2.6	5.8			
125	106.8	1.1	1.6	75.7	1.2	2.1	54.7	1.3	2.6	40.9	1.5	3.1	31.5	1.6	3.7	24.3	1.8	4.3	18.7	2.1	4.9	15.2	2.3	5.4	12.8	2.5	5.8			
130	111.0	1.1	1.6	78.7	1.2	2.1	56.9	1.3	2.6	42.5	1.5	3.1	32.7	1.6	3.7	25.3	1.8	4.3	19.4	2.1	4.9	15.9	2.3	5.4	13.4	2.5	5.8			
135	115.3	1.1	1.6	81.7	1.2	2.1	59.1	1.3	2.6	44.2	1.5	3.1	34.0	1.6	3.7	26.3	1.8	4.3	20.2	2.0	4.9	16.6	2.3	5.4	14.1	2.5	5.8			
140	119.6	1.1	1.6	84.7	1.2	2.1	61.3	1.3	2.6	45.8	1.5	3.1	35.2	1.6	3.7	27.3	1.8	4.3	21.0	2.0	4.9	17.2	2.3	5.4	14.7	2.5	5.8			
145	123.8	1.1	1.6	87.8	1.2	2.1	63.5	1.3	2.6	47.5	1.5	3.1	36.5	1.6	3.7	28.7	1.8	4.3	21.8	2.0	4.9	17.9	2.3	5.4	15.3	2.5	5.8			
150	128.1	1.1	1.6	90.8	1.2	2.1	65.7	1.3	2.6	49.1	1.5	3.1	37.8	1.6	3.7	29.7	1.8	4.3	22.6	2.0	4.9	18.6	2.3	5.4	15.9	2.4	5.8			

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 5 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"

Grade 1.25 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	4.1	1.2	1.5																								
10	9.4	1.0	1.5	6.3	1.2	2.0																					
15	14.3	1.0	1.6	9.9	1.1	2.0	6.8	1.3	2.6																		
20	19.4	1.0	1.5	13.4	1.1	2.0	9.5	1.2	2.6	6.7	1.4	3.1															
25	24.2	1.0	1.5	17.0	1.1	2.0	12.1	1.2	2.6	8.8	1.4	3.1	5.9	1.7	3.6												
30	29.0	1.0	1.6	20.4	1.1	2.0	14.6	1.2	2.6	10.7	1.4	3.1	7.8	1.6	3.7												
35	33.8	1.0	1.6	23.8	1.1	2.0	17.1	1.2	2.6	12.7	1.3	3.1	9.4	1.5	3.7	6.5	1.9	4.2									
40	38.6	1.0	1.6	27.1	1.1	2.0	19.8	1.2	2.5	14.6	1.3	3.1	10.9	1.5	3.7	8.1	1.7	4.2									
45	43.5	1.0	1.6	30.5	1.1	2.0	22.3	1.2	2.5	16.5	1.3	3.1	12.5	1.5	3.7	9.4	1.7	4.2									
50	48.3	1.0	1.6	33.9	1.1	2.0	24.8	1.2	2.5	18.3	1.3	3.1	13.9	1.5	3.7	10.6	1.7	4.2	7.7	2.0	4.8						
55	53.1	1.0	1.6	37.3	1.1	2.0	27.2	1.2	2.6	20.5	1.3	3.1	15.4	1.5	3.7	11.8	1.6	4.3	9.0	1.9	4.8						
60	57.9	1.0	1.6	40.7	1.1	2.0	29.7	1.2	2.6	22.3	1.3	3.1	16.9	1.5	3.7	13.0	1.6	4.3	10.1	1.9	4.8						
65	62.8	1.0	1.6	44.1	1.1	2.0	32.2	1.2	2.6	24.2	1.3	3.1	18.3	1.5	3.7	14.2	1.6	4.3	11.1	1.8	4.8	8.0	2.3	5.3			
70	67.6	1.0	1.6	47.5	1.1	2.0	34.6	1.2	2.6	26.0	1.3	3.1	19.8	1.4	3.7	15.4	1.6	4.3	12.0	1.8	4.8	9.3	2.1	5.3			
75	72.4	1.0	1.6	50.8	1.1	2.0	37.1	1.2	2.6	27.9	1.3	3.1	21.2	1.4	3.7	16.5	1.6	4.3	13.0	1.8	4.8	10.1	2.1	5.3			
80	77.2	1.0	1.6	54.2	1.1	2.0	39.6	1.2	2.6	29.7	1.3	3.1	23.0	1.4	3.6	17.7	1.6	4.3	14.0	1.8	4.8	11.0	2.0	5.3			
85	82.1	1.0	1.6	57.6	1.1	2.0	42.0	1.2	2.6	31.6	1.3	3.1	24.4	1.4	3.6	18.8	1.6	4.3	14.9	1.8	4.8	11.8	2.0	5.3			
90	86.9	1.0	1.6	61.0	1.1	2.0	44.5	1.2	2.6	33.5	1.3	3.1	25.8	1.4	3.6	20.0	1.6	4.3	15.9	1.8	4.8	12.6	2.0	5.3	9.1	2.5	5.9
95	91.7	1.0	1.6	64.4	1.1	2.0	47.0	1.2	2.6	35.3	1.3	3.1	27.3	1.4	3.6	21.1	1.6	4.3	16.8	1.8	4.8	13.4	2.0	5.4	10.2	2.4	5.9
100	96.6	1.0	1.6	67.8	1.1	2.0	49.4	1.2	2.6	37.2	1.3	3.1	28.7	1.4	3.6	22.3	1.6	4.3	17.7	1.8	4.8	14.2	2.0	5.4	10.9	2.3	5.9
105	101.4	1.0	1.6	71.2	1.1	2.0	51.9	1.2	2.6	39.0	1.3	3.1	30.1	1.4	3.6	23.4	1.6	4.3	18.7	1.8	4.8	15.0	2.0	5.4	11.6	2.3	5.9
110	106.2	1.0	1.6	74.6	1.1	2.0	54.4	1.2	2.6	40.9	1.3	3.1	31.6	1.4	3.6	24.6	1.6	4.3	19.6	1.7	4.8	15.8	2.0	5.4	12.3	2.3	5.9
115	111.0	1.0	1.6	78.0	1.1	2.0	56.8	1.2	2.6	42.7	1.3	3.1	33.0	1.4	3.6	26.1	1.6	4.2	20.5	1.7	4.8	16.6	1.9	5.4	13.0	2.2	5.9
120	115.9	1.0	1.6	81.3	1.1	2.0	59.3	1.2	2.6	44.6	1.3	3.1	34.4	1.4	3.6	27.2	1.6	4.2	21.5	1.7	4.8	17.3	1.9	5.4	13.6	2.2	5.9
125	120.7	1.0	1.6	84.7	1.1	2.0	61.8	1.2	2.6	46.4	1.3	3.1	35.9	1.4	3.6	28.3	1.6	4.2	22.4	1.7	4.8	18.1	1.9	5.4	14.3	2.2	5.9
130	125.5	1.0	1.6	88.1	1.1	2.0	64.3	1.2	2.6	48.3	1.3	3.1	37.3	1.4	3.7	29.5	1.6	4.2	23.3	1.7	4.8	18.9	1.9	5.4	14.9	2.2	5.9
135	130.3	1.0	1.6	91.5	1.1	2.0	66.7	1.2	2.6	50.2	1.3	3.1	38.7	1.4	3.7	30.6	1.6	4.2	24.2	1.7	4.8	19.6	1.9	5.4	15.6	2.2	5.9
140	135.2	1.0	1.6	94.9	1.1	2.0	69.2	1.2	2.6	52.0	1.3	3.1	40.2	1.4	3.7	31.7	1.6	4.2	25.1	1.7	4.8	20.4	1.9	5.4	16.2	2.2	5.9
145	140.0	1.0	1.6	98.3	1.1	2.0	71.7	1.2	2.6	53.9	1.3	3.1	41.6	1.4	3.7	32.9	1.6	4.2	26.1	1.7	4.8	21.2	1.9	5.4	16.9	2.2	5.9
150	144.8	1.0	1.6	101.7	1.1	2.0	74.1	1.2	2.6	55.7	1.3	3.1	43.0	1.4	3.7	34.0	1.6	4.2	27.0	1.7	4.8	21.9	1.9	5.4	17.5	2.2	5.9

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 6 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"

Grade 1.50 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0			
	T	D	V2																									
5	4.9	1.0	1.5																									
10	10.5	0.9	1.5	7.1	1.1	2.0	4.6	1.3	2.5																			
15	16.0	0.9	1.5	10.9	1.0	2.0	7.8	1.1	2.5	5.3	1.4	3.1																
20	21.3	0.9	1.5	14.7	1.0	2.0	10.6	1.1	2.5	7.7	1.3	3.1	5.1	1.6	3.6													
25	26.6	0.9	1.5	18.6	1.0	2.0	13.4	1.1	2.5	9.9	1.2	3.1	7.3	1.4	3.6													
30	31.9	0.9	1.5	22.3	1.0	2.0	16.2	1.1	2.5	12.0	1.2	3.1	9.0	1.4	3.6	6.8	1.6	4.2										
35	37.3	0.9	1.5	26.0	1.0	2.0	19.1	1.1	2.5	14.1	1.2	3.1	10.7	1.4	3.6	8.1	1.5	4.2										
40	42.6	0.9	1.5	29.7	1.0	2.0	21.8	1.1	2.5	16.2	1.2	3.1	12.4	1.3	3.6	9.5	1.5	4.2	6.9	1.8	4.7							
45	47.9	0.9	1.5	33.4	1.0	2.0	24.5	1.1	2.5	18.3	1.2	3.1	14.0	1.3	3.6	10.8	1.5	4.2	8.3	1.7	4.7							
50	53.2	0.9	1.5	37.1	1.0	2.0	27.3	1.1	2.5	20.6	1.2	3.0	15.7	1.3	3.6	12.1	1.5	4.2	9.4	1.7	4.8							
55	58.5	0.9	1.5	40.8	1.0	2.0	30.0	1.1	2.5	22.7	1.2	3.0	17.3	1.3	3.6	13.4	1.5	4.2	10.5	1.6	4.8	8.1	1.9	5.3				
60	63.8	0.9	1.5	44.5	1.0	2.0	32.7	1.1	2.5	24.7	1.2	3.0	18.9	1.3	3.6	14.7	1.4	4.2	11.6	1.6	4.8	9.1	1.9	5.3				
65	69.2	0.9	1.5	48.2	1.0	2.0	35.4	1.1	2.5	26.8	1.2	3.1	20.8	1.3	3.6	16.0	1.4	4.2	12.7	1.6	4.8	10.0	1.8	5.3				
70	74.5	0.9	1.5	51.9	1.0	2.0	38.2	1.1	2.5	28.8	1.2	3.1	22.4	1.3	3.6	17.3	1.4	4.2	13.7	1.6	4.8	10.9	1.8	5.3	8.2	2.2	5.8	
75	79.8	0.9	1.5	55.6	1.0	2.0	40.9	1.1	2.5	30.9	1.2	3.1	23.9	1.3	3.6	18.6	1.4	4.2	14.8	1.6	4.8	11.8	1.8	5.3	9.3	2.1	5.8	
80	85.1	0.9	1.5	59.4	1.0	2.0	43.6	1.1	2.5	32.9	1.2	3.1	25.5	1.3	3.6	19.9	1.4	4.2	15.8	1.6	4.8	12.7	1.8	5.3	10.1	2.0	5.9	
85	90.4	0.9	1.5	63.1	1.0	2.0	46.3	1.1	2.5	35.0	1.2	3.1	27.1	1.3	3.6	21.2	1.4	4.2	16.9	1.6	4.8	13.6	1.8	5.3	10.9	2.0	5.9	
90	95.8	0.9	1.5	66.8	1.0	2.0	49.0	1.1	2.5	37.1	1.2	3.1	28.7	1.3	3.6	22.8	1.4	4.1	17.9	1.6	4.8	14.5	1.8	5.3	11.6	2.0	5.9	
95	101.1	0.9	1.5	70.5	1.0	2.0	51.8	1.1	2.5	39.1	1.2	3.1	30.3	1.3	3.6	24.0	1.4	4.2	18.9	1.6	4.8	15.3	1.7	5.3	12.4	2.0	5.9	
100	106.4	0.9	1.5	74.2	1.0	2.0	54.5	1.1	2.5	41.2	1.2	3.1	31.9	1.3	3.6	25.3	1.4	4.2	20.0	1.6	4.8	16.2	1.7	5.3	13.1	1.9	5.9	
105	111.7	0.9	1.5	77.9	1.0	2.0	57.2	1.1	2.5	43.2	1.2	3.1	33.5	1.3	3.6	26.5	1.4	4.2	21.0	1.6	4.8	17.0	1.7	5.3	13.9	1.9	5.9	
110	117.0	0.9	1.5	81.6	1.0	2.0	59.9	1.1	2.5	45.3	1.2	3.1	35.1	1.3	3.6	27.8	1.4	4.2	22.0	1.6	4.8	17.9	1.7	5.3	14.6	1.9	5.9	
115	122.4	0.9	1.5	85.3	1.0	2.0	62.6	1.1	2.5	47.3	1.2	3.1	36.7	1.3	3.6	29.1	1.4	4.2	23.1	1.6	4.8	18.8	1.7	5.3	15.3	1.9	5.9	
120	127.7	0.9	1.5	89.0	1.0	2.0	65.4	1.1	2.5	49.4	1.2	3.1	38.3	1.3	3.6	30.3	1.4	4.2	24.1	1.6	4.8	19.6	1.7	5.3	16.1	1.9	5.9	
125	133.0	0.9	1.5	92.7	1.0	2.0	68.1	1.1	2.5	51.4	1.2	3.1	39.9	1.3	3.6	31.6	1.4	4.2	25.4	1.6	4.8	20.5	1.7	5.3	16.8	1.9	5.9	
130	138.3	0.9	1.5	96.4	1.0	2.0	70.8	1.1	2.5	53.5	1.2	3.1	41.4	1.3	3.6	32.8	1.4	4.2	26.4	1.6	4.8	21.3	1.7	5.3	17.5	1.9	5.9	
135	143.6	0.9	1.5	100.1	1.0	2.0	73.5	1.1	2.5	55.6	1.2	3.1	43.0	1.3	3.6	34.1	1.4	4.2	27.4	1.6	4.8	22.2	1.7	5.3	18.2	1.9	5.9	
140	149.0	0.9	1.5	103.9	1.0	2.0	76.3	1.1	2.5	57.6	1.2	3.1	44.6	1.3	3.6	35.3	1.4	4.2	28.5	1.6	4.8	23.0	1.7	5.3	18.9	1.9	5.9	
145	154.3	0.9	1.5	107.6	1.0	2.0	79.0	1.1	2.5	59.7	1.2	3.1	46.2	1.3	3.6	36.6	1.4	4.2	29.5	1.6	4.8	23.8	1.7	5.3	19.7	1.9	5.9	
150	159.6	0.9	1.5	111.3	1.0	2.0	81.7	1.1	2.5	61.7	1.2	3.1	47.8	1.3	3.6	37.9	1.4	4.2	30.5	1.6	4.8	24.7	1.7	5.3	20.4	1.9	5.9	

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 7 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																											
Grade 1.75 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	5.4	0.9	1.5																								
10	11.4	0.9	1.5	7.7	1.0	2.0	5.4	1.1	2.5																		
15	17.3	0.9	1.5	11.8	1.0	2.0	8.6	1.1	2.5	6.2	1.2	3.0															
20	23.1	0.9	1.5	16.0	0.9	2.0	11.6	1.0	2.5	8.6	1.2	3.0	6.3	1.3	3.6												
25	28.8	0.9	1.5	20.0	0.9	2.0	14.6	1.0	2.5	10.9	1.1	3.0	8.2	1.3	3.6	5.9	1.5	4.1									
30	34.6	0.9	1.5	24.0	0.9	2.0	17.8	1.0	2.5	13.2	1.1	3.0	10.1	1.2	3.6	7.6	1.4	4.2									
35	40.3	0.9	1.5	28.0	0.9	2.0	20.7	1.0	2.5	15.5	1.1	3.0	11.9	1.2	3.6	9.1	1.4	4.2	6.9	1.6	4.7						
40	46.1	0.9	1.5	32.0	0.9	2.0	23.7	1.0	2.5	18.0	1.1	3.0	13.7	1.2	3.6	10.6	1.4	4.2	8.2	1.6	4.7						
45	51.9	0.9	1.5	36.0	0.9	2.0	26.6	1.0	2.5	20.2	1.1	3.0	15.4	1.2	3.6	12.0	1.3	4.2	9.4	1.5	4.7	7.0	1.8	5.3			
50	57.6	0.9	1.5	40.0	0.9	2.0	29.6	1.0	2.5	22.4	1.1	3.0	17.2	1.2	3.6	13.5	1.3	4.1	10.6	1.5	4.7	8.3	1.7	5.3			
55	63.4	0.9	1.5	44.0	0.9	2.0	32.5	1.0	2.5	24.7	1.1	3.0	19.2	1.2	3.6	14.9	1.3	4.1	11.8	1.5	4.7	9.3	1.7	5.3	6.7	2.1	5.8
60	69.1	0.9	1.5	48.0	0.9	2.0	35.5	1.0	2.5	26.9	1.1	3.0	20.9	1.2	3.6	16.3	1.3	4.1	12.9	1.5	4.7	10.3	1.6	5.3	8.1	1.9	5.8
65	74.9	0.9	1.5	52.0	0.9	2.0	38.4	1.0	2.5	29.2	1.1	3.0	22.7	1.2	3.6	17.7	1.3	4.1	14.1	1.5	4.7	11.3	1.6	5.3	9.0	1.9	5.8
70	80.7	0.9	1.5	56.0	0.9	2.0	41.4	1.0	2.5	31.4	1.1	3.0	24.4	1.2	3.6	19.1	1.3	4.1	15.2	1.5	4.7	12.3	1.6	5.3	9.8	1.8	5.8
75	86.4	0.9	1.5	60.0	0.9	2.0	44.3	1.0	2.5	33.6	1.1	3.0	26.1	1.2	3.6	20.5	1.3	4.1	16.4	1.4	4.7	13.2	1.6	5.3	10.7	1.8	5.8
80	92.2	0.9	1.5	63.9	0.9	2.0	47.3	1.0	2.5	35.9	1.1	3.0	27.9	1.2	3.6	22.2	1.3	4.1	17.5	1.4	4.7	14.2	1.6	5.3	11.5	1.8	5.8
85	97.9	0.9	1.5	67.9	0.9	2.0	50.2	1.0	2.5	38.1	1.1	3.0	29.6	1.2	3.6	23.5	1.3	4.1	18.6	1.4	4.7	15.1	1.6	5.3	12.3	1.8	5.8
90	103.7	0.9	1.5	71.9	0.9	2.0	53.2	1.0	2.5	40.3	1.1	3.0	31.4	1.2	3.6	24.9	1.3	4.1	19.8	1.4	4.7	16.1	1.6	5.3	13.1	1.8	5.8
95	109.5	0.9	1.5	75.9	0.9	2.0	56.1	1.0	2.5	42.6	1.1	3.0	33.1	1.2	3.6	26.3	1.3	4.1	20.9	1.4	4.7	17.0	1.6	5.3	13.9	1.7	5.8
100	115.2	0.9	1.5	79.9	0.9	2.0	59.1	1.0	2.5	44.8	1.1	3.0	34.8	1.2	3.6	27.7	1.3	4.1	22.0	1.4	4.7	17.9	1.6	5.3	14.7	1.7	5.8
105	121.0	0.9	1.5	83.9	0.9	2.0	62.0	1.0	2.5	47.1	1.1	3.0	36.6	1.2	3.6	29.0	1.3	4.1	23.4	1.4	4.7	18.9	1.6	5.3	15.5	1.7	5.8
110	126.8	0.9	1.5	87.9	0.9	2.0	65.0	1.0	2.5	49.3	1.1	3.0	38.3	1.2	3.6	30.4	1.3	4.1	24.5	1.4	4.7	19.8	1.6	5.3	16.3	1.7	5.8
115	132.5	0.9	1.5	91.9	0.9	2.0	67.9	1.0	2.5	51.5	1.1	3.0	40.1	1.2	3.6	31.8	1.3	4.1	25.6	1.4	4.7	20.7	1.6	5.3	17.1	1.7	5.9
120	138.3	0.9	1.5	95.9	0.9	2.0	70.9	1.0	2.5	53.8	1.1	3.0	41.8	1.2	3.6	33.2	1.3	4.1	26.8	1.4	4.7	21.7	1.6	5.3	17.9	1.7	5.9
125	144.0	0.9	1.5	99.9	0.9	2.0	73.8	1.0	2.5	56.0	1.1	3.0	43.5	1.2	3.6	34.6	1.3	4.1	27.9	1.4	4.7	22.6	1.6	5.3	18.7	1.7	5.9
130	149.8	0.9	1.5	103.9	0.9	2.0	76.8	1.0	2.5	58.3	1.1	3.0	45.3	1.2	3.6	35.9	1.3	4.1	29.0	1.4	4.7	23.5	1.6	5.3	19.4	1.7	5.9
135	155.6	0.9	1.5	107.9	0.9	2.0	79.7	1.0	2.5	60.5	1.1	3.0	47.0	1.2	3.6	37.3	1.3	4.1	30.1	1.4	4.7	24.5	1.6	5.3	20.2	1.7	5.9
140	161.3	0.9	1.5	111.9	0.9	2.0	82.7	1.0	2.5	62.7	1.1	3.0	48.8	1.2	3.6	38.7	1.3	4.1	31.2	1.4	4.7	25.7	1.6	5.3	21.0	1.7	5.9
145	167.1	0.9	1.5	115.9	0.9	2.0	85.6	1.0	2.5	65.0	1.1	3.0	50.5	1.2	3.6	40.1	1.3	4.1	32.3	1.4	4.7	26.6	1.6	5.3	21.8	1.7	5.9
150	172.8	0.9	1.5	119.9	0.9	2.0	88.6	1.0	2.5	67.2	1.1	3.0	52.2	1.2	3.6	41.5	1.3	4.1	33.4	1.4	4.7	27.5	1.6	5.3	22.6	1.7	5.9

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 8 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"
Grade 2.00 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	5.9	0.9	1.5																								
10	12.4	0.8	1.5	8.1	0.9	2.0	5.9	1.0	2.5																		
15	18.5	0.8	1.5	12.3	0.9	2.0	9.3	1.0	2.5	6.8	1.1	3.0	4.7	1.4	3.5												
20	24.7	0.8	1.5	16.7	0.9	2.0	12.5	1.0	2.5	9.4	1.1	3.0	7.0	1.2	3.6	4.7	1.5	4.1									
25	30.8	0.8	1.5	20.8	0.9	2.0	15.9	1.0	2.4	11.8	1.1	3.0	9.0	1.2	3.5	6.8	1.3	4.1									
30	37.0	0.8	1.5	25.0	0.9	2.0	19.0	1.0	2.5	14.3	1.1	3.0	11.0	1.2	3.5	8.5	1.3	4.1	6.4	1.5	4.7						
35	43.2	0.8	1.5	29.1	0.9	2.0	22.2	1.0	2.5	16.9	1.0	3.0	12.9	1.1	3.5	10.1	1.3	4.1	7.8	1.4	4.7						
40	49.3	0.8	1.5	33.3	0.9	2.0	25.3	1.0	2.5	19.3	1.0	3.0	14.8	1.1	3.5	11.6	1.3	4.1	9.1	1.4	4.7	7.1	1.6	5.2			
45	55.5	0.8	1.5	37.4	0.9	2.0	28.5	1.0	2.5	21.7	1.0	3.0	16.7	1.1	3.5	13.1	1.3	4.1	10.4	1.4	4.7	8.2	1.6	5.2			
50	61.7	0.8	1.5	41.6	0.9	2.0	31.7	1.0	2.5	24.1	1.0	3.0	18.8	1.1	3.5	14.7	1.2	4.1	11.7	1.4	4.7	9.3	1.5	5.3	7.1	1.8	5.8
55	67.8	0.8	1.5	45.7	0.9	2.0	34.8	1.0	2.5	26.5	1.0	3.0	20.7	1.1	3.5	16.2	1.2	4.1	12.9	1.4	4.7	10.4	1.5	5.3	8.2	1.7	5.8
60	74.0	0.8	1.5	49.9	0.9	2.0	38.0	1.0	2.5	28.9	1.0	3.0	22.6	1.1	3.5	17.7	1.2	4.1	14.1	1.4	4.7	11.4	1.5	5.3	9.2	1.7	5.8
65	80.2	0.8	1.5	54.0	0.9	2.0	41.1	1.0	2.5	31.4	1.0	3.0	24.5	1.1	3.5	19.5	1.2	4.1	15.4	1.3	4.7	12.4	1.5	5.3	10.1	1.7	5.8
70	86.3	0.8	1.5	58.2	0.9	2.0	44.3	1.0	2.5	33.8	1.0	3.0	26.3	1.1	3.5	21.0	1.2	4.1	16.6	1.3	4.7	13.5	1.5	5.3	11.0	1.6	5.8
75	92.5	0.8	1.5	62.3	0.9	2.0	47.5	1.0	2.5	36.2	1.0	3.0	28.2	1.1	3.5	22.4	1.2	4.1	17.8	1.3	4.7	14.5	1.5	5.3	11.8	1.6	5.8
80	98.7	0.8	1.5	66.5	0.9	2.0	50.6	1.0	2.5	38.8	1.0	3.0	30.1	1.1	3.5	23.9	1.2	4.1	19.0	1.3	4.7	15.5	1.5	5.3	12.7	1.6	5.8
85	104.8	0.8	1.5	70.6	0.9	2.0	53.8	1.0	2.5	41.0	1.0	3.0	32.0	1.1	3.5	25.4	1.2	4.1	20.3	1.3	4.7	16.5	1.5	5.3	13.6	1.6	5.8
90	111.0	0.8	1.5	74.8	0.9	2.0	57.0	1.0	2.5	43.4	1.0	3.0	33.8	1.1	3.5	26.9	1.2	4.1	21.8	1.3	4.6	17.5	1.5	5.3	14.4	1.6	5.8
95	117.2	0.8	1.5	78.9	0.9	2.0	60.1	1.0	2.5	45.8	1.0	3.0	35.7	1.1	3.5	28.4	1.2	4.1	23.0	1.3	4.6	18.6	1.5	5.3	15.3	1.6	5.8
100	123.3	0.8	1.5	83.1	0.9	2.0	63.3	1.0	2.5	48.2	1.0	3.0	37.6	1.1	3.5	29.9	1.2	4.1	24.2	1.3	4.6	19.6	1.5	5.3	16.2	1.6	5.8
105	129.5	0.8	1.5	87.3	0.9	2.0	66.4	1.0	2.5	50.6	1.0	3.0	39.5	1.1	3.5	31.4	1.2	4.1	25.4	1.3	4.6	20.6	1.5	5.3	17.0	1.6	5.8
110	135.7	0.8	1.5	91.4	0.9	2.0	69.6	1.0	2.5	53.0	1.0	3.0	41.3	1.1	3.5	32.9	1.2	4.1	26.6	1.3	4.7	21.6	1.4	5.3	17.9	1.6	5.8
115	141.8	0.8	1.5	95.6	0.9	2.0	72.8	1.0	2.5	55.4	1.0	3.0	43.2	1.1	3.5	34.4	1.2	4.1	27.9	1.3	4.7	22.6	1.4	5.3	18.7	1.6	5.8
120	148.0	0.8	1.5	99.7	0.9	2.0	75.9	1.0	2.5	57.9	1.0	3.0	45.1	1.1	3.5	35.9	1.2	4.1	29.1	1.3	4.7	23.9	1.4	5.2	19.5	1.6	5.8
125	154.1	0.8	1.5	103.9	0.9	2.0	79.1	1.0	2.5	60.3	1.0	3.0	47.0	1.1	3.5	37.4	1.2	4.1	30.3	1.3	4.7	24.8	1.4	5.2	20.4	1.6	5.8
130	160.3	0.8	1.5	108.0	0.9	2.0	82.3	1.0	2.5	62.7	1.0	3.0	48.8	1.1	3.5	38.9	1.2	4.1	31.5	1.3	4.7	25.8	1.4	5.3	21.2	1.6	5.8
135	166.5	0.8	1.5	112.2	0.9	2.0	85.4	1.0	2.5	65.1	1.0	3.0	50.7	1.1	3.5	40.3	1.2	4.1	32.7	1.3	4.7	26.8	1.4	5.3	22.1	1.6	5.8
140	172.6	0.8	1.5	116.3	0.9	2.0	88.6	1.0	2.5	67.5	1.0	3.0	52.6	1.1	3.5	41.8	1.2	4.1	33.9	1.3	4.7	27.8	1.4	5.3	22.9	1.6	5.8
145	178.8	0.8	1.5	120.5	0.9	2.0	91.8	1.0	2.5	69.9	1.0	3.0	54.5	1.1	3.5	43.3	1.2	4.1	35.1	1.3	4.7	28.8	1.4	5.3	23.7	1.6	5.8
150	185.0	0.8	1.5	124.6	0.9	2.0	94.9	1.0	2.5	72.3	1.0	3.0	56.4	1.1	3.5	44.8	1.2	4.1	36.3	1.3	4.7	29.8	1.4	5.3	24.6	1.6	5.8

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 9 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																											
Grade 3.00 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	7.4	0.7	1.4	4.9	0.8	1.9	3.2	1.0	2.3																		
10	15.1	0.7	1.4	10.2	0.8	1.9	7.6	0.8	2.4	5.7	0.9	2.9	4.0	1.1	3.4												
15	22.6	0.7	1.4	15.6	0.8	1.9	11.5	0.8	2.4	8.8	0.9	2.9	6.7	1.0	3.4	5.1	1.1	4.0									
20	30.1	0.7	1.4	20.7	0.8	1.9	15.5	0.8	2.4	11.8	0.9	2.9	9.2	0.9	3.4	7.2	1.0	4.0	5.5	1.2	4.6						
25	37.6	0.7	1.4	25.9	0.8	1.9	19.4	0.8	2.4	15.0	0.9	2.9	11.6	0.9	3.4	9.2	1.0	4.0	7.2	1.1	4.6	5.6	1.3	5.1			
30	45.1	0.7	1.4	31.1	0.8	1.9	23.3	0.8	2.4	18.0	0.9	2.9	14.0	0.9	3.4	11.1	1.0	4.0	8.9	1.1	4.6	7.1	1.2	5.2	5.3	1.5	5.7
35	52.7	0.7	1.4	36.2	0.8	1.9	27.1	0.8	2.4	21.0	0.9	2.9	16.5	0.9	3.4	13.0	1.0	4.0	10.5	1.1	4.6	8.4	1.2	5.2	6.7	1.4	5.7
40	60.2	0.7	1.4	41.4	0.8	1.9	31.0	0.8	2.4	24.0	0.9	2.9	18.9	0.9	3.4	14.9	1.0	4.0	12.0	1.1	4.6	9.8	1.2	5.2	7.9	1.3	5.7
45	67.7	0.7	1.4	46.6	0.8	1.9	34.9	0.8	2.4	27.0	0.9	2.9	21.2	0.9	3.4	17.0	1.0	4.0	13.6	1.1	4.6	11.1	1.2	5.2	9.1	1.3	5.7
50	75.2	0.7	1.4	51.8	0.8	1.9	38.8	0.8	2.4	29.9	0.9	2.9	23.6	0.9	3.4	18.9	1.0	4.0	15.2	1.1	4.6	12.4	1.2	5.2	10.2	1.3	5.7
55	82.8	0.7	1.4	56.9	0.8	1.9	42.6	0.8	2.4	32.9	0.9	2.9	25.9	0.9	3.4	20.8	1.0	4.0	16.7	1.1	4.6	13.7	1.2	5.2	11.3	1.3	5.7
60	90.3	0.7	1.4	62.1	0.8	1.9	46.5	0.8	2.4	35.9	0.9	2.9	28.3	0.9	3.4	22.7	1.0	4.0	18.5	1.1	4.5	14.9	1.2	5.2	12.4	1.3	5.7
65	97.8	0.7	1.4	67.3	0.8	1.9	50.4	0.8	2.4	38.9	0.9	2.9	30.6	0.9	3.4	24.6	1.0	4.0	20.0	1.1	4.5	16.2	1.2	5.2	13.5	1.3	5.7
70	105.3	0.7	1.4	72.4	0.8	1.9	54.3	0.8	2.4	41.9	0.9	2.9	33.0	0.9	3.4	26.4	1.0	4.0	21.5	1.1	4.5	17.5	1.2	5.2	14.5	1.3	5.7
75	112.8	0.7	1.4	77.6	0.8	1.9	58.1	0.8	2.4	44.9	0.9	2.9	35.3	0.9	3.4	28.3	1.0	4.0	23.1	1.1	4.5	19.1	1.2	5.1	15.6	1.3	5.7
80	120.4	0.7	1.4	82.8	0.8	1.9	62.0	0.8	2.4	47.9	0.9	2.9	37.7	0.9	3.4	30.2	1.0	4.0	24.6	1.1	4.5	20.3	1.2	5.1	16.7	1.3	5.7
85	127.9	0.7	1.4	88.0	0.8	1.9	65.9	0.8	2.4	50.9	0.9	2.9	40.1	0.9	3.4	32.1	1.0	4.0	26.1	1.1	4.5	21.6	1.2	5.1	17.8	1.2	5.7
90	135.4	0.7	1.4	93.1	0.8	1.9	69.8	0.8	2.4	53.9	0.9	2.9	42.4	0.9	3.4	34.0	1.0	4.0	27.7	1.1	4.5	22.9	1.2	5.1	18.9	1.2	5.7
95	142.9	0.7	1.4	98.3	0.8	1.9	73.6	0.8	2.4	56.9	0.9	2.9	44.8	0.9	3.4	35.9	1.0	4.0	29.2	1.1	4.5	24.1	1.2	5.1	20.2	1.2	5.7
100	150.5	0.7	1.4	103.5	0.8	1.9	77.5	0.8	2.4	59.9	0.9	2.9	47.1	0.9	3.4	37.8	1.0	4.0	30.7	1.1	4.5	25.4	1.2	5.1	21.2	1.2	5.7
105	158.0	0.7	1.4	108.7	0.8	1.9	81.4	0.8	2.4	62.8	0.9	2.9	49.5	0.9	3.4	39.6	1.0	4.0	32.3	1.1	4.5	26.7	1.2	5.1	22.3	1.2	5.7
110	165.5	0.7	1.4	113.8	0.8	1.9	85.3	0.8	2.4	65.8	0.9	2.9	51.8	0.9	3.4	41.5	1.0	4.0	33.8	1.1	4.6	27.9	1.2	5.1	23.3	1.2	5.7
115	173.0	0.7	1.4	119.0	0.8	1.9	89.1	0.8	2.4	68.8	0.9	2.9	54.2	0.9	3.4	43.4	1.0	4.0	35.4	1.1	4.6	29.2	1.2	5.1	24.4	1.2	5.7
120	180.5	0.7	1.4	124.2	0.8	1.9	93.0	0.8	2.4	71.8	0.9	2.9	56.6	0.9	3.4	45.3	1.0	4.0	36.9	1.1	4.6	30.5	1.2	5.1	25.5	1.2	5.7
125	188.1	0.7	1.4	129.4	0.8	1.9	96.9	0.8	2.4	74.8	0.9	2.9	58.9	0.9	3.4	47.2	1.0	4.0	38.4	1.1	4.6	31.7	1.2	5.1	26.5	1.2	5.7
130	195.6	0.7	1.4	134.5	0.8	1.9	100.8	0.8	2.4	77.8	0.9	2.9	61.2	0.9	3.4	49.1	1.0	4.0	40.0	1.1	4.6	33.0	1.2	5.1	27.6	1.2	5.7
135	203.1	0.7	1.4	139.7	0.8	1.9	104.6	0.8	2.4	80.8	0.9	2.9	63.6	0.9	3.4	51.0	1.0	4.0	41.5	1.1	4.6	34.3	1.2	5.1	28.6	1.2	5.7
140	210.6	0.7	1.4	144.9	0.8	1.9	108.5	0.8	2.4	83.8	0.9	2.9	66.0	0.9	3.4	52.8	1.0	4.0	43.0	1.1	4.6	35.6	1.2	5.1	29.7	1.2	5.7
145	218.2	0.7	1.4	150.1	0.8	1.9	112.4	0.8	2.4	86.8	0.9	2.9	68.3	0.9	3.4	54.7	1.0	4.0	44.6	1.1	4.6	36.8	1.2	5.1	30.7	1.2	5.7
150	225.7	0.7	1.4	155.2	0.8	1.9	116.3	0.8	2.4	89.8	0.9	2.9	70.7	0.9	3.4	56.6	1.0	4.0	46.1	1.1	4.6	38.1	1.2	5.1	31.8	1.2	5.7

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second; include allowance for freeboard and settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 10 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																											
Grade 4.00 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	8.5	0.8	1.4	5.9	0.7	1.8	4.1	0.8	2.3																		
10	17.2	0.6	1.4	12.1	0.7	1.8	8.8	0.7	2.3	6.7	0.8	2.8	5.2	0.9	3.3	3.8	1.0	3.9									
15	25.8	0.6	1.4	18.1	0.7	1.8	13.4	0.7	2.3	10.3	0.8	2.8	8.1	0.8	3.4	6.4	0.9	3.9	4.9	1.0	4.5						
20	34.4	0.6	1.4	24.2	0.7	1.8	17.8	0.7	2.3	13.9	0.8	2.8	10.9	0.8	3.4	8.7	0.9	3.9	6.9	1.0	4.5	5.5	1.1	5.0			
25	43.0	0.6	1.4	30.2	0.7	1.9	22.3	0.7	2.3	17.4	0.8	2.8	13.8	0.8	3.3	10.9	0.9	3.9	8.8	1.0	4.5	7.1	1.0	5.1	5.7	1.2	5.8
30	51.6	0.6	1.4	36.3	0.7	1.9	26.7	0.7	2.3	20.8	0.8	2.8	16.5	0.8	3.3	13.2	0.9	3.9	10.7	0.9	4.5	8.7	1.0	5.1	7.1	1.1	5.6
35	60.2	0.6	1.4	42.3	0.7	1.9	31.1	0.7	2.3	24.3	0.8	2.8	19.3	0.8	3.4	15.6	0.9	3.9	12.5	0.9	4.5	10.3	1.0	5.0	8.4	1.1	5.6
40	68.8	0.6	1.4	48.3	0.7	1.9	35.6	0.7	2.3	27.8	0.8	2.8	22.0	0.8	3.4	17.8	0.9	3.9	14.4	0.9	4.5	11.8	1.0	5.0	9.8	1.1	5.7
45	77.4	0.6	1.4	54.4	0.7	1.9	40.0	0.7	2.4	31.2	0.8	2.8	24.8	0.8	3.4	20.0	0.9	3.9	16.4	0.9	4.4	13.3	1.0	5.0	11.1	1.1	5.7
50	86.0	0.6	1.4	60.4	0.7	1.9	44.5	0.7	2.4	34.7	0.8	2.8	27.5	0.8	3.4	22.2	0.9	3.9	18.2	0.9	4.4	14.9	1.0	5.0	12.3	1.1	5.7
55	94.6	0.6	1.4	66.5	0.7	1.9	48.9	0.7	2.4	38.2	0.8	2.8	30.3	0.8	3.4	24.4	0.9	3.9	20.0	0.9	4.4	16.6	1.0	5.0	13.6	1.1	5.7
60	103.2	0.6	1.4	72.5	0.7	1.9	53.4	0.7	2.4	41.7	0.8	2.8	33.0	0.8	3.4	26.6	0.9	3.9	21.8	0.9	4.5	18.1	1.0	5.0	14.9	1.1	5.7
65	111.8	0.6	1.4	78.5	0.7	1.9	57.8	0.7	2.4	45.1	0.8	2.8	35.8	0.8	3.4	28.9	0.9	3.9	23.6	0.9	4.5	19.6	1.0	5.0	16.2	1.1	5.7
70	120.4	0.6	1.4	84.6	0.7	1.9	62.3	0.7	2.4	48.6	0.8	2.8	38.6	0.8	3.4	31.1	0.9	3.9	25.4	0.9	4.5	21.1	1.0	5.0	17.7	1.1	5.6
75	129.0	0.6	1.4	90.6	0.7	1.9	66.7	0.7	2.4	52.1	0.8	2.8	41.3	0.8	3.4	33.3	0.9	3.9	27.2	0.9	4.5	22.6	1.0	5.0	19.0	1.1	5.6
80	137.6	0.6	1.4	96.7	0.7	1.9	71.2	0.7	2.4	55.5	0.8	2.8	44.1	0.8	3.4	35.5	0.9	3.9	29.1	0.9	4.5	24.1	1.0	5.0	20.2	1.1	5.6
85	146.2	0.6	1.4	102.7	0.7	1.9	75.6	0.7	2.4	59.0	0.8	2.8	46.8	0.8	3.4	37.7	0.9	3.9	30.9	0.9	4.5	25.6	1.0	5.0	21.5	1.1	5.6
90	154.8	0.6	1.4	108.7	0.7	1.9	80.0	0.7	2.4	62.5	0.8	2.8	49.6	0.8	3.4	39.9	0.9	3.9	32.7	0.9	4.5	27.1	1.0	5.0	22.8	1.1	5.6
95	163.4	0.6	1.4	114.8	0.7	1.9	84.5	0.7	2.4	65.9	0.8	2.8	52.3	0.8	3.4	42.2	0.9	3.9	34.5	0.9	4.5	28.6	1.0	5.0	24.0	1.1	5.6
100	172.0	0.6	1.4	120.8	0.7	1.9	88.9	0.7	2.4	69.4	0.8	2.8	55.1	0.8	3.4	44.4	0.9	3.9	36.3	0.9	4.5	30.1	1.0	5.0	25.3	1.1	5.6
105	180.6	0.6	1.4	126.9	0.7	1.9	93.4	0.7	2.4	72.9	0.8	2.8	57.8	0.8	3.4	46.6	0.9	3.9	38.1	0.9	4.5	31.6	1.0	5.0	26.5	1.1	5.6
110	189.2	0.6	1.4	132.9	0.7	1.9	97.8	0.7	2.4	76.3	0.8	2.8	60.6	0.8	3.4	48.8	0.9	3.9	39.9	0.9	4.5	33.1	1.0	5.0	27.8	1.1	5.6
115	197.8	0.6	1.4	138.9	0.7	1.9	102.3	0.7	2.4	79.8	0.8	2.8	63.3	0.8	3.4	51.0	0.9	3.9	41.7	0.9	4.5	34.6	1.0	5.0	29.0	1.1	5.6
120	206.4	0.6	1.4	145.0	0.7	1.9	106.7	0.7	2.4	83.3	0.8	2.8	66.1	0.8	3.4	53.3	0.9	3.9	43.6	0.9	4.5	36.1	1.0	5.0	30.2	1.1	5.7
125	215.0	0.6	1.4	151.0	0.7	1.9	111.2	0.7	2.4	86.8	0.8	2.8	68.8	0.8	3.4	55.5	0.9	3.9	45.4	0.9	4.5	37.6	1.0	5.0	31.5	1.1	5.7
130	223.7	0.6	1.4	157.1	0.7	1.9	115.6	0.7	2.4	90.2	0.8	2.8	71.6	0.8	3.4	57.7	0.9	3.9	47.2	0.9	4.5	39.1	1.0	5.0	32.7	1.1	5.7
135	232.3	0.6	1.4	163.1	0.7	1.9	120.1	0.7	2.4	93.7	0.8	2.8	74.3	0.8	3.4	59.9	0.9	3.9	49.0	0.9	4.5	40.6	1.0	5.0	34.0	1.1	5.7
140	240.9	0.6	1.4	169.1	0.7	1.9	124.5	0.7	2.4	97.2	0.8	2.8	77.1	0.8	3.4	62.1	0.9	3.9	50.8	0.9	4.5	42.1	1.0	5.0	35.2	1.1	5.7
145	249.5	0.6	1.4	175.2	0.7	1.9	129.0	0.7	2.4	100.6	0.8	2.8	79.8	0.8	3.4	64.3	0.9	3.9	52.6	0.9	4.5	43.6	1.0	5.0	36.5	1.1	5.7
150	258.1	0.6	1.4	181.2	0.7	1.9	133.4	0.7	2.4	104.1	0.8	2.8	82.6	0.8	3.4	66.6	0.9	3.9	54.4	0.9	4.5	45.1	1.0	5.0	37.8	1.1	5.7

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 11 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																													
Grade 5.00 Percent																													
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0				
	T	D	V2	T	D																								
5	9.5	0.6	1.4	6.7	0.6	1.8	4.7	0.7	2.3	3.5	0.8	2.8																	
10	19.0	0.6	1.4	13.7	0.6	1.8	9.7	0.7	2.3	7.6	0.7	2.8	6.0	0.8	3.3	4.7	0.8	3.8	3.4	1.0	4.4								
15	28.5	0.6	1.4	20.5	0.6	1.8	14.8	0.7	2.3	11.7	0.7	2.8	9.2	0.7	3.3	7.3	0.8	3.8	5.9	0.9	4.4	4.7	1.0	5.0					
20	38.0	0.6	1.4	27.3	0.6	1.8	19.7	0.7	2.3	15.5	0.7	2.8	12.4	0.7	3.3	9.9	0.8	3.8	8.0	0.9	4.4	6.5	0.9	4.9	5.3	1.0	5.5		
25	47.5	0.6	1.4	34.1	0.6	1.8	24.6	0.7	2.3	19.4	0.7	2.8	15.5	0.7	3.3	12.6	0.8	3.8	10.1	0.8	4.4	8.3	0.9	5.0	6.8	1.0	5.6		
30	57.0	0.6	1.4	40.9	0.6	1.8	29.5	0.7	2.3	23.3	0.7	2.8	18.6	0.7	3.3	15.1	0.8	3.8	12.2	0.8	4.4	10.1	0.9	5.0	8.3	1.0	5.6		
35	66.5	0.6	1.4	47.7	0.6	1.8	34.4	0.7	2.3	27.2	0.7	2.8	21.7	0.7	3.3	17.6	0.8	3.8	14.5	0.8	4.4	11.8	0.9	5.0	9.8	1.0	5.6		
40	76.0	0.6	1.4	54.6	0.6	1.8	39.4	0.7	2.3	31.0	0.7	2.8	24.8	0.7	3.3	20.1	0.8	3.8	16.5	0.8	4.4	13.6	0.9	5.0	11.3	1.0	5.5		
45	85.5	0.6	1.4	61.4	0.6	1.8	44.3	0.7	2.3	34.9	0.7	2.8	27.9	0.7	3.3	22.6	0.8	3.8	18.6	0.8	4.4	15.5	0.9	4.9	12.8	1.0	5.5		
50	95.0	0.6	1.4	68.2	0.6	1.8	49.2	0.7	2.3	38.8	0.7	2.8	31.0	0.7	3.3	25.1	0.8	3.8	20.6	0.8	4.4	17.2	0.9	4.9	14.3	1.0	5.5		
55	104.6	0.6	1.4	75.0	0.6	1.8	54.1	0.7	2.3	42.7	0.7	2.8	34.1	0.7	3.3	27.6	0.8	3.8	22.7	0.8	4.4	18.9	0.9	4.9	15.9	0.9	5.5		
60	114.1	0.6	1.4	81.8	0.6	1.8	59.0	0.7	2.3	46.6	0.7	2.8	37.2	0.7	3.3	30.1	0.8	3.8	24.7	0.8	4.4	20.6	0.9	4.9	17.3	0.9	5.5		
65	123.6	0.6	1.4	88.6	0.6	1.8	63.9	0.7	2.3	50.4	0.7	2.8	40.3	0.7	3.3	32.6	0.8	3.8	26.8	0.8	4.4	22.3	0.9	4.9	18.8	0.9	5.5		
70	133.1	0.6	1.4	95.5	0.6	1.8	68.9	0.7	2.3	54.3	0.7	2.8	43.4	0.7	3.3	35.1	0.8	3.8	28.9	0.8	4.4	24.0	0.9	4.9	20.2	0.9	5.5		
75	142.6	0.6	1.4	102.3	0.6	1.8	73.8	0.7	2.3	58.2	0.7	2.8	46.5	0.7	3.3	37.7	0.8	3.8	30.9	0.8	4.4	25.7	0.9	4.9	21.6	0.9	5.5		
80	152.1	0.6	1.4	109.1	0.6	1.8	78.7	0.7	2.3	62.1	0.7	2.8	49.6	0.7	3.3	40.2	0.8	3.8	33.0	0.8	4.4	27.4	0.9	4.9	23.1	0.9	5.5		
85	161.6	0.6	1.4	115.9	0.6	1.8	83.6	0.7	2.3	65.9	0.7	2.8	52.7	0.7	3.3	42.7	0.8	3.8	35.0	0.8	4.4	29.1	0.9	5.0	24.5	0.9	5.5		
90	171.1	0.6	1.4	122.7	0.6	1.8	88.5	0.7	2.3	69.8	0.7	2.8	55.8	0.7	3.3	45.2	0.8	3.8	37.1	0.8	4.4	30.9	0.9	5.0	26.0	0.9	5.5		
95	180.6	0.6	1.4	129.6	0.6	1.8	93.4	0.7	2.3	73.7	0.7	2.8	58.9	0.7	3.3	47.7	0.8	3.8	39.2	0.8	4.4	32.6	0.9	5.0	27.4	0.9	5.5		
100	190.1	0.6	1.4	136.4	0.6	1.8	98.4	0.7	2.3	77.6	0.7	2.8	62.0	0.7	3.3	50.2	0.8	3.8	41.2	0.8	4.4	34.3	0.9	5.0	28.8	0.9	5.5		
105	199.6	0.6	1.4	143.2	0.6	1.8	103.3	0.7	2.3	81.5	0.7	2.8	65.1	0.7	3.3	52.7	0.8	3.8	43.3	0.8	4.4	36.0	0.9	5.0	30.3	0.9	5.5		
110	209.1	0.6	1.4	150.0	0.6	1.8	108.2	0.7	2.3	85.3	0.7	2.8	68.2	0.7	3.3	55.2	0.8	3.8	45.3	0.8	4.4	37.7	0.9	5.0	31.7	0.9	5.5		
115	218.6	0.6	1.4	156.8	0.6	1.8	113.1	0.7	2.3	89.2	0.7	2.8	71.3	0.7	3.3	57.7	0.8	3.8	47.4	0.8	4.4	39.4	0.9	5.0	33.2	0.9	5.5		
120	228.1	0.6	1.4	163.6	0.6	1.8	118.0	0.7	2.3	93.1	0.7	2.8	74.3	0.7	3.3	60.2	0.8	3.8	49.5	0.8	4.4	41.1	0.9	5.0	34.6	0.9	5.5		
125	237.6	0.6	1.4	170.5	0.6	1.8	123.0	0.7	2.3	97.0	0.7	2.8	77.4	0.7	3.3	62.7	0.8	3.8	51.5	0.8	4.4	42.8	0.9	5.0	36.0	0.9	5.5		
130	247.1	0.6	1.4	177.3	0.6	1.8	127.9	0.7	2.3	100.8	0.7	2.8	80.5	0.7	3.3	65.2	0.8	3.8	53.6	0.8	4.4	44.6	0.9	5.0	37.5	0.9	5.5		
135	256.6	0.6	1.4	184.1	0.6	1.8	132.8	0.7	2.3	104.7	0.7	2.8	83.6	0.7	3.3	67.8	0.8	3.8	55.6	0.8	4.4	46.3	0.9	5.0	38.9	0.9	5.5		
140	266.1	0.6	1.4	190.9	0.6	1.8	137.7	0.7	2.3	108.6	0.7	2.8	86.7	0.7	3.3	70.3	0.8	3.8	57.7	0.8	4.4	48.0	0.9	5.0	40.4	0.9	5.5		
145	275.6	0.6	1.4	197.7	0.6	1.8	142.6	0.7	2.3	112.5	0.7	2.8	89.8	0.7	3.3	72.8	0.8	3.8	59.8	0.8	4.4	49.7	0.9	5.0	41.8	0.9	5.5		
150	285.1	0.6	1.4	204.6	0.6	1.8	147.5	0.7	2.3	116.4	0.7	2.8	92.9	0.7	3.3	75.3	0.8	3.8	61.8	0.8	4.4	51.4	0.9	5.0	43.2	0.9	5.5		

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second:
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 12 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"																											
Grade 6.00 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	10.6	0.5	1.3	7.3	0.6	1.8	5.3	0.6	2.3	4.0	0.7	2.8	2.9	0.8	3.2												
10	21.1	0.5	1.3	14.7	0.6	1.8	10.9	0.6	2.3	8.4	0.7	2.8	6.6	0.7	3.2	5.3	0.8	3.8	4.2	0.8	4.3						
15	31.8	0.5	1.3	22.1	0.6	1.8	16.3	0.6	2.3	12.7	0.8	2.7	10.1	0.7	3.3	8.2	0.7	3.8	6.6	0.8	4.3	5.4	0.9	4.9	4.3	1.0	5.5
20	42.1	0.5	1.3	29.5	0.6	1.8	21.7	0.6	2.3	17.0	0.6	2.7	13.6	0.7	3.2	11.1	0.7	3.7	9.0	0.8	4.3	7.4	0.8	4.9	6.1	0.9	5.5
25	52.7	0.5	1.3	36.8	0.6	1.8	27.1	0.6	2.3	21.2	0.6	2.8	17.0	0.7	3.2	13.9	0.7	3.8	11.3	0.8	4.3	9.3	0.8	4.9	7.8	0.9	5.5
30	63.2	0.5	1.3	44.2	0.6	1.8	32.5	0.6	2.3	25.4	0.6	2.8	20.4	0.7	3.2	16.6	0.7	3.8	13.7	0.8	4.3	11.3	0.8	4.9	9.4	0.9	5.5
35	73.7	0.5	1.3	51.6	0.6	1.8	38.0	0.6	2.3	29.7	0.6	2.8	23.8	0.7	3.2	19.4	0.7	3.8	16.0	0.8	4.3	13.4	0.8	4.9	11.1	0.9	5.5
40	84.2	0.5	1.3	58.9	0.6	1.8	43.4	0.6	2.3	33.9	0.6	2.8	27.2	0.7	3.3	22.2	0.7	3.8	18.3	0.8	4.3	15.3	0.8	4.9	12.7	0.9	5.5
45	94.8	0.5	1.3	66.3	0.6	1.8	48.8	0.6	2.3	38.2	0.6	2.8	30.7	0.7	3.3	24.9	0.7	3.8	20.6	0.8	4.3	17.2	0.8	4.9	14.5	0.9	5.4
50	105.3	0.5	1.3	73.6	0.6	1.8	54.2	0.6	2.3	42.4	0.6	2.8	34.1	0.7	3.3	27.7	0.7	3.8	22.8	0.8	4.3	19.1	0.8	4.9	16.1	0.9	5.4
55	115.8	0.5	1.3	81.0	0.6	1.8	59.7	0.6	2.3	46.6	0.6	2.8	37.5	0.7	3.3	30.5	0.7	3.8	25.1	0.8	4.3	21.0	0.8	4.9	17.7	0.9	5.4
60	126.4	0.5	1.3	88.4	0.6	1.8	65.1	0.6	2.3	50.9	0.6	2.8	40.9	0.7	3.3	33.3	0.7	3.8	27.4	0.8	4.3	22.9	0.8	4.9	19.3	0.9	5.4
65	136.9	0.5	1.3	95.7	0.6	1.8	70.5	0.6	2.3	55.1	0.6	2.8	44.3	0.7	3.3	36.0	0.7	3.8	29.7	0.8	4.3	24.8	0.8	4.9	20.9	0.9	5.4
70	147.4	0.5	1.3	103.1	0.6	1.8	75.9	0.6	2.3	59.3	0.6	2.8	47.7	0.7	3.3	38.8	0.7	3.8	32.0	0.8	4.3	26.7	0.8	4.9	22.5	0.9	5.4
75	158.0	0.5	1.3	110.5	0.6	1.8	81.3	0.6	2.3	63.6	0.6	2.8	51.1	0.7	3.3	41.6	0.7	3.8	34.3	0.8	4.3	28.6	0.8	4.9	24.1	0.9	5.4
80	168.5	0.5	1.3	117.8	0.6	1.8	86.8	0.6	2.3	67.8	0.6	2.8	54.5	0.7	3.3	44.3	0.7	3.8	36.5	0.8	4.3	30.5	0.8	4.9	25.7	0.9	5.5
85	179.0	0.5	1.3	125.2	0.6	1.8	92.2	0.6	2.3	72.0	0.6	2.8	57.9	0.7	3.3	47.1	0.7	3.8	38.8	0.8	4.3	32.4	0.8	4.9	27.3	0.9	5.5
90	189.6	0.5	1.3	132.6	0.6	1.8	97.6	0.6	2.3	76.3	0.6	2.8	61.3	0.7	3.3	49.9	0.7	3.8	41.1	0.8	4.3	34.3	0.8	4.9	28.9	0.9	5.5
95	200.1	0.5	1.3	139.9	0.6	1.8	103.0	0.6	2.3	80.5	0.6	2.8	64.7	0.7	3.3	52.6	0.7	3.8	43.4	0.8	4.3	36.2	0.8	4.9	30.5	0.9	5.5
100	210.6	0.5	1.3	147.3	0.6	1.8	108.5	0.6	2.3	84.8	0.6	2.8	68.1	0.7	3.3	55.4	0.7	3.8	45.7	0.8	4.3	38.1	0.8	4.9	32.1	0.9	5.5
105	221.1	0.5	1.3	154.6	0.6	1.8	113.9	0.6	2.3	89.0	0.6	2.8	71.5	0.7	3.3	58.2	0.7	3.8	47.9	0.8	4.3	40.0	0.8	4.9	33.7	0.9	5.5
110	231.7	0.5	1.3	162.0	0.6	1.8	119.3	0.6	2.3	93.2	0.6	2.8	74.9	0.7	3.3	60.9	0.7	3.8	50.2	0.8	4.3	41.9	0.8	4.9	35.3	0.9	5.5
115	242.2	0.5	1.3	169.4	0.6	1.8	124.7	0.6	2.3	97.5	0.6	2.8	78.3	0.7	3.3	63.7	0.7	3.8	52.5	0.8	4.3	43.8	0.8	4.9	36.9	0.9	5.5
120	252.7	0.5	1.3	176.7	0.6	1.8	130.2	0.6	2.3	101.7	0.6	2.8	81.7	0.7	3.3	66.5	0.7	3.8	54.8	0.8	4.3	45.7	0.8	4.9	38.5	0.9	5.5
125	263.3	0.5	1.3	184.1	0.6	1.8	135.6	0.6	2.3	106.0	0.6	2.8	85.1	0.7	3.3	69.3	0.7	3.8	57.1	0.8	4.3	47.6	0.8	4.9	40.1	0.9	5.5
130	273.8	0.5	1.3	191.5	0.6	1.8	141.0	0.6	2.3	110.2	0.6	2.8	88.5	0.7	3.3	72.0	0.7	3.8	59.4	0.8	4.3	49.5	0.8	4.9	41.7	0.9	5.5
135	284.3	0.5	1.3	198.8	0.6	1.8	146.4	0.6	2.3	114.4	0.6	2.8	91.9	0.7	3.3	74.8	0.7	3.8	61.6	0.8	4.3	51.4	0.8	4.9	43.3	0.9	5.5
140	294.9	0.5	1.3	206.2	0.6	1.8	151.8	0.6	2.3	118.7	0.6	2.8	95.3	0.7	3.3	77.6	0.7	3.8	63.9	0.8	4.3	53.3	0.8	4.9	44.9	0.9	5.5
145	305.4	0.5	1.3	213.6	0.6	1.8	157.3	0.6	2.3	122.9	0.6	2.8	98.7	0.7	3.3	80.3	0.7	3.8	66.2	0.8	4.3	55.2	0.8	4.9	46.5	0.9	5.5
150	315.9	0.5	1.3	220.9	0.6	1.8	162.7	0.6	2.3	127.1	0.6	2.8	102.1	0.7	3.3	83.1	0.7	3.8	68.5	0.8	4.3	57.1	0.8	4.9	48.1	0.9	5.5

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Table GS-4 Parabolic Grass Swale Design Sheet 13 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH' (D), AND V2 FOR RETARDANCE "C"																											
Grade 8.00 Percent																											
Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	12.0	0.5	1.3	8.5	0.5	1.7	6.2	0.5	2.2	4.6	0.6	2.7	3.7	0.6	3.2	2.9	0.7	3.6									
10	24.1	0.5	1.3	16.9	0.5	1.7	12.6	0.5	2.2	9.6	0.6	2.7	7.8	0.6	3.2	6.3	0.6	3.7	5.1	0.7	4.2	4.2	0.8	4.8	3.2	0.9	5.3
15	36.1	0.5	1.3	25.3	0.5	1.7	18.9	0.5	2.2	14.4	0.6	2.7	11.8	0.6	3.2	9.7	0.6	3.7	7.9	0.7	4.2	6.5	0.7	4.8	5.4	0.8	5.3
20	48.1	0.5	1.3	33.8	0.5	1.7	25.2	0.5	2.2	19.2	0.6	2.7	15.8	0.6	3.2	12.9	0.6	3.7	10.7	0.7	4.2	8.8	0.7	4.8	7.4	0.8	5.3
25	60.1	0.5	1.3	42.2	0.5	1.7	31.5	0.5	2.2	24.0	0.6	2.7	19.7	0.6	3.2	16.2	0.6	3.7	13.4	0.7	4.2	11.2	0.7	4.7	9.3	0.8	5.3
30	72.1	0.5	1.3	50.6	0.5	1.7	37.8	0.5	2.2	28.8	0.6	2.7	23.6	0.6	3.2	19.4	0.6	3.7	16.1	0.7	4.2	13.5	0.7	4.8	11.3	0.7	5.3
35	84.1	0.5	1.3	59.1	0.5	1.7	44.1	0.5	2.2	33.6	0.6	2.7	27.6	0.6	3.2	22.6	0.6	3.7	18.7	0.7	4.2	15.7	0.7	4.8	13.3	0.7	5.3
40	96.2	0.5	1.3	67.5	0.5	1.7	50.4	0.5	2.2	38.4	0.6	2.7	31.5	0.6	3.2	25.8	0.6	3.7	21.4	0.7	4.2	17.9	0.7	4.8	15.2	0.7	5.3
45	108.2	0.5	1.3	76.0	0.5	1.7	56.7	0.5	2.2	43.2	0.6	2.7	35.4	0.6	3.2	29.0	0.6	3.7	24.1	0.7	4.2	20.2	0.7	4.8	17.1	0.7	5.3
50	120.2	0.5	1.3	84.4	0.5	1.7	63.0	0.5	2.2	48.0	0.6	2.7	39.4	0.6	3.2	32.3	0.6	3.7	26.8	0.7	4.2	22.4	0.7	4.8	19.0	0.7	5.3
55	132.2	0.5	1.3	92.8	0.5	1.7	69.3	0.5	2.2	52.8	0.6	2.7	43.3	0.6	3.2	35.5	0.6	3.7	29.4	0.7	4.2	24.7	0.7	4.8	20.9	0.7	5.3
60	144.2	0.5	1.3	101.3	0.5	1.7	75.6	0.5	2.2	57.6	0.6	2.7	47.2	0.6	3.2	38.7	0.6	3.7	32.1	0.7	4.2	26.9	0.7	4.8	22.8	0.7	5.3
65	156.3	0.5	1.3	109.7	0.5	1.7	81.8	0.5	2.2	62.4	0.6	2.7	51.2	0.6	3.2	41.9	0.6	3.7	34.8	0.7	4.2	29.1	0.7	4.8	24.7	0.7	5.3
70	168.3	0.5	1.3	118.2	0.5	1.7	88.1	0.5	2.2	67.2	0.6	2.7	55.1	0.6	3.2	45.2	0.6	3.7	37.5	0.7	4.2	31.4	0.7	4.8	26.6	0.7	5.3
75	180.3	0.5	1.3	126.6	0.5	1.7	94.4	0.5	2.2	72.0	0.6	2.7	59.0	0.6	3.2	48.4	0.6	3.7	40.1	0.7	4.2	33.6	0.7	4.8	28.5	0.7	5.3
80	192.3	0.5	1.3	135.0	0.5	1.7	100.7	0.5	2.2	76.8	0.6	2.7	63.0	0.6	3.2	51.6	0.6	3.7	42.8	0.7	4.2	35.9	0.7	4.8	30.3	0.7	5.3
85	204.3	0.5	1.3	143.5	0.5	1.7	107.0	0.5	2.2	81.6	0.6	2.7	66.9	0.6	3.2	54.9	0.6	3.7	45.5	0.7	4.2	38.1	0.7	4.8	32.2	0.7	5.3
90	216.4	0.5	1.3	151.9	0.5	1.7	113.3	0.5	2.2	86.4	0.6	2.7	70.8	0.6	3.2	58.1	0.6	3.7	48.1	0.7	4.2	40.3	0.7	4.8	34.1	0.7	5.3
95	228.4	0.5	1.3	160.3	0.5	1.7	119.6	0.5	2.2	91.2	0.6	2.7	74.8	0.6	3.2	61.3	0.6	3.7	50.8	0.7	4.2	42.6	0.7	4.8	36.0	0.7	5.3
100	240.4	0.5	1.3	168.8	0.5	1.7	125.9	0.5	2.2	96.0	0.6	2.7	78.7	0.6	3.2	64.5	0.6	3.7	53.5	0.7	4.2	44.8	0.7	4.8	37.9	0.7	5.3
105	252.4	0.5	1.3	177.2	0.5	1.7	132.2	0.5	2.2	100.8	0.6	2.7	82.6	0.6	3.2	67.8	0.6	3.7	56.2	0.7	4.2	47.1	0.7	4.8	39.8	0.7	5.3
110	264.4	0.5	1.3	185.7	0.5	1.7	138.5	0.5	2.2	105.6	0.6	2.7	86.6	0.6	3.2	71.0	0.6	3.7	58.8	0.7	4.2	49.3	0.7	4.8	41.7	0.7	5.3
115	276.5	0.5	1.3	194.1	0.5	1.7	144.8	0.5	2.2	110.4	0.6	2.7	90.5	0.6	3.2	74.2	0.6	3.7	61.5	0.7	4.2	51.5	0.7	4.8	43.6	0.7	5.3
120	288.5	0.5	1.3	202.5	0.5	1.7	151.1	0.5	2.2	115.2	0.6	2.7	94.4	0.6	3.2	77.4	0.6	3.7	64.2	0.7	4.2	53.8	0.7	4.8	45.5	0.7	5.3
125	300.5	0.5	1.3	211.0	0.5	1.7	157.4	0.5	2.2	120.0	0.6	2.7	98.4	0.6	3.2	80.7	0.6	3.7	66.9	0.7	4.2	56.0	0.7	4.8	47.4	0.7	5.3
130	312.5	0.5	1.3	219.4	0.5	1.7	163.7	0.5	2.2	124.8	0.6	2.7	102.3	0.6	3.2	83.9	0.6	3.7	69.5	0.7	4.2	58.3	0.7	4.8	49.3	0.7	5.3
135	324.5	0.5	1.3	227.9	0.5	1.7	170.0	0.5	2.2	129.6	0.6	2.7	106.2	0.6	3.2	87.1	0.6	3.7	72.2	0.7	4.2	60.5	0.7	4.8	51.2	0.7	5.3
140	336.6	0.5	1.3	236.3	0.5	1.7	176.3	0.5	2.2	134.4	0.6	2.7	110.2	0.6	3.2	90.3	0.6	3.7	74.9	0.7	4.2	62.7	0.7	4.8	53.1	0.7	5.3
145	348.6	0.5	1.3	244.7	0.5	1.7	182.6	0.5	2.2	139.2	0.6	2.7	114.1	0.6	3.2	93.6	0.6	3.7	77.6	0.7	4.2	65.0	0.7	4.8	55.0	0.7	5.3
150	360.6	0.5	1.3	253.2	0.5	1.7	188.9	0.5	2.2	144.0	0.6	2.7	118.0	0.6	3.2	96.8	0.6	3.7	80.2	0.7	4.2	67.2	0.7	4.8	56.9	0.7	5.3

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second.
Depth "D" does not include allowance for freeboard or settlement

Table GS-4 Parabolic Grass Swale Design Sheet 14 of 14

V1 FOR RETARDANCE "D", TOP WIDTH (T), DEPTH (D), AND V2 FOR RETARDANCE "C"

Grade 10.00 Percent

Q CFS	V1=2.0			V1=2.5			V1=3.0			V1=3.5			V1=4.0			V1=4.5			V1=5.0			V1=5.5			V1=6.0		
	T	D	V2																								
5	13.3	0.4	1.3	9.4	0.5	1.7	6.8	0.5	2.2	5.3	0.5	2.6	4.1	0.6	3.2	3.4	0.6	3.6	2.6	0.7	4.1				4.0	0.7	5.3
10	26.6	0.4	1.3	18.7	0.5	1.7	13.8	0.5	2.2	10.9	0.5	2.6	8.5	0.6	3.2	7.1	0.6	3.6	5.9	0.6	4.1	4.9	0.7	4.7	6.3	0.7	5.2
15	39.9	0.4	1.3	28.0	0.5	1.7	20.7	0.5	2.2	16.3	0.5	2.6	12.8	0.6	3.2	10.9	0.6	3.6	9.0	0.6	4.1	7.5	0.6	4.7	8.5	0.7	5.2
20	53.2	0.4	1.3	37.4	0.5	1.7	27.6	0.5	2.2	21.7	0.5	2.7	17.0	0.6	3.2	14.5	0.6	3.6	12.1	0.6	4.1	10.2	0.6	4.6	10.8	0.7	5.2
25	66.5	0.4	1.3	46.7	0.5	1.7	34.5	0.5	2.2	27.1	0.5	2.7	21.3	0.6	3.2	18.1	0.6	3.6	15.1	0.6	4.1	12.7	0.6	4.7	12.9	0.7	5.2
30	79.8	0.4	1.3	56.1	0.5	1.7	41.4	0.5	2.2	32.5	0.5	2.7	25.5	0.6	3.2	21.7	0.6	3.6	18.1	0.6	4.1	15.2	0.6	4.7	15.1	0.7	5.2
35	93.1	0.4	1.3	65.4	0.5	1.7	48.3	0.5	2.2	37.9	0.5	2.7	29.8	0.6	3.2	25.3	0.6	3.6	21.1	0.6	4.1	17.8	0.6	4.7	17.2	0.7	5.2
40	106.4	0.4	1.3	74.7	0.5	1.7	55.2	0.5	2.2	43.3	0.5	2.7	34.0	0.6	3.2	29.0	0.6	3.6	24.1	0.6	4.1	20.3	0.6	4.7	19.4	0.7	5.2
45	119.7	0.4	1.3	84.1	0.5	1.7	62.1	0.5	2.2	48.8	0.5	2.7	38.3	0.6	3.2	32.6	0.6	3.6	27.2	0.6	4.1	22.8	0.6	4.7	21.5	0.7	5.2
50	133.0	0.4	1.3	93.4	0.5	1.7	69.0	0.5	2.2	54.2	0.5	2.7	42.5	0.6	3.2	36.2	0.6	3.6	30.2	0.6	4.1	25.4	0.6	4.7	23.7	0.7	5.2
55	146.3	0.4	1.3	102.8	0.5	1.7	75.9	0.5	2.2	59.6	0.5	2.7	46.8	0.6	3.2	39.8	0.6	3.6	33.2	0.6	4.1	27.9	0.6	4.7	25.9	0.7	5.2
60	159.6	0.4	1.3	112.1	0.5	1.7	82.8	0.5	2.2	65.0	0.5	2.7	51.0	0.6	3.2	43.4	0.6	3.6	36.2	0.6	4.1	30.5	0.6	4.7	28.0	0.7	5.2
65	172.9	0.4	1.3	121.4	0.5	1.7	89.7	0.5	2.2	70.4	0.5	2.7	55.3	0.6	3.2	47.1	0.6	3.6	39.2	0.6	4.1	33.0	0.6	4.7	30.2	0.7	5.2
70	186.2	0.4	1.3	130.8	0.5	1.7	96.6	0.5	2.2	75.8	0.5	2.7	59.5	0.6	3.2	50.7	0.6	3.6	42.2	0.6	4.1	35.5	0.6	4.7	32.3	0.7	5.2
75	199.5	0.4	1.3	140.1	0.5	1.7	103.5	0.5	2.2	81.2	0.5	2.7	63.8	0.6	3.2	54.3	0.6	3.6	45.2	0.6	4.1	38.1	0.6	4.7	34.5	0.7	5.2
80	212.8	0.4	1.3	149.5	0.5	1.7	110.5	0.5	2.2	86.7	0.5	2.7	68.0	0.6	3.2	57.9	0.6	3.6	48.3	0.6	4.1	40.6	0.6	4.7	36.6	0.7	5.2
85	226.1	0.4	1.3	158.8	0.5	1.7	117.4	0.5	2.2	92.1	0.5	2.7	72.3	0.6	3.2	61.5	0.6	3.6	51.3	0.6	4.1	43.1	0.6	4.7	38.8	0.7	5.2
90	239.4	0.4	1.3	168.1	0.5	1.7	124.3	0.5	2.2	97.5	0.5	2.7	76.5	0.6	3.2	65.2	0.6	3.6	54.3	0.6	4.1	45.7	0.6	4.7	40.9	0.7	5.2
95	252.7	0.4	1.3	177.5	0.5	1.7	131.2	0.5	2.2	102.9	0.5	2.7	80.8	0.6	3.2	68.8	0.6	3.6	57.3	0.6	4.1	48.2	0.6	4.7	43.1	0.7	5.2
100	266.0	0.4	1.3	186.8	0.5	1.7	138.1	0.5	2.2	108.3	0.5	2.7	85.0	0.6	3.2	72.4	0.6	3.6	60.3	0.6	4.1	50.7	0.6	4.7	45.2	0.7	5.2
105	279.3	0.4	1.3	196.2	0.5	1.7	145.0	0.5	2.2	113.7	0.5	2.7	89.3	0.6	3.2	76.0	0.6	3.6	63.3	0.6	4.1	53.3	0.6	4.7	47.4	0.7	5.2
110	292.6	0.4	1.3	205.5	0.5	1.7	151.9	0.5	2.2	119.2	0.5	2.7	93.5	0.6	3.2	79.6	0.6	3.6	66.4	0.6	4.1	55.8	0.6	4.7	49.5	0.7	5.3
115	305.9	0.4	1.3	214.9	0.5	1.7	158.8	0.5	2.2	124.6	0.5	2.7	97.8	0.6	3.2	83.3	0.6	3.6	69.4	0.6	4.1	58.3	0.6	4.7	51.7	0.7	5.3
120	319.2	0.4	1.3	224.2	0.5	1.7	165.7	0.5	2.2	130.0	0.5	2.7	102.0	0.6	3.2	86.9	0.6	3.6	72.4	0.6	4.1	60.9	0.6	4.7	53.8	0.7	5.3
125	332.5	0.4	1.3	233.5	0.5	1.7	172.6	0.5	2.2	135.4	0.5	2.7	106.3	0.6	3.2	90.5	0.6	3.6	75.4	0.6	4.1	63.4	0.6	4.7	56.0	0.7	5.3
130	345.8	0.4	1.3	242.9	0.5	1.7	179.5	0.5	2.2	140.8	0.5	2.7	110.5	0.6	3.2	94.1	0.6	3.6	78.4	0.6	4.1	66.0	0.6	4.7	58.1	0.7	5.3
135	359.1	0.4	1.3	252.2	0.5	1.7	186.4	0.5	2.2	146.2	0.5	2.7	114.8	0.6	3.2	97.7	0.6	3.6	81.4	0.6	4.1	68.5	0.6	4.7	60.3	0.7	5.3
140	372.4	0.4	1.3	261.6	0.5	1.7	193.3	0.5	2.2	151.7	0.5	2.7	119.0	0.6	3.2	101.3	0.6	3.6	84.4	0.6	4.1	71.0	0.6	4.7	62.5	0.7	5.3
145	385.7	0.4	1.3	270.9	0.5	1.7	200.2	0.5	2.2	157.1	0.5	2.7	123.3	0.6	3.2	105.0	0.6	3.6	87.5	0.6	4.1	73.6	0.6	4.7	64.6	0.7	5.3
150	399.0	0.4	1.3	280.2	0.5	1.7	207.1	0.5	2.2	162.5	0.5	2.7	127.5	0.6	3.2	108.6	0.6	3.6	90.5	0.6	4.1	76.1	0.6	4.7			

RETARDANCE "D" AND "C"

NOTE: Width and Depth dimensions are in feet; Velocity measurements are in feet per second;
Depth "D" does not include allowance for freeboard or settlement.

Construction

Prior to start of construction, grass swale channels should be designed by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the construction process to ensure that the channel has planned alignment, grade, and cross section.

Scheduling

Schedule construction during a period of relatively low rainfall and runoff events if practical. Consider also the establishment period (planting dates) for the planned species that will be used for long-term vegetative cover.

Site Preparation

Determine exact location of underground utilities. (See Appendix C: MS One-Call and 811 Color Coding.)

Install any structures required to stabilize the swale outlet or to provide drainage along the swale prior to beginning installation of the swale. Refer to design for structures to be installed.

Remove brush, trees, and other debris from the construction area and dispose of properly.

Constructing

Excavate and shape the channel to dimensions shown in the design specifications, removing and properly disposing of excess soil so surface water can enter the channel freely. The typical features of a grass swale are shown in Figure GS-2 and listed below, but may be different in the design for a specific site.

Cross Section: trapezoidal or parabolic.

Side Slopes: 3:1 (Horizontal: Vertical) or flatter for trapezoidal channels.

Outlet: Channel should empty into a stable outlet, sediment traps, or detention/retention basins.

Subsurface Drain: Use in areas with seasonally high water tables or seepage problems.

Topsoil: Provide topsoil as needed to grow grass on areas disturbed by construction.

Protect all concentrated inflow points along the channel with erosion-resistant linings, such as riprap, sod, mulch, erosion control blankets, turf-reinforcement mats or other appropriate practices as specified in the design plan.




Figure GS-2 Typical Trapezoidal Grass-Lined Channel

Construction Verification

Check finished grade and cross section of channel throughout the length of the watercourse. Verify channel cross sections at several locations to avoid constrictions to flow.

Vegetating

Prepare seedbed; apply lime, fertilizer, and seed or sod in the swale immediately after grading; and protect with erosion control blankets, turf-reinforcement mats, or mulch according to the design plan. If not specified in a plan, select lime, fertilizer, grass variety and mulching components from related practices (*Permanent Seeding* or *Temporary Seeding*, *Erosion Control Blanket* or *Sodding*).

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate practice will not function as intended.

Changes in plan may be needed.

Design specifications for seed variety, seeding dates or erosion control materials cannot be met; substitution may be required.

Erosion occurs in channel before vegetation is fully established.

Erosion occurs at channel outlet before vegetation is fully established.

Sediment is deposited at channel outlet before vegetation is fully established.

Maintenance

Inspect the channel following storm events both during and after grass cover is established; make needed repairs immediately.

Check the channel outlet and road crossings for blockage, ponding, sediment, and bank instability, breaks and eroded areas; remove any blockage; and make repairs immediately to maintain design cross section and grade.

References




BMPs from Volume 1

Chapter 4

Erosion Control Blanket (ECB)	4-33
Permanent Seeding (PS)	4-53
Sodding (SOD)	4-93
Temporary Seeding (TS)	4-103
Lined Swale (LS)	4-190
Riprap-lined Swale (RS)	4-210

MDOT Drawing DT-1

Details of Typical Ditch Treatments	4-185
-------------------------------------	-------



Level Spreader (LVS)



Practice Description

A level spreader provides a non-erosive outlet for concentrated runoff (diversions) by dispersing flow uniformly across a stable slope. They are relatively low-cost structures designed to release small volumes of water safely.

Planning Considerations

Level spreaders are designed to be used where sediment-free storm runoff is intercepted and diverted away from graded areas onto undisturbed stabilized areas. This practice applies only in those situations where the spreader can be constructed on undisturbed soil and the area below the level crest is stabilized by natural or pre-established vegetation. The water should not be allowed to re-concentrate after release.

The drainage area for a level spreader should be limited to 5 acres, and the size of the spreader based on design runoff. When the level spreader is used as an outlet for temporary or permanent diversions, runoff containing high sediment loads must be treated in a sediment trapping device before release into a level spreader (see *Sediment Basin Practice*).

Design Criteria

Capacity

The capacity of the spreader crest shall be limited to those drainage areas producing no more than 40 cfs from a 10-year storm.

Length

By estimating the flow, the spreader crest length can be determined from the following table.

<u>Design Flow (CFS)</u>	<u>Minimum Depression Depth (Feet)</u>	<u>Minimum Length (Feet)</u>
0-10	0.5	10
10-20	0.6	20
20-30	0.7	30
30-40	0.8	40

Width

The minimum acceptable width of the depressional area along the level crest shall be 6 feet.

Grade

The grade of the channel for the last 20 feet of the dike or diversion entering the level spreader shall be less than or equal to 1%. The grade of the depression along the level spreader shall be 0%.

Outlet

The release of the stormwater will be over the level crest onto an undisturbed stabilized area. The level crest should be of uniform height and zero grade over the length of the spreader crest.

Setback

Level spreader setbacks should be a minimum of 10 feet from property lines and receiving water features. Sheet flow depth at property lines shall be consistent with pre-development flow.

Construction**Site Preparation**

Level spreaders must be constructed on undisturbed soil (not fill material).




Figure LVS-1 Level Spreader, Sectional View (Source: NRCS)

Level Spreader Crest

The level spreader crest shall be constructed to a uniform height and zero grade over the length of the spreader. For flows of 4 cfs or greater, a rigid crest of non-erodible material shall be used. For flows less than 4 cfs, a vegetated crest may be used. An erosion control blanket should be used with a vegetative crest (see *Erosion Control Blanket Practice* for blanket requirements). The erosion control blanket should be a minimum of 4 feet wide and extend at least 1 foot downstream. Secure the blanket with heavy duty staples and bury the upstream and downstream edges in a trench at least 6 inches deep.

Erosion control blankets should be used for rigid crest level spreaders as well. The erosion control blanket should be entrenched a minimum of 4 inches below existing ground and securely anchored to prevent displacement. An apron of coarse aggregate should be placed along the rigid crest and extended downslope at least 3 feet.

Vegetation

The natural buffer-area vegetation is important to improve infiltration function, protect from rain and wind erosion and enhance aesthetic conditions. The level spreader itself does not need vegetation. The lower buffer area should be protected from disturbance during construction.

Filter Strip

Level spreaders used in conjunction with a filter strip should have a capacity designed based on the filter strip specifics (See *Filter Strip Practice*). The spreader shall run linearly along the entire width of the filter strip to which is discharges. The ends of the spreader should be tied into higher ground to prevent flow around the spreader.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate practice will not function as intended; changes in plan may be needed.

Design specifications cannot be met; substitution may be required. Unapproved substitutions could result in failure of the practice.

Maintenance

Annual inspection is required. Trees and shrubs that have established on the level spreader crest should be removed.

Inspection should occur annually for the presence of debris and sediment buildup on the level spreader.

Regulation inspection, especially after significant rain events (greater than 3-4 inches in 24-hours), should be done to address possible erosion and gully formation.

References

BMPs from Volume 1

Chapter 4

Erosion Control Blanket (ECB)	4-33
Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103
Diversion (DV)	4-131
Outlet Protection (OP)	4-199
Sediment Basin (SBN)	4-298

Lined Swale (LS)

☒ LW ☒



PAVED



Practice Description

A lined swale is a constructed channel with a permanent lining designed to carry concentrated runoff to a stable outlet. This practice applies to the following sites: 1) where grass swales are unsuitable because of conditions such as steep channel grades, prolonged flow areas, soils that are too erodible or not suitable to support vegetation or insufficient space and/or 2) where riprap-lined swales are not desired. The purpose of a lined swale is to conduct stormwater runoff without causing erosion problems in the area of channel flow.

The material that provides the permanent lining may be concrete, a specialized type of erosion control blanket, or manufactured concrete products.

Planning Considerations

A lined swale is used to convey concentrated runoff to a stable outlet in situations where a grass swale is inadequate. A lined swale can be lined with concrete, manufactured concrete products, or manufactured erosion-control products. Concrete-lined swales are the only type of lining covered in this practice. The practice *Erosion Control Blanket* should be referenced for criteria on permanent erosion control blankets. Product manufacturers and qualified design professional should be consulted for design requirements for manufactured concrete linings. Concrete-lined swales are generally used in areas where riprap-lined swales are not desired due to aesthetics, safety, or maintenance concerns. Concrete-lined swales allow easy maintenance of surrounding vegetation with normal lawn care equipment. The concrete generally provides a more

visually pleasing structure than the riprap linings. Concrete-lined swales are especially desirable in areas accessed by small children.

In areas where stormwater infiltration is a concern, riprap and manufactured products should be considered rather than the concrete lining.

Design Criteria

Capacity

Lined swales should be capable of passing the peak flow expected from a 10-year 24-hour duration storm.

Adjustments should be made for release rates from structures and other drainage facilities. Swales shall also be designed to comply with local stormwater ordinances, and should be designed for greater capacity whenever there is danger of flooding or when out-of-bank flow cannot be tolerated.

Peak rates of runoff values used to determine the capacity requirements should be calculated using accepted engineering methods. Some accepted methods are:

- Natural Resources Conservation Service, Engineering Field Manual for Conservation Practices, Chapter 2, Estimating Runoff.
- Natural Resources Conservation Service (formerly Soil Conservation Service), Technical Release 55, Urban Hydrology for Small Watersheds.
- Other comparable methods – See Appendix A: Erosion and Stormwater Runoff Calculations found in the Appendices Volume.

Slope

This practice applies only to paved flumes that are installed on slopes of 25% or less. Slopes steeper than this should be designed by a qualified design professional.

The slope in feet per 100 feet of length can be determined from a topographic map of the site or from a detailed survey of the planned lined swale location.

Cross Section

With peak flow (capacity) and slope known, the paved flume cross section can be determined by using Figures LS-1 – LS-3.

Concrete

Flumes should be constructed of concrete with a minimum 28-day compressive strength of 3,000 psi. Flumes shall have a minimum concrete thickness of 4".



Cutoff Walls

Cutoff walls shall be constructed at the beginning and end of every flume except where the flume connects with a catch basin or inlet.

Alignment

Keep paved flumes as straight as possible because they often carry supercritical flow velocities.

Inlet Section

The inlet section to the paved flume should be at least 6 feet long and have a bottom width equal to twice the bottom width of the flume itself. The bottom width should transition from twice the flume bottom width to the flume bottom width over the 6-foot length.

Outlet

Outlets of paved flumes shall be protected from erosion. The standard for *Outlet Protection* can be used to provide this protection. A method to dissipate the energy of low flows is to bury the last section of the flume in the ground. This will usually force the development of a “scour hole,” which will stabilize and serve as a plunge basin. For the design of large-capacity flumes, it may be necessary to design a larger energy dissipater at the outlet.




Figure LS-1 Capacity Graph for Concrete Flumes
 Depth of Flow = 0.50 Foot




Figure LS-2 Capacity Graph for Concrete Flumes
Depth of Flow = 0.75 Foot




Figure LS-3 Capacity Graph for Concrete Flumes
 Depth of Flow = 1.00 Foot

Construction

Prior to start of construction, lined swales should be designed by a qualified design professional, and specifications should be available to field personnel.

Plans and specifications should be referred to by field personnel throughout the construction process.

Note: Concrete-lined channel is the only lining method that is covered in this edition of the manual. Numerous permanent erosion control blankets and rock products are available with similar applications, and their unique installation procedures should be obtained from the manufacturer of the product being used. In addition, Riprap-Lined Swale is covered in this manual.

Site Preparation

Determine exact location of underground utilities (See Appendix C: MS One-Call and 811 Color Coding).

Remove brush, trees, and other debris from the channel and spoil areas, and dispose of properly.

Grade or excavate cross section to the lines and grades shown in design for the concrete subgrade.

Remove soft sections and unsuitable material and replace with suitable material. The subgrade should be thoroughly compacted and shaped to a smooth, uniform surface.

Material Placement

Place forms to meet the specific plan design for the project, and place concrete of the designed mix into the forms according to construction specifications.

Construction and expansion joints should be used where swale length exceeds 10 feet. Construction joints should be spaced at 10-foot intervals and expansion points at intervals not to exceed 20 feet.

The subgrade should be moist at the time the concrete is placed.

Place concrete for the lined channel to the thickness shown on the plans and finish it in a workmanlike manner.

Coat the concrete with an approved curing compound as soon as finish work is complete and the free water has disappeared from the surface.

Provisions should be made to protect the freshly poured concrete from extreme temperatures to ensure proper curing.

Stabilization

Stabilize channel inlet and outlet points according to the design plan.

Stabilize adjacent disturbed areas after construction is completed with a vegetation treatment (see *Permanent Seeding* or *Temporary Seeding Practices*) and mulching. Provide topsoil, lime, and fertilizer as needed to grow grass on areas disturbed by construction. Many design plans specify a row of sod at the edges of the concrete channel.

If not specified in a plan, select lime, fertilizer, variety and mulching components from related practices – *Permanent Seeding* or *Temporary Seeding*, *Mulching*, *Erosion Control Blankets*, or *Sodding*.

Construction Verification

Check finished grades and cross sections throughout the length of the channel. Verify channel cross-section dimensions at several locations to avoid flow constrictions.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate practice will not function as intended; changes in plan may be needed.

Design specifications cannot be met; substitution may be required. Unapproved substitutions could result in failure of the practice.

Maintenance

Inspect lined channel at regular intervals and after storm events. Check for erosion adjacent to the channel, at inlets and outlets, and underneath the lined channel.

Give special attention to the channel inlet and outlet, and repair eroded areas promptly.

Inspect for erosion in the entire swale, and repair with appropriate vegetative treatment (permanent or temporary seeding and mulching).

References

BMPs from Volume 1





Chapter 4

Erosion Control Blanket (ECB)	4-33
Permanent Seeding (PS)	4-53
Sodding (SOD)	4-93
Temporary Seeding (TS)	4-103
Outlet Protection (OP)	4-199

MDOT Drawing DT-1


Details of Typical Ditch Treatments	4-198
-------------------------------------	-------

STATE	PROJECT NO.
MISS.	





CONCRETE PAVED DITCH

- NOTES:
1. CONCRETE PAVED DITCHES SHALL BE GROOVED AT 20'-0" INTERVALS. THE GROOVES SHALL BE CUT TO A DEPTH OF NOT LESS THAN 1".
 2. DIMENSIONS D & W ARE AS FOLLOWS:
 DIMENSION D = 5"
 DIMENSION W = 9"
 MINIMUM = 24"
 3. CHAIR SUPPORTS FOR THE WIRE MESH WILL NOT BE REQUIRED. HOWEVER, THE CONTRACTOR SHALL PLACE THE WIRE MESH IN A SATISFACTORY AND WORKMANLIKE MANNER TO ENSURE THAT THE FINAL POSITION IS REASONABLY NEAR THE POSITION INDICATED.
 4. CENTER ROW OF STAPLES MAY BE OMITTED ON DITCH LINER.





ANCHOR TRENCH DETAIL

NOTE: ANCHOR TRENCH REQUIRED AT THE BEGINNING AND ENDING OF EACH AREA TO BE COVERED, EXCEPT DOWNSTREAM END ADJOINING A STRUCTURE.




DITCH LINER TREATMENT
 (EXCELSIOR BLANKET, JUTE MESH OR EROSION CONTROL FABRIC)

NOTE: DITCHES TREATED WITH DITCH LINER WILL BE VEGETATED PRIOR TO TREATMENT, UNLESS OTHERWISE INDICATED.



- RIP-RAP TREATMENT**
- NOTES:
1. DIMENSIONS D, W AND X ARE VARIABLE AND ARE SHOWN ELSEWHERE ON THE PLANS.
 2. THE RIP-RAP SIZE AND MINIMUM DEPTH "H" FOR RIP-RAP TREATMENT ARE AS FOLLOWS.

RIP-RAP SIZE & MINIMUM DEPTH "H"	
H	RIP-RAP SIZE
6"	100
12"	100
18"	300




GENERAL NOTE:

1. FOR LOCATION OF APPROPRIATE DITCH TREATMENTS, SEE PLAN SHEETS AS DENOTED BY THE FOLLOWING LEGEND OR AS DIRECTED BY THE ENGINEER:

- DITCH LINER
- SOLID SOD
- CONCRETE PAVED DITCH
- RIP-RAP

MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
DETAILS OF TYPICAL DITCH TREATMENTS	
DATE	WORKING NUMBER
DESIGN TEAM	DT-1
FILENAME: EROSION CONTROL-DT-1.DGN	SHEET NUMBER
DESIGN TEAM	

Outlet Protection (OP)



Practice Description

This practice is designed to prevent erosion at the outlet of a channel or conduit by reducing the velocity of flow and dissipating the energy. Outlet protection measures usually consist of a riprap-lined apron, a reinforced concrete flume with concrete baffles, a reinforced concrete box with chambers or baffles, and possibly pre-manufactured products. This practice applies wherever high-velocity discharge must be released on erodible material.

Planning Considerations

The outlets of pipes and structurally lined channels are points of critical erosion potential. Stormwater that is transported through man-made conveyance systems at design capacity generally reaches a velocity that exceeds the ability of the receiving channel or area to resist erosion. To prevent scour at stormwater outlets, a flow transition structure is required, which will absorb the initial impact of the flow and reduce the flow velocity to a level that will not erode the receiving channel or area of discharge.

The most commonly used structure for outlet protection is an erosion-resistant lined apron. These aprons are generally lined with loose rock riprap, grouted riprap, or concrete. They are constructed at zero grade for a distance that is related to the outlet flow rate and the tailwater level. Criteria for designing these structures are contained in this practice. Several outlet conditions are shown in Figure OP-1. Example design problems for outlet protection are found at the end of this practice.

Where the flow is excessive for the economical use of an apron, excavated stilling basins may be used. Acceptable designs for stilling basins may be found in the following documents available from the U.S. Government Printing Office.

- 1) Hydraulic Design of Energy Dissipaters for Culverts and Channels, Hydraulics Engineering Circular No.14, U.S. Department of Transportation, Federal Highway Administration.
- 2) Hydraulic Design of Stilling Basins and Energy Dissipaters, Engineering Monograph No. 25, U.S. Department of Interior-Bureau of Reclamation.

Design Criteria and Construction

Structurally lined aprons at the outlets of pipes and paved channel sections should be designed according to the following criteria:

Pipe Outlets

Capacity

The structurally lined apron should have the capacity to carry the peak stormflow from the 25-year 24-hour frequency storm, or the storm specified in state laws or local ordinances, or the design discharge of the water conveyance structure, whichever is greatest.

Tailwater

The depth of tailwater immediately below the pipe outlet must be determined for the design capacity of the pipe. Manning's Equation may be used to determine tailwater depth. Manning's Equation may be found in Appendix A: Erosion and Stormwater Runoff Calculations (available in the Appendices Volume). If the tailwater depth is less than half the diameter of the outlet pipe, it shall be classified as a Minimum Tailwater Condition. If the tailwater depth is greater than half the pipe diameter, it shall be classified as a Maximum Tailwater Condition. Pipes that outlet to flat areas, with no defined channel, may be assumed to have a Minimum Tailwater Condition.


Apron Length

The apron length should be determined from Figure OP-2 or OP-3 according to the tailwater condition.

Apron Thickness

The apron thickness should be determined by the maximum stone size (d_{max}), when the apron is lined with riprap. The maximum stone size shall be $1.5 \times d_{50}$ (median stone size), as determined from Figure OP-2 or OP-3. The apron thickness shall be $1.5 \times d_{max}$.

When the apron is lined with concrete, the minimum thickness of the concrete shall be 4".



Notes

1. L_a is the length of the riprap apron.
2. $D = 1.5$ times the maximum stone diameter but not less than 6".
3. In a well-defined channel extend the apron up the channel banks to an elevation of 6" above the maximum tailwater depth or to the top of the bank, whichever is less.
4. A filter blanket or filter fabric should be installed between the riprap and soil foundation.

Figure OP-1 Pipe Outlet Conditions




Figure OP-2 Outlet Protection Design for Tailwater < 0.5 Diameter

Apron Width

If the pipe discharges directly into a well-defined channel, the apron should extend across the channel bottom and up the channel banks to an elevation 1 foot above the maximum tailwater depth or to the top of the bank, whichever is the least.

If the pipe discharges onto a flat area with no defined channel, the width of the apron should be determined as follows:

- The upstream end of the apron, adjacent to the pipe, should have a width 3 times the diameter of the outlet pipe.
- For a Minimum Tailwater Condition, the downstream end of the apron should have a width equal to the pipe diameter plus the length of the apron obtained from the figures.
- For a Maximum Tailwater Condition, the downstream end shall have a width equal to the pipe diameter plus 0.4 times the length of the apron from Figure OP-2 or OP-3.

Bottom Grade

The apron should be constructed with no slope along its length (0.0% grade). The invert elevation of the downstream end of the apron shall be equal to the elevation of the invert of the receiving channel. There shall be no overfall at the end of the apron.

Side Slope

If the pipe discharges into a well-defined channel, the side slopes of the channel should not be steeper than 2:1 (Horizontal: Vertical).

Alignment

The apron should be located so that there are no bends in the horizontal alignment.




Figure OP-3 Outlet Protection Design for Tailwater ≥ 0.5 Diameter

Geotextile

When riprap is used to line the apron, geotextile should be used as a separator between the graded stone, the soil subgrade, and the abutments. Geotextile should be placed immediately adjacent to the subgrade without any voids between the fabric and the subgrade. The geotextile will prevent the migration of soil particles from the subgrade

into the graded stone. The geotextile shall meet the requirements shown in the table below for Class I geotextile:

Table OP-1 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTMD 4632	≥ 50	≥ 50	≥ 50	≥ 50
Puncture (pounds)	ASTMD 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD 4751	As specified max. no.40 ³			
Permittivity sec ⁻¹	ASTMD 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

- 1 Heat-bonded or resin-bonded geotextile may be used for Classes III and IV. They are particularly well suited to Class IV. Needle-punched geotextiles are required for all other classes.
- 2 Minimum average roll value (weakest principal direction).
- 3 U.S. standard sieve size.

Materials

The apron may be lined with loose rock-riprap, grouted riprap, or concrete. The median-sized stone for riprap should be determined from the curves on Figures OP-2 and OP-3 according to the tailwater condition.

After the median stone size is determined, the gradation of rock to be used should be specified using Tables OP-2 and OP-3. Table OP-2 is used to determine the weight of the median stone size (d_{50}). Using this median weight, a gradation can be selected from Table OP-3, which shows commercially available riprap gradations.

Stone for riprap should consist of field stone or rough unhewn quarry stone of approximately rectangular shape. The stone should be hard and angular and of such quality that it will not disintegrate on exposure to water or weathering; it shall be suitable in all other respects for the purpose intended. The specific gravity of the individual stones should be at least 2.5.

When the apron is lined with concrete, the concrete should have a minimum compressive strength at 28 days of 3000 pounds per square inch. American Concrete Institute

guidelines should be used to design concrete structures and reinforcement. As a minimum, the concrete should be reinforced with steel-welded wire fabric.

Construction

Prior to start of construction, the practice should be designed by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the construction process. The structure should conform to the dimensions, grades and alignments shown on the plans and specifications.

Site Preparation

Completely remove stumps, roots, and other debris from the construction area. Fill depressions caused by clearing and grubbing operations with clean, non-organic soil. Grade the site to the lines and grades shown on the plans. Compact any fill required in the subgrade to the density of the surrounding undisturbed material.

If possible, the alignment should be straight throughout its length. If a curve is required, it should be located in the upstream section of the outlet.

Riprap Structures

Ensure that the subgrade for the filter and riprap follows the required lines and grades shown in the plan. Low areas in the subgrade on undisturbed soil may also be filled by increasing the riprap thickness.

Geotextile fabric must meet design requirements and be properly protected from puncturing or tearing during installation. Repair any damage by removing the riprap and placing another piece of filter cloth over the damaged area. All connecting joints should overlap a minimum of 1.5 feet with the upstream edge over the downstream edge. If the damage is extensive, replace the entire geotextile fabric.

Riprap may be placed by equipment; however, care should be taken to avoid damaging the filter.

Construct the apron on zero grade with no overfall at the end. Make the top of the riprap at the downstream end level with the receiving area or slightly below it.

Concrete Structures

Reinforcing steel-welded wire fabric should be placed in strict accordance with the design plans and maintained in the proper position during the pouring of concrete. Concrete should be placed in horizontal layers not exceeding 24" in thickness, or as specified in the design, and consolidated by mechanical vibrating equipment supplemented by hand-spading, rodding, or tamping.

Concrete should be placed in sturdy wood or metal forms, adequately supported to prevent deformation. Forms should be oiled prior to placement to prevent bonding between concrete and forms.

If possible, concrete should not be placed during inclement weather or periods of temperature extremes. If temperature extremes cannot be avoided, American Concrete Institute guidelines for placement of concrete during such extremes should be consulted.

Concrete should be allowed to cure as required by the plans and specifications.

Typically, the surface should be kept wet during curing by covering it with wet burlap sacks or other means. Design strengths should be confirmed by laboratory tests on representative cylinders made during concrete placement. Form work should not be removed prior to the specified time.

Table OP-2 Size of Riprap Stones

Weight	Mean Spherical Diameter (feet)	Rectangular Shape	
		Length	Width, Height (feet)
50	0.8	1.4	0.5
100	1.1	1.75	0.6
150	1.3	2.0	0.67
300	1.6	2.6	0.9
500	1.9	3.0	1.0
1000	2.2	3.7	1.25
1500	2.6	4.7	1.5
2000	2.75	5.4	1.8
4000	3.6	6.0	2.0
6000	4.0	6.9	2.3
8000	4.5	7.6	2.5
20000	6.1	10.0	3.3

Table OP-3 Graded Riprap

Class	Weight (lbs.)					
	d ₁₀	d ₁₅	d ₂₅	d ₅₀	d ₇₅	d ₉₀
1	10	-	-	50	-	100
2	10	-	-	80	-	200
3	-	25	-	200	-	500
4	-	-	50	500	1000	-
5	-	-	200	1000	-	2000




Figure OP-4 Paved Channel Outlet

- 1) The flow velocity at the outlet of paved channels flowing at design capacity should not exceed the velocity, which will cause erosion and instability in the receiving channel.
- 2) The end of the paved channel should merge smoothly with the receiving channel section. There should be no overfall at the end of the paved section. Where the bottom width of the paved channel is narrower than the bottom width of the receiving channel, a transition section should be provided. The maximum side divergence of the transition shall be 1 in 3F where

$$F = v/gd, \text{ and}$$

$$F = \text{Froude no.}$$

$$v = \text{Velocity at beginning of transition (ft/sec.)}$$

$$d = \text{Depth of flow at beginning of transition (feet.)}$$

$$g = 32.2 \text{ ft/sec.}^2$$

- 3) Bends or curves in the horizontal alignment of the transition are not allowed unless the Froude no. (F) is 0.8 or less, or the section is specifically designed for turbulent flow.

Example Design Problems

Example 1

Given: An 18" pipe discharges 24 cu. ft/sec at design capacity onto a grassy slope (no defined channel).

Find: The required length, width and median stone size (d_{50}) for a riprap-lined apron.

Solution

Since the pipe discharges onto a grassy slope with no defined channel, a Minimum Tailwater Condition may be assumed.

From Figure OP-2, an apron length (L_a) of 20 feet and a median stone size (d_{50}) of 0.8 foot is determined.

The upstream apron width equals 3 times the pipe diameter: $3 \times 1.5 \text{ feet} = \underline{4.5 \text{ feet}}$.

The downstream apron width equals the apron length plus the pipe diameter: $20 \text{ feet} + 1.5 \text{ foot} = \underline{21.5 \text{ feet}}$.

Example 2

Given: The pipe in example No. 1 discharges into a channel with a triangular cross section, 2 feet deep and 2:1 side slopes. The channel has a 2% slope and an "n" coefficient of 0.045.

Find: The required length, width and the median stone size (d_{50}) for a riprap lining.

Solution

Determine the tailwater depth using Manning's Equation and the Continuity Equation.

$$Q = 1.49/n R^{2/3} S^{1/2} A$$

$$24 = 1.49/n [2d/4.47]^{2/3} (0.02)^{1/2} (2d^2)$$

where, d = depth of tailwater
 $d = 1.74 \text{ feet}^*$

*Since d is greater than half the pipe diameter, a Maximum Tailwater Condition exists.

From Figure OP-3, a median stone size (d_{50}) of 0.5 foot and an apron length (L_a) of 41 feet is determined.

The entire channel cross section should be lined, since the maximum tailwater depth is within 1 foot of the top of the channel.

Construction Verification

Check finished structures for conformance with design specifications.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate measure will not function as intended.

Design specifications for riprap, filter fabric, concrete, reinforcing steel, or backfill cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Problems with the structure develop during or after installation.

Maintenance

Inspect riprap outlet structures after heavy rains to see if any erosion around or below the riprap has taken place or if stones have been dislodged. Check concrete structures for cracks and movement. Immediately make all needed repairs to prevent further damage.

References

BMPs from Volume 1

Chapter 4

Grass Swale (GS)

4-162

Riprap-lined Swale (RS)



Practice Description

A riprap-lined swale is a natural or constructed channel with an erosion-resistant rock lining designed to carry concentrated runoff to a stable outlet. This practice applies where grass swales are unsuitable because of conditions such as steep channel grades, prolonged flow areas, or soils that are too erodible or not suitable to support vegetation or insufficient space.

Planning Considerations

Swales should be carefully built to the design cross section, shape, and dimensions. Swales are hydraulic structures and as such depend upon the hydraulic parameters to serve satisfactorily. Swales may be used to

- Serve as outlets for diversions and sediment control basins and stormwater detention basins.
- Convey water collected by road ditches or discharged through culverts.
- Rehabilitate natural draws and gullies carrying concentrations of runoff.

The design of a swale cross section and lining is based primarily upon the volume and velocity of flow expected in the swale. Riprap-lined swales should be used where velocities are in the range of 5 to 10 ft/sec.

Besides the primary design considerations of capacity and velocity, a number of other important factors should be taken into account when selecting a cross section. These factors include land availability, compatibility with land use and surrounding environment, safety, maintenance requirements, and outlet conditions, etc.

Riprap-lined swales are trapezoidal in shape. Trapezoidal swales are often used where the quantity of water to be carried is large and conditions require that it be carried at a relatively high velocity.

Outlet conditions for all swales should be considered. This is particularly important for the transition from the riprap lining to a vegetative lining. Appropriate measures must be taken to dissipate the energy of the flow to prevent scour of the receiving swale.

Design Criteria

Capacity

Lined swales shall be designed to convey the peak rate of runoff from a 10-year 24-hour rainfall event. Adjustments should be made for release rates from structures and other drainage facilities. Swales should also be designed to comply with local stormwater ordinances.

Swales should be designed for greater capacity whenever there is danger of flooding or when out-of-bank flow cannot be tolerated. The maximum capacity of the swale flowing at design depth should be 200 cubic ft/sec.

Peak rates of runoff values used to determine the capacity requirements should be calculated using accepted engineering methods. Some accepted methods are:

- Natural Resources Conservation Service, National Engineering Handbook Series, Part 650, Engineering Field Handbook, Chapter 2, Estimating Runoff.
- Natural Resources Conservation Service (formerly Soil Conservation Service), Technical Release 55, Urban Hydrology for Small Watersheds.
- Other comparable methods – See *Appendix A: Erosion and Stormwater Runoff Calculations* found in the Appendices Volume.

Cross section

The swale cross section should be trapezoidal in shape. The steepest permissible side slope of the swale should be 2:1 (Horizontal: Vertical). A bottom width should be selected based on area available for installation of the swale and available rock sizes. The bottom width will be used in determining stable rock size and flow depth.

Depth

Design flow depth should be determined by the following formula:

$$z = [n(q)/1.486(S)^{0.50}]^{3/5}$$

S = Bed slope, (ft/ft)

z = Flow depth, (ft)

q = Unit discharge, (ft³/s/ft) (Total discharge ÷ Bottom width)

n = Manning's coefficient of roughness (see formula under velocities)

The design water surface elevation of a swale receiving water from other tributary sources should be equal to or less than the design water surface elevation of the contributing source. The design water surface elevation of contributing and receiving waters should be the same, whenever practical. A minimum depth may be necessary to provide adequate outlets for subsurface drains and tributary swales.

Freeboard

The minimum freeboard is 0.25 foot. Freeboard is not required on swales with less than 1% slope and where out-of-bank flow will not be damaging and can be tolerated from an operational point of view.

Stable Rock Size

Stable rock sizes, for rock-lined swales having gradients between 2 percent and 40 percent should be determined using the following formulas from *Design of Rock Chutes* by Robinson, Rice, and Kadavy.

For swale slopes between 2% and 10%: $d_{50} = [q(S)^{1.5}/4.75(10)^{-3}]^{1/1.89}$

For swale slopes between 10% and 40%: $d_{50} = [q(S)^{0.58}/3.93(10)^{-2}]^{1/1.89}$

- d_{50} = Particle size for which 50 % of the sample is finer, inch
 S = Bed slope, ft/ft
 q = Unit discharge, ft³/s/ft
 (Total discharge ÷ Bottom width)

After the stable median stone size is determined, the gradation of rock to be used should be specified using Tables RS-1 and RS-2. Table RS-1 is used to determine the weight of the median stone size (d_{50}). Using this median weight, a gradation can be selected from Table RS-2, which shows commercially available riprap gradations.

Table RS-1 Size of Riprap Stones

Weight (lbs)	Mean Spherical Diameter (feet)	Rectangular Shape	
		Length	Width, Height (feet)
50	0.8	1.4	0.5
100	1.1	1.75	0.6
150	1.3	2.0	0.67
300	1.6	2.6	0.9
500	1.9	3.0	1.0
1000	2.2	3.7	1.25
1500	2.6	4.7	1.5
2000	2.75	5.4	1.8
4000	3.6	6.0	2.0
6000	4.0	6.9	2.3
8000	4.5	7.6	2.5
20000	6.1	10.0	3.3

Table RS-2 Graded Riprap

Class	Weight (lbs.)					
	d ₁₀	d ₁₅	d ₂₅	d ₅₀	d ₇₅	d ₉₀
1	10	-	-	50	-	100
2	10	-	-	80	-	200
3	-	25	-	200	-	500
4	-	-	50	500	1000	-
5	-	-	200	1000	-	2000

Velocities

Velocities should be computed by using Manning's Formula with a coefficient of roughness, "n," as follows: $n = 0.047(d_{50} \cdot S)^{0.147}$

Applies on slopes between 2 and 40% with a rock mantle thickness of $2 \times d_{50}$ where:
 d_{50} = median rock diameter (inch), S = lined section slope (ft/ft) ($0.02 \leq S \leq 0.4$)

Velocities exceeding critical velocity should be restricted to straight reaches.

Waterways or outlets with velocities exceeding critical velocity should discharge into an outlet protection structure to reduce discharge velocity to less than critical (see *Outlet Protection Practice*).

Lining Thickness

The minimum lining thickness should be equal to the maximum stone size of the specified riprap gradation plus the thickness of any required filter or bedding.

Lining Durability

Stone for riprap should consist of field stone or rough unhewn quarry stone of approximately rectangular shape. The stone should be hard and angular and of such quality that it will not disintegrate on exposure to water or weathering, and it should be suitable in all other respects for the purpose intended. The specific gravity of the individual stones should be at least 2.5.

Geotextiles

Geotextiles should be used where appropriate as a separator between rock and soil to prevent migration of soil particles from the subgrade, through the lining material. Geotextiles should be Class I material as selected from Table RS-3.

Filters or Bedding

Filters or bedding should be used where needed to prevent piping. Filters should be designed according to the requirements contained in the *Subsurface Drain Practice*. The minimum thickness of a filter or bedding should be 6".

Table RS-3 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTMD4632	≥50	≥50	≥50	≥50
Puncture (pounds)	ASTMD4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD4751	As specified max. no. 40 ³			
Permittivity sec ⁻¹	ASTMD4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

- 1 Heat-bonded or resin-bonded geotextile may be used for Classes III and IV. They are particularly well suited to Class IV. Needle-punched geotextile are required for all other classes.
- 2 Minimum average roll value (weakest principal direction).
- 3 U.S. standard sieve size.

Construction

Prior to start of construction, riprap-lined swales should be designed by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the construction process.

Site Preparation

Determine exact location of underground utilities (See Appendix C: MS One-Call and 811 Color Coding.)

Remove brush, trees, and other debris from the channel and spoil areas, and dispose of properly.

Grade or excavate cross section to the lines and grades shown in design. Over-excavate to allow for thickness of riprap and filter material. Foundation excavation not deep enough or wide enough may cause riprap to restrict channel flow and result in overflow and erosion. Side slopes are usually 2:1 (Horizontal: Vertical) or flatter.

Foundation Stabilization

Install geotextile fabric or aggregate in the excavated channel as a foundation for the riprap. Anchor fabric in accordance with design specifications. If the fabric is omitted or damaged during stone placement, there may be settlement failure and bank instability.

Installation

As soon as the foundation is prepared, place the riprap to the thickness, depth, and elevations shown in the design specifications. It should be a dense, uniform, and well-graded mass with few voids. Riprap should consist of a well-graded mixture of stone (size and gradation as shown in design specifications) that is hard, angular, and highly chemical, and weather resistant. Larger stone should predominate, with sufficient smaller sizes to fill the voids between the stones. The diameter of the largest stone size should be not greater than 1.5 times the d_{50} size. Minimum thickness of riprap liner should be 1.5 times the maximum stone diameter.

Blend the finished rock surface with the surrounding land surface so there are no overfalls, channel constrictions, or obstructions to flow.

Outlet Stabilization

Stabilize channel inlet and outlet points. Extend riprap as needed.

Stabilize adjacent disturbed areas after construction is completed.

Construction Verification

Check finished grades and cross sections throughout the length of the channel.

Verify channel cross section dimensions at several locations to avoid flow constrictions.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate channel will not function as intended; changes in plan may be needed.

Design specifications for riprap sizing, geotextile fabric or aggregate filter cannot be met; substitution may be required. Unapproved substitutions could result in channel erosion.

Maintenance

Inspect channels at regular intervals and after storm events. Check for rock stability, sediment accumulation, piping, and scour holes throughout the length of the channel.

Look for erosion at inlets and outlets.

When stones have been displaced, remove any debris and replace the stones in such a way as to not restrict the flow of water.

Give special attention to outlets and points where concentrated flow enters the channel and repair eroded areas promptly by extending the riprap as needed.

References

BMPs from Volume 1

Chapter 4

Outlet Protection (OP)	4-199
Subsurface Drain (SD)	4-218

Additional Resources

Natural Resources Conservation Service, National Engineering Handbook Series, Part 650, Engineering Field Handbook, Chapter 2, Estimating Runoff.





Natural Resources Conservation Service (formerly Soil Conservation Service), Technical Release 55, Urban Hydrology for Small Watersheds.

Robinson, K.M., Rice, C.E., and Kadavy, K.C., 1998. Design of Rock Chutes. Am. Soc. Agric. Eng. Trans. 41, 621–626.

MDOT Drawing DT-1


Details of Typical Ditch Treatments	4-217
-------------------------------------	-------

STATE	PROJECT NO.
MISS.	





CONCRETE PAVED DITCH

- NOTES:**
1. CONCRETE PAVED DITCHES SHALL BE GROOVED AT 20'-0" INTERVALS. THE GROOVES SHALL BE CUT TO A DEPTH OF NOT LESS THAN 1".
 2. DIMENSIONS D & W ARE AS FOLLOWS:
 DIM(NOMINAL) = 6"
 DIM(NOMINAL) = 9"
 W(MINIMUM) = 24"
 3. CHAIR SUPPORTS FOR THE WIRE MESH WILL NOT BE REQUIRED. HOWEVER, THE CONTRACTOR SHALL PLACE THE WIRE MESH IN A SATISFACTORY AND WORKMANLIKE MANNER TO ENSURE THAT THE FINAL POSITION IS REASONABLY NEAR THE POSITION INDICATED.
 4. CENTER ROW OF STAPLES MAY BE OMITTED ON DITCH LINER.





NOTE: ANCHOR TRENCH REQUIRED AT THE BEGINNING AND ENDING OF EACH AREA TO BE COVERED, EXCEPT DOWNSTREAM END ADJOINING A STRUCTURE.




DITCH LINER TREATMENT
(EXCELSIOR BLANKET, JUTE MESH OR EROSION CONTROL FABRIC)

NOTE: DITCHES TREATED WITH DITCH LINER WILL BE VEGETATED PRIOR TO TREATMENT, UNLESS OTHERWISE INDICATED.



- NOTES:**
1. DIMENSIONS D, W AND X ARE VARIABLE AND ARE SHOWN ELSEWHERE ON THE PLANS.
 2. THE RIP-RAP SIZE AND MINIMUM DEPTH "H" FOR RIP-RAP TREATMENT ARE AS FOLLOWS.

RIP-RAP SIZE & MINIMUM DEPTH "H"	
H	RIP-RAP SIZE
12"	100
18"	300



- GENERAL NOTE:**
1. FOR LOCATION OF APPROPRIATE DITCH TREATMENTS, SEE PLAN SHEETS AS DENOTED BY THE FOLLOWING LEGEND OR AS DIRECTED BY THE ENGINEER:
- █ DITCH LINER
 - █ EXCELSIOR SOLID SOD
 - █ CONCRETE PAVED DITCH
 - █ RIP-RAP

DESIGNED BY: MISSISSIPPI DEPARTMENT OF TRANSPORTATION

DATE: _____

FILENAME: EROSION CONTROL\DT-1.DGN

WORKING NUMBER: DT-1

SHEET NUMBER: _____

Subsurface Drain (SD)



Practice Description

A subsurface drain is a perforated pipe or continuous layer of porous material installed below the ground surface that intercepts, collects, and carries excessive groundwater to a stable outlet. Subsurface drains by themselves do not provide erosion control. The purpose of a subsurface drain is to improve soil moisture conditions, vegetation growth, and ground stability. Subsurface drains may reduce wet ground from interfering with construction activities. Drains may be constructed using a gravel-filled trench, perforated pipe in gravel bedding, or manufactured drain panel products. This practice applies where groundwater is at or near the ground surface or where adequate drainage cannot be provided for surface runoff.

Planning Considerations

To properly design and install this practice, a detailed site investigation will be required. This investigation should include a site survey to determine the location of the area to be drained, the depth of the area to be drained, the topography of the area to be drained, the outlet of the drain system, and the soils at the site.

When considering use of this practice, the qualified design professional should consider the intended use of the area to be drained. Base flow and interflow of groundwater may increase with installation of this practice due to excess soil water being removed. Groundwater recharge may also be reduced by this practice. Finally, surface runoff may increase due to this practice reducing deep percolation at the site.

All federal, state, and local laws and regulations should be adhered to when planning and installing this practice.

Design Criteria

Layout and Depth

In the absence of site-specific information, a depth of 3 feet and a spacing of 50 feet for drains should be adequate. However, it is recommended that site-specific information be obtained. Typical details of subsurface drain construction can be seen in Figures SD-1 and SD-2. The following guidelines should be followed.

The depth at which the drain is installed will determine how much the water table is lowered. The minimum depth for the drain is 2 feet under normal conditions. The maximum depth is limited by the depth of the impermeable layer and, if a pipe is used in the drain, by the allowable load on the pipe used.

Spacing

The permeability of the soil at the site and the depth of the drain will determine the spacing of the drain.

Multiple Drains

In some cases more than one drain will be needed to achieve the desired results. The first drain should be installed, and additional drains should be added only if seepage or high water table problems continue.

Location

Drains should be located a minimum of 50 feet from any trees to prevent damage to the trees.

Grade

In areas where sedimentation is not likely, the minimum grades should be based on site conditions and a velocity of not less than 0.5 ft/sec. Where a potential for sedimentation exists, a velocity of not less than 1.4 ft/sec should be used to establish the minimum grades if site conditions permit. Otherwise, provisions should be made for prevention of sedimentation by filters or collection and for periodic removal of sediment from installed traps. Steep grades should be avoided.

Gravel Bedding

Typically, 3" or more of gravel is placed completely around the drain and graded to prevent the infiltration of fine-grained soils into the drain.

Filters and Filter Material

Filters will be used around conduits, as needed, to prevent movement of the surrounding soil material into the conduit. The need for a filter will be determined by the characteristics of the surrounding soil material (i.e. permeability), site conditions, and the velocity of flow in the conduit.

A suitable filter should be specified if

- Local experience indicates a need.

- Soil materials surrounding the conduit are dispersed clay, low-plasticity silts, or fine sands (ML or SM with plasticity index less than 7).
- Where deep soil cracking is expected.
- Where the method of installation may result in voids between the conduit and backfill material.

The filter can be geotextile filter fabric, sand, gravel, or sand-gravel combination. If a geotextile is used, it should meet the requirements of the material table found in the *Outlet Protection Practice*. Care should be taken when using geotextile filter fabric since small soil particles can clog the fabric. If a sand-gravel filter is specified, the filter gradation will be based on the gradation of the base material surrounding the conduit within the following limits:

- D_{15} size smaller than 7 times d_{95} size, but not smaller than 0.6 mm.
- D_{15} size larger than 4 times d_{15} size.
- Less than 5% passing No. 200 sieve.
- Maximum size smaller than 1.5".

D represents the filter material, and d represents the surrounding base material. The number following each letter is the percent of the sample, by weight, that is finer than that size. For example, D_{15} size means that 15 percent of the filter material is finer than that size.

Specified filter material must completely encase the conduit so that all openings are covered with at least 3" of filter material, except that the top of the conduit and side filter material may be covered by a sheet of plastic or similar impervious material to reduce the quantity of filter material required.

Clean-outs

In long sections of drain and in areas where sedimentation is concerned, clean-outs should be installed in the drain to facilitate removal of sediment deposits.

Outlet and Protection

The outlet must be protected against erosion and undermining of the conduit, entry of tree roots, damaging periods of submergence, and entry of rodents or other animals into the subsurface drain. A continuous section of rigid pipe without open joints or perforations will be used at the outlet end of the line and must discharge above the normal elevation of low flow in the outlet ditch. Corrugated plastic tubing is not suitable for the outlet section.

Materials

Pipe should be perforated, continuous closed-joint pipes of corrugated plastic, concrete, corrugated metal, or bituminous fiber. The pipe should have sufficient strength to withstand the load to be placed on it under the planned installation design.

Manufacturer's recommendations should be followed in designing the pipe to withstand design loads.




Figure SD-1 Details of Typical Subsurface Drain Construction




Figure SD-2 Details of Subsurface Drain Construction

Construction

Prior to start of construction, subsurface drains should be designed by a qualified design professional. Materials such as sand, gravel, geotextile filter cloth, and pipe must be properly designed in order for the subsurface drain system to function properly. Plans and specifications should be available to field personnel.

Site Preparation

Determine exact location of underground utilities. At least 3 days prior to construction, request Mississippi One-Call System (1-800-227-6477) to mark all underground utilities within the project area. See Appendix C for more information about utility marking.

Locate and mark the alignment of the drains as shown on the design plans.

Clear installation area of debris and obstacles, such as trees and stumps, that might hinder grading and installation of the subsurface drain.

Trench Excavation

Excavate the trench to the specified depth and grade shown in the design plan. To accommodate the gravel bedding or filter material, excavate the trench to at least 3" below the design bottom elevation of the pipe (or as shown on the design plans).

Place materials excavated from the trench on the up-gradient side of the trench to prevent water from entering the trench during construction.

Grade the trench to prevent siltation into the drain.

Installation of Drain Pipe, Bedding Material and Geotextile Filter Cloth

Line trench with filter cloth (if specified), providing enough material to overlap over the top of the finished gravel bedding. This helps prevent movement of soil into the gravel.

Spread bedding material specified in the design plan, usually 3" of gravel, to fill the over-excavated bottom of the trench.

Lay pipe on the design grade and elevation, avoiding reverse grade or low spots, after checking to ensure the pipe meets specifications.

Cap the upper end of each drain with a standard cap made for this purpose or with concrete or other suitable material to prevent soil from entering the open end.

Place bedding material around pipe, on all sides, with the amount shown in the design plan.

Fold filter cloth over the top of the gravel bedding.

Backfill Installation

Backfill immediately after placement of the pipe and bedding. Ensure that the material does not contain rocks or other sharp objects, and place it in the trench in a manner that will not damage or displace the pipe. Overfill the trench slightly to allow for settlement.

Installation of Clean-Out Device

Install clean-outs for maintenance of the subsurface drain in the locations shown on design plan.

Outlet Installation

Construct the outlet of the subsurface drain at the elevation in the design plan. The outlet section of the drain should be at least 10 feet of non-perforated corrugated metal, cast iron, steel, or heavy-duty plastic pipe. Cover at least half of the pipe length with well-compacted soil. Place a suitable animal guard securely over the pipe outlet to keep out rodents.

Stabilization

Keep the settled fill over the pipe outlet slightly higher than the surrounding ground to prevent erosion, rills and gullies.

Stabilize all bare areas of the trench with temporary seeding and mulching unless construction will disturb the area within 13 days.

Safety

Narrow trenches are subject to collapse and can be a safety hazard to persons in the trench. No person should enter a trench without shoring protection or properly sloping the sides of the trench.

Construction Verification

Verify the dimensions during construction with those shown on the plans for location, length, depth, and cross section of trench.

Verify the dimensions and specifications of the aggregate used in the bedding and manufactured materials such as pipe, tile or panel drain.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate subsurface drains will not function as intended or originally designed.

Design specifications for aggregate or manufactured products cannot be met; substitutions may be required. Unapproved substitutions could result in failure of the drain to function as intended.

Pipe is crushed by construction traffic.

Maintenance

Check subsurface drains periodically to ensure that they are free-flowing and not clogged with sediment.

Keep outlet clean and free of debris.

Keep surface inlets open and free of sediment and other debris.

Where drains are crossed by heavy vehicles, check the pipe to ensure that it is not crushed.

References

BMPs from Volume 1

Chapter 4

Outlet Protection (OP)

4-199

Temporary Slope Drain (TSD)

⇒ SD ⇒



Practice Description

A temporary slope drain is a pipe or other conduit designed to convey concentrated runoff down the face of a cut- or fill-slope without causing erosion. This practice applies wherever concentrated stormwater runoff must be conveyed down a steep slope.

Planning Considerations

There is often a significant lag between the time a cut- or fill-slope is completed and the time a permanent runoff-conveyance system can be installed. During this period, the slope is usually not stabilized and is particularly vulnerable to erosion. This situation also occurs on slope construction that is temporarily delayed before final grade is reached. Temporary slope drains, sometimes called “downdrains,” can provide valuable protection of exposed slopes until permanent runoff-conveyance structures can be installed. See Figure TSD-1 for typical details of a temporary slope drain.

When used in conjunction with diversions, temporary slope drains can be used to convey stormwater from the entire drainage area above a slope to the base of the slope without erosion. It is very important that these temporary structures be installed properly since their failure will often result in severe gully erosion. The entrance section must be securely entrenched, all connections must be watertight, and the conduit must be securely staked. Prior approval may be required from local regulatory agencies if the downdrain outlet is tied into an existing storm sewer or in areas where municipal stormwater is regulated.

Design Criteria

Drainage Area

The maximum allowable drainage area per drain is 5 acres.

Flexible Conduit

The downdrain should consist of heavy-duty flexible material designed for this purpose. The diameter of the downdrain should be equal over its entire length. Reinforced hold-down grommets should be spaced at 10-foot (or less) intervals, with the outlet end securely fastened in place. The conduit should extend beyond the toe of the slope.

Downdrains may be sized according to the table TSD-1.

Drains should be designed to convey the peak rate of runoff from a 10-year 24-hour rainfall whenever it is desired to individually design each installation.

Table TSD-1 Flexible Conduit Diameters

Maximum Drainage Area (Acres)	Pipe Diameter (D) (Inches)
0.5	12
1.5	18
2.5	21
3.5	24
5.0	30

Entrance Sections

The entrance to the downdrain (Figures TSD-2 and TSD-3) should consist of a standard flared end-section for metal pipe culverts. All fittings should be watertight.

The toe plate should be a minimum of 8" deep.

Extension collars should consist of 12" long corrugated metal pipe. Avoid use of helical pipe. Securing straps should be fabric, metal, or other material well suited to providing a watertight connection. The strap should secure at least one corrugation of the extension collar.

Diversion Design

An earthen diversion should be used to direct stormwater runoff into the slope drain and should be constructed according to the *Diversion Practice*.

The height of the diversion at the centerline of the inlet should be equal to at least the diameter of the pipe (D) plus 12". Where the dike height is greater than 18" at the inlet, it should be level for 3 feet each side of the pipe and be sloped at the rate of 3:1 (Horizontal: Vertical) or flatter to transition with the remainder of the dike.

Outlet Protection

The outlet of the downdrain should be protected from erosion as detailed in the *Outlet Protection Practice*.




Figure TSD-1 Typical Temporary Slope Drain Detail




Figure TSD-2 Flared End-Section Detail




Figure TSD-3 Flared End-Section Details (continued)

Construction

Prior to start of construction, temporary slope drains should be designed by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the construction process.

Site Preparation

Determine exact location of underground utilities (see Appendix C: MS One-Call and 811 Color Coding).

Place temporary slope drain on undisturbed soil or well-compacted fill at locations and elevations shown on the plans.

Grade the diversion channel at the top of the slope toward the temporary slope drain according to the design plan. Provide positive grade in the pipe under the ridge.

Hand tamp the soil under and around the pipe in lifts not to exceed 6".

Ensure that the fill over the drain pipe at the top of the slope is placed to the dimensions shown on the design plan.

Ensure that all slope drain connections are secure and watertight.

Ensure that all fill material is well compacted. Securely anchor the exposed section of the drain according to the design.

Extend the drain beyond the toe of the slope and adequately protect the outlet from erosion.

Make the settled, compacted diversion ridge no less than 1 foot above the top of the pipe at every point.

Erosion Control

Compaction of earthfill around the pipe in the vicinity of the ridge is extremely important to avoid piping failure and blowouts.

Immediately stabilize all disturbed areas following construction according to the design plan (with vegetation or other appropriate means of protection).

Construction Verification

Verify that materials, elevations, and installation procedures meet design specifications.

Joints should be carefully inspected for separations or looseness.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate temporary slope drains will not function as intended.

Pipe separates or is displaced.

Animals are going into the pipe outlet.

Maintenance

Inspect slope drains and supporting diversions once a week and after every storm event.

Check the inlet for sediment or trash accumulation; clear and restore to proper condition.

Check the fill over the pipe for settlement, cracking or piping holes; repair immediately.

Check for holes where the pipe emerges from the ridge; repair immediately.

Check the conduit for evidence of leaks or inadequate anchoring; repair immediately.

Check the outlet for erosion or sedimentation; clean and repair, or extend if necessary.

Once slopes have been stabilized, remove the temporary diversions and slope drains so that runoff water no longer concentrates but flows uniformly over the protected slope. Stabilize the diversion and slope drain areas.

References

BMPs from Volume 1


Chapter 4

Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103
Diversion (DV)	4-131
Outlet Protection (OP)	4-199


MDOT Drawing TEC-2

Typical Temporary Erosion Control Measures (Slope Drain and Type A Silt Basin)	4-232
--	-------


STATE	PROJECT NO.
MSS.	



TEMPORARY SHOULDER BERM



TEMPORARY MEDIAN SILT BASIN (TYPE A)




TEMPORARY SILT BASIN (TYPE A)


NOTE: TEMPORARY SILT BASIN (TYPE A) TO BE PLACED IN SURFACE DRAIN DITCHES AND SIDE DITCHES AT THE END OF CUT SECTIONS, IMMEDIATELY PRECEDING DITCH INLETS AND JUST BEFORE THE WATER DRUMPSIT LEAVES THE RIGHT-OF-WAY OR ENTERS A WATER COURSE. LOCATION AND SIZE (OTHER THAN AS SHOWN) MAY BE REQUIRED AS DIRECTED BY THE ENGINEER.

GENERAL NOTES:

1. THE CONTRACTOR SHALL BE REQUIRED TO FURNISH ALL MATERIALS AND PERFORM ALL WORK FOR THE PROPER INSTALLATION, MAINTENANCE AND REMOVAL OF TEMPORARY EROSION CONTROL MEASURES NECESSARY TO CONTROL SILTATION.




SECTION A-A



PLAN

TEMPORARY SLOPE DRAIN

NOTE: TEMPORARY SLOPE DRAINS TO BE PLACED AT LOW POINT OF ALL SAG VERTICAL CURVES. INTERMEDIATE LOCATIONS TO BE PLACED AS DESIGNATED OR DEEMED APPROPRIATE BY THE CONTRACTOR AND APPROVED BY THE ENGINEER.



RECOMMENDED ANCHOR DETAIL

NOTE: CONTRACTOR MAY PROPOSE ALTERNATE ANCHORING DETAIL. ENGINEER'S APPROVAL WILL BE BASED ON PERFORMANCE

DESIGNED BY	REVISION	DATE	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
			TYPICAL TEMPORARY EROSION CONTROL MEASURES (SLOPE DRAIN AND TYPE A SILT BASIN)
FILENAME: EROSION CONTROL\TEC-2.DGN	WORKING NUMBER	TEC-2	
DESIGN TEAM	CHECKED	DATE	SHEET NUMBER

Block and Gravel Inlet Protection (BIP)



Practice Description

Block and gravel inlet protection is a sediment control barrier formed around a storm drain inlet by the use of standard concrete block and gravel. The purpose is to help minimize sediment entering storm drains during construction. This practice applies where use of the storm drain system is necessary during construction and where inlets have a drainage area of 1 acre or less and an approach slope of 1% or less.

Planning Considerations

Storm sewers that are made operational before their drainage area is stabilized can convey large amounts of sediment to natural drainageways. In case of extreme sediment loading, the storm sewer itself may clog and lose a major portion of its capacity. To avoid these problems, it is necessary to prevent sediment from entering the system at the inlets.

This practice is for drainage areas of less than 1 acre. Runoff from large disturbed areas should be routed through a sediment basin (see *Sediment Basin Practice*). This method is for areas where heavy flows are expected and where overflow capacity is necessary to prevent excessive ponding around the structure.

The best way to prevent sediment from entering the storm sewer system is to minimize erosion by leaving as much of the site undisturbed as possible and disturbing the site in small increments, if possible. After disturbance, stabilize the site as quickly as possible to prevent erosion and sediment delivery.

Design Criteria and Construction

Drainage Area

Drainage area should be less than 1 acre per inlet.

Capacity

The design storm for the inlet should be able to enter the inlet without bypass flow.

Approach

The approach to the block and gravel structure should be less than 1%.

Height

The height of the block structure should be 1 to 2 feet.

Side Slopes

Gravel placed around the concrete block structure should have 2:1 (Horizontal: Vertical) side slopes or flatter.

Dewatering

Place a minimum of one block on the bottom row (more as needed) on its side to allow for dewatering the pool.

Site Preparation

Determine exact location of underground utilities (see Appendix C: MS One-Call and 811 Color Coding available in the Appendices Volume).

Clear area of all debris that might hinder excavation and disposal of spoil.

Grade the approach to the inlet uniformly. The top elevation of the structure must be lower than the ground elevation downslope from the inlet. It is important that all storm flows pass over the structure and into the storm drain and not past the structure. Temporary dikes below the structure may be necessary to prevent bypass flow. Material may be excavated from inside the sediment pool for this purpose.

Installation of Blocks, Wire Mesh and Gravel

Lay one block on its side in the bottom row on each side of the structure to allow pool drainage. The foundation for the blocks should be excavated at least 2" below the crest of the storm drain. The bottom row of blocks should be placed against the edge of the storm drain for lateral support and to avoid washouts when overflow occurs. If needed, lateral support may be given to subsequent rows by placing 2" x 4" wood studs through block openings.

Place concrete blocks lengthwise on their sides in a single row around the perimeter of the inlet, with the ends of adjacent blocks abutting. The height of the barrier can be varied, depending on design needs, by stacking combinations of 4", 8" and 12" wide blocks. The barrier of blocks should be at least 12" high and no greater than 24" high.

The top elevation of the structure must be at least 6" lower than the ground elevation downslope from the inlet. It is important that all storm flows pass over the structure and into the storm drain and not past the structure. Temporary dikes below the structure may

be necessary to prevent bypass flow. Material may be excavated from inside the sediment pool for this purpose.

Wire mesh should be placed over the outside vertical face (webbing) of the concrete blocks to prevent stone from being washed through the holes in the blocks. Hardware cloth or comparable wire mesh with ½" openings should be used.

Place stone of the specified gradation around blocks to the lines and dimensions shown on the drawings and smooth to an even grade.

Gravel

Stone should be piled against the wire to the top of the block barrier, as shown in the typical details in Figure BIP-1. Coarse aggregate or similar gradations should be used.

If the stone filter becomes clogged with sediment so that it no longer adequately performs its function, the stone must be pulled away from the blocks, cleaned, and replaced.

Erosion Control

Stabilize disturbed areas in accordance with the vegetation plan.

Construction Verification

Check finished grades and dimensions of block and gravel barrier. Check materials for compliance with specifications.

Safety

Provide protection to prevent children from entering the area.




Figure BIP-1 Typical Details of Block and Gravel Inlet Protection

Common Problems

Consult with qualified design professional if the following occurs:

Variations in topography on site indicate block and gravel drop inlet protection will not function as intended; changes in plan may be needed.

Maintenance

Inspect the barrier after each rain and make repairs as needed.

Remove sediment promptly following storms to provide adequate storage volume for subsequent rains and prevent sediment entering the storm drain in subsequent rains.

If the gravel becomes clogged with sediment so that barrier does not drain properly, remove gravel and replace with clean gravel of the specified gradation.

When the contributing drainage area has been adequately stabilized, remove all materials and any sediment, bring the disturbed area to proper grade, and stabilize it with vegetation or other materials shown in the design plan.

References

BMPs from Volume 1


Chapter 4

Sediment Basin (SBN) 4-298




MDOT Drawing ECD-1

Inlet Protection Details for Coarse Aggregate on Grades and Sags 4-238

STATE	PROJECT NO.
MISS.	



- NOTES:
1. THE ELEVATION OF THE TOP OF THE REQUIRED STONE BERM SHALL BE A MINIMUM OF 1.5' ABOVE THE ELEVATION OF THE INLET WORKING POINT AND A MINIMUM OF 6" BELOW THE ELEVATION OF THE OUTSIDE EDGE OF THE INSIDE SHOULDER.
 2. THIS COARSE AGGREGATE INLET PROTECTION SHALL NOT BE UTILIZED DURING STAGE 1 AND STAGE 2 INLET CONSTRUCTION. SEE INLET PROTECTION TYPICAL APPLICATIONS AND DETAILS.)
 3. 2" x 6" BOARDS MAY BE REPLACED WITH WIRE MESH W/OPENINGS LESS THAN 1" x 1". COST IS ABSORBED.



DATE	BY	REVISION	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
			INLET PROTECTION
			DETAILS FOR COARSE AGGREGATE
			ON GRADES & SAGS
			WORKING NUMBER
			ECD-11
			SHEET NUMBER
			FILENAME: EROSION_CTRL_SECD-11.DGN
			DESIGN TEAM CREDITS DATE

Excavated Inlet Protection (EIP)



Practice Description

Excavated inlet protection is a sediment control technique formed around a storm drain inlet by excavating a small area around the inlet to act as a settling pool. The purpose is to help minimize sediment entering storm drains during construction. This practice applies where use of the storm drain system is necessary during construction and where inlets have a drainage area of 1 acre or less.

Planning Considerations

Storm sewers that are made operational before their drainage area is stabilized can convey large amounts of sediment to natural drainageways. In case of extreme sediment loading, the storm sewer itself may clog and lose a major portion of its capacity. To avoid these problems, it is necessary to prevent sediment from entering the system at the inlets.

This practice is for drainage areas of less than 1 acre. Runoff from large disturbed areas should be routed through a sediment basin (see *Sediment Basin Practice*). This method is not recommended for areas where heavy flows are expected as it may overflow the excavated area.

The best way to prevent sediment from entering the storm sewer system is to minimize erosion by leaving as much of the site undisturbed as possible and disturbing the site in small increments, if possible. After disturbance, stabilize the site as quickly as possible to prevent erosion and sediment delivery.

Design Criteria and Construction

Drainage Area

Drainage area should be less than 1 acre per inlet.

Capacity

The trap should be sized to provide a minimum storage of 67 cubic yards for 1 acre of drainage area.

Approach

The approach to the block and gravel structure should be less than 1%.

Depth

The depth of the trap should be no less than 1 foot and no more than 2 feet deep measured from the top of the inlet structure.

Side Slopes

The side slopes of the trap should not exceed 3:1.

Dewatering

Weep holes should be installed to allow for dewatering the pool (Figure EIP-1).

Site Preparation

Determine exact location of underground utilities (see Appendix C: MS One-Call and 811 Color Coding available in the Appendices Volume).

Clear area of all debris that might hinder excavation and disposal of spoil.

Grade the approach to the inlet uniformly. The top elevation of the structure must be lower than the ground elevation downslope from the inlet. It is important that all storm flows pass over the structure and into the storm drain and not past the structure directly into the storm drain. Sediment may be excavated from inside the sediment pool for this purpose.

Erosion Control

Stabilize disturbed areas in accordance with the vegetation plan.

Construction Verification

Check finished grades and dimensions of block and gravel barrier. Check materials for compliance with specifications.

Safety

Provide protection to prevent children from entering the area.




Figure EIP- 1 Excavated Inlet Protection

Common Problems

Consult with qualified design professional if the following occurs:

Storm drains subject to heavy flows may not benefit from excavated inlet protection; changes in plan may be needed.

Maintenance

Inspect the trap after each rain and make repairs as needed.

Remove sediment promptly following storms to provide adequate storage volume for subsequent rains and to prevent sediment entering the storm drain in subsequent rains.

When the contributing drainage area has been adequately stabilized, remove all materials and any sediment, bring the disturbed area to proper grade, and stabilize it with vegetation or other materials shown in the design plan.

References

BMPs from Volume 1

Chapter 4

Sediment Basin (SBN)

4-298

Fabric Drop Inlet Protection (FIP)



Practice Description

Fabric drop inlet protection is a structurally supported geotextile barrier placed around or over a drop inlet to prevent sediment from entering storm drains during construction. This practice applies where early use of the storm drain system is necessary prior to stabilization of the disturbed drainage area. This practice is suitable for inlets with a drainage area of less than 1 acre and a gentle approach slope generally of 1% or less.

Planning Considerations

Storm sewers that are made operational before their drainage area is stabilized can convey large amounts of sediment to natural drainage ways. In case of extreme sediment loading, the storm sewer itself may clog and lose a major portion of its capacity. To avoid these problems, it is necessary to prevent sediment from entering the system at the inlets that discharge directly to waters of the state.

The best way to prevent sediment from entering the storm sewer system is to stabilize the site as quickly as possible, preventing erosion and stopping sediment at its source. Sediment is best treated by preventing erosion. Leave as much of the site undisturbed as possible in the total site plan. Clear and disturb the site in small increments, if possible.

Numerous products have been developed to facilitate the capture of suspended soil particles at inlets. The design criteria for performance should be considered when evaluating alternative products. Products that will likely not meet performance goals or that usually fail under storm conditions should not be selected.

Design Criteria and Installation

Prior to start of construction, fabric drop inlet protection structures should be designed by a qualified professional. Plans and specifications should be available to field personnel. (*Note: Premanufactured fabric drop inlet protective structures should be installed and maintained according to the manufacturer's requirements.*)



Drainage Area

Drainage area should be less than 1 acre per inlet.

Sediment Storage

The basin created at the inlet should provide 67 cubic yards per disturbed acre of sediment storage.

Site Preparation

The soil around the drop inlet should be well compacted. The area around the drop inlet should be shaped, if necessary, to store the runoff on an almost level area. If runoff could bypass the protected inlet, a temporary dike should be planned and force the runoff to be trapped by the protective device.

Approach

The approach to the inlet protection practice should generally be less than 1% slope.

Height

The height of the structurally supported geotextile should be at least 1 foot but no more than 2.5 feet. The base of the fabric should be buried with compacted earth fill at least 12 inches into the soil or extend horizontally and be adequately secured with ballast material according to the manufacturer's recommendations. Ensure that the height of the structure when fully ponded does not cause unintentional damage or hazards to adjacent areas.

Structural Frame Installation

The frame (premanufactured or constructed) should provide the internal support necessary to prevent the structure from buckling, the fabric from sagging, or the fabric from being undermined. Frames should be positioned so that water that overtops the device goes directly into the inlet and does not cause erosion between the frame and inlet. Premanufactured frames should be installed according to manufacturer's recommendations.

Fabric Installation

Generally, fabric is installed by one of two methods:

Fabric can be buried vertically in a trench. The trench is excavated at least 12 inches into compacted soil adjacent to the inlet. Support posts are installed securely against the exterior of the drop inlet. Fabric along with wire fence is secured in the bottom of the trench and against the exterior surface of the inlet with stakes no more than 2 feet apart

and driven at least 6 inches into the soil. The trench is backfilled with hand-compacted soil to the density equivalent to the surrounding soil. Fence and fabric are secured to the posts and the structure internally supported to meet the structural requirements of the device.

Fabric for pre-manufactured drop inlet protective devices is generally secured with ballast pockets on well-compacted soil around the inlet. Install these according to manufacturer's recommendations

Performance

Either the system of protection for the project or the drop inlet protection that discharges directly to the outfall of the project must be designed to meet the NTU requirements for discharge.

Stabilization

Stabilize all bare areas that drain to the inlet with temporary seeding and mulching unless construction will disturb it within 13 days.

Safety

Protection should be provided to prevent children from entering open-top structures.

Construction Verification

Check finished grades and dimensions of fabric drop inlet protection structures.

Common Problems

Consult with a qualified design professional if any of the following occurs:

Variations in site conditions indicate that the practice will not function as intended; change in plan may be needed.

Sediment not removed from pool resulting in inadequate storage volume for the next storm.

Top of fabric set too high, resulting in flow bypassing the inlet.

Fabric is not adjacent to the inlet exterior surface, resulting in erosion and undercutting of inlet.

Maintenance

Inspect fabric barrier after each rainfall event and make needed repairs immediately.

Remove sediment from the pool area when sediment has reached ½ the fabric height. Take care not to damage or undercut the fabric during the sediment removal.

When the contributing drainage area has been adequately stabilized, remove all materials and unstable sediment and dispose of properly. Fill the disturbed area to the grade of the drop inlet. Stabilize disturbed areas in accordance with the plans.

References

BMPs from Volume 1

Chapter 4

Sediment Barrier (SB) 4-284

Sediment Basin (SBN) 4-298


MDOT Drawing ECD-3

Details of Silt Fence Installation 4-247


MDOT Drawing ECD-13

Inlet Protection Details of Manufactured Inlet Protection 4-248

STATE	PROJECT NO.
MSS.	




ELEVATION VIEW



METHOD I
METHOD II
MECHANICAL INSTALLATION

SIDE VIEW


- NOTES:
1. SILT FENCES SHALL BE USED IN AREAS WHERE FLOW IS NOT SEVERE.
 2. SILT FENCES ARE TEMPORARY SEDIMENT CONTROL ITEMS THAT SHALL BE ERRECTED OPPOSITE ERODIBLE AREAS SUCH AS NEWLY GRADED FILL SLOPES AND ADJACENT TO STREAMS AND CHANNELS.
 3. SILT FENCE SHOULD BE PLACED WELL INSIDE RIGHT-OF-WAY AND ALONG EDGE OF CLEARING LIMITS. THIS WILL ALLOW ROOM FOR A BACK-UP FENCE IF FIRST FENCE BECOMES FULL.
 4. WHEREVER POSSIBLE SILT FENCE SHALL BE CONSTRUCTED ACROSS A LEVEL AREA IN THE SHAPE OF A SABLE. THIS ADS IN PONDING OF RUNOFF AND FACILITATES SEDIMENTATION.
 5. THE CONTRACTOR MAY ELECT TO USE EITHER METHOD I OR METHOD II. COST TO BE LINEAR FEET OF SILT FENCE.
 6. METHOD II INSTALLATION SHALL BE ACCOMPLISHED USING AN IMPLEMENT THAT IS MANUFACTURED FOR THE APPLICATION AND PROVIDES A CONFIGURATION MEETING THE REQUIREMENTS OF THE DETAIL.
 7. WIRE SHALL BE MINIMUM OF 32" IN WIDTH AND SHALL HAVE A MINIMUM OF 6 LINE WIRES WITH 12" STAY SPACING.
 8. GEOTEXTILE FABRIC MEETING THE TYPE I MATERIAL REQUIREMENTS AND INSTALLED ACCORDING TO SPECIFICATION MAY BE USED WITHOUT WIRE FENCE.



PLAN VIEW
REQUIRED LAPPING


DESIGN		BY		DATE		REVISION		NO.		DATE	
MISSISSIPPI DEPARTMENT OF TRANSPORTATION											
DETAILS OF SILT FENCE INSTALLATION											
FILENAME: EROSION_CONTROL\ECD-3.DGN										WORKING NUMBER ECD-3	
DESIGN TEAM										SHEET NUMBER	

STATE	PROJECT NO.
MISS.	



PLAN

- NOTES:
1. FRAMES WITH EITHER SQUARE OR CIRCULAR BASES MAY BE USED. SELECTED FRAME BASE SHOULD PROVIDE BEST SEAL AROUND INLET AS DIRECTED BY THE ENGINEER.
 2. FILL POCKETS AROUND BASE OF FILTER COVER WITH #57 STONE OR SOIL. STONE IS REQUIRED WHEN ANCHORING THE MANUFACTURED INLET PROTECTION DEVICE OVER PAVED DITCH OR FLUME.
 3. USE ONLY DURING STAGE 3 OR STAGE 4 INLET CONSTRUCTION.
 4. FOR MEDIAN INLET PROTECTION, THE ELEVATION OF THE COARSE SCREEN TOP SHOULD BE A MINIMUM OF 6" BELOW THE ELEVATION OF THE OUTSIDE EDGE OF THE INSIDE SHOULDER.



SECTION "A-A"

BY	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
DATE	
DESIGN	
CHECKED	
DATE	
FILENAME:	EROSION CONTROL#ECD-13.DGN
DESIGN TEAM	
ORDER	
DATE	
WORKING NUMBER	ECD-13
SHEET NUMBER	

Straw Bale Inlet Protection (SBIP)



Practice Description

Straw bale inlet protection is a sediment control barrier formed around a storm drain inlet by the use of standard straw bales. The purpose is to help minimize sediment entering storm drains during construction. This practice applies where use of the storm drain system is necessary during construction and where inlets have a drainage area of 1 acre or less and an approach slope of 1% or less.

Planning Considerations

Storm sewers that are made operational before their drainage area is stabilized can convey large amounts of sediment to natural drainageways. In case of extreme sediment loading, the storm sewer itself may clog and lose a major portion of its capacity. To avoid these problems, it is necessary to prevent sediment from entering the system at the inlets.

This practice is for drainage areas of less than 1 acre. Runoff from large disturbed areas should be routed through a sediment basin. This method is for areas where heavy flows are expected and where overflow capacity is necessary to prevent excessive ponding around the structure.

The best way to prevent sediment from entering the storm sewer system is to minimize erosion by leaving as much of the site undisturbed as possible and disturbing the site in small increments, if possible. After disturbance, stabilize the site as quickly as possible to prevent erosion and sediment delivery.

Design Criteria and Construction

Drainage Area

Drainage area should be less than 1 acre per inlet. The drainage area should be relatively flat (slopes no greater than 5 percent) where sheet or overland flows are typical. The method shall not apply to inlets receiving concentrated flows.

Capacity

The design storm for the inlet should be able to enter the inlet without bypass flow.

Bale Size

Bales should be either wire bound or string-tied with binding oriented around the sides rather than over and under the bales. Bales should be 14" x 18" x 36". Straw wattles can also be used for this practice. A drawing representing straw wattle inlet protection is provided by the MDOT at the end of this practice (MDOT Drawing ECD-12).

Effective Life

Straw and hay bales have a relatively short period of usefulness and should not be used if the project duration is expected to exceed 3 months. Bale placement should result in the twine or cord being on the side and not the bottom of the bale.

Site Preparation

Determine exact location of underground utilities (see Appendix C: MS One-Call and 811 Color Coding available in the Appendices Volume).

Clear area of all debris that might hinder excavation and disposal of spoil.

Installation

Bales should be placed lengthwise in a single row surrounding the inlet with the ends of the adjacent bales pressed together.

If filter fabric is used, it should be entrenched and backfilled. A trench can be excavated around the inlet the width of the bale to a minimum depth of 4". After the bales are staked, the bales should be backfilled with the excavated soil and compacted against the filter barrier.

Anchors

Two 36" long (minimum), 2" x 2" hardwood stakes should be driven through each bale after the bales are properly entrenched. Alternate anchors can be two pieces of No. 4 steel rebar, 36" long (minimum).

Erosion Control

Stabilize disturbed areas in accordance with vegetation plan. If no vegetation plan exists, consider planting and mulching as part of installation and select planting information from either the *Permanent Seeding* or *Temporary Seeding Practice*. Select mulching information from the *Mulching Practice*.

Construction Verification

Check finished grades and dimensions of the straw bale inlet protection. Check materials for compliance with specifications.




Figure SBIP- 1 Straw Bale Drop Inlet Sediment Filter

Common Problems

Consult with registered design professional if the following occurs:

Variations in topography on site indicate sediment trap will not function as intended; changes in plan may be needed.

Design specifications for materials cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Maintenance

Inspect straw bale barriers after each storm event and remove sediment deposits promptly after it has accumulated to $\frac{1}{2}$ of the original capacity, taking care not to undermine the entrenched bales.

Inspect periodically for deterioration or damage from construction activities. Repair damaged barrier immediately.

After the contributing drainage area has been stabilized, remove all straw bales and sediment, bring the disturbed area to grade, and stabilize it with vegetation or other materials shown in the design plan.

Straw bales may be recycled as mulch.

References

BMPs from Volume 1

Chapter 4

Sediment Basin (SBN) 4-298


MDOT Drawing ECD-10

Inlet Protection Typical Application and Details 4-253

MDOT Drawing ECD-12


Inlet Protection Details of Wattles 4-254

STATE	PROJECT NO.
MISS.	




STAGE 2
INLET/JUNCTION BOX
CONSTRUCTED BUT NOT BACKFILLED

NOTE: ACCEPTABLE INLET PROTECTION DEVICES FOR STAGE 2 INCLUDE WATTLE, SILT FENCE OR SAND BAGS. HAY BALE PROTECTION NOT ACCEPTABLE DURING THIS PHASE.




STAGE 3
INLET CONSTRUCTED AND BACKFILLED

NOTE: ACCEPTABLE INLET PROTECTION FOR STAGE 3 INCLUDES MANUFACTURED INLET PROTECTION DEVICE, WATTLE OR SAND BAGS. HAY BALES NOT ACCEPTABLE PROTECTION DURING THIS STAGE.



STAGE 1
INLET/JUNCTION BOX LOCATION EXCAVATED



STAGE 4
COMPLETED INLET WITH
ADJACENT IMPERMEABLE SURFACE

NOTE: A MANUFACTURED INLET PROTECTION DEVICE OR SAND BAGS W/GRAVEL MAY BE SUBSTITUTED FOR THE PERIMETER BARRIER DURING STAGE 4 CONSTRUCTION.


DITCH INLET CONSTRUCTION STAGES

- NOTES:
1. FOUNDATION BACKFILL SHOULD BE PLACED IN STAGE 1 IMMEDIATELY AFTER PIPE INSTALLATION. INLET CONSTRUCTION SHOULD COMMENCE AS SOON AS POSSIBLE AND BE CONTINUOUS THROUGH COMPLETION.
 2. CONFIGURATIONS MAY BE ADJUSTED WITH APPROVAL OF THE ENGINEER FOR TRAVELWAY SAFETY, WATER FLOW, SOIL OR INSTALLATION CHALLENGES.
 3. DURING STAGE 1 AND STAGE 2, SILT FENCE MAY BE REQUIRED UPSLOPE OF THE INLET EXCAVATION AS DIRECTED BY THE ENGINEER.
 4. IF SILT FENCING IS INSTALLED AROUND THE INLET EXCAVATION IT SHOULD BE PLACED IN A CONFIGURATION THAT WILL ALLOW INLET CONSTRUCTION.


DATE	BY	REVISION	MISSISSIPPI DEPARTMENT OF TRANSPORTATION INLET PROTECTION TYPICAL APPLICATIONS AND DETAILS
			WORKING NUMBER ECD-10
			SHEET NUMBER
			FILENAME: EROSION CONTROL#ECD-10.DGN
DESIGN TEAM	CHECKED	DATE	

STATE	PROJECT NO.
MSS.	


NOTE:
SILT FENCE OR SAND BAGS MAY ALSO BE USED FOR THIS APPLICATION.
HAY BALES NOT ACCEPTABLE DURING THIS STAGE.



CURB INLET PROTECTION (STAGE 2)
SINGLE OR DOUBLE WING INLET




SECTION B-B



DROP INLET PROTECTION

NOTES:

1. ANCHORING STAKES SHALL BE SIZED, SPACED, AND BE OF A MATERIAL THAT EFFECTIVELY SECURES THE WATTLE. STAKE SPACING SHALL BE A MAXIMUM OF THREE FEET.
2. OVERLAP ENDS OF WATTLES PER MANUFACTURERS RECOMMENDATIONS (1' MIN., 3' MAX.).
3. TRENCHING OF WATTLES MAY BE NECESSARY IF PIPING BECOMES EVIDENT.



SECTION A-A

BY		MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
DATE		INLET PROTECTION DETAILS OF WATTLES	
FILENAME:	EROSION CONTROL-EC-12.DWG	WORKING NUMBER	ECD-12
DESIGN TEAM:	AKOCEL JHT	SHEET NUMBER	

Brush/Fabric Barrier (BFB)



Practice Description

A brush/fabric barrier is a dam-like structure constructed from woody residue and faced with a geotextile fabric to provide a temporary sediment basin. This practice is applicable on sites with a small drainage area where brush and other woody debris are available from a clearing and grubbing operation.

Planning Considerations

This practice is intended to be a temporary sediment basin with a limited life span and applicable only for small drainage areas.

The barrier should be located downslope from areas with potential sheet and rill erosion, with adequate storage volume in front of the barrier, and with no more than 2 acres of drainage area.

Adequate woody material from clearing and grubbing required on the site must be available for the construction of the barrier.

The practice should be located and designed so that adequate storage volume and detention time can be obtained, and failure of the barrier will not result in hazard to the public or damage to work on either on-site or off-site property.

Design Criteria and Construction

Prior to start of construction, a qualified design professional should determine the location and storage for the barrier. Typically, brush/fabric barriers are constructed where materials are readily available and at a location with adequate storage characteristics.

Drainage Area

Brush/fabric barriers should be designed with no more than 2 acres of drainage area. A sediment basin should be considered for larger drainage areas (see *Sediment Basin Practice*).

Structure Life

The design life of the structure should be 1 year or less. The barrier should be removed, and sediment accumulations properly stabilized prior to completion of the construction project.

Sediment Storage

The barrier should be designed to provide 67 cubic yards of sediment storage per acre of disturbed drainage area. Sediment should be removed and properly utilized on-site when half of the sediment storage volume has been filled.

Site Location and Preparation

The site for the barrier should be located so that a basin capable of providing the sediment storage required can be obtained or created. The site for the barrier should be smoothed prior to placement of the brush.




Figure BFB-1 Typical Installation

Materials Installation

Place the cleared and grubbed material in a densely compacted row, mostly on the contour, with each end upturned so that excessive flows will go over the top of the barrier and not around the ends of the barrier. Figure BFB-1 shows the typical installation.

Densely packed material should be placed so that the main stems of the woody debris are aligned with the length of the barrier. Small stems and limbs protruding from the bundle that could damage the fabric should be trimmed.

Generally, the barrier should be at least 3 feet tall, but no more than 6 feet tall. The width of the barrier perpendicular to the direction of flow should be at least 5 feet at its base.

Geotextile filter fabric consistent with the fabric used for silt fencing can be used to cover the face of the barrier. It is best to use wide and long rolls of the fabric so that splicing is minimized or eliminated. The fabric used to face the upstream surface of the brush should be non-woven geotextile equivalent to Class II fabric (see Table BFB-1).

The fabric should be securely buried at the bottom of an excavated trench that is at least 6" deep in front of the barrier. Prior to backfilling the trench, the fabric should be securely staked at 3-foot centers with minimum 18" long wooden stakes.

The fabric to be used should be supplied in lengths and widths to minimize vertical splices and eliminate horizontal splices. Avoid longitudinal splices of the fabric. Vertical splices must be securely fastened to each other so that flows will not short-circuit through the splice. The minimum vertical splice overlap should be 3 feet. Vertical splices must be securely fastened to each other so that flows will not short-circuit through the splice.

The top edge of the fabric should be secured so that it will not sag below the designed storage elevation. The upper edge can be anchored with twine fastened to the fabric and secured to stakes behind the barrier.

Table BFB-1 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTMD 4632	≥50	≥50	≥50	≥50
Puncture (pounds)	ASTMD 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD 4751	As specified max. no. 40 ³	As specified max. no. 40 ³	As specified max. no. 40 ³	As specified max. no. 40 ²
Permittivity sec ⁻¹	ASTMD 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

¹ Heat-bonded or resin-bonded geotextiles may be used for Classes III and IV. They are particularly well suited to Class IV. Needle-punched geotextile is required for all other classes.

² Minimum average roll value (weakest principal direction).

³ U.S. standard sieve size.

Construction Verification

Check finished size, elevation, storage, and shape for compliance with standard drawings and materials list. (Check for compliance with specifications if included in contract specifications.)

Common Problems

Consult with a qualified design professional if any of the following occurs:

Variations in topography on-site indicate brush/fabric barrier will not function as intended. Change in design plan will be needed.

There is not adequate cleared, woody material to construct the barrier.

Materials specified in the plan are not available.

Maintenance

Inspect the barrier for short-circuiting of water or flow around the ends of the barrier after each significant rainfall event.

Sediment should be removed if it reaches a depth half of the original fabric height. If the area behind the barrier fills with sediment, there is a greater likelihood that water will flow around the end of the barrier and cause the practice to fail.

Large rainfall events that overtop the structure can result in gully erosion behind the barrier. This should be repaired as needed.

Brush/fabric barriers are temporary structures and should be removed when their useful life has been completed. All accumulated sediment should be properly stabilized, and the area where the barrier was located should be seeded and mulched immediately unless a different treatment is prescribed.

References**BMPs from Volume 1****Chapter 4**

Sediment Basin (SBN) 4-298


MDOT Drawing ECD-2

Details of Sediment Barrier Applications 4-259


MDOT Drawing TEC-1

Typical Temporary Erosion Control Measures 4-260


STATE	PROJECT NO.
MSS.	



SEDIMENT BARRIER AT CROSS DRAIN



FRONT ELEVATION




SIDE ELEVATION


TEMPORARY BRUSH BARRIER

- NOTES:
- BRUSH BARRIER MAY BE USED WHERE NATURAL GROUND IS LEVEL OR SLOPING AWAY FROM PROJECT.
 - PLACE BRUSH LOG AND TREE LAPS APPROXIMATELY PARALLEL TO TOE OF FILL SLOPE WITH SOME OF THE HEAVIER MATERIALS BEING PLACED ON TOP TO PROPERLY SECURE THE BARRIER AS DETAILED AT LOCATIONS SHOWN ON PLANS OR AS DIRECTED OR PERMITTED BY THE ENGINEER.
 - TO ALLOW WATER TO SEEP THROUGH BRUSH BARRIER, INTERMINGLE THE BRUSH LOG AND TREE LAPS SO AS NOT TO FORM A SOLID DAM.
 - THE BRUSH BARRIER MAY BE CHOKED WITH FILTER FABRIC.
 - TEMPORARY BRUSH BARRIER WILL NOT BE MEASURED FOR SEPARATE PAYMENT.


NOTE:
1. ANCHOR AND INSTALL SILT FENCE PER DETAILS SHOWN ON ECD-3



SILT FENCE SECTION AT TOE OF FILL




"J-HOOK" SILT FENCE APPLICATION



"SMILE-CONFIGURATION" SILT FENCE APPLICATION

MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
DETAILS OF SEDIMENT BARRIER APPLICATIONS	
WORKING NUMBER	ECD-2
FILENAME: EROSION CONTROL\ECD-2.DGN	SHEET NUMBER
DESIGN TEAM	CHECKED DATE

STATE	PROJECT NO.
MISS.	




FRONT ELEVATION


SIDE ELEVATION

TEMPORARY SILT FENCE

- NOTES:
1. WIRE SHALL BE MINIMUM OF 32" IN WIDTH AND SHALL HAVE A MINIMUM OF 6 LINE WIRES WITH 12" STAY SPACING.
 2. GEOTEXTILE FABRIC SHALL BE A MINIMUM OF 36" IN WIDTH AND SHALL BE FASTENED ADEQUATELY TO THE WIRE AS DIRECTED BY THE ENGINEER.
 3. STEEL POST SHALL BE 5'-0" IN HEIGHT AND OF THE SELF-FASTENER ANGLE STEEL TYPE. WOOD POST SHALL BE A MINIMUM OF 3'-0" IN HEIGHT AND 3" OR MORE IN DIAMETER. WIRE FENCE SHALL BE FASTENED TO WOODEN POST WITH NOT LESS THAN 9 GAGE WIRE STAPLES 1' LONG.
 4. GEOTEXTILE FABRIC MEETING THE TYPE II MATERIAL REQUIREMENTS AND INSTALLED ACCORDING TO SPECIFICATIONS MAY BE USED WITHOUT WIRE FENCE.



FRONT ELEVATION




SIDE ELEVATION

TEMPORARY BRUSH BARRIER


- NOTES:
1. BRUSH BARRIER TO BE USED WHERE NATURAL GROUND IS LEVEL OR SLOPING AWAY FROM PROJECT.
 2. PLACE BRUSH, LOG AND TREE LAPS APPROXIMATELY PARALLEL TO TOE OF FILL SLOPE WITH SOME OF THE HEAVIER MATERIALS BEING PLACED ON TOP TO PROPERLY SECURE THE BARRIER AS DETAILED AT LOCATIONS SHOWN ON PLANS OR AS DIRECTED BY THE ENGINEER.
 3. TO ALLOW WATER TO FLOW THROUGH BRUSH BARRIER, INTERMINGLE THE BRUSH, LOG AND TREE LAPS SO AS NOT TO FORM A SOLID DAM.

GENERAL NOTES:


1. THE CONTRACTOR SHALL BE REQUIRED TO FURNISH ALL MATERIALS AND PERFORM ALL WORK FOR THE PROPER INSTALLATION, MAINTENANCE AND REMOVAL OF TEMPORARY EROSION CONTROL MEASURES NECESSARY TO CONTROL SILTATION.
2. TEMPORARY BRUSH BARRIERS SHALL BE USED AS REQUIRED BUT WILL NOT BE MEASURED FOR SEPARATE PAYMENT.
3. THE USE OF TEMPORARY EROSION CONTROL MEASURES OTHER THAN TEMPORARY BRUSH BARRIERS WILL ONLY BE REQUIRED AND MEASURED FOR SEPARATE PAYMENT WHEN APPROPRIATE PAY ITEM(S) IS INCLUDED IN THE BID SCHEDULE OF THE PROPOSAL.



ELEVATION




ELEVATION




PLAN


FALL OF DITCH (ft)	DISTANCE* (ft)
0 - 1	100'
1 - 2	50'
>2	25'



PLAN



CULVERT



DROP INLET

TEMPORARY EROSION CHECKS USING HAY OR STRAW BALES

NOTE: EMBED ALL BALES 3" MINIMUM INTO GROUND AND STAKE (2" X 2" X 36") SECURELY.

MISSISSIPPI DEPARTMENT OF TRANSPORTATION ROADWAY DESIGN DIVISION STANDARD PLAN	
TYPICAL TEMPORARY EROSION CONTROL MEASURES (SILT FENCE, HAY BALES & BRUSH BARRIER)	
DATE	ISSUE DATE: OCTOBER 1, 1998
REVISION	WORKING NUMBER TEC-1
	SHEET NUMBER 142

Filter Strip (FS)



Practice Description

A filter strip is a wide belt of vegetation designed to provide infiltration, intercept sediment and other pollutants, and reduce stormwater flow and velocity. Filter strips are similar to grassed swales except that they are designed to intercept overland sheet flow (not channel flow). They cannot treat high-velocity flows. Surface runoff must be evenly distributed across the filter strip. Vegetation may consist of existing cover that is preserved and protected or that is to be planted to establish the strip. Once a channel forms in the filter strip, the filter strip is no longer effective. This practice applies on construction sites and other disturbed areas.

Planning Considerations

Filter strips provide their maximum benefit when established as early as possible after disturbances begin. This concept should receive strong consideration during the scheduling of practices to be installed. In some instances, the existing vegetation may be preserved to serve as a filter strip.

Filter strips should be strategically located on the contour to reduce runoff and increase infiltration. They should be situated downslope from the disturbed site and where runoff-water enters environmentally sensitive areas.

Overland flow entering filter strips should be primarily sheet flow. All concentrated flow should be dispersed prior to entering the filter strip.

Flow length should be based on slope percent and length, predicted amount and particle size distribution of sediment delivered to the filter strip, density and height of the filter strip vegetation, and runoff volume.

The slope of the drainage area above a filter strip should be greater than 1% but less than 10%. The ratio of the drainage area to the filter strip should be less than 50:1.

Existing vegetation may be used if it meets stand density and height requirements and provides for uniform flow through the existing vegetation. The existing vegetation strip must be on a contour to be effective.

Site preparation for filter strips requires that the filter strip be placed on the contour. Variation in placement on the contour should not exceed a 0.5% longitudinal (perpendicular to the flow length) gradient.

All soil amendments should be applied according to a soil test recommendation for the planned vegetation.

The vegetation for filter strips must be permanent herbaceous vegetation of a single species or a mixture of grasses or legumes that have stiff stems and a high stem density near the ground surface. Stem density should be such that the stem spacing does not exceed 1".

Design Criteria and Construction

Installation (Preservation of Existing Vegetation)

Prior to start of installation, filter strips should be designed by a qualified professional. Plans and specifications should be referred to by field personnel throughout the construction process.

Designate the areas for preserving vegetation on the design plan map.

Indicate in the plan that the designated areas will be fenced or flagged and will not be disturbed. This includes avoiding surface disturbances that affect sheet flow of stormwater runoff and not storing debris from clearing and grubbing, and other construction waste material, in the filter strips during construction.

Installation (Planting)

Site Preparation

If the upper edge of the filter strip does not have a level edge, remove any obstructions and grade the upper edge of the filter strip so that runoff evenly enters the filter strip.

Fill and smooth any rills and gullies that exist over the filter strip area to ensure that overland flow will discharge across the filter strip along a smooth surface.

Seedbed Preparation

Grade and loosen soil to a smooth firm surface to enhance rooting of seedlings and reduce rill erosion. If existing, break up large clods and loosen compacted, hard, or crusted soil surfaces with a disk, ripper, chisel, harrow, or other tillage equipment. Avoid preparing the seedbed under excessively wet conditions.

For broadcast seeding and drilling, tillage should adequately loosen the soil to a depth of at least 6", alleviate compaction, and smooth and firm the soil for the proper placement of seed.

For no-till drilling, the soil surface does not need to be loosened unless the site has surface compaction. If compaction exists, the area should be chiseled across the slope to a depth of at least 6".

Applying Soil Amendments

Liming

Follow soil test recommendation. If a soil test is not available, use 2 tons/acre of ground agricultural lime on clayey soils (approximately 90 lbs/1000 ft²) and 1 ton/acre on sandy soils (approximately 45 lbs/1000 ft²). (Exception: If the cover is tall fescue and clover, use the 2 tons/acre rate (90 lbs/1000 ft²) on both clayey and sandy soils.)

Spread the specified amount of lime and incorporate into the top 6" of soil after applying fertilizer.

Fertilizing

Apply fertilizer at rates specified in the soil test recommendation. In the absence of soil tests, use the following as a guide:

Grass alone: 8-24-24 or equivalent - 400 lbs/acre (9.2 lbs/1000 ft²). When vegetation has emerged to a stand and is growing, 30 to 40 lbs/acre (0.8 lb/1000 ft²) of additional nitrogen fertilizer should be applied.

Grass-legume mixture: 8-24-24 or equivalent-400 lbs/acre (9.2 lbs/1000 ft²). When vegetation has emerged to a stand and is growing, 30 to 40 lbs (0.8 lb/1000 ft²) of additional nitrogen fertilizer should be applied.

Legume alone: 0-20-20 or equivalent-500 lbs/acre (11.5 lbs/1000 ft²).

Note: Fertilizer can be blended to meet exact fertilizer recommendations. Take soil test recommendations to local fertilizer dealer for bulk fertilizer blends. This may be more economical than bagged fertilizer.

Incorporate lime and fertilizer to a minimum depth of at least 6" or more by disking or chiseling on slopes of up to 3:1.

Planting

Plant the species specified in the plan at the rate and depth specified. In the absence of plans and specifications, plant species and seeding rates may be selected by qualified persons using Figure FS-1 and Table FS-1.

Apply seed uniformly using a cyclone seeder, drill seeder, cultipacker seeder, or hydroseeder.

When using a drill seeder, plant grasses and legumes ¼" to ½" deep. Calibrate equipment in the field.

When planting by methods other than a drill seeder or hydroseeder, cover seed by raking or by dragging a chain, brush, or mat. Then firm the soil lightly with a roller. Seed can also be covered with hydro-mulched wood fiber and tackifier. Legumes require inoculation with nitrogen-fixing bacterial to ensure good growth. Purchase inoculum specific for the seed and mix with seed prior to planting.

Mulching

Cover 65% to 75% of the surface with the specified mulch materials. Crimp, tack, or tie down straw mulch with netting. Mulching is extremely important for successful seeding (see *Mulching Practice* for more details.)

Construction Verification

Check materials and installation for compliance with specifications during installation of products.

Table FS-1 Commonly Used Plants for Permanent Cover

Species	Seeding Rates/Ac PLS ¹	North Seeding Dates	Central	South
Bahia grass, ² Pensacola	40 lbs	--	Mar 1-July 1	Feb 1-Nov 1
Bermuda grass, Common	10 lbs	Apr 1-July 1	Mar 15-July 15	Mar 1-July 15
Bahia grass, Pensacola Bermuda grass, Common	30 lbs 5 lbs	--	Mar 1-July 1	Mar 1-July 15
Bermuda grass, Hybrid (Lawn Types)	Solid sod	Anytime	Anytime	Anytime
Bermuda grass, Hybrid (Lawn Types)	Sprigs 1/sq ft	Mar 1-Aug 1	Mar 1-Aug 1	Feb 15 - Sep 1
Fescue, Tall	40-50 lbs	Sep 1-Nov 1	Sep 1-Nov 1	--
Sericea	40-60 lbs	Mar 15-July 15	Mar 1-July 15	Feb 15 -July 15
Sericea & Common Bermuda grass	40-60 lbs 10 lbs	Mar 15 -July 15	Mar 1-July 15	Feb 15-July 15
Switch grass, Alamo	4 lbs	Apr 1-Jun 15	Mar 15-Jun 15	Mar 15-Jun 15

¹ A late-fall planting of Bahia grass should contain 45 pounds of small grain to provide cover during winter months.

² PLS means pure live seed and is used to adjust seeding rates. For example, to plant 10 lbs of a species with germination of 80% and with 10% inert material, 10 PLS = 10 lbs/80% - 10% = 10/0.70 = 14.3 lbs.




Figure FS-1 Geographical Areas for Species Adaptation and Seeding Dates

Common Problems

Consult with a qualified design professional if any of the following occurs:

Variations in topography on-site indicate filter strip will not function as intended.

Design specifications for seed variety, seeding dates, or mulching cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Seeding at the wrong time of the year results in an inadequate stand. Reseed according to specifications of a qualified professional.

Inadequate mulching results in an inadequate stand, bare spots, or eroded areas; prepare seedbed, reseed, cover seed evenly, and tack or tie down mulch, especially on slopes, ridges, and in channels (see recommendations under *Maintenance*).

Maintenance

Erosion

Check for eroded channels in the filter strip after every storm event until the vegetation is well established. Eroded areas should be repaired by filling and/or smoothing and by reapplication of lime, fertilizer, seed, and mulch. It is particularly important that the surface is smooth and promotes sheet flow of storm runoff.

Generally, a stand of vegetation cannot be determined to be fully established until vegetative cover has been maintained for at least 1 year after planting.

Reseeding

Inspect seeding monthly for stand survival and vigor.

If stand is inadequate, identify the cause of failure—choice of plant materials, lime and fertilizer quantities, poor seedbed preparation, or weather—and take corrective action. If vegetation fails to grow, have the soil tested to determine whether pH is in the correct range or if nutrient deficiency is a problem.

Stand conditions, particularly percent coverage, will determine the extent of remedial actions such as seedbed preparation and reseeding. A qualified professional should be consulted to advise on remedial actions. Consider drill seeding if enough residue exists.

Fertilizing

Establishment may require refertilizing the stand in the second growing season. Follow soil test recommendations or the specifications provided for establishment.

Mowing

Mow vegetation to prevent woody plants from invading.

Certain species can be weakened by mowing regimes that significantly reduce their food reserves stored for the next growing season. Fescue should not be mowed closer than 4" during the summer. Sericea should not be mowed closer than 4" during the growing season, and it should not be mowed at all between late summer and frost. Bermuda grass

and Bahia grass are tolerant of most mowing regimes and can be mowed often and close, if so desired, during their growing season.

References

Volume 1

Chapter 2

Vegetation for Erosion and Sediment Control 2-10

Chapter 4

Land Grading (LG) 4-16

Permanent Seeding (PS) 4-53

Preservation of Vegetation (PV) 4-64

Temporary Seeding (TS) 4-103

Floating Turbidity Barrier (FB)

— FTB — FTB —



Practice Definition

A floating turbidity barrier consists of geotextile material (curtain) with floats on the top, weights on the bottom, and an anchorage system that minimizes sediment transport from a disturbed area that is adjacent to or within a body of water. The barrier provides sedimentation and turbidity protection for a watercourse from up-slope land-disturbance activities where conventional erosion and sediment controls cannot be used or need supplemental sediment control, or from dredging or filling operations within a watercourse. The practice can be used in non-tidal and tidal watercourses where intrusion into the watercourse by construction activities has been permitted and subsequent sediment movement is unavoidable.

Planning Considerations

Soil loss into a watercourse results in long-term suspension of sediment. In time, the suspended sediment may travel long distances and affect widespread areas. A turbidity barrier is designed to deflect and contain sediment within a limited area and provide enough residence time so that soil particles will fall out of suspension and not travel to other areas.

Turbidity barrier types must be selected based on the flow conditions within the waterbody, whether it is a flowing channel, lake, pond, or a tidal watercourse. The specifications contained within this practice pertain to minimal- and moderate-flow conditions where the velocity of flow may reach 5 ft/sec (or a current of approximately 3-knots). For situations where there are greater flow velocities or currents, a qualified design professional and the product manufacturer should be consulted.

Consideration must also be given to the direction of water movement in channel-flow situations. Turbidity barriers are not designed to act as water impoundment dams and

cannot be expected to stop the flow of a significant volume of water. They are designed and installed to trap sediment; not to halt the movement of water itself. In most situations, turbidity barriers should not be installed across channel flows. There is an exception to this rule. This occurs when there is a danger of creating a sediment buildup in the middle of a watercourse, thereby blocking access or creating a sediment bar. Curtains have been used effectively in large areas of moving water by forming a very long-sided, sharp “V” to deflect clean water around a work site, confining a large part of the sediment-laden water to the work area inside the “V” and directing much of the sediment toward the shoreline. Care must be taken, however, not to install the curtain perpendicular to the water current.

In tidal or moving water conditions, provisions must be made to allow the volume of water contained within the barrier to change. Since the bottom of the barrier is weighted and external anchors are frequently added, the volume of water contained within the curtain will be much greater at high tide versus low tide, and measures must be taken to prevent the curtain from submerging. In addition to allowing slack in the curtain to rise and fall, water must be allowed to flow through the curtain if the curtain is to remain in roughly the same place and maintain the same shape. Normally, this is achieved by constructing part of the curtain from a heavy, woven filter fabric. The fabric allows the water to pass through the curtain, but retains the sediment particles. Consideration should be given to the volume of water that must pass through the fabric and the sediment particle size when specifying fabric permeability.

Sediment, which has been deflected and settled out by the curtain, may be removed if so directed by the on-site inspector or the permitting agency. However, consideration must be given to the probable outcome of the procedure, which may create more of a sediment problem by re-suspension of particles and accidental dumping of the material by the equipment involved. It is, therefore, recommended that the soil particles trapped by a turbidity curtain be removed only if there has been a significant change in the original contours of the affected area in the watercourse. Regardless of the decision made, soil particles should always be allowed to settle for a minimum of 6-12 hours before removal by equipment or before removal of a turbidity curtain.

It is imperative that all measures in the erosion-control plan be used to keep sediment out of the watercourse. However, when proximity to the watercourse makes successfully mitigating sediment loss impossible, the use of the turbidity curtain during land disturbance is essential. Under no circumstances should permitted land-disturbing activities create violations of water quality standards.

Design Criteria and Construction

Floating turbidity barriers are normally classified into three types:

- Type I (see Figure FB-1) is used in protected areas where there is no current and the area is sheltered from wind and waves.
- Type II (see Figure FB-1) is used in areas where there may be small to moderate current (up to 2 knots or 3.5 ft/sec) and/or wind and wave action can affect the curtain.

- Type III (see Figure FB-2) is used in areas where considerable current (up to 3 knots or 5 ft/sec) may be present, where tidal action may be present, and/or where the curtain is potentially subject to wind and wave action.

Turbidity curtains should extend the entire depth of the watercourse whenever the watercourse in question is not subject to tidal action and/or significant wind and wave forces. This prevents sediment-laden water from escaping under the barrier, scouring, and re-suspending additional sediments.

In tidal and/or wind- and wave-action situations, the curtain should never be so long as to touch the bottom. A minimum 1-foot gap should exist between the weighted, lower end of the skirt and the bottom at “mean” low water. Movement of the lower skirt over the bottom due to tidal reverses or wind and wave action on the flotation system may fan and stir sediments already settled out.

In tidal and/or wind- and wave-action situations, it is seldom practical to extend a turbidity curtain depth lower than 10 to 12 feet below the surface, even in deep water. Curtains that are installed deeper than this will be subjected to very large loads with consequent strain on curtain materials and the mooring system. In addition, a curtain installed in such a manner can “billow up” toward the surface under the pressure of the moving water, which will result in an effective depth that is significantly less than the skirt depth.

Turbidity curtains should be located parallel to the direction of flow of a moving body of water. Turbidity curtains should not be placed across the main flow of a significant body of moving water.

When sizing the length of the floating curtain, allow an additional 10-20% variance in the straight-line measurements. This will allow for measuring errors, make installation easier and reduce stress from potential wave action during high winds.

An attempt should be made to avoid an excessive number of joints in the curtain. A minimum continuous span of 50 feet between joints is a good “rule of thumb.”

For stability reasons, a maximum span of 100 feet between anchor or stake locations is also a good rule to follow.

The ends of the curtain, both floating upper and weighted lower, should extend well up onto the shoreline, especially if high water conditions are expected. The ends should be secured firmly to the shoreline to fully enclose the area where sediment may enter the water.

When there is a specific need to extend the curtain to the bottom of the watercourse in tidal or moving water conditions, a heavy, woven, pervious filter fabric may be substituted for the normally recommended impervious geotextile. This creates a “flow-through” medium, which significantly reduces the pressure on the curtain and will help to keep it in the same relative location and shape during the rise and fall of tidal waters.

Typical installation layouts of turbidity curtains can be seen in Figure FB-3. The number and spacing of external anchors will vary depending on current velocities and potential wind and wave action. Manufacturer’s recommendations should be followed.

In navigable waters, additional permits may be required from the U.S. Army Corps of Engineers or other regulatory agencies if the barrier creates an obstruction to navigation.

Site Preparation

If a floating turbidity barrier is specified in the erosion and sediment control plan, it should be installed before any land-disturbing activities. Shoreline anchor points should be located according to the plans.

Materials and Installation Requirements

Barriers should be a bright color (yellow or “international” orange) that will attract the attention of nearby boaters. The curtain fabric must meet the minimum requirements noted in Table FB-1.

When installing Type I barrier in the calm water of lakes or ponds, it is usually sufficient to merely set the curtain end stakes or anchor points (using anchor buoys if bottom anchors are employed); then, tow the curtain in the furled condition out and attach it to these stakes or anchor points. Following this, any additional stakes or buoyed anchors required to maintain the desired location of the curtain may be set, and these anchor points made fast to the curtain. Only then, the furling lines should be cut to let the curtain skirt drop.

When installing Type II or III barriers in rivers or in other moving water, it is important to set all the curtain anchor points. Care must be taken to ensure that anchor points are of sufficient holding power to retain the curtain under the expected current conditions, before putting the furled curtain into the water. Anchor buoys should be employed on all anchors to prevent the current from submerging the flotation at the anchor points. If the moving water into which the curtain is being installed is tidal and will subject the curtain to currents in both directions as the tide changes, it is important to provide anchors on both sides of the curtain for two reasons:

- Curtain movement will be minimized during tidal current reversals.
- The curtain will not overrun the anchors, pulling them out when the tide reverses.

When the anchors are secure, the furled curtain should be secured to the upstream anchor point and then sequentially attached to each next downstream anchor point until the entire curtain is in position. At this point, and before unfurling, the “lay” of the curtain should be assessed and any necessary adjustments made to the anchors. Finally, when the location is ascertained to be as desired, the furling lines should be cut to allow the skirt to drop.

The anchoring line attached to the flotation device on the downstream side will provide support for the curtain. Attaching the anchors to the bottom of the curtain could cause premature failure of the curtain due to the stresses imparted on the middle section of the curtain.

Seams in the fabric should be either vulcanized welded or sewn, and should develop the full strength of the fabric.

Flotation devices should be flexible, buoyant units contained in an individual flotation sleeve or collar attached to the curtain. Buoyancy provided by the flotation units should be sufficient to support the weight of the curtain and maintain a freeboard of at least 3" above the water surface level.

Load lines must be fabricated into the bottom of all floating turbidity curtains. Type II and Type III curtains must have load lines also fabricated into the top of the fabric. The top load line should consist of woven webbing or vinyl-sheathed steel cable and should have break strength in excess of 10,000 pounds (5 t). The supplemental (bottom) load line should consist of a chain incorporated into the bottom hem of the curtain of sufficient weight to serve as ballast to hold the curtain in a vertical position. Additional anchorage should be provided as necessary. The load lines should have suitable connecting devices that develop the full breaking strength for connecting to load lines in adjacent sections. (See Figures FB-1 and FB-2 which portray this orientation.)

Table FB-1 Curtain Fabric Material Requirements for Floating Turbidity Barriers

Characteristic Test Method	16 Oz Nominal Laminated	18 Oz Laminated	22 Oz Coated	Geotextile Filter
Construction	Vinyl Laminate On 1300 Denier 9 X 9 Scrim	Vinyl Laminate On1300 Denier 9 X 9 Scrim	Vinyl Coated On Woven 6 Oz Polyester Base	Woven Polypropylene
Weight ASTM D-751-95 Sec 16	Nominal 16 Oz/Sq Yd 376 Gr/Sq M	18 Oz/Sq Yd 423 Gr/Sq M	22 Oz/Sq Yd 517 Gr/Sq M	7.5 Oz/Sq Yd 176 Gr/Sq M
Adhesion ASTM D-751-95 Sec 43.1.2	15 Lb/In 14 Dan/5 Cm	15 Lb/In 14 Dan/5 Cm	14 Lb/In 13 Dan/5 Cm	Not Applicable
Tensile Strength ASTM D-751-95 Sec 12	324 X 271 Lb/In 308 X 258 Dan/5 Cm	397 X 373 Lb/In 378 X 363 Dan/5 Cm	500 X 400 Lb/In 476 X 389 Dan / 5 Cm	350 X 250 Lb/ In 333 X 230 Dan / 5 Cm
Tear Strength ASTM D-751-95 Sec 29	76 X 104 Lb/In 72 X 99 Dan/5 Cm	96 X 86 Lb/In 91 X 82 Dan/5 CM	132 X 143 Lb/In 126 X 136 Dan / 5 Cm	95 X 55 Lb/In 90 X 52 Dan / 5 Cm
Hydrostatic ASTM D-751-95 Sec 34.2	385 Lb/Sq In 2674 kPa	385 Lb/Sq In 674 kPa	881 Lb/Sq In 6118 kPa	Not Applicable

External anchors may consist of 2" x 4" or 2½" minimum-diameter wooden stakes, or 1.33 pounds/linear foot steel posts when Type I installation is used. When Type II or Type III installations are used, bottom anchors should be used.

Bottom anchors must be sufficient to hold the curtain in the same position relative to the bottom of the watercourse without interfering with the action of the curtain. The anchor may dig into the bottom (grappling hook, plow, or fluke-type) or may be weighted (mushroom type), and should be attached to a floating anchor buoy via an anchor line. The anchor line would then run from the buoy to the top load line of the curtain. When used with Type III installations, these lines must contain enough slack to allow the buoy and curtain to float freely with tidal changes without pulling the buoy or curtain down and must be checked regularly to make sure they do not become entangled with debris. As previously noted, anchor spacing will vary with current velocity and expected wind

and wave action. Manufacturer's recommendations should be followed. See orientation of external anchors and anchor buoys for tidal installation in Figure FB-2.

Installing two parallel curtains, separated at regular intervals by 10-foot-long wooden boards or lengths of pipe can increase the effectiveness of the barrier.




Figure FB-1 Type I and II Floating Turbidity Barriers




Figure FB-2 Type III Floating Turbidity Barrier




Figure FB-3 Typical Installation Layouts

Construction Verification

Check the type of floating turbidity barrier, installation location, and the installation and anchorage procedures for compliance with the standard drawings and materials list. (Check for compliance with specifications if included in contract specifications.)

Removal

Care should be taken to protect the skirt from damage as the turbidity curtain is dragged from the water.

The site selected to bring the curtain ashore should be free of sharp rocks, broken cement, debris, etc., so as to minimize damage when hauling the curtain over the area.

If the curtain has a deep skirt, it can be further protected by running a small boat along its length with a crew installing furling lines before attempting to remove the curtain from the water.

Common Problems

Consult with a qualified design professional if any of the following occurs:

Variations in topography on site indicate that a floating turbidity barrier will not function as intended. Change in plan will be needed.

The specified anchorage system will not function as planned.

Turbid water is escaping from the barrier enclosure.

Materials specified in the plan are not available.

Maintenance

The floating turbidity barrier should be maintained for the duration of the project to ensure the continuous protection of the watercourse. Anchors, anchor lines, and buoys must be regularly checked to remove debris.

If repairs to the geotextile fabric become necessary, normally, repair kits are available from the manufacturer. Follow the manufacturer's instructions to ensure the adequacy of the repair.

When the curtain is no longer required as determined by the responsible individual, the curtain and related components should be removed in such a manner as to minimize turbidity. If required by the contract or the responsible individual, sediment should be removed and the original depth (or plan elevation) restored before removing the curtain. Remaining sediment should be sufficiently settled before removing the curtain. Any spoils should be taken to an upland area and stabilized.

References


MDOT Drawing ECD-19

Floating Turbidity Curtain


4-277

STATE	PROJECT NO.
MSS.	


FLOATING TURBIDITY CURTAIN




TYPICAL ANCHORING PLAN FOR SHORELINE/RIVER EDGE WORK



TYPICAL ANCHORING PLAN FOR MID CHANNEL WORK (BRIDGE PIER, CAISSON, ETC.)



TYPICAL ANCHORING SECTION



SECTION A-A

AUTOMATIC FLASHING LIGHT BUOY (ON AT DUSE-OFF AT DAWN) 100' ON CENTER SHALL BE USED IN NAVIGABLE CHANNELS ONLY

EROSION CONTROL PLAN LEGEND: [Symbol] FLOATING TURBIDITY CURTAIN

FLOATING TURBIDITY CURTAIN GENERAL NOTES

- A) FLOATING TURBIDITY CURTAINS (ALSO KNOWN AS TURBIDITY BARRIERS OR SILT CURTAINS) CREATE A BARRIER TO PREVENT TURBID WATER FROM ENTERING CLEAR WATER. FLOATING TURBIDITY CURTAINS SHOULD BE USED TO ISOLATE ACTIVE CONSTRUCTION AREAS WITHIN OR ADJACENT TO A BODY OF WATER TO MINIMIZE THE MIGRATION OF SILT LADEEN WATER OUT OF THE CONSTRUCTION ZONE.
- B) TURBIDITY CURTAINS SHALL NOT BE INSTALLED PERPENDICULAR ACROSS THE MAIN FLOW OF A SIGNIFICANT BODY OF MOVING WATER.
- C) FLOATING TURBIDITY CURTAINS SHALL NOT BE USED WHERE THE ANTICIPATED FLOW VELOCITIES WILL EXCEED 5 FT/SEC.
- D) TURBIDITY CURTAINS SHALL BE ANCHORED TO PREVENT DRIFT SHOREWARD OR DOWNSTREAM. ANCHORAGE SHALL BE INSTALLED ON BOTH SHORE AND STREAM SIDE. CURTAINS SHALL BE INSTALLED AS CLOSE TO PROJECT SITE AS POSSIBLE. BARRIERS SHOULD BE A BRIGHT COLOR (YELLOW OR "INTERNATIONAL" ORANGE ARE RECOMMENDED) THAT WILL ATTRACT THE ATTENTION OF NEARBY BOATERS.
- E) SHORE ANCHORS SHALL CONSIST OF A POST WITH DEADMAN OR APPROVED EQUAL. STREAM ANCHORS SHALL BE OF SUFFICIENT SIZE TO STABILIZE THE BARRIER WITH NUMBER AND SPACING DEPENDENT ON WATERWAY VELOCITIES AND MANUFACTURER'S RECOMMENDATIONS.
- F) IN SHALLOW WATER (2 FEET OF DEPTH OR LESS) A TURBIDITY CURTAIN MAY BE INSTALLED ON STAKES DRIVEN INTO THE BED OF THE WATER BODY.
- G) FABRIC SECTIONS SHALL BE CONNECTED END TO END WITH MINIMUM 1/2" DIAMETER POLYPROPYLENE ROPE. FABRIC SHALL BE SEAMED TOGETHER IN A MANNER THAT RETAINS THE OVERALL TENSILE STRENGTH.
- H) DESIGN OF CURTAIN AND ANCHORAGE SHALL BE IN ACCORDANCE WITH MANUFACTURER'S RECOMMENDATIONS. FILTER CLOTH SKIRT SHOULD BE ABLE TO WITHSTAND THE FORCES IMPOSED ON IT DUE TO THE EXPECTED WIND VELOCITY OR STREAM VELOCITY. FABRIC SHALL BE MADE OF A NON-DETERIORATING MATERIAL, SUCH AS PLASTIC OR NYLON, WHICH WILL ALLOW WATER TO PASS THROUGH WHILE STILL RETAINING SEDIMENT.
- I) THE TURBIDITY CURTAIN AND ADJACENT WORK AREAS SHALL NOT BE DISTURBED 12 HOURS PRIOR TO REMOVAL FROM WATER BODY. MAINTENANCE SHALL BE PERFORMED AS NEEDED. CONTRACTOR SHALL REMOVE THE CURTAIN AT COMPLETION OF WORK IN A MANNER THAT WILL PREVENT SILTATION OF THE WATERWAY. DURING REMOVAL, EXTREME CARE SHOULD BE TAKEN NOT TO DISTURB ANY SEDIMENT DEPOSITS.
- J) MAINTAIN 12" MINIMUM GAP BETWEEN SKIRT BOTTOM AND CHANNEL BOTTOM TO PREVENT ACCUMULATED SEDIMENT FROM PULLING TOP OF CURTAIN BELOW WATER SURFACE.
- K) IN WIND OR WAVE ACTION SITUATIONS, THE MAXIMUM DEPTH OF THE CURTAIN SHALL BE 12 FEET.
- L) CONCENTRATED FLOWS SHALL NOT DISCHARGE BEYOND FLOATING TURBIDITY CURTAIN. CURTAINS ARE NOT TO BE INSTALLED ACROSS FLOWING BODY OF WATER.
- M) WHEN INSTALLED IN A NAVIGABLE WATERWAY, BUOYS SHOULD BE LIT ACCORDING TO REGULATORY AGENCY STANDARDS.
- N) WHEN ESTIMATING THE LENGTH OF TURBIDITY CURTAIN, ALLOW 10 TO 20 PERCENT VARIANCE IN STRAIGHT LINE MEASUREMENT.
- O) PAYMENT FOR FLOATING TURBIDITY CURTAIN SHALL INCLUDE ALL MATERIAL AND LABOR NECESSARY FOR CONSTRUCTION, MAINTENANCE, AND REMOVAL OF TURBIDITY CURTAINS.
- P) ONLY FLOATING TURBIDITY CURTAINS LISTED ON THE APPROVED PRODUCTS LIST MAY BE USED.

DATE		BY		MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
DATE		BY		FLOATING TURBIDITY CURTAIN	
DATE		BY		WORKING NUMBER	
DATE		BY		ECD-19	
DATE		BY		SHEET NUMBER	
DATE		BY		FILENAME: EROSION CONTROL.ECD-19.DGN	
DATE		BY		SHEET NUMBER	

Rock Filter Dam (RD)



Practice Description

A rock filter dam is a stone embankment designed to help capture sediment in natural or constructed drainageways on construction sites. This practice can also be used as a forebay to a sediment basin to help capture coarser particles of sediment. It is usually located so that it intercepts runoff (primarily from disturbed areas), is accessible for periodic sediment removal, and does not interfere with construction activities.

Planning Considerations

Rock filter dams are used across drainageways to help remove coarser sediment particles and reduce off-site sediment delivery. Since rock filter dams are installed in flowing water, all local, state and federal laws and regulations must be followed during the design and construction process.

Dams should be designed so that impounded water behind the structures will not encroach on adjoining property owners or on other sediment- and erosion-control measures that outlet into the impoundment area.

Dams should be located so that the basin intercepts runoff (primarily from disturbed areas) and has adequate storage, and so that the basin can be accessed for sediment removal. Dams should also be located, as much as possible, in areas that do not interfere with construction activities.

Rock filter dams are not permanent structures. The design life of the structure is 3 years or less.

Design Criteria and Construction

Drainage Area

The drainage area above the dam should not exceed 10 acres.

Dam Height

The height of dam will be limited by the channel bank height or 8 feet, whichever is less. The dam height should also not exceed the elevation of the upstream property line. Water will bypass over the top of the dam, and the back slope of the rock dam should be designed to be stable.

Spillway Capacity

The top of the dam should be designed to handle the peak runoff from a 10-year, 24-hour design storm with a maximum flow depth of 1 foot and freeboard of 1 foot. Therefore, the center portion of the dam should be at least 2 feet lower than the outer edges at the abutment (see Figure RD-1).

Dam Top Width

The minimum top width should be 6 feet (see Figure RD-2).

Dam Side Slopes

Side slopes should be 3:1 (horizontal: vertical) or flatter on the back slope and 2.5:1 (horizontal: vertical) or flatter on the front slope.

Outlet Protection

The downstream toe of the dam should be protected from erosion by placing a riprap apron at the toe. The apron should be placed on a zero grade with a riprap thickness of 1.5 feet. The apron should have a length equal to the height of the dam as a minimum (and longer, if needed) to protect the toe of the dam.

Location

The dam should be located as close to the source of sediment as possible so that it will not cause water to back up onto adjoining property.

Basin Requirements

The basin behind the dam should provide a surface area that maximizes the sediment trapping efficiency. The basin should have a sediment storage capacity of 67 cubic yards per acre of drainage area.

Riprap Requirements

Stone for riprap should consist of field stone or rough, unhewn quarry stone of approximately rectangular shape. The stone should be hard and angular and of such quality that it will not disintegrate on exposure to water or weathering, and it should be suitable in all other respects for the purpose intended. The specific gravity of the individual stones should be at least 2.5.

The minimum median stone size should be 9". The gradation of rock to be used should be specified using Tables RD-1 and RD-2. Table RD-1 is used to determine the weight of the median stone size (d_{50}). Using this median weight, a gradation can be selected from Table RD-2, which shows the commercially available riprap gradations as classified by the Mississippi Department of Transportation.

The dam should be faced with 1 foot of smaller stone ($\frac{1}{2}$ " to $\frac{3}{4}$ " gravel) on the upstream side to increase efficiency for trapping coarser particles.

Table RD-1 Size of Riprap Stones

Weight	Mean Spherical Diameter (ft)	Rectangular Shape	
		Length	Width, Height (ft)
50	0.8	1.4	0.5
100	1.1	1.75	0.6
150	1.3	2.0	0.67
300	1.6	2.6	0.9
500	1.9	3.0	1.0
1000	2.2	3.7	1.25
1500	2.6	4.7	1.5
2000	2.75	5.4	1.8
4000	3.6	6.0	2.0
6000	4.0	6.9	2.3
8000	4.5	7.6	2.5
20000	6.1	10.0	3.3

Table RD-2 Graded Riprap

Class	Weight (lbs.)					
	d ₁₀	d ₁₅	d ₂₅	d ₅₀	d ₇₅	d ₉₀
1	10	-	-	50	-	100
2	10	-	-	80	-	200
3	-	25	-	200	-	500
4	-	-	50	500	1000	-
5	-	-	200	1000	-	2000

Geotextiles

Geotextiles should be used as a separator between the graded stone, the soil base, and the abutments. Class I geotextile, as specified in Table RD-3 below, should be used. Geotextile should be placed immediately adjacent to the subgrade with no voids between the fabric and the subgrade.

Table RD-3 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ¹
Tensile strength (lb) ²	ASTMD4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ²	ASTMD4632	≥50	≥50	≥50	≥50
Puncture (pounds)	ASTMD4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD4751	As specified max. no. 40 ³			
Permittivity sec ⁻¹	ASTMD4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

¹ Heat-bonded or resin-bonded geotextile may be used for Classes III and IV. They are particularly well suited to Class IV. Needle-punched geotextile are required for all other classes.

² Minimum average roll value (weakest principal direction).

³ U.S. standard sieve size.




Figure RD-1 Typical Front View of Rock Filter Dam




Figure RD-2 Typical Section of Rock Filter Dam

Construction

Prior to start of construction, rock filter dams should be designed by a qualified design professional. The rock filter dam plan should include details on dam height, dam top width, dam side slopes, and rock size(s). Plans and specifications should be referred to by field personnel throughout the construction process.

Site Preparation

Determine exact location of underground utilities, and avoid construction over and under utilities.

Clear and grub the area under the dam, removing and properly disposing of all root material, brush, and other debris.

Divert runoff from undisturbed areas away from the rock dam and basin area. Smooth the dam foundation.

If specified, cover the foundation with geotextile fabric, making sure the upstream strips overlap the downstream strips at least 1 foot and the upslope end is embedded into the foundation at least 1 foot.

Rock Placement

Construct the dam by placing well-graded, hard, angular, durable rock of the specified size over the foundation to planned dimensions and securely embed into both channel banks.

Once the dam is in place, clear the sediment basin area and dispose of the cleared material.

Set a marker stake to indicate the clean-out elevation (i.e., point at which the basin is 50% full of sediment).

Erosion and Sediment Control

Stabilize all disturbed areas with either *Temporary* or *Permanent Seeding*.

Construction Verification

Check materials and finished elevations of the rock filter dam for compliance with specifications.

Common Problems

Consult with a qualified design professional if any of the following occurs:

Variations in topography on site indicate rock filter dam will not function as intended; changes in plan may be needed.

Materials specified in the plan are not available.

Maintenance

Inspect the rock dam and basin after each storm event.

Check the dam for rock displacement and the abutments for erosion and repair immediately when repair is needed. If rock size appears too small or embankment slope is too steep, replace stone with larger size or reduce slope.

Check the drainageway at toe of dam for erosion. If erosion is occurring, a repair involving geotextile fabric (including another toe-in) and additional rock are probably needed to establish a stable outlet.

Remove sediment from the pond reservoir area when it accumulates to $\frac{1}{2}$ the design volume. If the basin does not drain between storms because the filter stone (small gravel) on the upstream face has become clogged, the clogged filter stone should be replaced with clean stone.

Once the construction site is permanently stabilized, remove the structure and any unstable sediment. Smooth the basin site to blend with the surrounding area and stabilize. Sediment should be placed in designated disposal areas and stabilized.

References

BMPs from Volume 1

Chapter 4

Mulching (MU)	4-48
Permanent Seeding (PS)	4-53
Temporary Seeding (TS)	4-103

Sediment Barrier (SB)

SILT FENCE 
 STRAW BALE BARRIER 



Practice Description

Silt fencing is a temporary sediment barrier used across a landscape to reduce the quantity of sediment that is moving farther downslope. Commonly used barriers include silt fence (a geotextile fabric that is trenched into the ground and attached to supporting posts) or hay bales trenched into the ground. Other barrier materials include sand bags, brush piles, and various man-made materials and devices that can be used in a similar manner as silt fence and hay bales.

This practice applies where sheet and rill erosion occurs on small disturbed areas. Barriers intercept runoff from upslope to form ponds that temporarily store runoff and allow sediment to settle out of the water and stay on the construction site.

Planning Considerations

Sediment barriers may be used on developing sites. They should be installed on the contour so that flow will not concentrate and cause bypassing by runoff going around the end of the barrier or overtopping because of lack of storage capacity.

The most commonly used sediment barriers are silt fences, manufactured sediment logs (several names other than “logs” are used), and hay bales. Silt fences and manufactured sediment logs are preferable to hay bales because they are more likely to be installed correctly. The design and installation of a hay bale sediment barrier is the same as for *Straw Bale Sediment Traps*. Manufactured sediment logs should be installed according to manufacturer’s recommendations.

The silt fence is the only sediment barrier covered in this manual.

The success of silt fences depends on a proper installation that causes the fence to develop maximum efficiency of sediment trapping. Silt fences should be carefully installed to meet the intended purpose.

A silt fence is specifically designed to retain sediment transported by sheet flow from disturbed areas, while allowing water to pass through the fence. Silt fences should be installed to be stable under the flows expected from the site. Silt fences should not be installed across streams, ditches, waterways, or other concentrated flow areas.

Silt fences are composed of woven geotextile supported between steel or wooden posts. Silt fences are commercially available with geotextile attached to the post, and can be rolled out and installed by driving the post into the ground. This type of silt fence is simple to install, but more expensive than some other installations. Silt fences must be trenched in at the bottom to prevent runoff from undermining the fence and developing rills under the fence. Locations with high runoff flows or velocities should use wire reinforcement.

Design Criteria

Silt fence installations are normally limited to situations in which only sheet- or overland-flow is expected because they normally cannot pass the volumes of water generated by channel flows. Silt fences are normally constructed of synthetic fabric (woven geotextile), and the life is expected to be the duration of most construction projects. Silt fence fabric should conform to the requirements of Table SB-1.

The drainage area behind the silt fence should not exceed $\frac{1}{4}$ acre per 100 linear feet of silt fence for non-reinforced fence and $\frac{1}{2}$ acre per 100 linear feet of wire-reinforced fence. When all runoff from the drainage area is to be stored behind the fence (i.e. no stormwater disposal system is in place), the maximum slope length behind the fence should not exceed the value shown in Table SB-2.

Type A Silt Fence

The Type A fence is 36" wide with wire reinforcement and is used on sites needing the highest degree of protection by a silt fence. The wire reinforcement is necessary because the Type A silt fence is used for the highest flow situations and has almost 3 times the flow rate as the Type B silt fence. Type A silt fence should be used where runoff flows or velocities are particularly high or where slopes exceed a vertical height of 10 feet.

Provide a riprap splash pad or other outlet protection device for any point where flow may overtop the sediment fence. Ensure that the maximum height of the fence at a protected, reinforced outlet does not exceed 1 foot and that support post spacing does not exceed 4 feet.

This silt fence should be installed as shown in Figure SB-1. Materials for posts and fasteners are shown in Tables SB-3 and SB-4. Details for overlap of the silt fence and fastener placement are shown in Figure SB-4.

Table SB-1 Specifications for Silt Fence

Specifications	Type A	Type B	Type C
Tensile Strength (Lbs. Min.)¹ (ASTM D-4632)	Warp – 260 Fill – 100	Warp – 120 Fill – 100	Warp – 120 Fill – 100
Elongation (% Max.) (ASTM D-4632)	40	40	40
AOS (Apparent Opening Size) (Max. Sieve Size) (ASTM D-4751)	No. 30	No. 30	No. 30
Flow Rate (Gal/Min/Sq. Ft.) (GDT-87)	70	25	25
Ultraviolet Stability² (ASTM D-4632 after 300 hours weathering in accordance with ASTM D-4355)	80	80	80
Bursting Strength (PSI Min.) (ASTM D-3786 Diaphragm Bursting Strength Tester)	175	175	175
Minimum Fabric Width (Inches)	36	36	22

¹ Minimum roll average of five specimens.

² Percent of required initial minimum tensile strength.

Table SB-2 Slope Limitations for Silt Fence

Land Slope (Percent)	Maximum Slope Length Above Fence (Feet)
<2	100
2 to 5	75
5 to 10	50
10 to 20*	25
>20	15

*In areas where the slope is greater than 10%, a flat area length of 10 feet between the toe of the slope to the fence should be provided.

Type B Silt Fence

This 36" wide filter fabric should be used on developments where the life of the project is greater than or equal to 6 months.

This silt fence should be installed as shown in Figure SB-2. Materials for posts and fasteners are shown in Tables SB-3 and SB-4. Details for overlap of the silt fence and fastener placement are shown in Figure SB-4.

Type C Silt Fence

Though only 22" wide, this filter fabric allows the same flow rate as Type B silt fence. Type C silt fence should be limited to use on relatively minor projects, such as residential

home sites or small commercial developments where permanent stabilization will be achieved in less than 6 months.

This silt fence should be installed as shown in Figure SB-3. Materials for posts and fasteners are shown in Tables SB-3 and SB-4. Details for overlap of the silt fence and fastener placement are shown in Figure SB-4.

Table SB-3 Post Size for Silt Fence

	Minimum Length	Type of Post	Size of Post
Type A	4'	Steel	1.3 lb./ft. min.
Type B	4'	Soft Wood	3" diameter or 2 X 4
		Oak	1.5" X 1.5"
Type C	3'	Steel	1.3 lb./ft. min.
		Soft Wood	2" diameter or 2 X 2
		Oak	1" X 1"
		Steel	0.75 lb./ft. min.

Table SB-4 Wood Post Fasteners for Silt Fence

	Gauge	Crown	Legs	Staples/Post
Wire Staples	17 min.	¾" wide	½" long	5 min.
	Gauge	Length	Button Heads	Nail/Post
Nails	14 min.	1"	¾" long	4 min.




Figure SB-1 Silt Fence-Type A

- (1) For fabric material requirements see Table SB-1
- (2) For post material requirements see Tables SB-3 and SB-4




Figure SB-2 Silt Fence - Type B

- (1) For fabric material requirements see Table SB-1
- (2) For post material requirements see Tables SB-3 and SB-4




Figure SB-3 Silt Fence – Type C

- (1) For fabric material requirements see Table SB-1
- (2) For post material requirements see Tables SB-3 and SB-4




Figure SB-4 Silt Fence Installation Details

Construction

Prior to start of construction, sediment barriers should be designed by a qualified professional. Plans and specifications should be referred to by field personnel throughout the construction process.

Note: Silt fence is the only barrier installation being covered in this handbook.

Site Preparation

Determine exact location of underground utilities so that locations for digging or placement of stakes can be selected where utilities will not be damaged.

Smooth the construction zone to provide a broad, nearly level area for the fence. The area should be wide enough throughout the length of the fence to provide storage of runoff and sediment behind the fence.

Silt Fence Installation

Silt fence should be installed on the contour, so that runoff can be intercepted as sheet flow; ends should be flared uphill to provide temporary storage of water. Silt fence should be placed so that runoff from disturbed areas must pass through the fence. Silt fence should not be placed across concentrated flow areas such as channels or waterways. When placed near the toe of a slope, the fence should be installed far enough from the slope toe to provide a broad, flat area for adequate storage capacity for sediment. Dig a trench at least 6" deep along the fence alignment as shown in Figures SB-1 and SB-2 for Types A & B fences. Type C fences require only a 4" deep trench as shown in Figure SB-3. **Please note that installation with a silt fence installation machine may permit different depths if performance is equal.**

Drive posts at least 18" into the ground on the downslope side of the trench. Space posts a maximum of 10 feet if fence is supported by woven wire, or 6 feet if high-strength fabric and no support fence is used.

Fasten support wire fence to upslope side of posts, extending 6" into the trench, as shown in the appropriate figure for the type fence (see Figure SB-1, SB-2 or SB-3).

Attach a continuous length of fabric to the upslope side of fence posts. Minimize the number of joints and, when necessary to join



rolls, they should be joined by rolling the ends together using the "roll joint" method illustrated in Figure SB-4. Avoid joints at low points in the fence line.

For Types A and B silt fence, place the bottom 12" of fabric in the 6" deep (minimum) trench, lapping toward the upslope side. For Type C fabric, place the bottom 6" in the 4" deep (minimum) trench lapping toward the upslope side.

Backfill the trench with compacted earth or gravel as shown in Figures SB-1 – SB-3.

Provide good access in areas of heavy sedimentation for cleanout and maintenance.

Erosion Control

Stabilize disturbed areas in accordance with the vegetation plan. If no vegetation plan exists, consider planting and mulching as a part of barrier installation, and select planting information from the appropriate planting practice (*Permanent Seeding* or *Temporary Seeding*). Select mulching information from the *Mulching Practice*.

Construction Verification

Check finished grades and dimensions of the sediment fence. Check materials for compliance with specifications.

Common Problems

Consult with a qualified design professional if any of the following occurs:

Variations in topography on site indicate sediment fence will not function as intended, or alignment is not on contour, or fence crosses concentrated flow areas; changes in plan may be needed.

Design specifications for filter fabric, support posts, support fence, gravel, or riprap cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Drainage area appears to exceed ¼ acre for 100 feet of non-reinforced silt fence and ½ acre for 100 feet for reinforced fence. Additional sediment-control BMPs may be required.

Maintenance

Inspect sediment fences at least once a week and after each significant rain event.

Make required repairs immediately.

Should the fabric of silt fence collapse, tear, decompose, or become ineffective, replace it promptly.

Remove sediment deposits when they reach a depth of 15" or ½ the height of the fence as installed, to provide adequate storage volume for the next rain event and to reduce pressure on the fence.

After the contributing drainage area has been properly stabilized, remove all barrier materials and unstable sediment deposits, bring the area to grade, and stabilize it with vegetation.

References

BMPs from Volume I

Chapter 4

Mulching (MU)

4-48

MDOT Drawing ECD-2

Details of Sediment Barrier Applications

4-295

MDOT Drawing ECD-3

Details of Silt Fence Installation


4-296

MDOT Drawing SSF-1


Super Silt Fence

4-297


STATE	PROJECT NO.
MSS.	



SEDIMENT BARRIER AT CROSS DRAIN




FRONT ELEVATION




SIDE ELEVATION

TEMPORARY BRUSH BARRIER

- NOTES:
1. BRUSH BARRIER MAY BE USED WHERE NATURAL GROUND IS LEVEL OR SLOPING AWAY FROM PROJECT.
 2. PLACE BRUSH LOG AND TREE LAPS APPROXIMATELY PARALLEL TO TOE OF FILL SLOPE WITH SOME OF THE HEAVIER MATERIALS BEING PLACED ON TOP TO PROPERLY SECURE THE BARRIER AS DETAILED AT LOCATIONS SHOWN ON PLANS OR AS DIRECTED OR PERMITTED BY THE ENGINEER.
 3. TO ALLOW WATER TO SEEP THROUGH BRUSH BARRIER, INTERMINGLE THE BRUSH LOG AND TREE LAPS SO AS NOT TO FORM A SOLID DAM.
 4. THE BRUSH BARRIER MAY BE CHOKED WITH FILTER FABRIC.
 5. TEMPORARY BRUSH BARRIER WILL NOT BE MEASURED FOR SEPARATE PAYMENT.




"J-HOOK" SILT FENCE APPLICATION



"SMILE-CONFIGURATION" SILT FENCE APPLICATION


NOTE:
1. ANCHOR AND INSTALL SILT FENCE PER DETAILS SHOWN ON ECD-3




SILT FENCE SECTION AT TOE OF FILL

MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
DETAILS OF SEDIMENT BARRIER APPLICATIONS	
WORKING NUMBER	ECD-2
SHEET NUMBER	
FILENAME: EROSION CONTROL/ECD-2.DGN	
DESIGNER	CHECKED
DATE	

STATE	PROJECT NO.
MISS.	



ELEVATION VIEW




METHOD I

METHOD II
MECHANICAL INSTALLATION

SIDE VIEW

NOTES:

1. SILT FENCES SHALL BE USED IN AREAS WHERE FLOW IS NOT SEVERE.
2. SILT FENCES ARE TEMPORARY SEDIMENT CONTROL ITEMS THAT SHALL BE ERECTED OPPOSITE ERODIBLE AREAS SUCH AS NEWLY GRADED FILL SLOPES AND ADJACENT TO STREAMS AND CHANNELS.
3. SILT FENCE SHOULD BE PLACED WELL INSIDE RIGHT-OF-WAY AND ALONG EDGE OF CLEARING LIMITS. THIS WILL ALLOW ROOM FOR A BACK-UP FENCE IF FIRST FENCE BECOMES FULL.
4. WHEREVER POSSIBLE SILT FENCE SHALL BE CONSTRUCTED ACROSS A LEVEL AREA IN THE SHAPE OF A SMILE. THIS AID IN PONDING OF RUNOFF AND FACILITATES SEDIMENTATION.
5. THE CONTRACTOR MAY ELECT TO USE EITHER METHOD I OR METHOD II. COST TO BE LINEAR FEET OF SILT FENCE.
6. METHOD I INSTALLATION SHALL BE ACCOMPLISHED USING AN IMPLEMENT THAT IS MANUFACTURED FOR THE APPLICATION AND PROVIDES A CONFIGURATION MEETING THE REQUIREMENTS OF THE DETAIL.
7. WIRE SHALL BE MINIMUM OF 32" IN WIDTH AND SHALL HAVE A MINIMUM OF 6 LINE WIRES WITH 12" STAY SPACING.
8. GEOTEXTILE FABRIC MEETING THE TYPE I MATERIAL REQUIREMENTS AND INSTALLED ACCORDING TO SPECIFICATION MAY BE USED WITHOUT WIRE FENCE.



PLAN VIEW
REQUIRED LAPPING

DATE	BY	MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
		DETAILS OF SILT FENCE INSTALLATION	
DATE	BY	FILENAME: EROSION_CONTROL/ECD-3.DGN	WORKING NUMBER ECD-3
DATE	BY	DESIGN TEAM	CHECKED DATE SHEET NUMBER

Sediment Basin (SBN)



Practice Description

A sediment basin is an earthen embankment suitably located to capture runoff, with an emergency spillway lined to prevent spillway erosion, interior porous baffles to reduce turbulence and evenly distribute flows, and equipped with a floating skimmer for dewatering. Sediment basins are designed to provide an area for runoff to pool and settle out a portion of the sediment. Old technology utilized a perforated riser for dewatering, which allowed water to leave the basin from all depths. One way to improve the sediment capture rate is to have an outlet that dewateres the basin from the top of the water column where the water is cleanest. A skimmer is probably the most common method to dewater a sediment basin from the surface. The basic concept is that the skimmer does not dewater the basin as fast as runoff enters it but, instead, allows the basin to fill and then slowly drain over multiple days. This process has two effects. First, the sediment in the runoff has more time to settle out prior to discharge. Second, a pool of water forms early in a storm event, which increases sedimentation rates in the basin and reduces turbidity. Many of the storms will produce more volume than the typical sediment basin capacity and flow rates in excess of the skimmer capability, resulting in flow over the emergency spillway. This water is also coming from the top of the water column and has thereby been “treated” to remove sediment as much as possible (adapted from *Soil Facts: Dewatering Sediment Basins Using Surface Outlets*, N. C. State University, Soil Science Department).

Planning Considerations

Sediment basins are needed where drainage areas are too large for other sediment-control practices.

Select locations for basins during initial site evaluation. Locate basin so that sudden failure should not cause loss of life or serious property damage. Install sediment basins before any site grading takes place within the drainage area.

Select sediment basin sites to capture sediment from all areas that are not treated adequately by other sediment-control measures. Always consider access for cleanout and disposal of the trapped sediment. Locations where a pond can be formed by constructing a low dam across a natural swale are generally preferred to sites that require excavation. Where practical, divert sediment-free runoff away from the basin.

Because the emergency spillway is actually used relatively frequently, it is generally stabilized using geotextile and riprap that can withstand the expected flows without erosive velocities. The spillway should be placed as far from the inlet of the basin as possible to maximize sedimentation before discharge. The spillway should be located in natural ground (not over the embankment) to the greatest extent possible.

As discussed in the *Chemical Stabilization Practice*, the proper introduction of polyacrylamides (PAM) into the turbid runoff water at the inlet of the basin and/or at the first baffle should be considered to help polish the discharge from the basin for decreasing the turbidity. See the *Flocculants and Polymers Practice*.

Where heavy loads of coarse sediment are expected, a forebay or sump area prior to the basin should be considered for capture of heavier particles.

Baffles

Porous baffles effectively spread the flow across the entire width of a sediment basin, or trap and cause increased deposition within the basin. Water flows through the baffle material, but is slowed sufficiently to back up the flow, causing it to spread across the entire width of the baffle (Figure SBN-1). Spreading the flow in this manner utilizes the full cross section of the basin and reduces turbulence, which shortens the time required for sediment to be deposited.

The installation of baffles should be similar to a silt fence (Figure SBN-2) utilizing posts and wire backing. The most proven material for a baffle is 700-900 g/m² coir erosion blanket (Figure SBN-3). Other materials proven by research to be equivalent in this application may be used. A support wire or rope across the top will help prevent excessive sagging if the material is attached to it with appropriate ties. Another option is to use a sawhorse type of support with the legs stabilized with rebar inserted into the basin floor. These structures work well and can be prefabricated off-site and quickly installed.

Baffles need to be installed correctly to fully provide their benefits. Refer to Figure SBN-2 and the following key points:

- The baffle material needs to be secured at the bottom and sides by staking, trenching, or securing horizontally to the bottom. Flow should not be allowed under the baffle.

- Most of the sediment will accumulate in the first bay, so this should be readily accessible for maintenance.




Figure SBN-1 Porous baffle in a sediment basin
(from North Carolina Erosion and Sediment Control Planning and Design Manual)




Figure SBN-2 Cross section of a porous baffle in a sediment basin
(Note: there is no weir because the water flows through the baffle material)
(from North Carolina Erosion and Sediment Control Planning and Design Manual)



Figure SBN-3 Example of porous baffle made of 700 g/m² coir erosion blanket as viewed from the inlet

Skimmer Option

A skimmer is a sediment basin dewatering-control device that withdraws water from the basin's water surface, thus removing the highest quality water for delivery to the uncontrolled environment. A skimmer is shown in Figure SBN-4. By properly sizing the skimmer's control orifice, the skimmer can be made to dewater a design hydrologic event in a prescribed period.

The costs of using a skimmer system are similar, or occasionally less, than a conventional rock outlet or perforated riser. However, the basin is more efficient in removing sediment when a skimmer is used. Another advantage of the skimmer is that it can be reused on future projects. Skimmers are generally maintenance free, but may require occasional maintenance to remove debris from the orifice.

A skimmer must dewater the basin from the top of the water surface. The rate of dewatering must be controlled. A dewatering time of 48 to 120 hours (2 to 5 days) is required for the basin to function properly.

Perforated Riser

The perforated risers are a common dewatering device in basins that will be retained for stormwater detention post-construction. These devices dewater the basin quickly by drawing water from the entire water column.

Flashboard Riser Option

A flashboard riser forces the basin to fill to a given level before the water tops the riser and is then drained. As with the skimmer option, removing water from the top improves sediment capture, as the top of the water column is often where the least amount of sediment resides. The benefit of the flashboard riser is that water level can be controlled by removed (or adding) “stop logs” to adjust the water level.



Flashboard Riser (Source: NRCS)

Solid Riser Option

A solid riser option is another that is commonly used when the sediment basin will be used for post-construction stormwater control. A solid riser manages stormwater by forcing water to drain over the top of the riser pipe. The disadvantage to the solid riser option is that the only way to fully dewater the basin (for sediment removal) is through a pump system.

Design Criteria and Construction

Summary:	Temporary Sediment Trap
Emergency Spillway:	Trapezoidal spillway with non-erosive lining. 10-year, 24-hour rainfall event
Maximum Drainage Area:	10 acres
Minimum Volume:	3,600 cubic feet per acre of drainage area
Minimum L/W Ratio:	2:1
Minimum Depth:	2 feet
Dewatering Mechanism:	Skimmer(s) attached at bottom of barrel pipe
Dewatering Time:	2 – 5 days
Baffles Required:	3

Compliance with Laws and Regulations

Design and construction should comply with state and local laws, ordinances, rules, and regulations.

Design Basin Life

Structures intended for more than 3 years of use should be designed as permanent structures. Procedures outlined in this section do not apply to permanent structures. See *Volume 2: Stormwater Runoff Management* for permanent stormwater control methods.

Dam Height

Maximum height should be 10 feet, measured from the designed (settled) top elevation of the dam to the lowest point of the original ground surface.

Basin Locations

Select areas that

- Are not intermittent or perennial streams;
- Allow a maximum amount of construction runoff to be brought into the structure;
- Provide capacity for storage of sediment from as much of the planned disturbed area as practical;
- Exclude runoff from undisturbed areas where practical;
- Provide access for sediment removal throughout the life of the project; and
- Interfere minimally with construction activities.

Basin Shape

Ensure that the flow-length to basin-width ratio is 2:1 or larger to improve trapping efficiency. Length is measured at the elevation associated with the minimum storage volume. Generally, the bottom of the basin should be level to ensure that the baffles function properly. The area between the inlet and first baffle (forebay) can be designed with reverse grade to improve the trapping efficiency.

Storage Volume

Ensure that the sediment-storage volume of the basin is at least 3,600 cubic feet per acre for the area draining into the basin. Volume is measured below the emergency spillway crest. Remove sediment from the basin when approximately one-half of the storage volume has been filled.

Baffles

Space the baffles to create equal zones of volume within the basin.

The top of the baffle should be the same elevation as the maximum water depth flowing through the emergency spillway.

Baffles should be designed to go up the sides of the basin banks so water does not flow around the baffles. Most of the sediment will be captured in the inlet zone. Smaller particle size sediments are captured in the latter cells.

The design life of the fabric can be up to 3 years, but it may need to be replaced more often if damaged or clogged.

Spillway Capacity

The emergency spillway system must carry the peak runoff from the 10-year 24-hour storm with a minimum 1 foot of freeboard (distance between the surface of the water with the spillway flowing full and the top of the embankment). Base runoff computations on the most severe soil cover conditions expected in the drainage area during the effective life of the structure.

Sediment Cleanout Elevation

Determine the elevation at which the invert of the basin would be half-full. This elevation should also be marked in the field with a permanent stake set at this ground elevation (not the top of the stake).

Basin Dewatering

Basin dewatering discussion will be limited to the skimmer options. Additional dewatering options are discussed in “Planning Considerations” (earlier in this practice). The basin should be provided with a surface outlet. A floating skimmer should be attached to a Schedule 40 PVC barrel pipe of the same diameter as the skimmer arm. The skimmer apparatus will control the rate of dewatering. The skimmer should be sized to dewater the basin in 48 to 120 hours (2–5 days). The barrel pipe should be located under the embankment with at least one anti-seep collar at the center of the embankment projecting a minimum of 1.5 ft in all directions from the pipe. The barrel-pipe outlet must be stable and not cause erosion.

Skimmer Orifice Diameter

Faircloth Skimmer Selection Procedure

The skimmer performance charts (Table SBN-1) are recommended for use in selecting Faircloth Skimmers for use in dewatering sediment control basins. Always verify performance with the manufacturer’s information.

Required input data:

Basin volume = _____ ft³

Desired dewatering time = _____ days

Procedure:

1. First use the basin volume (ft³) and the desired dewatering time (days) and determine the required skimmer outflow rate in cubic feet per day (ft³/d) from the following equation

$$Q = \frac{V}{t_d}$$

2. Scan the skimmer performance charts (Table SBN-1) and select the (a) skimmer size and (b) the skimmer orifice diameter (in inches) if desired.

Table SBN-1 Faircloth Skimmer Selection Charts

1.5-inch skimmer (H = 0.125 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	2,079
1.0	809
0.5	193

2-inch skimmer (H = 0.167 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	5,429
1.0	924
0.5	231

2.5-inch skimmer (H = 0.167 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	9,548
1.0	1,039
0.5	250

3-inch skimmer (H = 0.25 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	10,588
1.5	2,541
1.0	1,136
0.5	289

4-inch skimmer (H = 0.333 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	16,863
2.5	8,181
2.0	5,236
1.5	2,945
1.0	1,309
0.5	327

5-inch skimmer (H = 0.333 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	26,276
3.5	16,035
3.0	11,781
2.5	8,181
2.0	5,236
1.5	3,715
1.0	1,309
0.5	327

6-inch skimmer (H = 0.417 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	44,371
4.5	29,645
4.0	23,427
3.5	17,941
3.0	13,186
2.5	9,144
2.0	5,852
1.5	3,292
1.0	1,463
0.5	366

8-inch skimmer (H = 0.5 ft)

Orifice (in.)	Outflow Rate (ft ³ /d)
None	127,416
5.5	48,510
5.0	40,098
4.5	32,475
4.0	25,660
3.5	19,654
3.0	14,438
2.5	10,029
2.0	6,410
1.5	3,619
1.0	1,598
0.5	404

Example: Select a skimmer that will dewater a 20,000-ft³ sediment basin in 3 days.

Solution: First, compute the required outflow rate as

$$Q = \frac{V}{t_d} = \frac{20000 \text{ ft}^3}{3d} = 6670 \text{ ft}^3 / d$$

Now, go the Selection Charts (Table SBN-1) and select an appropriate skimmer. If the 2-inch skimmer with no orifice is chosen, the outflow rate will be 5,429 ft³/d, which will require about 3.5 days to dewater the basin. An alternative might be to use a 4-inch skimmer with a 2.5-inch-diameter orifice, which will have an outflow rate of 8,181 ft³/d and dewater the basin in about 2.5 days.

Example: A More Precise Alternative: Each skimmer comes with a plastic plug that

can be drilled forming a hole that will limit the skimmer's outflow to any desired rate. Thus, for a specific skimmer, the orifice that will dewater a basin in a more precisely chosen time can be determined. The flow through an orifice can be computed as

$$Q = CA\sqrt{2gH}$$

where C is the orifice coefficient (usually taken to be 0.6), A is the orifice cross-sectional area in ft², g is the acceleration of gravity (32.2 ft/sec²), and H is the driving head on the orifice center in feet. The orifice equation can be simplified to yield the orifice flow in gpm using the diameter, D (in inches), and the head, in feet, as

$$Q = 12D^2\sqrt{H}$$

Or, the orifice flow in ft³/d using the diameter, D (in inches), and the head, in feet, as

$$Q = 2310D^2\sqrt{H}$$

If we solve the orifice equation for the orifice diameter using the desired outflow rate (6670 ft³/d) and the head driving water through the skimmer (0.333 ft for a 4-inch skimmer) as

$$D = \sqrt{\frac{Q}{2310\sqrt{H}}} = \sqrt{\frac{6670}{2310\sqrt{0.333}}} = 2.24 \text{ inches}$$

We see that if the plastic plug were drilled to a diameter of 2.24 inches and placed in a 4-inch skimmer, the dewater rate would be 6,670 ft³/d and the 20,000-ft³ basin would dewater in 3 days.

Outlet Protection

Provide outlet protection to ensure erosion does not occur at the pipe outlet.

Basin Emergency Spillway

The emergency spillway should carry the peak runoff from a 10-year storm. The spillway should have a minimum 10-foot bottom width, 0.5-foot flow depth, and 1-foot freeboard above the design water surface.

Construct the entire flow area of the spillway in undisturbed soil to the greatest extent possible. The cross section should be trapezoidal, with side slopes 3:1 (horizontal: vertical) or flatter for grass spillways (Figure SBN-5) and 2:1 (horizontal: vertical) for riprap. Select vegetated lining to meet flow requirements and site conditions.




Figure SBN-5 Excavated grass spillway views

Inlet Section

Ensure that the approach section has a slope toward the impoundment area of not less than 2% and is flared at its entrance, gradually reducing to the design width of the control section. The inlet portion of the spillway may be curved to improve alignment.

The Control Section

The control section of the spillway should be level and straight and at least 20 feet long for grass spillways and 10 feet for riprap. Determine the width and depth for the required capacity and site conditions. Wide, shallow spillways are preferred because they reduce outlet velocities.

The Outlet Section

The outlet section of the spillway should be straight, aligned, and sloped to ensure supercritical flow with exit velocities not exceeding values acceptable for site conditions.

Outlet Velocity

Ensure that the velocity of flow from the basin is nonerosive for existing site conditions. It may be necessary to stabilize the downstream areas or the receiving channels.

Embankment

Embankments should not exceed 10 feet in height, measured at the center line from the original ground surface to the designed (settled) top elevation of the embankment. Keep a minimum of 1 foot between the designed (settled) top of the dam and the design water level in the emergency spillway. Additional freeboard may be added to the embankment height, which allows flow through a designated bypass location. Construct embankments with a minimum top width of 8 feet and side slopes of 2.5:1 (horizontal: vertical) or flatter.

There should be a cutoff trench in stable soil material under the dam at the centerline. The trench should be at least 2 feet deep with 1.5:1 (horizontal: vertical) side slopes, and sufficiently wide (at least 8 feet) to allow compaction by machine.

Embankment material should be a stable mineral soil, free of roots, woody vegetation, rocks, or other objectionable materials, with adequate moisture for compaction. Place fill in 9-inch layers through the length of dam and compact by routing construction hauling equipment over it. Maintain moisture and compaction requirements according to the plans and specifications. Hauling or compaction equipment must traverse each layer so that the entire surface has been compacted by at least one pass of the equipment wheels or tracks.

Excavation

Where sediment pools are formed or enlarged by excavation, keep side slopes at 2:1 (horizontal: vertical) or flatter for safety.

Erosion Protection

Minimize the area disturbed during construction. Divert surface water from disturbed areas. When possible, delay clearing the sediment impoundment area until the dam is in place. Keep the remaining temporary pool area undisturbed. Stabilize the spillway, embankment, and all disturbed areas with permanent vegetation. The basin bottom should also be established to a vegetative cover as this promotes sediment deposition.

Trap Efficiency

Improve sediment basin trapping efficiency by employing the following considerations in the basin design:

- Surface area—In the design of the settling pond, allow the largest surface area possible. The shallower the pool, the better.
- Length—Maximize the length-to-width ratio of the basin to provide the longest flow path possible.
- Baffles—Provide a minimum of three porous baffles to evenly distribute flow across the basin and reduce turbulence.
- Inlets—Area between the sediment inlets and the basin bottom should be stabilized by geotextile material, riprap with geotextile, a pipe drop, or other similar methods (Figure SBN-6 shows the area with rocks). Inlets to basin should be located the greatest possible distance away from the spillway.
- Dewatering—Allow the maximum reasonable detention period before the basin is completely dewatered (at least 48 hours).
- Inflow rate—Reduce the inflow velocity to nonerosive rates, and divert all sediment-free runoff.
- Establish permanent vegetation in the bottom and side slopes of the basin.
- Introduce the appropriate PAM material either at the turbulent entrance of the runoff water into the basin and/or apply to the first baffle. Apply the PAM according to manufacturer's recommendations.

Safety

Avoid steep side slopes. Fence basins properly and mark them with warning signs if trespassing is likely. Follow all state and local safety requirements.




Figure SBN-6 Example of a sediment basin with a skimmer outlet and emergency spillway (modified from Pennsylvania Erosion and Sediment Control Manual, March 2000)

Design Procedure

Step 1. Determine peak flow, Q_{10} , for the basin drainage area utilizing the NRCS runoff curve number method (see *Appendix A: Erosion and Stormwater Runoff Calculations*).

Step 2. Determine any site limitations for the sediment pool elevation, emergency spillway, or top of the dam.

Step 3. Determine basin volumes:

- Compute minimum volume required (3,600 ft³/acre of drainage area).
- Specify sediment cleanout level to be clearly marked (one-half the design volume). Specify that the basin area is to be cleared after the dam is built.

Step 4. Determine area of basin, shape of basin, and baffles:

- Check length/width ratio (should be 2:1 or larger).
- Ensure the bottom of the basin is level.
- Design and locate a minimum of three coir baffles. The baffle spacing should produce equal volumes of storage within the basin when the basin is full. The top elevation of the baffles will be set in Step 7.

Step 5. Size the skimmer, skimmer orifice, and barrel pipe.

Use Table SBN-1 or the precise alternative design to size the orifice. Generally, a Schedule 40 PVC barrel pipe the same size as the skimmer arm is used under the embankment.

Step 6. Design the anti-seep collar.

Ensure that anti-seep collar is no closer than 2 feet from a pipe joint and as close to the center of the embankment as possible. Collar must project at least 1.5 feet from the pipe and be watertight.

Step 7. Determine the emergency spillway dimensions.

Size the spillway bottom width and flow depth to handle the Q_{10} peak flow. Tables SBN 2 and SBN-3 can be used for the design process for grassed emergency spillways. Use appropriate design procedures for spillways with other surfaces. Set top of baffles at the elevation of the designed maximum flow depth of the emergency spillway.

Step 8. Spillway approach section.

Adjust the spillway alignment so that the control section and outlet section are straight. The entrance width should be 1.5 times the width of the control section with a smooth transition to the width of the control section. The approach channel should slope toward the reservoir no less than 2%.

Step 9. Spillway control section.

- Locate the control section in natural ground to the greatest extent possible.
- Keep a level area to extend at least 20 feet (grass) or 10 feet (riprap) upstream from the outlet end of the control section to ensure a straight alignment.
- Side slopes should be 3:1 (grass) or 2:1 (riprap).

Step 10. Design spillway exit section.

- Spillway exit should align with the control section and have the same bottom width and side slopes.
- Slope should be sufficient to maintain supercritical flow, but make sure it does not create erosive velocities for site conditions. (Stay within slope ranges in appropriate design tables.)
- Extend the exit channel to a point where the water may be released without damage.

Step 11. Size the embankment.

- Set the design elevation of the top of the dam a minimum of 1 foot above the water surface for the design flow in the emergency spillway.
- Constructed height should be 10% greater than the design to allow for settlement.
- Set side slopes 2.5:1 or flatter.
- Determine depth of cutoff trench from site borings. It should extend to a stable, tight soil layer (a minimum of 2 ft deep).
- Select borrow site remembering that the spillway cut may provide a significant amount of fill.

Step 12. Erosion control

- Select surface-stabilization measures to control erosion.
- Select groundcover for emergency spillway to provide protection for design flow velocity and site conditions. Riprap stone over geotextile fabric may be required in erodible soils or when the spillway is not in undisturbed soils.
- Establish all disturbed areas, including the basin bottom and side slopes, to vegetation.

Step 13. Safety.

- Construct a fence and install warning signs as needed.

Table SBN-2 Design Table for Vegetated Spillways Excavated in Erosion-Resistant Soils
(side slopes 3 horizontal: 1 vertical)

Discharge Q CFS	Slope Range		Bottom Width Feet	Stage Feet	Discharge Q CFS	Slope Range		Bottom Width Feet	Stage Feet
	Minimum Percent	Maximum Percent				Minimum Percent	Maximum Percent		
15	3.3	12.2	8	.83	80	2.8	5.2	24	1.24
	3.5	18.2	12	.69		2.8	5.9	28	1.14
20	3.1	8.9	8	.97	2.9	7.0	32	1.06	
	3.2	13.0	12	.81	2.5	2.6	12	1.84	
	3.3	17.3	16	.70	2.5	3.1	16	1.61	
25	2.9	7.1	8	1.09	2.6	3.8	20	1.45	
	3.2	9.9	12	.91	2.7	4.5	24	1.32	
	3.3	13.2	16	.79	2.8	5.3	28	1.22	
	3.3	17.2	20	.70	2.8	6.1	32	1.14	
30	2.9	6.0	8	1.20	2.5	2.8	16	1.71	
	3.0	8.2	12	1.01	2.6	3.3	20	1.54	
	3.0	10.7	16	.88	2.6	4.0	24	1.41	
	3.3	13.8	20	.78	2.7	4.8	28	1.30	
35	2.8	5.1	8	1.30	2.7	5.3	32	1.21	
	2.9	6.9	12	1.10	2.8	6.1	36	1.13	
	3.1	9.0	16	.94	2.5	2.8	20	1.71	
	3.1	11.3	20	.85	2.6	3.2	24	1.56	
40	3.2	14.1	24	.77	2.7	3.8	28	1.44	
	2.7	4.5	8	1.40	2.7	4.2	32	1.34	
	2.9	6.0	12	1.18	2.7	4.8	36	1.26	
45	2.9	7.6	16	1.03	2.5	2.7	24	1.71	
	3.1	9.7	20	.91	2.5	3.2	28	1.58	
	3.1	11.9	24	.83	2.6	3.6	32	1.47	
	2.6	4.1	8	1.49	2.6	4.0	36	1.38	
50	2.8	5.3	12	1.25	2.7	4.5	40	1.30	
	2.9	6.7	16	1.09	2.5	2.7	28	1.70	
	3.0	8.4	20	.98	2.5	3.1	32	1.58	
	3.0	10.4	24	.89	2.6	3.4	36	1.49	
55	2.7	3.7	8	1.57	2.6	3.8	40	1.40	
	2.8	4.7	12	1.33	2.7	4.3	44	1.33	
	2.8	6.0	16	1.16	2.4	2.7	32	1.72	
	2.9	7.3	20	1.03	2.4	3.0	36	1.60	
60	3.1	9.0	24	.94	2.5	3.4	40	1.51	
	2.6	3.1	8	1.73	2.6	3.7	44	1.43	
	2.7	3.9	12	1.47	2.5	2.7	36	1.70	
	2.7	4.8	16	1.28	2.5	2.9	40	1.60	
	2.9	5.9	20	1.15	2.5	3.3	44	1.52	
65	2.9	7.3	24	1.05	2.6	3.6	48	1.45	
	3.0	8.6	28	.97	2.4	2.6	40	1.70	
	2.5	2.8	8	1.88	2.5	2.9	44	1.61	
	2.6	3.3	12	1.60	2.5	3.2	48	1.53	
	2.6	4.1	16	1.40	2.5	2.6	44	1.70	
70	2.7	5.0	20	1.26	2.5	2.9	48	1.62	
	2.8	6.1	24	1.15	2.6	3.2	52	1.54	
	2.9	7.0	28	1.05	2.4	2.6	48	1.70	
	2.5	2.9	12	1.72	2.5	2.9	52	1.62	
75	2.6	3.6	16	1.51	280	2.4	2.6	52	1.70
	2.7	4.3	20	1.35	300	2.5	2.6	56	1.69

Example of Table Use:

Given: Discharge, $Q_{10} = 87$ cfs, Spillway slope (exit section) = 4%.

Find: Bottom Width and Stage in Spillway.

Procedure: Using a discharge of 90 cfs, note that the spillway (exit section) slope falls within slope ranges corresponding to bottom widths of 24, 28, and 32 ft. Use bottom width of 32 ft, to minimize velocity. Stage in the spillway is 1.14 ft.

Note: Computations are based on: Roughness coefficient, $n = 0.40$, and a maximum velocity of 5.50 ft per sec.

Table SBN-3 Design Table for Vegetated Spillways Excavated in Very Erodible Soils
(side slopes 3 horizontal: 1 vertical)

Discharge Q CFS	Slope Range		Bottom Width Feet	Stage Feet
	Minimum Percent	Maximum Percent		
10	3.5	4.7	8	.68
15	3.4	4.4	12	.69
	3.4	5.9	16	.60
20	3.3	3.3	12	.80
	3.3	4.1	16	.70
	3.5	5.3	20	.62
25	3.3	3.3	16	.79
	3.3	4.0	20	.70
	3.5	4.9	24	.64
30	3.3	3.3	20	.78
	3.3	4.0	24	.71
	3.4	4.7	28	.65
	3.4	5.5	32	.61
35	3.2	3.2	24	.77
	3.3	3.9	28	.71
	3.5	4.6	32	.66
	3.5	5.2	36	.62
40	3.3	3.3	28	.76
	3.4	3.8	32	.71
	3.4	4.4	36	.67
	3.4	5.0	40	.64
45	3.3	3.3	32	.76
	3.4	3.8	36	.71
	3.4	4.3	40	.67
	3.4	4.8	44	.64
50	3.3	3.3	36	.75
	3.3	3.8	40	.71
	3.3	4.3	44	.68
60	3.2	3.2	44	.75
	3.2	3.7	48	.72
70	3.3	3.3	52	.75
80	3.1	3.1	56	.78

Example of Table Use:

Given: Discharge, $Q_{10} = 38$ cfs, Spillway slope (exit section) = 4%.

Find: Bottom Width and Stage in Spillway.

Procedure: Using a discharge of 40 cfs, note that the spillway (exit section) slope falls within slope ranges corresponding to bottom widths of 36 and 40 ft. Use bottom width of 40 ft, to minimize velocity. Stage in the spillway is 0.64 ft.

Note: Computations are based on: Roughness coefficient, $n = 0.40$ and a maximum velocity of 3.50 ft per sec.

Construction

Prior to the start of construction, sediment basins should be designed by a qualified design professional.

Plans and specifications should be referred to by field personnel throughout the construction process. The sediment basin should be built according to planned grades and dimensions. Follow all federal, state and local requirements on impoundments.

Consider the following guidance as construction proceeds.

Site Preparation

Locate all utilities at the site to ensure avoidance.

Clear, grub, and strip the dam foundation and emergency spillway area, removing all woody vegetation, rocks, and other objectionable material. Dispose of trees, limbs, logs, and other debris in designated disposal areas.

Stockpile surface soil for use later during topsoiling.

Delay clearing the pool area until the dam is complete and then remove brush, trees, and other objectionable materials to facilitate sediment cleanout.

Keyway Trench

Excavate the keyway trench along the centerline of the planned embankment to a depth determined by the qualified design professional (at least 2 feet). The trench bottom elevation should extend up both abutments to the riser crest elevation and should have a bottom width of at least 8 feet and side slopes no steeper than 1.5:1 (horizontal: vertical). Compaction requirements will be the same as those for the embankment.

Skimmer

Prevent the skimming device from settling into the mud by excavating a shallow pit under the skimmer or providing a low support under the skimmer of stone or timber (Figure SBN-1).




Figure SBN-1 Schematic of a skimmer (Source: Pennsylvania Erosion and Sediment Pollution Control Manual, March 2000)

Place the barrel pipe (typically the same size as the skimmer arm) on a firm, smooth foundation of impervious soil. Do not use pervious material such as sand, gravel, or crushed stone as backfill around the pipe. Place the fill material around the pipe in 4-inch layers and manually compact it under and around the pipe to at least the same density as the adjacent embankment. Care must be taken not to raise the pipe from the firm contact with its foundation when compacting under the pipe haunches.

Construct the anti-seep collar(s), if shown on the plans.

Place a minimum depth of 2 feet of compacted backfill over the pipe before crossing it with construction equipment. In no case should the pipe conduit be installed by cutting a trench through the dam after the embankment is complete.

Assemble the skimmer following the manufacturer's instructions, or as designed.

Lay the assembled skimmer on the bottom of the basin with the flexible joint at the inlet of the barrel pipe. Attach the flexible joint to the barrel pipe and position the skimmer over the excavated pit or support. Be sure to attach a rope to the skimmer and anchor it to the side of the basin. This will be used to pull the skimmer to the side for maintenance.

Install outlet protection as specified.

Embankment

Scarify the foundation of the dam before placing fill.

Use fill from predetermined borrow areas. It should be clean, stable soil free of roots, woody vegetation, rocks, and other debris; and must be wet enough to form a ball without crumbling, yet not so wet that water can be squeezed out.

Place the most permeable soil in the downstream toe and the least permeable in the center portion of the dam.

Place the fill material in 6" to 9" continuous uncompacted layers over the length of the dam. Fill should then be compacted to a 4" to 6" thick continuous layer (for example, routing construction equipment over the dam so that each layer is traversed by at least four passes of the equipment).

Protect the spillway barrel with 2 feet of fill that has been compacted with hand tampers before traversing over the pipe with equipment.

Construct and compact the dam to an elevation 10% above the design height to allow for settling. The embankment should have a minimum 8-foot top width and 2.5:1 side slopes, but the design may specify additional width and gentler side slopes.

Place a reference stake at the sediment clean-out elevation shown on the plans (50% of design storage volume).

Emergency Spillway

Construct the spillway at the site located by a qualified design professional according to the plan design (in undisturbed soil around one end of the embankment, and so that any flow will return to the receiving channel without damaging the embankment).

Basin and Baffles

Ensure the basin has a length-to-width ratio of at least 2:1 or more as specified. Grade the basin so that the bottom is level front-to-back and side-to-side. Discharge water into the basin in a manner to prevent erosion. Use diversions with outlet protection to divert sediment-laden water to the upper end of the pool area to improve basin trap efficiency.

Install porous coir baffles as specified to ensure water does not flow under or around the baffles (Figure SBN-2).

Install posts or sawhorses across the width of the sediment trap.

Steel posts should be driven to a depth of 24 inches, spaced a maximum of 4 feet apart, and installed up the sides of the basin as well. The top of the fabric should be at least the height of the required storage volume elevation.

Install at least three rows of baffles between the inlet and outlet discharge point and at the locations specified in the plans.

When using posts, add a support wire or rope across the top to prevent sagging.

Wrap porous coir material (700–900 g/m²) over a sawhorse or the top wire. Hammer rebar into the sawhorse legs for anchoring. Attach fabric to a rope and a support structure with zip ties, wire, or staples.

The bottom and sides of the fabric should be anchored in a trench or pinned with 8-inch erosion-control matting staples.

Do not splice the fabric, but use a continuous piece across the basin.



Figure SBN-2 Example of porous baffle made of 700-g/m² coir erosion blanket as viewed from the inlet (Source: North Carolina Erosion and Sediment Control Planning and Design Manual)

Erosion Control

Minimize the size of all disturbed areas.

Divert runoff from undisturbed areas away from the basin.

Use temporary diversions to prevent surface water from running onto disturbed areas.

Divert sediment-laden water to the upper end of the sediment pool to improve trap effectiveness.

Vegetate and stabilize the embankment, the emergency spillway, and all disturbed areas including the basin bottom and side slopes.

Safety

Because sediment basins that impound water are hazardous, the following precautions should be taken:

- Fence the area and post warning signs if trespassing is likely.
- Ensure that the basin does not exceed design heights.

Construction Verification

Check the finished grades and configurations for all earthworks. Check elevations and dimensions of all pipes and structures.

Common Problems

Consult with a registered design professional if any of the following occurs:

Variations in topography on-site indicate sediment basin will not function as intended.

Seepage is encountered during construction; it may be necessary to install drains.

Design specifications for fill, pipe, seed variety, or seeding dates cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Maintenance

Inspect the sediment basin at least weekly and after each significant storm event (½ inch or greater).

Remove and properly dispose of sediment when it accumulates to ½ the design volume.

Remove trash and other debris from the skimmer, emergency spillway, and pool area.

Periodically check the embankment, emergency spillway, and outlet for erosion damage, piping, settling, seepage, or slumping along the toe or around the barrel and repair immediately.

Remove the basin after the drainage area has been permanently stabilized, inspected and approved. Do so by draining any water, removing the sediment to a designated disposal area, and smoothing the site to blend with the surrounding area; then stabilize.

References

Volume 1

Chapter 2

Vegetation for Erosion and Sediment Control 2-10

Chapter 4

Permanent Seeding (PS) 4-53

Flocculants and Polymers (FLC) 4-328


MDOT Drawing TEC-3

Typical Temporary Erosion Control Measures 4-321


Appendix G (Available in Appendices Volume)

MDOT Vegetation Schedule G-1


STATE	PROJECT NO.
MISS.	




PLAN




TEMPORARY SILT BASIN (TYPE B)




SECTION A-A



PIPE ANCHORAGE



NOTE: POST MEMBERS MAY BE GREEN TIMBER AND MAY BE CUT OFF AT NATURAL GROUND REMOVAL. POST MUST BE 8" MINIMUM CLEAN DIAMETER.



TRASH RACK INSTALLATION

GENERAL NOTES:

1. PROVIDE OVERFLOW SPILLWAY IN NATURAL GROUND AT A MINIMUM OF 1'-0" BELOW TOP OF DIKE. CROSS-SECTIONAL AREA OF SPILLWAY IS EQUAL TO 1.5 TIMES THE AREA OF THE OUTLET PIPE. MINIMUM RIPRAP SHALL BE REQUIRED AT THE SPILLWAY. AFTER THE PURPOSE OF THE SILT BASIN HAS BEEN SERVED, THE DIKE AND RIPRAP MAY REMAIN IN PLACE AT THE DISCRETION OF THE ENGINEER, BUT THE DRAIN PIPE WITH RISER SHALL BE REMOVED AND THE NEWLY DISTURBED AREA REVEGETATED.
2. BASIN AND DIKE DIMENSIONS DO NOT REQUIRE CONSTRUCTION TO NEAT LINES.
3. THE SILT BASIN MAY BE CONSTRUCTED IN ANY SHAPE WITH THE DIKE EXTENDING ALONG ONE OR MORE SIDES AS LONG AS THE LENGTH MEASURED IN THE DIRECTION OF FLOW IS APPROXIMATELY TWICE THE WIDTH AND THE IMPOUNDMENT AREA AND DEPTH AT LEAST AS LARGE AS INDICATED.
4. MINIMUM DIMENSIONS FOR SILT BASIN (TYPE B) ARE AS FOLLOWS:

PIPE	# x D (ft.-in)	H (ft.-in)	# AREA (ft.²)	1 COUPLING BAND LENGTH (ft.)	COUPLING RODS/SIDE
15"	4'-0"	1'-0"	310	12"	2 & 2
18"	5'-0"	1'-0"	550	12"	2 & 2
24"	5'-0"	1'-0"	1100	12"	2 & 2
30"	6'-0"	1'-6"	1850	24"	3 & 3
36"	6'-0"	1'-6"	2800	24"	3 & 3
42"	7'-0"	2'-0"	4200	24"	3 & 3
48"	8'-0"	2'-0"	6200	24"	3 & 3

- NOTES:
1. IMPOUNDMENT SURFACE AREAS ARE MEASURED AT ELEVATION OF TOP OF ELBOW RISER.
 2. RISER REQUIRED WHERE MINIMUM "D" DIMENSION IS EXCEEDED. LENGTH OF RISER IS EQUAL TO THE AMOUNT THAT MINIMUM "D" DIMENSION IS EXCEEDED.
 3. COUPLING RODS TO BE 1/2" DIAMETER MINIMUM WITH LUGS.

MISSISSIPPI DEPARTMENT OF TRANSPORTATION
ROADWAY DESIGN DIVISION
STANDARD PLAN

TYPICAL TEMPORARY EROSION CONTROL MEASURES (TYPE B SILT BASIN)

ISSUE DATE: OCTOBER 1, 1998

WORKING NUMBER: TEC-3

SHEET NUMBER: 144

Straw Bale Sediment Trap (SST)



Practice Description

A straw bale sediment trap is a temporary catch basin consisting of a row or more of entrenched and anchored straw bales. The purpose is to intercept and detain small amounts of sediment to prevent sediment from leaving the construction site. This practice applies within disturbed areas with small drainage basins.

Planning Considerations

In certain situations, straw bales can be used as an alternative to silt fence for trapping sediment. The practice should be used to trap sediment only for a short duration from small drainage areas. Straw bales' comparatively low flow rate should be considered before choosing to use this practice. Ponding above the bales can occur rapidly due to the low flow rate. Overtopping and bypass of the bales can cause significant damage to the site. Additional measures should be used if turbidity leaving the site served by this practice is an issue.

Design Criteria and Construction

Drainage Area

For disturbed areas subject to sheet erosion the drainage area should be restricted to $\frac{1}{4}$ acre per 100 feet of barrier. The slope length behind the barrier should be restricted according to Table SST-1.

If used in minor swales, the swale should be relatively flat in grade (3 percent or less) and the drainage area should be limited to 1 acre.

Table SST-1 Criteria for Straw or Hay Bale Placement

Land Slope (Percent)	Maximum Slope Length Above Bale (Feet)
<2	75
2 to 5	50
5 to 10	35
10 to 20	20
>20	10

Bale Size

Bales should be 14" x 18" x 36".

Anchors

Two 36" long (minimum) 2" x 2" hardwood stakes should be driven through each bale after the bales are properly entrenched. Alternate anchors can be two pieces of No. 4 steel rebar, 36" long (minimum). See Figures SST-1 and SST-2 for details on proper installation of straw bales.

Effective Life

Straw and hay bales have a relatively short period of usefulness and should not be used if the project duration is expected to exceed 3 months. Bale placement should result in the twine or cord being on the side and not the bottom of the bale.

Location

This practice should be used on nearly level ground and be placed at least 10 feet from the toe of any slope. The barrier should follow the land contour. The practice should never be used in live streams or in swales where there is a possibility of washout. The practice should also not be used in areas where rock or hard surfaces prevent the full and uniform anchoring of the bales.




Figure SST-1 Placement of Straw Bale




Figure SST-2 Anchoring Technique for Straw Bales

Construction

Prior to start of construction, straw bale sediment traps should be designed by a qualified professional. Plans and specifications should be referred to by field personnel throughout the construction process. The straw bale sediment trap should be built according to planned grades and dimensions.

Site Preparation

Determine exact location of underground utilities so that locations for digging or placement of stakes can be selected where utilities will not be damaged.

Smooth the construction zone to provide a broad, nearly level area for the row of bales. The area should be wide enough to provide storage of runoff and sediment behind the straw bales.

To facilitate maintenance, provide good access for cleanout of sediment during maintenance period.

Installation of Straw Bale

Excavate a trench to the dimensions shown on the drawings. The trench should be long enough that the end bales are somewhat upslope of the sediment pool to ensure that excess flows go over the bales and not around the bales.

Place each bale end-to-end in the trench so the bindings are oriented around the sides rather than top and bottom.

Anchor the bales by driving two 36" long 2" x 2" hardwood stakes through each bale at least 18" into the ground. Drive the first stake toward the previously laid bale to force the bales together.

Wedge loose straw into any gaps between the bales to slow the movement of sediment-laden water.

Anchor the bales in place according to the details shown on the drawings. If specific details are not shown, backfill and compact the excavated soil against the bales to ground level on the downslope side and to 4" above ground level on the upslope side.

Erosion Control

Stabilize disturbed areas in accordance with the vegetation plan. If no vegetation plan exists, consider planting and mulching as part of the installation and select planting information from either the *Permanent Seeding* or *Temporary Seeding Practice*. Select mulching information from the *Mulching Practice*.

Construction Verification

Check finished grades and dimensions of the straw bale sediment trap. Check materials for compliance with specifications.

Common Problems

Consult with a registered design professional if any of the following occurs:

Variations in topography on site indicate sediment trap will not function as intended; changes in plan may be needed.

Design specifications for materials cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Maintenance

Inspect straw bale barriers after each storm event and remove sediment deposits promptly after it has accumulated to ½ of the original capacity, taking care not to undermine the entrenched bales.

Inspect periodically for deterioration or damage from construction activities. Repair damaged barrier immediately.

After the contributing drainage area has been stabilized, remove all straw bales and sediment, bring the disturbed area to grade, and stabilize it with vegetation or other materials shown in the design plan.

Straw bales may be recycled as mulch.

References

BMPs from Volume 1

Chapter 4

Mulching (MU)	4-48
Permanent Seeding (PS)	4-53
Temporary Seeding	4-103

Flocculants and Polymers (FLC)



Practice Description

Flocculants are used to promote clumping in sediment-laden water. Flocculants can be used in chemical stabilization of soils on steep slopes as is discussed in the *Chemical Stabilization Practice*. This section discusses the use of flocculants in conjunction with pumped construction site stormwater systems. Flocculant is dissolved into sediment retention basin inflows via a rainfall-activated system. The flocculant causes individual particles to be destabilized (i.e. neutralizing electrical charges that cause particles to repel each other), accelerating the coagulation and settlement of particles out of the water column. Flocculant types include polyacrylamides (PAM), gypsum, and alum. Anionic PAM is a negatively charged long-chained molecule that consists of acrylamide and acrylate units. It is available as a crystalline powder, an emulsion, or a solid block or log (McLaughlin, 2007). Anionic PAM used for turbidity reduction should contain less than 0.5 percent free acrylamide due to the suspected carcinogenic effect of acrylamide. Gypsum, a natural mineral composed of calcium sulfate and water, is often used in water and wastewater treatment processes. Alum is an aluminum sulfate material that can also be used for water clarification.

Planning Considerations

When utilizing flocculants to aid in sediment removal, the following criteria are required by the MDEQ: 1) only anionic polyacrylamide (PAM) polymer; 2) polymer shall contain less than 0.05% free acrylamide; 3) polymer shall be non-toxic to fish and other aquatic organisms, and; 4) polymer shall be selected for site-specific soil conditions (i.e. jar test). For polymer system treatment of turbidity, the following criteria are required at a minimum: 1) polymer shall be introduced through turbulent mixing into the stormwater upstream of sedimentation BMPs; 2) sedimentation basin shall be constructed in

accordance with the criteria specified in ACT 5, T-5 (2)(A) of the Large Construction General Permit (see *Appendix B*); and 3) polymer shall be applied in accordance with manufacturer's instructions, and there shall be no discharge of undissolved polymer, clumps of polymer, and/or unsettled flocculant material.

Design Criteria and Construction

PAM Screening Method

Because of the varied type of soils across the state, there is no one type of PAM that is applicable to all. At this time, the only way to determine the most effective type (or types, if the site is large) of PAM is to do a jar test. Most PAM retailers will perform this test.

1. Obtain a clear container (approximately 16 oz).
2. Fill with tap water.
3. Add a small amount of PAM (a "pinch").
4. Add a teaspoon of soil from the site.
5. Shake for 10-20 seconds or until the water begins to clear, then allow to settle.
6. Repeat for several PAM products, and then select the product that clears the water the most quickly.

Pumped Injection

Pumped injection is an effective treatment route because the concentrations of PAM used can be controlled and the reaction between PAM particles and suspended solids is faster than a solid PAM dosing technique. This setup includes a turbid water source, a PAM dosing pump, and a silting basin to treat turbidity.

A pumped injection system consists of a PAM solution pump and a PAM reservoir. An electric pump is often used to inject the PAM solution, preferably a peristaltic pump with variable speeds. The PAM pump hose can be connected into the intake hose to ensure proper dosing and mixing. A sample configuration is provided as Figure FLC-1.

Dosage Rate

The recommended dosage rate of PAM is 1–5 milligrams per liter or parts per million. Rates can be adjusted based on the results of a jar test.

Baffles

A porous baffle of coir netting is recommended to catch the floating flocs created by the flocculation reaction. The preferred weight for sediment basins is 900 grams per square meter. The flocculation of turbid water may cause sediment baffles to become clogged faster than systems without flocculant use and may require more frequent replacements.




Figure FLC-1 Sample Pumped Injection System

PAM-Treated Channel

This practice uses solid PAM crystalline powder with a jute or coir-lined channel. The turbid water is pumped into the channel and mixes with the solid PAM as it travels toward a sediment basin. This method is also effective when used with fiber check dams (wattles).

The PAM power should only be applied when no water is in the channel. Some wetting of the erosion-control fabric may be required to stabilize the PAM powder. If PAM powder is added directly to the water flow, it will simply settle out and will not be effectively mixed.



Figure FLC- 1 PAM-Treated Channel - Runoff Flows over Inlet Protection Fabric into Sediment Basin (Source: North Carolina State University)

Treatment Approach

Flocculant use should be installed as a treatment-train approach. Turbid water should be contained on-site, treated with flocculant, and then stored in a sediment basin until solid particles have settled out.

Coagulants

Coagulants such as gypsum and alum can be used to reduce turbidity as well, with approval of MDEQ. These materials can be spread by hand into the water after each storm. The suggested dosage rate is 20–30 pounds per 1,000 cubic feet of water, spread over the surface.

Monitoring

Monitoring is currently voluntary, the results of which will not be required to be documented and/or reported. There are currently no active numeric effluent limitations for construction stormwater discharges. Numeric effluent limitations are expected to be established by the EPA for the next permitting cycle. While these monitoring activities are currently optional, they are still helpful in determining the effectiveness of turbidity reduction procedures. The following monitoring procedures were taken from the Mississippi Large Construction General Permit recommendations found in Act 9: Optional Monitoring (see *Appendix B* for full permit document):

1. Monitor the turbidity of each storm water discharge from actively disturbed areas of the project site for each work day the discharge occurs. Actively disturbed areas are those portions of the project site that have undergone soil disturbing activities (i.e., clearing, grading, filling, excavating, etc.) and have not been stabilized.
 - a) Monitoring should be conducted for each point of storm water discharge from the project site. For the purpose of this permit, a discharge point means any discernible, confined, and discrete conveyance, including but not limited to, any pipe, ditch, channel, tunnel, conduit, well, discrete fissure, or container from which storm water and/or pollutants are, or may be, discharged.
 - b) Diffuse storm water, such as non-channelized flow that infiltrates into a vegetated area, and does not then discharge to surface waters, would not generally require monitoring.
2. Due to the unique characteristics of linear projects, portions may have suspended construction activity and have undergone temporary or final stabilization [see Definitions] while other portions of the same project may have active construction activities. Therefore, in recognition of these unique regulatory circumstances, only those areas that have active construction activities will require numeric turbidity monitoring. Those areas that have been completed and stabilized will not require turbidity monitoring.
3. Sampling:
 - a) A minimum of three (3) samples per work day, per discharge, should be used to calculate a daily average turbidity value. Samples should be collected so as to be representative of the nature of the discharge over its duration. For example,

- (i) Collect first sample within the first hour of discharge or within the first hour of the work day.
 - (ii) Collect second sample in the middle of discharge or the middle of the work day.
 - (iii) Collect last sample at the end of discharge or at the end of the work day.
 - (iv) Continue sampling at the start of the next work day if there continues to be a discharge (until discharge ends or end of the work day). These data should be used to calculate a separate daily average.
- b) Monitoring samples should be collected at the nearest accessible point after final treatment, but prior to mixing with the receiving water body.
- (i) Due to the unique characteristics of linear projects, there may be multiple discharge points spaced over a wide geographic area. Therefore, MDEQ will allow representative discharge sampling. For example, representative sampling at certain discharge locations may be representative of the discharge characteristics of other locations within the same sub-watershed. For multiple outfalls that discharge substantially identical effluents, the owner or operator may sample one (or more) of the outfalls and report that data as representative of the other outfalls. At a minimum, at least one discharge point per sub-watershed must be monitored and the same or similar controls must be implemented on the different discharge points.
 - (ii) Representative sampling of non-linear projects may be allowed on a case-by-case basis.
- c) Monitoring may be accomplished via portable turbidity meters or fixed automated sampling/meter stations.
- (i) Monitoring should be based on grab samples for portable meters.
 - (ii) Automated samplers should be programmed to yield a minimum of three (3) representative readings per discharge, per day.
 - (iii) Daily turbidity averages should be the average of all monitoring results collected on the day of discharge for the respective discharge point(s). For example, if there were five (5) turbidity readings in a given day, then the average turbidity for that day would be the average of all five (5) readings.
- d) Grab samples should be collected according to the following methodology to ensure that each sample is representative of the flow conditions and other characteristics of the discharge.
- (i) Collect samples from the horizontal and vertical center of the storm water outfall channel(s) or other sources of concentrated flow.
 - (ii) Avoid stirring the bottom sediments in the storm water channel in which samples are taken by not walking through the areas of storm water flow or disturbing the sediment with the sampling device.
 - (iii) Hold sampling container so that the opening faces the upstream direction of the storm water channel in which samples are taken.
 - (iv) Avoid overfilling sample container.
- e) Monitoring should be conducted for any discharge that occurs during the normal working hours of the project site.

4. Turbidity Meters:
 - a) Turbidity meters should meet the following design criteria:
 - (i) Accuracy within +/- 5% of measurement,
 - (ii) Minimum upper range of 1000 NTU,
 - (iii) Able to be calibrated by operator, and
 - (iv) Operating temperature range be at least 32 to 122 degrees.
 - b) Turbidity meters should be operated, calibrated and maintained according to the meter manufacturer's instructions.

Construction Verification

Check finished grades and dimensions of the sediment basin. Check materials for compliance with specifications.

Common Problems

Consult with a registered design professional if any of the following occurs:

Pumped injection systems are not reducing turbidity in sediment basin. Check PAM reservoir and dosage rates.

A thick gel forms in PAM-treated channel. Application rates are too high – only a thin coating of PAM powder is need.

Maintenance

Regular inspections of PAM reservoir are required to maintain adequate supply.

Inspect power source and piping for potential failures.

Coir baffles may require regular replacement when using flocculants; inspect frequently for clogged baffles.

In PAM-treated channels, inspect channel lining often and replace when needed.

References

BMPs from Volume 1

Chapter 4

Chemical Stabilization (CHS)

4-25

Introduction to Stream Protection Practices

Disturbing the natural process of streams and associated wetlands must be avoided whenever possible. The following provides information regarding federal regulations protecting wetlands and streams and should be reviewed before beginning construction projects adjacent to or within stream channels.

Wetlands

Wetlands are defined by 33CFR328 as “areas that are inundated or saturated by surface or ground water at a frequency and duration sufficient to support, and that under normal circumstances do support, a prevalence of vegetation typically adapted for life in saturated soil conditions. Wetlands generally include swamps, marshes, bogs, and similar areas.” Ecologically, wetlands provide a number of valuable functions, including habitat and foraging opportunities for many species of animals. From a water quality perspective, wetlands provide attenuation of floodwaters, processing of nutrients, and infiltration of stormwater, all of which improve the water quality of the respective watershed.

Stream Channels

Stream channel morphology and adjacent wetland areas play an important role in water quality, flood attenuation, sediment retention, wildlife and aquatic habitat and species, and endangered and threatened species. Stream channelization causes water flowing through the straightened section to move more rapidly and can lead to further erosion problems downstream of the channelized area. Channelization often necessitates the removal of vegetation along the streambanks and placement of fill within wetland areas. The removal of overhanging vegetation in the bends and pools of a stream can reduce the habitat for fish by decreasing feeding and spawning habitat. Restoring these areas after stream channel construction is important to prevent water quality impairment, improve flood control, and restore fish and wildlife habitat.

Stormwater

It should be noted that Region 4 of the EPA has established that “the Region will express objections to Section 404 permit applications that propose to construct control structures in waters of the United States for the express purposes of impounding waters to provide storm water treatment or conveyance in lieu of implementation of the required upland controls.” However, the Region 4 EPA has stated that “In the case where circumstances preclude the use of upland controls, Region 4 will consider an exceptional case exists.” The views of the EPA on in-stream treatment should be carefully considered during the site planning process, as permit authorization will likely be a long process including the satisfaction of the 404(b)(1) guidelines. Upland controls should always be considered first.

Clean Water Act

Section 404 of the Clean Water Act provides regulation of activities affecting waters of the United States. Activities requiring authorization from the U.S. Army Corps of Engineers include the following:

- Construction of piers, marinas, ramps, and cable or pipeline crossings;
- Dredging and excavation in or adjacent to waters of the United States;
- Fill for residential, commercial or recreational developments;
- Construction of revetments, groins, breakwaters, levees, dams, dikes and weirs; and
- Placement of riprap (for channel stabilization)

The U.S. Army Corps of Engineers issues two types of Section 404 permits applicable to the construction industry, General Permits and Individual Permits. It is advisable that you contact the U.S. Army Corps of Engineers District of the proposed project and the MDEQ before site planning to determine if permits are required.



The Section 404 authorization process requires that the developer has taken steps to avoid wetland impacts, minimized the potential impacts on wetlands, and provided compensatory mitigation for any remaining unavoidable impacts. For projects in the Mississippi Coastal Zone (Hancock, Harrison, and Jackson counties) the Mississippi Department of Marine Resources (DMR) acts as the lead regulatory agency, and permit applications are submitted to the DMR Bureau of Wetland Permitting for review. Projects outside of the Mississippi Coastal Zone will submit permit applications to the nearest U.S. Army Corps of Engineers District office.

Section 401 of the Clean Water Act, through the EPA, gives the MDEQ the authority to prohibit an activity, including a construction project, if it can impact water quality or

have other unacceptable environmental consequences. Projects which require a 404 permit will also require a 401 Water Quality Certification from the MDEQ.

References

Appendix B: State and Federal Regulations, Permits and Applications

Appendix J: Local Information

U.S. Army Corps of Engineers District Offices:

U.S. Army Corps of Engineers, Mobile District
Attention: CESAM-OP-S
P.O. Box 2288
Mobile, AL 36628-0001
Phone: 334-690-2658
FAX: 334-690-2660

U.S. Army Corps of Engineers, Vicksburg District
Attention: CEMVK-OD-F
4155 Clay Street
Vicksburg, MS 39183-3435
Phone: 601-631-5276
FAX: 601-631-5459

U.S. Army Corps of Engineers, Memphis District
Attention: CEMVM-CO-GR
Clifford Davis Federal Building
Room B-202
Memphis, TN 38103-1894
Phone: 901-544-3471
FAX: 901-544-3266

U.S. Army Corps of Engineers, Nashville District
Attention: CELRN-CO-F
3701 Bell Road
Nashville, TN 37214-2660
Phone: 615-369-7500
FAX: 615-369-7501

Buffer Zone (BZ)



Figure BZ-1 Buffer Zone in Agricultural Area

Practice Description

A buffer zone is a strip of plants adjacent to land-disturbing sites or bordering streams, lakes, and wetlands that provides streambank stability, reduces scour erosion, reduces storm runoff velocities, and filters sediment in stormwater. This practice applies on construction sites and other disturbed areas that can support vegetation and can be particularly effective on floodplains, next to wetlands, along streambanks, and on steep, unstable slopes.

Planning Considerations

Streams, wetlands, and other waters of United States must be avoided as much as possible in all construction and earth-moving activities. (See the *Introduction to Stream Protection Practice* for more information on the regulations protecting streams, wetlands, and other waters of the United States.)

The width and plant composition of a buffer zone will determine its effectiveness.

There is no ideal width and plant community for buffer zones. A buffer zone 150 feet wide with desirable vegetation is required by the MDEQ to provide significant protection of a perennial stream, water body or wetland. Adjustments can be made to account for the purpose(s) of the buffer and landscape characteristics.

Three zones are typically recognized in the buffer area. If planned to be 45 to 55 feet wide, the recommended width and plant categories are described in the following listings:

Zone 1: The first 15 to 20 feet nearest the stream. Cover is close growing trees (commonly 6 to 10 feet apart).

Zone 2: The next 10 to 15 feet. Cover is trees or trees and shrubs.

Zone 3: The remaining buffer area. Cover is grass or dense groundcover.

Note: All widths are for one side of the stream only and are measured from top of streambank.

Existing vegetation should be considered for retention, especially hardwoods that are in Zones 1 and 2.

Buffer Zone 3 may be established with a grass planting or with close-growing groundcover that will provide dense cover to filter sediment. Where topography accommodates sheet flow from the adjacent landscape, Zone 3 should be retained or developed as a filter strip.

Necessary site preparation and planting for establishing new buffers should be done at a time and manner to ensure survival and growth of selected species.

Buffer zones may become part of the overall landscape of the project.

The layout and density of the buffer should complement natural features and mimic natural riparian forests.

Design Criteria and Construction

Preservation

Evaluate vegetation and landscape features in a proposed buffer zone to determine the potential for the existing plant community to maintain streambank stability, prevent sheet, rill and scour erosion, reduce stormwater velocities, and filter sediment.

Dedicate a vegetated zone to effectively minimize streambank and shoreline erosion, prevent sheet, rill and scour erosion in the buffer zone, and remove sediment from sheet flow from the disturbed area. Initially, estimate a width of 50 feet adjacent to the stream (each side), water body or wetland. Adjust the width to account for slope of the land adjacent to the stream and the purposes of the buffer. If the buffer is planned to trap sediment in sheet flow, the width should be increased 2 feet for every 1% slope measured along a line perpendicular to the streambank and immediately downslope of the disturbed area.

Installation (Plantings)

To determine the width and zone requirements for buffer zone plantings, MDEQ recommends the buffer zone should extend 150 feet from the waterway to be protected. The MDEQ will review cases where the 150-foot buffer zone cannot be achieved. See *Preservation of Vegetation* for more information on width and zone requirements.

Site Preparation

Plan appropriate site preparation to provide a suitable planting medium for grass, or for trees and shrubs.

Plan to install sediment- and erosion-control measures such as a silt fence and diversions if zones are graded before seedbed preparation.

If significant compaction exists, plan for chiseling or subsoiling.

For Zone 3 plantings, clear area of clods, rocks, etc., that would interfere with seedbed preparation; smooth the area, to encourage sheet flow, before the soil amendments are applied and firm the soil after the soil amendments are applied. Follow guidelines in the *Filter Strip Practice* if Zone 3 is to be used to filter sheet flow from the adjacent construction area.

Soil Amendments (Lime and Fertilizer)

Plan soil amendments using design criteria for the appropriate category (see *Permanent Seeding; Tree Planting on Disturbed Areas; and Shrub, Vine and Groundcover Planting Practices*). Incorporate amendments to a depth of 4" to 6" with a disc or chisel plow.

In the absence of a plan or soil test recommendations, apply agricultural limestone at the rate of 2 tons per acre (90 lbs per ft²) and 10-10-10 fertilizer at the rate of 1000 lbs per acre (25 lbs per 1000 ft²). Apply ground agricultural limestone unless a soil test shows pH of 6.0 or greater. Incorporate amendments to a depth of 4" to 6" with a disc or chisel plow.

Planting Desired Vegetation

Plan the vegetation for buffer zones using design criteria given in the *Permanent Seeding, Tree Planting on Disturbed Areas, and/or Shrub, Vine and Groundcover Planting Practices*. No invasive species shall be used. If trees are planted, at least two hardwood species should be used.

Mulching

Spread mulch according to guidelines in the *Mulching Practice*.

Common Problems

Consult with a qualified design professional if any of the following occur:

Soil compaction can prevent adequate plant growth. Compaction should be addressed during site preparation.

Design specifications for plants (variety, seeding/planting dates) and mulch cannot be met; substitutions may be required. Unapproved substitutions could lead to failure.

Problems that require remedial actions:

Erosion, washout and poor plant establishment – repair eroded surface, reseed, reapply mulch and anchor.

Mulch is lost to wind or stormwater runoff – reapply mulch and anchor.

Maintenance

Replant trees, grass, shrubs or vines where needed to maintain adequate cover for erosion control. Maintain grass plantings with periodic applications of fertilizer and mowing.

References

BMPs from Volume 1

Chapter 4

Permanent Seeding (PS)	4-53
Preservation of Vegetation (PV)	4-64
Shrub, Vine and Groundcover Planting (SVG)	4-80
Temporary Seeding (TS)	4-103
Filter Strip (FS)	4-261

BMPs from Volume 2

Chapter 4

Riparian/Forested Buffer

MDOT Drawing PD-1

Typical Planting Details for Trees and Shrubs	4-341
---	-------


Additional Resources

Allen, H.H., and Fischenich, J.C. (1999) “Coir geotextile roll and wetland plants for streambank erosion control,” *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-04), U.S. Army Engineer Research and Development Center, Vicksburg, MS. www.wes.army.mil/el/emrrp.


Fischenich, C. (1999). "Irrigation systems for establishing riparian vegetation," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-12), U.S. Army Engineer Research and Development Center, Vicksburg, MS. www.wes.army.mil/el/emrrp.

Fisher, R.A., and Fischenich, J.C. (2000). “Design recommendations for riparian corridors and vegetated buffer strips,” *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-24), U.S. Army Engineer Research and Development Center, Vicksburg, MS. www.wes.army.mil/el/emrrp.


STATE	PROJECT NO.
MISS.	




B & B AND CONTAINER GROWN PLANTS





BARE ROOT PLANTS
NOTE: METHOD OF "HEELING IN" BEFORE PLANTING CONSISTS OF PLACING THE PLANTS IN A TRENCH AND COVERING THE ROOTS WITH DIRT. THIS MAY BE DONE ON TRUCK FOR EASE OF MOVEMENT. SAW DUST OR OTHER APPROVED MATERIAL MAY BE USED. ROOTS MUST BE KEPT MOIST AT ALL TIMES.




ELEVATION



ROOT PROTECTION ("HEELING-IN") DURING STORAGE



PLAN




PLAN


DOUBLE VERTICAL STAKING METHOD

NOTE: ALL TREES SHALL BE STAKED OR GUYED. THE TRUNK OF ALL SMOOTH BARKED TREES SHALL BE WRAPPED. LARGE SHRUBS TO BE STAKED AND WRAPPED WHEN SPECIFIED ON PLANS.

TREE AND SHRUB PLANTING (BARE ROOT)



TREE AND SHRUB PLANTING (B & B OR CONTAINER GROWN)



ELEVATION

GUYING TRIPOD METHOD

- GENERAL NOTES:
1. THE TYPE(S), RATE(S) OF APPLICATION AND PLACEMENT OF FERTILIZER AND MULCH SHALL BE IN ACCORDANCE WITH THE REQUIREMENTS OF THE PLANS AND SPECIFICATIONS.
 2. TENSION IN GUY WIRES WILL BE SUCH AS TO ALLOW SOME SWAYING MOTION IN TREE.

DESIGNED BY	DATE	MISSISSIPPI DEPARTMENT OF TRANSPORTATION ROADWAY DESIGN DIVISION STANDARD PLAN TYPICAL PLANTING DETAIL FOR TREES & SHRUBS  WORKING NUMBER PD-1 SHEET NUMBER 141
DRAWN BY	DATE	
CHECKED BY	DATE	
ISSUE DATE:	OCTOBER 1, 1998	

Channel Stabilization (CS)



Practice Description

Channel stabilization is stabilizing a channel, either natural or artificial, in which water flows with a free surface. The purpose of this practice is to establish a non-erosive channel. This practice applies to the stabilization of open channels and existing streams or ditches with drainage areas less than 1 square mile. Methods of channel stabilization include rock riprap lining, concrete lining, grade stabilization structures, and bioengineered treatments, i.e., combinations of structural and vegetative materials. Vegetative-based structural reinforcements are preferred, especially in cases with fisheries resources and/or water quality issues.

Note: The design of open-channel conveyance structures other than Grass Swale is beyond the scope of this edition of the Mississippi Erosion and Sediment Control Manual, Volume 1, and should be done by a qualified design professional and should meet applicable state, federal, and local regulatory requirements.

Planning Considerations

This practice applies to the improvement or stabilization of open channels and existing streams or ditches with drainage areas less than 1 square mile. Channels with drainage greater than 1 square mile will be designed with appropriate criteria. In all cases, channel stabilization design should be done by a qualified design professional experienced in hydrology and hydraulics.

An adequate outlet for the channel must be available for discharge by gravity flow. Construction or other improvements to the channel should not adversely affect the

environmental integrity of the area and must not cause significant erosion upstream or flooding and/or sediment deposition downstream.

The alignment and design of channels and stabilization structures shall give careful consideration to the preservation of valuable fish and wildlife habitat and trees of significant value for aesthetic purposes.

Where construction will adversely affect significant fish or wildlife habitat, mitigation measures should be included in the plan. Mitigation measures may include in-stream structures such as pools, riffles, and woody structures, or streamside measures such as trees, shrubs, and other features that enhance wildlife habitat.

Due to the varied nature of these considerations, an interdisciplinary team consisting of engineers, soil bioengineers, hydrologists, and fishery biologists should prepare the design of streambank protection for each unique channel reach. If instability is occurring over a significant length of stream, the team should consider performing a geomorphic analysis of the stream. All local, state and federal laws, especially laws relating to 404 permits, should be followed during the design and construction process.

Design Criteria and Construction

Prior to the start of construction, channel stabilization should be designed by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the construction process.

Consider the following guidance as construction proceeds.

Realignment

The realignment of channels should be kept to an absolute minimum. Where realignment is unavoidable, the realigned channel should be designed to have a stable grade considering the soil type, vegetation, and new channel length.

Channel Capacity

The design capacity of open channels and stabilization structures should be determined by procedures applicable to the purposes to be served.

Hydraulic Requirements

Manning's formula should be used to determine velocities in channels. The "n" values for use in this formula should be estimated using currently accepted guides along with knowledge and experience regarding the conditions. Acceptable guides can be found in hydrology textbooks.

Channel Cross Section

The required channel cross section of new or realigned channels is determined by the design capacity, the bed and bank materials, vegetation, and the requirements for maintenance. A minimum depth may be required to provide adequate outlets for subsurface drains and tributary channels. To enhance fisheries and wildlife, consider a channel cross section configuration that will ensure concentrated and unobstructed flow during periods of low flow, but one that incorporates bioengineered treatments with adequate habitat features to ensure refugia, etc., for fish and wildlife.

Drop Structure

Drop structures are used to reduce or prevent excessive erosion by reduction of velocities in the watercourse or by providing structures that can withstand and reduce the higher velocities. They may be constructed of concrete, rock, masonry, steel, aluminum or non-toxic treated wood.


These structures are constructed where the capability of earth and vegetative measures is exceeded in the safe handling of water at permissible velocities, where excessive grades or overall conditions are encountered, or where water is to be lowered structurally from one elevation to another. These structures should generally be planned and installed along with or as part of other erosion-control practices. The structures must be designed hydraulically to adequately carry the channel discharge and structurally to withstand loadings imposed by the site conditions, but must allow fish to traverse if the stream has fish inhabitation. Therefore, a fisheries biologist should be consulted before the design is finalized and the structure installed.

Channel Stability

All channel construction, improvement and modification should be in accord with a design expected to result in a stable channel that can be maintained.

Characteristics of a stable channel are:

- It neither aggrades nor degrades beyond tolerable limits.
- The channel banks do not erode to the extent that the channel cross section is changed appreciably.
- Excessive sediment bars do not develop.
- Excessive erosion does not occur around culverts, bridges or elsewhere.
- Gullies do not form or enlarge due to the entry of uncontrolled surface flow to the channel.
- The determination of channel stability considers “bankfull” flow.
- Bankfull flow is defined as the flow in the channel which creates a water surface that is at or near normal ground elevation for a significant length of a channel reach. Excessive channel depth created by cutting through high ground, such as might result from realignment of the channel, should not be considered in determinations of bankfull flow.



The design for channels in natural materials shall be considered stable if the check velocity is less than the allowable velocities shown in Table CS-1. The check

velocity is defined as the lesser of the bankfull velocity or the 10-year frequency peak discharge velocity.

Table CS-1 Allowable Velocities for Various Soil Textures

Soil Texture	Allowable Velocity (ft/sec.)
Sand and Sandy Loam (noncolloidal)	2.5
Silt Loam (also high lime clay)	3.0
Sandy Clay Loam	3.5
Clay Loam	4.0
Stiff Clay, Fine Gravel, Graded Loam to Gravel	5.0
Graded Silt to Cobbles (colloidal)	5.5
Shale, Hardpan and Coarse Gravel	6.0

Scheduling

Installation scheduling should be phased according to the following considerations. Hard structures such as rock and other inert materials could be installed during a period not suitable for vegetative establishment whereas vegetation could be planted during the appropriate time for more assurance of its survival. For instance, vegetation would be better established in the late winter/early spring after hard structures have been installed or concurrent with hard structure installation, depending on the design plan. Hard structures could be installed during a construction season prior to vegetative establishment with the vegetation being installed the following spring. For vegetation on high banks (those areas used for the adjoining *Streambank Protection*), schedule that installation during a planting period tailored for optimum survival of the plant species used. In addition, use local weather forecasts to avoid installation activities during rain events that can potentially create abnormal flows and flooding.

Site Preparation

Follow all local, state and federal government regulations on stream modifications.

Determine exact location of all underground activities.

Remove trees, brush, stumps and other objectionable materials according to the design plan. Where possible, vegetation will be left standing and stumps will not be removed.

Spoil material resulting from clearing and grubbing should be disposed of according to the design plan.

The foundation for structures should be cleared of all undesirable materials prior to the installation of the structures.

Channel Linings and Structural Measures

Where channel velocities exceed safe velocities for bare soil, channel linings of rock, concrete, or other durable material may be needed. Grade stabilization structures may also be needed.

Total channel linings covering the entire cross section of the stream are discouraged if the stream is inhabited by fisheries and other biota. Alternatively, a bioengineered stream is preferred that incorporates a zoned approach, such as a rocked toe and then vegetative treatments on the mid- and upper-banks. For more information, please review “Appendix B—Bioengineering for Streambank Erosion Control, Guidelines” of *The WES Stream Investigation and Streambank Stabilization Handbook* referenced at the end of this section. Total covering of ditches with channel linings may be appropriate if they are used solely for drainage and erosion control.

One or more of the following methods can be used to stabilize channels or portions of channels given the above considerations, i.e., whether a stream or a ditch.

Rock Riprap Lining

Rock riprap should be designed to resist displacement when the channel is flowing at the bankfull discharge or the 10-year 24-hour frequency discharge, whichever is the lesser. Rock riprap lining should not be used when channel velocities exceed 10 feet per second unless a detailed engineering analysis is performed using appropriate guidelines.

Use Figure CS-1 to determine the stable basic stone weight (d_{100}). Using the d_{100} size as a d_{90} , select a commercially available riprap gradation as classified by the Mississippi Department of Transportation, from Table CS-2.

Dumped and machine-placed riprap should be installed on slopes flatter than 2 horizontal to 1 vertical. Where riprap is placed by hand, the slopes may be steeper. Stone for riprap should consist of field stone or rough unhewn quarry stone of approximately rectangular shape. The stone should be hard and angular and of such quality that it will not disintegrate on exposure to water or weathering, and it should be suitable in all other respects for the purpose intended. The specific gravity of the individual stones should be at least 2.5.

A filter blanket should be placed between the riprap and base material, if needed. A filter blanket is a layer of material placed between the riprap and the underlying soil surface to prevent soil movement into or through the riprap. A filter blanket should be considered where soils have a high piping potential and/or there is significant seepage of groundwater from the bed or banks.




Figure CS-1 Ishbash Curve

Procedure

- 1) Determine the design velocity.
- 2) Use design velocity and Figure CS-1 to determine d_{100} rock size.
- 3) Use d_{100} from Figure CS-1 as d_{90} to select rock gradation from Table CS-2.

Table CS-2 Commercially Available Riprap Gradations

Class	Weight (lbs.)					
	d_{10}	d_{15}	d_{25}	d_{50}	d_{75}	d_{90}
1	10	-	-	50	-	100
2	10	-	-	80	-	200
3	-	25	-	200	-	500
4	-	-	50	500	1000	-
5	-	-	200	1000	-	2000

A filter blanket can be of two general forms: a gravel layer or a geotextile filter cloth. Gravel filter blankets are to be designed in accordance with the criteria below.

Gravel Filter Blanket

The following relationships must exist:

$$\frac{d_{15} \text{ filter}}{d_{85} \text{ base}} < 5 < \frac{d_{15} \text{ filter}}{d_{15} \text{ base}} < 40$$

$$\frac{d_{50} \text{ filter}}{d_{50} \text{ base}} < 40$$

In these relationships, filter refers to the overlying material and base refers to the underlying material. The relationships must hold between the filter material and the base material and between the riprap and the filter material. In some cases, more than one layer of filter material may be needed. Each layer of filter material should be approximately 6" thick.

Geotextile Filter Cloth

Geotextile filter cloth may be used in place of or in conjunction with gravel filters. Geotextile will meet the requirements of Class I geotextile as shown in Table CS-4.

Filter blankets should always be provided where seepage from underground sources threatens the stability of the riprap.

Rock Riprap Lining Installation

Where excavation is required, channels will be excavated from one side, leaving vegetation on the opposite side.

Excavation should be at the locations and grades shown on the drawings.

Spoil material resulting from channel excavation should be disposed of according to the design plan.

If required by the plans, place geotextile fabric or a granular filter as a bedding material for the riprap. Install riprap of the specified gradation to the lines and grades shown in the design plan. Ensure that the subgrade for the filter and riprap follows the required lines and grades shown in the plan.

Riprap may be placed by equipment. Care should be taken to avoid punching or tearing of the filter cloth during placement of rock. Repair any damage by removing the riprap and placing another piece of filter cloth over the damaged area. All connecting joints should overlap a minimum of 1.5 feet so that the upstream piece of fabric lies on top of the downstream piece of fabric. If the damage is extensive, replace the entire filter cloth.

Installation usually includes some bank shaping. If bank shaping is included, follow details in the design plan and refer to the construction guidelines in *Streambank Protection Practice*.

Concrete Lining

Concrete linings should be designed according to currently accepted guides for structural and hydraulic adequacy. They must be designed to carry the required discharge and to withstand the loading imposed by site conditions. Concrete linings are generally used when velocities exceed 10 ft/sec. Erosion at the outlet of concrete-lined channels is generally a problem due to the high velocities. Measures should be taken to reduce the velocity and erosion potential at the outlet by use of outlet protection measures (see *Outlet Protection Practice*).

Concrete Lining Installation

Where excavation is required, channels will be excavated from one side, leaving vegetation on the opposite side.

Excavation should be at the locations and grades shown on the drawings.

Spoil material resulting from channel excavation should be disposed of according to the design plan.

Install concrete lining using concrete of the specified design strength according to the lines and grades in the design plan.

Installation of concrete linings usually includes some bank shaping. If bank shaping is included, follow details in the design plan and refer to the construction guidelines in *Streambank Protection Practice*.

Place filter material and weep holes according to the plans. Place concrete according to American Concrete Institute standards. Concrete on sloping surfaces should be placed from the bottom of the slope toward the top, at the required thickness, and with good vibration.

As required by the design plan, install expansion joints at the locations shown in the plan.

As required by the design plan, install welded wire fabric in the concrete forms before placing concrete.

Divert flow around the concrete lining until the concrete has reached 75% of its design strength (usually 7 days after concrete placement).

Table CS-4 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ³
Tensile strength (lb) ¹	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ¹	ASTMD 4632	≥50	≥50	≥50	≥50
Puncture (pounds)	ASTMD 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD 4751	As specified max. #40 ²			
Permittivity sec ⁻¹	ASTMD 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

- 1 Minimum average roll value (weakest principal direction).
- 2 U.S. standard sieve size.
- 3 Heat-bonded or resin-bonded geotextile may be used for Classes III and IV. They are particularly well suited to class IV. Needle-punched geotextile is required for all other classes.

Grade Stabilization Structures

For streams with fish inhabitation, a fisheries biologist should be consulted before the design is finalized and the structure installed, to ensure fish transport will not be adversely affected by the structure.

Where excavation is required, channels will be excavated from one side, leaving vegetation on the opposite side.

Excavation should be at the locations and grades shown on the drawings.

Spoil material resulting from clearing, grubbing and channel excavation should be disposed of according to the design plan.

Install the structure to the lines and grades shown in the design plan.

If earthfill is required, install according to the design plan and refer to the construction guidelines for *Sediment Basin* embankments.

If rock riprap is required, install according to the design plan and refer to the installation requirements listed earlier for *Riprap-Lined Swale*.

Other products used, including concrete, masonry, steel, aluminum or treated wood, should be installed according to details in the design plan. Installation usually includes

some bank shaping. If bank shaping is included, follow details in the design plan and refer to the construction guidelines in the *Streambank Protection Practice*.

Erosion Control

Seeding, fertilizing and mulching of the disturbed areas should be done immediately after construction and should conform to the guidelines in the design plan. If vegetation establishment specifications are not included in the design plan, see the appropriate practice (*Permanent* or *Temporary Seeding*) for guidelines. If planting needs to be deferred until the next planting season, the disturbed areas should be protected with mulch (see *Mulching Practice* if details are not included in the design plan).

Safety

Store all construction materials well away from the stream. Consider weather forecasts when determining risks of damage by flooding.

Equipment used to construct channel stabilization measures should be free of leaks of fuel and hydraulic fluids to prevent contamination of surface waters. Operation of equipment in the stream should be minimized. At the completion of each workday, move all construction equipment away from the stream to prevent damage to equipment by flooding. Consider weather forecasts when determining risks of flooding.

The following precautions should be taken:

- Exercise caution on steep slopes.
- Fence the area and post warning signs if trespassing is likely.
- All equipment used for practice installation should be free of leaks of gas, oil, and hydraulic fluid. Measures should be in place to prevent accidental spills from entering the stream.
- Equipment should not be operated within flowing water in the stream.

Construction Verification

Check material and finished grades to determine if job meets specifications in the design plan.

Common Problems

Variations in site conditions indicate practice will not function as intended; changes in plan may be needed.

Design specifications for materials cannot be met; substitution may be required. Unapproved substitutions could result in failure of the practice.

Maintenance

All structures should be maintained in an “as built” condition.

Check the stream channel at the construction site after each major event until the job is considered mature and a success.

Structural damage caused by storm events should be repaired as soon as possible to prevent further damage to the structure or erosion of the streambank.

Unwanted brush or excessive sediment that will impede flow should be removed to maintain design conditions.

References

BMPs from Volume 1

Chapter 4

Mulching (MU)	4-48
Permanent Seeding (PS)	4-53
Preservation of Vegetation (PV)	4-64
Shrub, Vine and Groundcover Planting (SVG)	4-80
Temporary Seeding (TS)	4-103
Tree Planting on Disturbed Areas (TP)	4-110
Outlet Protection (OP)	4-199
Riprap-Lined Swale (RS)	4-210
Filter Strip (FS)	4-261
Sediment Basin (SBN)	4-298
Streambank Protection (SP)	4-362

BMPs from Volume 2

Chapter 4

Riparian/Forested Buffer
Vegetated Filter Strip

Additional Resources

Allen, H.H., and Fischenich, J.C. (1999) "Coir geotextile roll and wetland plants for streambank erosion control," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-04), U.S. Army Engineer Research and Development Center, Vicksburg, MS. www.wes.army.mil/el/emrrp.

Biedenharn, D.S., Elliot, C.M., and Watson, C.C. (1997) "The WES Stream Investigation and Streambank Stabilization Handbook." <http://chl.erdc.usace.army.mil/Media/2/8/7/StreambankManual.pdf>.

Fischenich, C. (1999). "Irrigation systems for establishing riparian vegetation," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-12), U.S. Army Engineer Research and Development Center, Vicksburg, MS. www.wes.army.mil/el/emrrp.

Fisher, R.A., and Fischenich, J.C. (2000). "Design recommendations for riparian corridors and vegetated buffer strips," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-24), U.S. Army Engineer Research and Development Center, Vicksburg, MS. www.wes.army.mil/el/emrrp.

Stream Diversion Channel (SDC)



Practice Description

A stream diversion channel is a temporary practice to convey stream flow in an environmentally safe manner around or through a construction site while a permanent structure or conveyance is being installed in the stream channel.

Planning Considerations

Construction projects often cross and impact live streams, creating a potential for excessive sediment delivery into the stream. In cases where in-stream work is unavoidable, a temporary stream diversion channel should be planned. In-stream projects of this nature are subject to the rules and regulations of the U.S. Army Corps of Engineers for in-stream modifications (Clean Water Act Section 404 permit) and, if applicable, MDEQ CWA Section 401 water quality certification. Temporary stream diversions shall be used only on streams with a drainage area less than 1 square mile (640 acres). Detailed engineering analysis and design should be used for larger drainage areas to ensure a stable diversion channel. For sites with very small drainage areas, the designer may consider temporary blocking and overland pumping of the stream. To avoid crossing a live stream, the planner or designer should consider allowing access for construction of the permanent structure only from the side opposite the stream diversion channel. At locations where access from both sides of the stream is required to construct the permanent structure in the stream channel, a *Temporary Stream Crossing (TSC)* may be necessary. It is best to locate this crossing either up- or down-stream of the stream diversion channel.

Vegetation along the existing stream channel should be left undisturbed and protected with effective sediment-control practices until such time as the diversion channel is constructed and can safely convey stream flows. Construction equipment should not be allowed to operate in flowing waters and should be operated and maintained according to the *Housekeeping (HK) Practice*. Excavated materials should be stockpiled away from the stream and diversion channel and protected to ensure the material does not erode and

enter the stream system. The stream diversion channel should be planned and installed in such a manner and time (dry season) that the impact to fisheries and the aquatic environment is minimized. A pictorial representation of a stream diversion channel is shown in Figure SDC-1.




Figure SDC-1 Typical Stream Diversion Channel Layout

Design Criteria and Construction

Prior to the start of construction, stream diversion channels are required to be designed by a qualified design engineer registered in the State of Mississippi.

Size

The combination of bottom width, depth, and gradient shall be sufficient to provide the required flow capacity. The minimum bottom width of the stream diversion channel shall be 6 feet or equal to the bottom width of the existing stream bed, whichever is greater. The bottom surface should be shaped or configured to ensure adequate concentrated and unobstructed flow of water during periods of low flow.

Side Slope

Side slopes of the stream diversion channel shall be no steeper than 2 horizontal to 1 vertical (2:1).

Gradient

The diversion bottom grade may be variable, dependent on site conditions, but shall be sufficient to ensure continuous flow of water in the diversion at velocities not exceeding the allowable velocities for the selected channel lining material. The stream diversion channel length should be the same or greater than the length of the stream diverted.

Capacity

The capacity of the stream diversion channel shall be at least bankfull capacity of the existing stream. Consideration should be given to providing greater capacity where construction is expected to extend over several weeks or months.

Channel Lining

The stream diversion channel shall be lined to prevent erosion of the channel and sedimentation in the stream. The lining should be selected based on the velocity at bankfull flow. Use Table SDC-1 for general guidance on the type of lining to be used. Pre-manufactured products, like turf reinforcement mats (TRM), cellular blocks, and similar products, shall be designed and installed according to the manufacturer's recommendations.

Table SDC-1 Stream Diversion Channel Linings

Lining Materials	Acceptable Velocity Range
Geotextile fabric, polyethylene film, light-weight TRM, block sod	0 – 2.5 fps
Geotextile fabric, heavy-weight TRM	2.5 – 9.0 fps
Class I riprap and geotextile	9.0 – 13.0 fps

Riprap linings shall be designed in accordance with the guidance contained in the *Channel Stabilization (CS) Practice*. Class I non-woven geotextile shall be used underneath riprap lining for high-velocity applications.

When rolled products such as polyethylene film or geotextile fabric are used as a channel lining, the product should be placed so that one width of material will cover the entire channel bottom and slopes, while also providing enough material for a minimum 6-inch anchorage at the top of the bank. The upstream end of the material shall be buried at least 2 feet from top-of-bank to top-of-bank with additional trench anchorages of at least 1 foot by 1 foot at 50-foot intervals. Upstream sections of material shall overlap downstream sections by at least 2 feet, and overlap should occur at a trench anchorage location. Polyethylene film shall be at least 6 mil thick and capable of maintaining strength against the effects of ultraviolet light for a period of at least 60 days.

Block sod shall be covered with erosion-control netting and staked at minimal 3-foot by 3-foot spacing, and also staked at the upstream edge of each piece of sod.

Transitions

Additional protection such as riprap may be needed at the entrance and exit portion of the stream diversion channel to ensure velocities do not scour the existing stream bed or bank.

Sequence of Construction

To minimize detrimental effects to the environment and the aquatic community, the stream diversion channel should be quickly and carefully installed, well maintained, and removed as soon as possible when the construction area is stable. A sequence of construction should be specified in the contract work. While the sequence of construction should be tailored to the specific site, the general process should be as follows:

- Install sediment barrier at locations alongside stream to intercept runoff from the construction of the stream diversion channel.
- Install sediment barrier around or downstream of stockpile location.
- Maintain vegetation around stream.
- Clear downstream portion of stream diversion channel except for the area of the temporary plug.
- Begin excavation of the stream diversion channel at least 25 feet from the outlet and maintain this undisturbed plug.
- Stockpile excavated material at designated location and clear additional portions of the stream diversion channel as needed for excavation operations.
- Complete the excavation and leave at least a 25-foot undisturbed plug at the entrance to the stream diversion channel.
- Dewater the excavated area as needed for installation of the lining, and pump the dewatered material to a settling basin before any discharge is allowed.
- Install the lining in diversion channel.
- Excavate the downstream plug and install the transition riprap.
- Adjust sediment barrier locations as needed for stream protection.
- Excavate the upstream plug and install the transition riprap.
- Install an upstream flow barrier, forcing flow into the diversion channel.
- Allow time for aquatic organisms to move or migrate downstream.
- Install a downstream flow barrier if needed.
- Seed and mulch the stockpile and the disturbed area around the stream diversion channel.
- Complete the “in-stream” work.
- Divert flow into the completed “in-stream” conveyance system.
- Place sediment barriers for protection while decommissioning the stream diversion channel.
- Remove channel linings as needed, recycle or properly dispose of the material.
- Place excavated material into diversion channel.
- Apply seed and mulch to disturbed areas.

Site Preparation

Determine exact location of underground utilities.

Maintain vegetation around the stream until the stream diversion channel has been fully completed including vegetation. Clear only enough of the stream-diversion channel area for the next day’s work.

The centerline of the stream diversion channel should be established in the plans or by the responsible engineer. Slope and grade stakes should be established for use during excavation.

Erosion and Sediment Control

Sediment barrier or other sediment-control practices to protect the stream from the construction of the diversion channel should be installed prior to any land disturbance. The stockpile for excavated material should be located well away from the work area with sediment-control practices installed prior to placement of stockpiled materials. All construction areas should be seeded and mulched as soon as work is complete. Maintain a minimum 25-foot vegetated grass filter around the stream diversion channel.

Excavation

A 25-foot undisturbed plug should be left at the exit and entrance of the stream diversion channel until the diversion channel itself has been finished. The stream diversion channel should be excavated according to the dimensions and grade shown in the construction plans, beginning at the downstream end next to the plug and continuing in an upstream direction. The grade of the stream diversion channel should be uniform and continuous in order to tie into the existing stream bottom elevations without any overfalls that would create turbulence. Construction equipment should not be allowed to operate in flowing waters. Construction equipment should be well maintained to prevent drip/leaks of oil, hydraulic fluid, etc. Water that collects in the stream diversion channel excavation should be pumped as necessary to a settling basin prior to its discharge. The excavated material should be hauled to the stockpile location.

Lining Placement

Different lining materials can be specified for the stream diversion channel. Install the selected linings according to the construction specifications.

When rolled products like polyethylene film or geotextile fabric are specified for use as a channel lining, the product should be placed so that one width of material will cover the entire channel bottom and slopes while also providing enough material for a minimum 6-inch anchorage at the top of the bank. The upstream end of the material shall be buried at least 2 feet from top-of-bank to top-of-bank with additional trench anchorages of at least 1 foot by 1 foot at 50-foot intervals. Upstream sections of material shall overlap downstream sections by at least 2 feet and occur at a trench anchorage location. Polyethylene film shall be at least 6 mil thick and capable of maintaining strength against the effects of ultraviolet light for a period of at least 60 days.

Pre-manufactured products, such as turf reinforcement mats (TRM), cellular blocks, and other similar products, shall be designed and installed according to the manufacturer's recommendations.

Block sod shall be covered with erosion-control netting and staked at minimal 3-foot by 3-foot spacing, and also at the upstream edge of each piece of sod.

Generally, Class I non-woven geotextile fabric is used underneath riprap linings. Additional protection such as riprap may be needed at the entrance and exit portions of the stream diversion channel to ensure scour does not occur in the existing stream bed or bank.

Stream Diversion

After the lining between the upstream and downstream plugs has been installed, the downstream plug should be removed first and the transition installation completed. Next, the upstream plug should be removed and the transition installation completed. Finally, the stream flow should be diverted into the stream diversion channel using an upstream flow barrier, as specified in the plans and in such a manner as to minimize sediment delivery into the stream. Allow time for the stream to drain so that aquatic organisms have an opportunity to move or migrate downstream. The downstream flow barrier, if required, can then be installed so that work can commence for the installation of the permanent structure.

Construction Verification

Check finished grades and cross sections throughout the length of the stream diversion channel.

Verify the stream diversion channel cross-section dimensions at several locations to confirm plan specifications.

Common Problems

Consult with a qualified design professional if any of the following occur:

The topography of the site does not allow the practice to function as intended and changes in the plan are needed.

The design specifications for materials cannot be met and substitutions may be necessary. Unapproved substitutions could result in an unstable diversion channel.

Maintenance

Inspect the stream diversion channel at regular intervals and especially after storm events; check for lining displacement, erosion of the lining, and erosion at the transition areas.

Repair damaged lining and erosion promptly.

Once the permanent structure has been completed, flow can be diverted into the new conveyance structure and the stream diversion channel decommissioned. The decommissioning should occur in such a manner as to minimize erosion and sediment runoff into the stream system. Lining materials should be recycled or disposed of properly.

References

BMPs from Volume 1

Chapter 4

Housekeeping (HK)	4-43
Channel Stabilization (CS)	4-342
Temporary Stream Crossing (TSC)	4-382


MDOT Drawing ECD-17

Temporary Stream Diversions 4-360


MDOT Drawing ECD-18

Temporary Stream Diversions (Box Extensions) 4-361


STATE	PROJECT NO.
MSS.	




CULVERT CONSTRUCTED WITHIN EXISTING STREAM



CULVERT CONSTRUCTED OUTSIDE EXISTING STREAM



TEMPORARY DIVERSION CHANNEL WITH GEOTEXTILE FABRIC



TEMPORARY CULVERT USED DURING CONSTRUCTION

- NOTES:
- TEMPORARY DIVERSION CHANNELS MAY BE USED TO DIVERT NORMAL STREAM PATH FLOW FROM AN ERODIBLE AREA UNTIL SUCH AREAS CAN BE STABILIZED.
 - TYPE III FILTER FABRIC OR PRE-FAB DITCH LINER MAY BE USED FOR CHANNEL LINING.
 - RIP-RAP WITH FILTER FABRIC MAY BE USED FOR CHANNEL FLOW VELOCITIES OF 3.0 FPS TO 9.0 FPS. THE RIP-RAP SHALL BE SIZED 300 LB
 - LOCATIONS OR TYPES OF TEMPORARY DIVERSION WILL NOT BE SHOWN ON THE PLANS
 - DIVERSION CHANNEL SHALL BE STABILIZED AND INSPECTED BY THE ENGINEER BEFORE FLOW IS DIVERTED.
 - DURING CONSTRUCTION OF DIVERSION CHANNEL, DAMAGE TO THE EXISTING STREAM, CANOPY REMOVAL, AND DEPTH OF THE CHANNEL CONSTRUCTION SHALL BE MINIMIZED.
 - CONSTRUCTION OF THE CHANNEL RELOCATIONS AND CULVERTS SHALL PROCEED AS FOLLOWS:
 - CONSTRUCT A HEADINGING TEMPORARY CHANNEL CHANGE ADJACENT TO THE PROPOSED CULVERT TO DIVERT WATER TEMPORARILY DURING THE CULVERT CONSTRUCTION. TEMPORARY EROSION CONTROL MEASURES SHALL BE INSTALLED IN ACCORDANCE WITH THE STANDARD SPECIFICATIONS.
 - RELOCATE CHANNEL AND CONSTRUCT CULVERT SIMULTANEOUSLY.
 - SID AND/OR RIP-RAP RECONSTRUCTED BANKS AT TRANSITIONS. THE UPPER CHANNEL PLUG IS TO REMAIN IN PLACE UNTIL SUBNOTE (7.1) THROUGH (7.4) UNDER THIS HEADING ARE COMPLETED TO INSURE THAT ALL CONSTRUCTION IS IN THE DRY.
 - IF AN EARTH PLUG IS NECESSARY AT THE DOWNSTREAM END OF THE CHANNEL IT SHOULD BE REMOVED FIRST, THEN REMOVE THE UPPER PLUG TO RELEASE WATER INTO THE RECONSTRUCTED CHANNEL.
 - PLUGS SHOULD REMAIN IN PLACE UNTIL PERMANENT STABILIZATION OF THE NEW WATER COURSE IS COMPLETED. REMOVAL OF PLUGS SHOULD ONLY BE PERFORMED FOLLOWING ACCEPTANCE OF ALL STABILIZATION WORK BY THE ENGINEER.
 - THE DETAILS PROVIDED DEPICT TYPICAL TEMPORARY DIVERSION CHANNELS.
 - THE CONTRACTOR MAY PROPOSE THE USE OF OTHER DIVERSION OPTIONS SUCH AS PIPING, PUMPING OR STAGED CONSTRUCTION.
 - THE EFFECTIVE AREA OF FLOW IN THE TEMPORARY CHANNEL OR CULVERT SHALL BE AT LEAST ONE-HALF THAT OF THE EXISTING STRUCTURE.

DATE	BY	MISSISSIPPI DEPARTMENT OF TRANSPORTATION
	REVISION	TEMPORARY STREAM DIVERSION
DATE	FILENAME	EROSION CONTROL#ECD-17.DGN
DATE	CHECKED	DATE
		WORKING NUMBER ECD-17
		SHEET NUMBER


STATE	PROJECT NO.
MSS.	

DIAMETER OF PIPE (IN.)	STEEL THICKNESS (IN.)				
	0.064	0.079	0.109	0.138	0.168
	2" X 1/2" CORRUGATION				
24	13	15	20		
36	12	15	20	25	
48	11	14	19	25	30
60		14	19	24	29
72			18	24	29
5" X 1" OR 3" X 1" CORRUGATION					
36	9	11	15		
48	9	11	15		
60	9	10	14	18	
72	9	10	14	18	22

FOR PIPE SIZES NOT SHOWN REFER TO NEXT LARGER SIZE


GENERAL NOTES

- SUSPENDED PIPE DIVERSIONS MAY BE USED TO ALLOW BOX CULVERT EXTENSIONS TO BE CONSTRUCTED WHILE SEPARATED FROM FLOWING WATER, THUS REDUCING SEDIMENTATION. OPTIONAL FLEXIBLE PIPE DIVERSION MAY BE UTILIZED ON STREAMS WITH INTERMITTENT FLOW WHERE THE DURATION OF CONSTRUCTION IS EXPECTED TO BE BRIEF.
- EXCAVATION SLOPES FOR BOX CULVERT EXTENSIONS SHALL BE PROTECTED WITH TYPE #1 FILTER FABRIC PRIOR TO CONSTRUCTION OF THE BOX.
- SUSPENDED PIPE DIVERSIONS MAY BE USED WHERE ADVERSE IMPACTS WILL NOT BE CAUSED BY WATER PONDED UPSTREAM OF THE PIPE.
- THE SANDBAG PLUG AT THE UPSTREAM END OF THE SUSPENDED PIPE DIVERSION SHOULD BE CONSTRUCTED TO A HEIGHT EQUAL TO THREE QUARTERS OF THE RISE OF THE BOX CULVERT.
- POLYETHYLENE SHEETING (6 MIL. MINIMUM) SHALL BE PLACED INSIDE THE SANDBAG PLUG IN THE BOX CULVERT AND IN THE SAND BAG BERM WITHIN THE CHANNEL IN ORDER TO PROVIDE THE BEST POSSIBLE SEAL. SANDBAGS ON THE DOWNSTREAM SIDE OF THE SHEETING SHOULD BE PLACED FIRST, AND THEN SHEETING PLACED ON THESE BAGS AS MUCH AS POSSIBLE. THE SHEETING SHOULD BE FITTED AROUND THE PIPE. THE REMAINING SANDBAGS WOULD THEN BE PLACED ON THE SHEETING. WHERE MULTIPLE SHEETS ARE USED, THEY SHOULD OVERLAP A MINIMUM OF 18 INCHES.
- THE PROPOSED CULVERT CONSTRUCTION SHALL BE SEALED FROM THE EXISTING STREAM BY MEANS OF A SANDBAG BERM WHICH SHOULD BE AT THE SAME HEIGHT AS THE PLUG INSIDE THE BOX CULVERT. THIS BERM SHALL BE TIED INTO EITHER HIGH GROUND ADJACENT TO THE CHANNEL OR THE EXISTING ROADWAY EMBANKMENT. IT SHALL BE PROVIDED WITH A SPILLWAY EQUAL IN WIDTH TO THE BOX CULVERT AND AT A HEIGHT LOWER THAN THE REST OF THE BERM.
- THE TEMPORARY DRAINAGE PIPE SHALL BE SUPPORTED AT ALL JOINTS AND AT INTERVALS NOT TO EXCEED MAXIMUM VALUES SPECIFIED IN THE TABLE "MAXIMUM SPAN FOR SUPPORTS". SUPPORTS AT JOINTS SHALL BE A MINIMUM OF 18 INCHES IN LENGTH ALONG THE TEMPORARY DRAINAGE PIPE AND CENTERED ON THE JOINT. SUPPORTS SHOULD "CRADLE" THE TEMPORARY DRAINAGE PIPE TO ENSURE THAT IT WILL NOT ROLL DURING CONSTRUCTION OF THE BOX CULVERT.
- ALL PIPE JOINTS SHALL BE PROPERLY BANGED OR OTHERWISE PROVIDED WITH A REASONABLE SEAL AGAINST LEAKAGE.
- THE OPTIONAL FLEXIBLE PIPE DIVERSION USING PUMPS MAY BE USED AS AN ALTERNATE FOR SUSPENDED PIPE DIVERSIONS (UPSTREAM AND DOWNSTREAM).
- CONSTRUCTION SHALL PROCEED AS FOLLOWS:
 - INSTALL TEMPORARY DRAINAGE PIPE ON ITS SUPPORTS INSIDE THE CULVERT TO BE EXTENDED.
 - CONSTRUCT THE SANDBAG PLUG AT THE UPSTREAM END OF THE SUSPENDED PIPE DIVERSION.
 - CONSTRUCT THE SANDBAG BERM AT THE DOWNSTREAM END OF THE SUSPENDED PIPE DIVERSION.
 - ONCE THE BOX CULVERT EXTENSION HAS BEEN COMPLETED, REMOVE THE DOWNSTREAM SANDBAG STRUCTURE.
 EXCEPT FOR THOSE BAGS NEEDED TO SUPPORT THE END OF THE PIPE, THE UPSTREAM SANDBAG STRUCTURE SHOULD THEN BE REMOVED GRADUALLY, IN ORDER TO ALLOW THE UPSTREAM WATER LEVEL TO DRAW DOWN AT A SAFE RATE.
- REMOVE THE TEMPORARY DRAINAGE PIPE, SUPPORTS AND ANY REMAINING SANDBAGS.
- TEMPORARY DRAINAGE PIPE, SANDBAG PLUGS, BERMS, AND SUPPORTS SHALL BE INSPECTED WEEKLY OR AFTER EVERY RAIN EVENT. ANY NEEDED REPAIRS SHALL BE DONE IMMEDIATELY. ANY DEBRIS WHICH HAS ACCUMULATED AT THE INLET OF THE SUSPENDED PIPE DIVERSION SHALL BE IMMEDIATELY REMOVED.
- RIP RAP MAY BE SUBSTITUTED FOR SAND BAGS




SECTION B-B

PLAN VIEW




SAND BAG PLUG & BERM CROSS SECTION
(SEE NOTE 4)



SECTION A-A

BY		MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
DATE		TEMPORARY STREAM DIVERSION (BOX EXTENSIONS)	
DESIGN TEAM		WORKING NUMBER ECD-18	
		SHEET NUMBER	
FILENAME: EROSION_CONTROL/ECD-18.DGN		CHECKED: JWC	

Streambank Protection (SP)



Practice Description

Streambank protection is the stabilization of the side slopes of a stream. Streambank protection can be vegetative, structural, or a combined method (bioengineering) in which live plant materials are incorporated into a structure. Vegetative protection is the least costly and the most compatible with natural stream characteristics. Additional protection is required when hydrologic conditions have been greatly altered and stream velocities are excessively high. Streambank protection is often necessary where failure mechanisms cause erosion. According to Fischenich and Allen (2000), banks fail and erode because they exist in a dynamic environment that is constantly subjected to various forces. River banks fail in one of four ways: 1) hydraulic forces remove erodible bed or bank material; 2) geotechnical instabilities result in bank failures; 3) mechanical actions cause a reduction in the strength of the bank; or 4) a combination of the above factors causes failure. These modes of failure have distinct characteristics. An investigation must be conducted to determine the specific mode of failure because this is indicative of the problem. These modes of failure are further discussed in Fischenich and Allen (2000). Streambank protection is often necessary in areas where development has occurred in the upstream watershed and full channel flow occurs several times a year.

Planning Considerations

Since there are several different methods of streambank protection, the first step in the design process is a determination of the type protection to be used at the site. Items to consider include:

- Overall condition of the stream within and adjacent to the reach to be stabilized.
- Current and future watershed conditions.

- Amount of discharge at the site.
- Flow velocity at the site.
- Sediment load in the stream.
- Channel slope.
- Controls for bottom scour.
- Soil conditions.
- Present and anticipated channel roughness.
- Compatibility of selected protection with other improvements at the site.
- Changes in channel alignment.
- Fish and wildlife habitat.

Due to the varied nature of these considerations, an interdisciplinary team consisting of engineers, soil bioengineers, hydrologists, and fishery biologists should prepare the design of streambank protection for each unique channel reach. If instability is occurring over a significant length of stream, the team should consider performing a geomorphic analysis of the stream. All local, state, and federal laws, especially laws relating to Clean Water Act Section 404 permits, should be followed during the design and construction process.

Design Criteria and Construction

Velocities

As a general rule, use vegetation alone with velocities up to 6 ft/sec if the stream bottom is stable. Use structural (to include soil bioengineered) protection for velocities greater than 6 ft/sec. The design velocity should be the velocity associated with the peak discharge of the design storm for the channel. Any protection method should take into consideration a variety of site conditions, to include an analysis of failure mechanisms, and should be designed and/or reviewed by the aforementioned interdisciplinary team.

Channel Bottom

The channel bottom must be stabilized before installing bank protection. Grade control in the channel bottom may be needed to prevent downcutting (see *Channel Stabilization Practice*).

Permits

All local, state, and federal laws should be complied with during the design and construction of bank protection. If fill is to be placed in wetlands or streams, the U.S. Army Corps of Engineers should be contacted regarding a 404 permit for the work.

Aquatic Zone

This area includes the stream bed and is normally submerged at all times. No planting is required in this zone.

Wetland Plants/Shrub Zone

This zone is on the bank slopes above mean water level and is normally dry except during floods. Plants with high root densities, high root shear and tensile strength, and an ability to transpire water at high rates are recommended for this zone. Willows, silver maples, and poplars are examples of species to use here.

Normally, grasses are not used in this area, but they can be if velocities are low and the grass will not be submerged frequently or for long periods of time. Wetland plants such

as various sedges, rushes, and bulrushes can be utilized just below the shrub zone and are often used in bioengineering techniques.

Tree Zone

This area is at the top of the streambank. Plants in this area usually provide shade for the stream and riparian habitat for wildlife. Upland but flood-tolerant species should be planted in this location.




Figure SP-1 Vegetative Zones for Streambank Protection

Vegetative Measures

When vegetation is used alone, without toe protection, this practice can be used when velocities are less than 6 ft/sec. Greater velocities can be tolerated given adequate toe and flank protection at the upper and lower ends of the practice, but each stream reach addressed should be analyzed and designed by the interdisciplinary team. The design team should consider the natural zones of a streambank community when selecting vegetation for use in the protection design. Native plant materials should be used for establishment and long-term success. No exotic or invasive species should be used.

Prior to start of construction, streambank protection, for each unique channel reach, should be designed by a qualified design professional and/or an interdisciplinary team. Plans and specifications should be referred to by field personnel throughout the construction process.

Scheduling

Installation scheduling should be phased according to the following considerations. Hard structures such as rock and other inert materials could be installed during a period not suitable for vegetative establishment, whereas vegetation could be planted during the appropriate time for more assurance of its survival. For instance, vegetation would be

better established in the late winter/early spring after hard structures have been installed or concurrent with hard-structure installation, depending on the design plan. Hard structures could be installed during a construction season prior to vegetative establishment, with the vegetation being installed the following spring. For vegetation on high banks, schedule that installation during a planting period tailored for optimum survival of the plant species used. In addition, use local weather forecasts to avoid installation activities during rain events that can potentially create abnormal flows and flooding.

Site Preparation

Follow all local, state, and federal government regulations on stream modifications.

Determine exact location of all underground activities.

Stabilize the channel bottom as specified in the design plan before streambank protection measures are installed.

Installation

Plant live plant materials, cuttings, or other forms of plant materials according to the planting plan. Options for protective vegetation measures are described in detail in the upcoming soil bioengineering section.

Safety

The following precautions should be taken:

Exercise caution on steep slopes.

Fence the area and post warning signs if trespassing is likely.

Store equipment, tools, and materials well away from the stream during non-work periods. Consider weather forecasts when determining risks of damage to equipment, tools, and materials by flooding.

All equipment used for practice installation should be free of leaks of gas, oil, and hydraulic fluid. Measures should be in place to prevent accidental spills from entering the stream.

Equipment should not be operated within flowing water in the stream.

Construction Verification

Check to see that planting and seeding was done in compliance with the design specifications.

Structural Measures

Structural Protection

Structural protection is used in areas where velocities exceed 6 feet per second, along channel bends, in areas with highly erodible soils, and in areas of steep channel slopes. Common measures are riprap, gabions, fabric-formed revetments, and reinforced concrete.

Prior to start of construction, streambank protection, for each unique channel reach, should be designed by a qualified design professional and/or an interdisciplinary team. Plans and specifications should be referred to by field personnel throughout the construction process.

Scheduling

Schedule installation during a period that is least likely to have flooding and that includes the planting season for the species that are to be established in association with the structural measures.

Site Preparation

Follow all local, state, and federal government regulations on stream modifications.

Determine exact location of all underground activities.

Stabilize the channel bottom as specified in the design plan before streambank protection measures are installed.

Remove brush and trees only if absolutely necessary to make the site suitable to install the planned measures.

Grade or excavate the areas specified in the design plan, but limit earthmoving to that absolutely necessary to make the site suitable to install the planned measures

Riprap

This is the most commonly used material for streambank protection. The following criteria should be used when designing riprap bank protection.

Riprap should be designed to be stable under the design flow conditions using the following procedure:

Determine the design velocity.

- 1) Use velocity and Figure SP-2 to determine d_{100} rock size.
- 2) Use d_{100} from Figure SP-2 as d_{90} to select rock gradation from Table SP-1.

Streambanks should be sloped at 2:1 or flatter.

Where needed to prevent movement of soil from the channel bank into the riprap, place a filter fabric between the soil and riprap. Filter fabric should meet the requirements for Class I geotextile as shown in Table SP-3.

The toe of the riprap should extend a minimum of 1 foot below the stream channel bottom or anticipated scour depth to prevent failure of the riprap protection.

The top of the riprap should extend up to the 2-year water surface elevation as a minimum, unless it is determined that a lesser height in combination with vegetative measures will provide the needed protection. The remainder of the bank above the riprap can be vegetated.

Install riprap of the specified gradation to the lines and grades shown in the design plan. Installation usually includes some bank shaping.

Place geotextile fabric or a granular filter between the riprap and the natural soil and placement of the rock.

Ensure that the subgrade for the filter and riprap follows the required lines and grades shown in the plan. Low areas in the subgrade on undisturbed soil may also be filled by increasing the riprap thickness.

Riprap may be placed by equipment. Care should be taken to avoid punching or tearing of the geotextile fabric cloth during placement of rock. Avoid dropping rock onto the fabric more than 1/2-1 foot from the equipment delivering the rock. This will more amply prevent punching or tearing the fabric. Repair any damage by removing the riprap and placing another piece of filter cloth over the damaged area. All connecting joints should overlap a minimum of 1.5 feet with the upstream edge over the downstream edge. If the damage is extensive, replace the entire geotextile fabric.




Figure SP-2 Isbash Curve

Table SP-1 Graded Riprap

Class	Weight (lbs.)					
	d ₁₀	d ₁₅	d ₂₅	d ₅₀	d ₇₅	d ₉₀
1	10	-	-	50	-	100
2	10	-	-	80	-	200
3	-	25	-	200	-	500
4	-	-	50	500	1000	-
5	-	-	200	1000	-	2000

Table SP-2 Requirements for Nonwoven Geotextile

Property	Test method	Class I	Class II	Class III	Class IV ³
Tensile strength (lb) ¹	ASTMD 4632 grab test	180 minimum	120 minimum	90 minimum	115 minimum
Elongation at failure (%) ¹	ASTMD 4632	≥50	≥50	≥50	≥50
Puncture (pounds)	ASTMD 4833	80 minimum	60 minimum	40 minimum	40 minimum
Ultraviolet light (% residual tensile strength)	ASTMD 4355 150-hr exposure	70 minimum	70 minimum	70 minimum	70 minimum
Apparent opening size (AOS)	ASTMD 4751	As specified max. #40 ²			
Permittivity sec ⁻¹	ASTMD 4491	0.70 minimum	0.70 minimum	0.70 minimum	0.10 minimum

Table copied from NRCS Material Specification 592.

¹ Minimum average roll value (weakest principal direction).

² U.S. standard sieve size.

³ Heat-bonded or resin-bonded geotextile may be used for Classes III and IV. They are particularly well suited to Class IV. Needle-punched geotextile is required for all other classes.

Gabions

These rock-filled wire baskets are very labor intensive to construct, but they are semi-flexible and permeable. Gabions should be designed and constructed according to manufacturer's guidelines and recommendations. They should be filled with durable rock. Use only durable crushed limestone, dolomite, or granite rock. Shale, siltstone, and weathered limestone should not be used. If needed, a filter fabric can be used between the gabions and the soil subgrade. Fabric will be selected from the table for geotextiles shown above.



Fabric-Formed Revetments

These are manufactured, large, quilted envelopes that can be sewn or zipped together at the site to form continuous coverage of the area to be protected. Once the fabric is in place, it is pumped full of grout to form a solid, hard and semi-impervious cover. Revetments should be designed and installed according to manufacturer's recommendations.

Reinforced Concrete

A qualified design professional using sound and accepted engineering procedures should design this protection method. Installation usually includes some bank shaping, placing a filter fabric or a granular filter between the streambank material and the retaining wall or bulkhead, and anchoring. The design should include a solid foundation for the retaining wall and a method of draining excess water from behind the wall.

Anchor the foundation for these structures to a stable, nonerrodible base material such as bedrock. Also, water stops should be installed at all joints in concrete retaining walls.

All structural protection methods should begin and end along stable reaches of the stream.

Combined Methods of Protection

Combinations of vegetative and structural protection can be used in any area where a structural measure would be used. An example of exceptions would be in the vicinity of highway bridges and culverts where heavy armorment with rocks, concrete, etc., is required to prevent erosion of the highway. Common measures include cellular matrix confinement systems, grid pavers, and bioengineering techniques. As with structural measures, all combined methods should begin and end along stable reaches of the stream. See Figures SP-3 and SP-4 for examples of combined methods of protection.



Figure SP-3 Retrofitted urban stream using a bioengineered approach. Note hard, encapsulated-rock toe in lower zone and then coir geotextile rolls to be planted with wetland plants in upper-bank zones.



Figure SP-4 Same stream, after bioengineered restoration. This type of bioengineered stream improves habitat, water quality, and numerous other functions that cannot be achieved with hardened stream channels.

Cellular Confinement Matrices

These are commercially available products made of heavy-duty polyethylene formed into a honeycomb type matrix. The product is flexible to conform to surface irregularities. The combs may be filled with soil, sand, gravel, or cement. Where soil is used to fill the combs, vegetation may also be established. These systems should be designed and installed according to manufacturer's recommendations.

Grid Pavers

These are modular concrete units with interspaced voids. They are used to armor the bank and provide an area for vegetation as well. Pavers come in a variety of shapes and sizes with various anchoring methods. They should be designed and installed according to manufacturer's recommendations.

Soil Bioengineering

Soil bioengineering is the combination of biological, mechanical, and ecological techniques to control erosion and stabilize soil through the use of vegetation alone or in combination with engineered structures and materials. This may include the use of both woody and herbaceous vegetation. An interdisciplinary team of engineers, soil bioengineers, hydrologists, and fishery biologists should be consulted for the planning and design required for soil bioengineering projects. This method of stream protection is more complex than the scope of this manual permits; however, additional resources are listed at the end of this section and in **Appendix I**. Examples of the more commonly used techniques are listed below.

Woody Vegetation

Plant Species

Use native, locally harvested species that root easily and are suitable for the intended use and adapted to site conditions, such as willow. Plants are usually harvested from a nearby local area.

Woody Vegetation Cutting Size

Normally $\frac{3}{8}$ " to 2" in diameter and from 2 to 6 feet long (length will depend on project requirements). Three types of cuttings are common:

- Pole cuttings, generally from shrubs and trees $\frac{1}{2}$ to 3 inches in diameter;
- Post cuttings, trees larger than 3 inches in diameter but smaller than 6 inches; and
- Bundled cuttings that contain shrub and tree cuttings smaller than $\frac{1}{2}$ inch but no smaller than $\frac{3}{8}$ "

Harvesting

Cut plant materials at a blunt angle, 8" to 10" from the ground, leaving enough trunk so that cut plants will regrow.

Transportation and Handling

Bundle cuttings together on harvest site, removing side branches. Keep material moist. Handle carefully during loading and unloading to prevent damage. Cover to protect cuttings from drying out.

Installation Timing

Deliver to construction site within 8 hours of harvest and install immediately, especially when temperatures are above 50° F. Store up to 2 days if cuttings are submerged, "heeled in" moist soil, shaded, and protected from wind.

Season

Install during plants' dormant season, generally late October to March.

Soil

Must be able to support plant growth. Compact backfill to eliminate voids, and maintain good branch cutting-to-soil contact.

Herbaceous Vegetation

Plant Species

Use native, locally harvested species that root easily and are suitable for the intended use and adapted to site conditions. Plants are usually harvested from a nearby local area. Herbaceous plants such as sedges and bulrushes can be planted as seeds, clumps, or rhizomes depending on the species.

Planting Methods

Herbaceous plantings can be established through a variety of techniques: container stock, bare root plants, transplant plugs, rhizomes, clumps, and seeds. Methods of planting will be dependent on the plant species as well as the habitat specifics. The *Surface Stabilization Practices* in this volume discuss vegetation suitable for Mississippi in greater detail and should be referenced before any planting project.

Harvesting

Plant materials for herbaceous plantings have the following harvesting recommendations:

- **Transport plugs:** Plugs are often used for wetland plants and therefore should remain moist. Plugs should be 3-12 inches in diameter, excavated 5-6 inches deep. Extraction rate should not exceed 1 square foot in a 10-foot area. Plugs should be kept moist at all times.
- **Rhizomes:** These are the underground horizontal stems and can be collected in the early spring or at the end of the growing season. Rhizomes can be dug up and divided into sections. Rhizomes should be kept cool.
- **Clumps:** Clumps of herbaceous vegetation are generally harvested using a backhoe. Digging in 12-15 inches deep is sufficient for most plants collected with this method. Clump plantings should be kept moist.

Transportation and Handling

Transportation and handling of herbaceous plants depends somewhat on the planting method chosen. For container stock plants, refer to the provider or plant nursery's suggestions on acclimating and moisture needs. For harvested plants, see the notes listed in the Harvesting section above.

Season

Install during plants' dormant season, generally late October to March.

Soil

Must be able to support plant growth. Compact backfill to eliminate voids and maintain good branch cutting-to-soil contact.

Protective Vegetation

Live staking, live fascines, brush layers, and branchpacking are soil bioengineering practices that use the stems or branches of living plants as a soil reinforcing and stabilizing material. Eventually the vegetation becomes a major structural component of the bioengineered system.



Live Staking

Live staking is the use of live, rootable vegetative cuttings, inserted and tamped into the ground. As the stakes grow, they create a living root mat that stabilizes the soil. Use live stakes to peg down surface erosion-control materials. Most native willow species root rapidly and can be used to repair small earth slips and slumps in wet areas.




Figure SP-5 Pole Plantings – End of stake should reach water table, while the height above the ground will vary (Bentrup, 1998)

To prepare live material, cleanly remove side branches, leaving the bark intact. Use cuttings $\frac{1}{2}$ " to $1\frac{1}{2}$ " in diameter and 2 to 3 feet long. Cut bottom ends at an angle to insert into soil. Cut top square. Tamp the live stake into the ground at right angles to the slope, starting at any point on the slope face. Buds should point up. Install stakes 2 to 3 feet apart using triangular spacing with from 2 to 4 stakes per square yard. An iron bar can be used to make a pilot hole in firm soil. Drive the stake into the ground with a dead blow hammer (hammerhead filled with shot or sand). Four-fifths of the live stake should be underground with soil packed firmly around it after installation. Replace stakes that split during installation.

Live Fascines

Live fascines are long bundles of branch cuttings bound together into sausage-like structures. They should be placed in shallow contour trenches and at an angle on wet slopes to reduce erosion and shallow face sliding. This practice is suited to steep, rocky slopes, where digging is difficult.

To prepare live materials, make cuttings from species such as young willows or shrub dogwoods that root easily and have long, straight branches. Make stakes $2\frac{1}{2}$ feet long for cut slopes and 3 feet long for fill slopes. Make bundles of varying lengths from 5 to

30 feet or longer, depending on site conditions and limitations in handling. Use untreated twine for bundling. Completed bundles should be 6" to 8" in diameter. Orient growing tips in the same direction. Stagger cuttings so that root ends are evenly distributed throughout the length of the bundle. Install live fascine bundles the same day they are prepared. Prepare dead stakes 2½ feet long, untreated 2" by 4" lumber, cut diagonally lengthwise to make two stakes. Live stakes will also work. Beginning at the base of the slope, dig a trench on the contour large enough to contain the live fascine. Vary width of trench from 12" to 18", depending on angle of the slope. Trench depth will be 6" to 8", depending on size of the bundle. Place the live fascine into the trench. Drive the dead stakes directly through the bundle every 2 to 3 feet. Use extra stakes at connections or bundle overlap. Leave the top of the stakes flush with the bundle. Install live stakes on the downslope side of the bundle between the dead stakes.




Figure SP- 6 Fascine placement (Bentrup, 1998)

Brush Layering

Brush layering is similar to live fascine systems. Both involve placing live branch cuttings on slopes. However, in brush layering, the cuttings are oriented at right angles to the slope contour. Also, the cuttings used in brush layering are not bound in bundles like fascines. Brush layering can be used on slopes up to 2:1 (horizontal: vertical) in steepness.

Install toe protection if needed to prevent undercutting. Then, starting at the toe of the slope, excavate benches horizontally, on the contour, or angled slightly down the slope to aid drainage. Construct benches 2 to 3 feet wide. Slope each bench so that the outside edge is higher than the inside.

Crisscross or overlap live branch cuttings on each bench. Place growing tips toward the outside of the bench. The branches should not extend more than 18" from the bank to prevent damage during high flows. Place backfill on top of the root ends and compact to eliminate air spaces. Growing tips should extend slightly beyond the fill to filter sediment. Soil for backfill can be obtained from excavating the bench above. Space brush layer rows 3 to 5 feet apart, depending upon the slope angle and stability.




Figure SP-7 Brush Layering (Source: Bentrup, 1998)

Brush layering can be used between encapsulated soil lifts; lifts are encapsulated in erosion-control fabric (or similar material such as burlap). This setup can be used where space is limited and a more vertical structure is required.




Figure SP-8 Brush Layering with Erosion Control Fabric (Source: Bentrup, 1998)

Branchpacking

Branchpacking consists of alternating layers of live branch cuttings and compacted backfill to repair small localized slumps and holes in slopes (no greater than 4 feet deep or 5 feet wide). Use for earth reinforcement and mass stability of small earthen fill sites.

Make live branch cuttings from ½" to 2" in diameter and long enough to reach from soil at the back of the trench to extend slightly from the front of the rebuilt slope face.

Make wooden stakes 5 to 8 feet long from 2" by 4" lumber or 3" to 4" diameter poles. Start at the lowest point and drive wooden stakes vertically 3 to 4 feet into the ground. Set them 1 to 1½ feet apart. Place a layer of living branches 4" to 6" thick in the bottom of the hole, between the vertical stakes, and at right angles to the slope face. Place live branches in a crisscross arrangement with the growing tips oriented toward the slope face. Some of the root ends of the branches should touch the back of the hole. Follow each layer of branches with a layer of compacted soil to ensure soil contact with the branch cuttings. The final installation should match the existing slope. Branches should protrude only slightly from the rebuilt slope face.

The soil should be moist or moistened to ensure that live branches do not dry out.

Woody Vegetation with Inert Structures

Live cribwalls, vegetated rock gabions, and joint plantings are soil bioengineering practices that combine a porous structure with vegetative cuttings. The structures provide immediate erosion, sliding, and washout protection. As the vegetation becomes established, the structural elements become less important.

Live Cribwall

A live cribwall consists of a hollow, box-like interlocking arrangement of untreated logs or timber. Use at the base of a slope where a low wall may be required to stabilize the toe of the slope and reduce its steepness or where space is limited and a more vertical structure is required. It should be tilted back if the system is built on a smooth, evenly sloped surface.

Make live branch cuttings ½" to 2" in diameter and long enough to reach the back of the wooden crib structure. Build the constructed crib of logs or timbers from 4" to 6" in diameter or width. The length will vary with the size of the crib structure. Starting at the lowest point of the slope, excavate loose material 2 to 3 feet below the ground elevation until a stable foundation is reached. Excavate the back of the stable foundation (closest to the slope) slightly deeper than the front to add stability. Place the first course of logs or timbers at the front and back of the excavated foundation, approximately 4 to 5 feet apart and parallel to the slope contour. Place the next set of logs or timbers at right angles to the slope on top of the previous set. Place each set of timbers in the same manner and nail to the preceding set. Place live branch cuttings on each set to the top of the cribwall structure with growing tips oriented toward the slope face. Backfill the cribwall, compact the soil for good root-to-soil contact, then apply seed and mulch.

Vegetated Rock Gabions

Vegetated gabions combine layers of live branches and gabions (rectangular baskets filled with rock). This practice is appropriate at the base of a slope where a low wall is required to stabilize the toe of the slope and reduce its steepness. It is not designed to resist large, lateral earth stresses. Use where space is limited and a more vertical structure is required. Overall height, including the footing, should be less than 5 feet.

Make live branch cuttings from ½" to 1" in diameter and long enough to reach beyond the rock basket structure into the backfill. Starting at the lowest point of the slope, excavate loose material 2 to 3 feet below the ground elevation until a stable foundation is reached. Excavate the back of the stable foundation (closest to the slope) slightly deeper than the front to add stability and ensure rooting. Place the wire baskets in the bottom of the excavation and fill with rock. Backfill between and behind the wire baskets. Place live branch cuttings on the wire baskets at right angles to the slope with the growing tips oriented away from the slope and extending slightly beyond the gabions. Root ends must extend beyond the backs of the wire baskets into the fill material. Place soil over the cuttings and compact it. Repeat the construction sequence until the structure reaches the required height.

Joint Planting

Joint planting or vegetated riprap involves tamping or pushing live cuttings into soil between the joints or open spaces in rocks that have previously been placed on a slope. Use where rock riprap is required. Joint planting is used to remove soil moisture, to prevent soil from washing out below the rock, and to increase slope stability over riprap alone.

Make live branch cuttings from ½" to 1½" in diameter and long enough to extend into soil below the rock surface. Remove side branches from cuttings leaving the bark intact. Tamp or push live branch cuttings into the openings of the rock during or after construction. Care should be taken to avoid splitting the cutting by tamping. The root ends should extend into the soil behind the riprap. Mechanical probes may be needed to create pilot holes for the live cuttings so that they can be pushed into substrate without stripping their bark or splitting the cutting by tamping. It is critical to ensure the soil is packed around the cutting to prevent air pockets. "Mudding" (filling the hole with water and then adding soil to make a mud slurry) can remove air pockets. Place cuttings at right angles to the slope with growing tips protruding from the finished face of the rock.

Safety

Store all construction materials well away from the stream. Consider weather forecasts when determining risks of damage by flooding.

At the completion of each workday, move all construction equipment out of and away from the stream to prevent damage to equipment by flooding. Consider weather forecasts when determining risks of flooding.

The following precautions should be taken:

Exercise caution on steep slopes.

Fence the area and post warning signs if trespassing is likely.

All equipment used for practice installation should be free of leaks of gas, oil, and hydraulic fluid. Measures should be in place to prevent accidental spills from entering the stream.

Equipment should not be operated within flowing water in the stream.

Construction Verification

Check cross section of the channel, thickness of structural product used, and confirm the presence of filter cloth between the product and the streambank.

Check to see that planting and seeding was done in compliance with the design specifications.

Common Problems

Consult with a qualified design professional if any of the following occur:

Variations in topography on site indicate practice will not function as intended; changes in plan may be needed.

Design specifications for vegetative or structural protection cannot be met; substitution may be required. Unapproved substitutions could result in erosion damage to the streambank.

Maintenance

Check the streambank for rill and gully erosion after every storm event.

Repair eroded areas with appropriate plantings, structural materials, or new plants.

Check the streambank for signs of voids beneath gabions, riprap, and concrete. Deterioration of the filter fabric or granular material should be repaired; make needed repairs with similar material.

Protect new plantings from livestock.

Check the streambank for reduction in stream capacity, caused by overgrowth of vegetation on the streambank. Selectively remove overgrown vegetation at regular intervals to maintain capacity and to maintain desired plant communities.

References

BMPs from Volume 1

Chapter 4

Permanent Seeding (PS)	4-53
Shrub, Vine and Groundcover Planting (SVG)	4-80
Tree Planting on Disturbed Areas (TP)	4-110
Filter Strip (FS)	4-261
Channel Stabilization (CS)	4-342

MDOT Drawing PD-1

Typical Planting Details for Trees and Shrubs	4-381
---	-------

Additional Resources

Allen, H.H., and Fischenich, J.C. (1999) "Coir geotextile roll and wetland plants for streambank erosion control," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-04), U.S. Army Engineer Research and Development Center, Vicksburg, MS.
<http://el.erdc.usace.army.mil/elpubs/pdf/sr04.pdf>.

Bentrup, G., and Hoag, C. (1998) "The Practical Streambank Bioengineering Guide" Interagency Riparian/Wetland Plant Development Project. USDA.

Freeman, G., and Fischenich, C. (2001). "Units and Conversions for Stream Restoration Projects," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-28), U.S. Army Engineer Research and Development Center, Vicksburg, MS.
www.wes.army.mil/el/emrrp.

Fischenich, C. (1999). "Irrigation systems for establishing riparian vegetation," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-12), U.S. Army Engineer Research and Development Center, Vicksburg, MS.
www.wes.army.mil/el/emrrp.



Fischenich, J.C., and Allen H. (2000). U.S. Army Engineer Research and Development Center, Environmental Laboratory, SR-W-001.
<http://el.erdc.usace.army.mil/elpubs/pdf/srw00-1/srw00-1.pdf>.

Fischenich, C., and Morrow, J., Jr. (1999). "Streambank Habitat Enhancement with Large Woody Debris," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-13), U.S. Army Engineer Research and Development Center, Vicksburg, MS.
www.wes.army.mil/el/emrrp.


Fisher, R.A., and Fischenich, J.C. (2000). "Design recommendations for riparian corridors and vegetated buffer strips," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-24), U.S. Army Engineer Research and Development Center, Vicksburg, MS.
www.wes.army.mil/el/emrrp.

Sotir, R.B., and Fischenich, J.C. (2001), "Live and Inert Fascine Streambank Erosion Control," *EMRRP Technical Notes Collection* (ERDC TN-EMRRP-SR-31), U.S. Army Engineer Research and Development Center, Vicksburg, MS.
www.wes.army.mil/el/emrrp.





STATE	PROJECT NO.
MISS.	



NOTE: METHOD OF "HEELING-IN" BEFORE PLANTING CONSISTS OF PLACING THE PLANTS IN A TRENCH AND COVERING THE ROOTS WITH DIRT. THIS MAY BE DONE ON TRUCK FOR EASE OF MOVEMENT. SAW DUST OR OTHER APPROVED MATERIAL MAY BE USED. ROOTS MUST BE KEPT MOIST AT ALL TIMES.





ROOT PROTECTION ("HEELING-IN") DURING STORAGE



DOUBLE VERTICAL STAKING METHOD

NOTE: ALL TREES SHALL BE STAKED OR GUYED. THE TRUNK OF ALL SMOOTH BARKED TREES SHALL BE WRAPPED. LARGE SHRUBS TO BE STAKED AND WRAPPED WHEN SPECIFIED ON PLANS.

TREE AND SHRUB PLANTING (BARE ROOT)



GENERAL NOTES:

1. THE TYPE(S), RATE(S) OF APPLICATION AND PLACEMENT OF FERTILIZER AND MULCH SHALL BE IN ACCORDANCE WITH THE REQUIREMENTS OF THE PLANS AND SPECIFICATIONS.
2. TENSION IN GUY WIRES WILL BE SUCH AS TO ALLOW SOME SWAYING MOTION IN TREE.

DATE	DESIGNED BY	CHECKED BY	IN CHARGE	STATE	PROJECT NO.

MISSISSIPPI DEPARTMENT OF TRANSPORTATION
ROADWAY DESIGN DIVISION
STANDARD PLAN

TYPICAL PLANTING DATA
FOR TREES & SHRUBS

ISSUE DATE: OCTOBER 1, 1998

WORKING NUMBER: PD-1
SHEET NUMBER: 141

Temporary Stream Crossing (TSC)



Practice Description

A temporary stream crossing is a short-term road crossing constructed over a stream for use by construction traffic to prevent turbidity and stream-bed disturbance caused by traffic. A temporary stream crossing can be a low-water crossing, a culvert crossing, or a bridge with or without embankment approaches. Temporary stream crossings are applicable on construction sites where traffic must cross streams during construction.

Planning Considerations

A stream crossing can be an open ford, a pipe (culvert), or bridge crossing. Stream crossings can be a useful practice to provide a means for construction traffic to cross flowing streams without damaging the channel or banks or causing flooding, and to keep sediment generated by construction traffic out of the stream. Stream crossings are generally applicable to flowing streams with drainage areas less than 1 square mile. A qualified design professional should design permanent structures to handle flow from larger drainage areas.

Careful planning can minimize the need for stream crossings, and the qualified design professional should always try to avoid crossing streams. Whenever possible, complete the development separately on each side and leave a natural buffer zone along the stream. Temporary stream crossings are a direct source of water pollution; they may create flooding and safety hazards; they can be expensive to construct; and they cause costly construction delays if damaged by flooding.

Temporary stream crossings are necessary to prevent construction vehicles from damaging streambanks and continually tracking sediment and other pollutants into the flow regime. However, these structures are also undesirable in that they could cause a

channel constriction, which can cause flow backups or washouts during periods of high flow. For this reason, the temporary nature of stream crossings is stressed. They should be planned to be in service for the shortest practical period of time and to be removed as soon as their function is completed.

Fords made of stabilizing material such as rock are often used in steep areas subject to flash flooding, where normal flow is shallow (less than 3") or intermittent. Fords should only be used where crossings are infrequent. Fords are especially adapted for crossing wide, shallow watercourses. Generally, do not use fords where bank height exceeds 5 ft. Rock material used for the ford may be washed out during large storm events and require the rock to be replaced. Mud and other contaminants are brought into the stream on vehicles using ford crossings unless crossings are limited to no-flow conditions.

The criteria contained in this practice pertain primarily to flow capacity and resistance to washout of the structure. From a safety and utility standpoint, the qualified design professional must also be sure that the structure is capable of withstanding the expected loads from heavy construction equipment. The qualified design professional must also be aware that such structures are subject to the rules and regulations of the U.S. Army Corps of Engineers for in-stream modifications (404 permits).

Design Criteria and Construction

Prior to start of construction, a temporary stream crossing should be designed by a qualified design professional. Plans and specifications should be referred to by field personnel throughout the construction process.

Scheduling

To minimize stream disturbance, attempt to construct temporary stream crossings during dry periods and relatively low flows. Use local weather forecasts to avoid installation during rain events that can potentially create turbidity.

Site Preparation

Ensure that all necessary materials are on the site before any work begins. If planned, construct a bypass channel and dewater the construction site before undertaking other work.

Installation and Removal Low Water Crossing

Excavate the foundation for the temporary crossing according to the design plan and in such a manner that the final finished surface is level with the stream bed.

Excavate roadways through the abutment approaches (bank) to the crossing according to the design plan.

Place the specified type of geotextile over the width and length of the crossing subgrade and anchor it in place as specified in the plans. Next, place riprap of the specified gradation to the required thickness across the channel. Finally, place a wearing course of gravel or crushed rock of the specified gradation to the required thickness over the riprap.

Remove gravel and excess rock riprap as soon as it is no longer needed. Restore original contours to the channel, leaving rock riprap level with the stream bed.

Culvert Crossings or Spans (Bridges)

The structure should be large enough to convey the flow expected from a 2-year frequency, 24-hour duration storm without appreciably altering the stream flow characteristics. The structure may be a span or culvert. If culverts are used, see Table TSC-1 for aid in selecting the appropriate size. (Multiple culverts may be used in place of one large culvert, if they have the equivalent capacity of the larger one). The minimum-sized culvert that may be used is 18".

Where culverts are installed (Figure TSC-1), compacted soil will be used to form the crossing. The depth of soil cover over the culvert should be equal to $\frac{1}{2}$ the diameter of the culvert or 24", whichever is greater. To protect the sides of the fill from erosion, riprap shall be used and designed in accordance with the practice *Outlet Protection*.

The length of the culvert should be adequate to extend the full width of the crossing, including side slopes.

The grade of the culvert pipe should be at least 0.25" per foot.

The top of the compacted fill should be covered with 6" of Mississippi Department of Transportation coarse aggregate No. 1 stone (3/4" to 4").

The approaches to the structure should consist of stone pads meeting the following specifications:

Stone: Mississippi Department of Transportation coarse aggregate No. 1.

Minimum thickness: 6".

Minimum width: equal to the width of the structure.

Minimum approach lengths: 25 feet.

Place a 4" layer of moist, clayey, workable soil (not pervious material such as sand, gravel, or silt) around the culvert. Compact by hand to at least the density of the embankment soil. (Do not raise the culvert from the foundation when compacting under the culvert haunches.) Continue with backfill of the pipe in 4" to 6" uncompacted layers, scarifying the surface between each compacted layer. All backfill material within 2 feet of the pipe (beside the pipe and above the pipe) should be compacted with hand tampers only.

Extend the end of the culvert 2 feet beyond the toe of the fill slope. The outlet end of the culvert should be placed on a stable natural stream bed. If this is not possible, install a riprap apron at least 5 feet wide and 10 feet long to a stable grade.

All backfill material within 2 feet of a culvert (beside the pipe and above the pipe) should be compacted with hand tampers only. Heavy equipment should not be allowed on top of the culvert until a minimum of 2 feet of hand-compacted material is placed.

If an embankment is required, use fill from predetermined borrow areas. It should be clean, stable mineral soil free of roots, woody vegetation, rocks, and other debris. It must be wet enough when placed to form a ball without crumbling yet not so wet that water can be squeezed out. Compact the fill material in 6" to 8" continuous layers over the length of the embankment. One way is by routing construction equipment over the embankment so that each layer is traversed by at least one wheel of the equipment. Construct and compact the culvert-crossing embankment to 10% above the design height to allow for settling.

Remove culvert as soon as it is no longer needed and restore stream bed to original contour.

Table TSC-1 Culvert Selection Guide (pipe, diameter, inches)

Drainage Area (Acres)	Average Slope of Watershed			
	1%	4%	8%	16%
1-25	30	30	36	36
26-50	30	36	42	48
51-100	36	48	48	54
101-150	42	48	60	60
151-200	42	54	72	72
201-250	48	60	72	72
251-300	48	60	72	72
301-350	48	60	72	2X60
351-400	54	72	2X60	2X60
401-450	54	72	2X60	2X60
451-500	54	72	2X60	2X72
501-550	60	72	2X60	2X72
551-600	60	72	2X60	2X72
601-640	60	72	2X60	2X72

Assumptions for determining USDA-NRCS Peak Discharge Method; CN = 70; Rainfall depth (average for Mississippi) = 4.3" for 2-year/24-hour storm; No tailwater exists; and the depth of water at the inlet invert is 1.5 X diameter.

Culvert crossings and spans should be designed with features that will prevent damage, destruction or removal during major flood events (i.e., cabling, emergency bypass, etc.).




Figure TSC-1 Culvert Stream Crossing

Fords (see Figure TSC-2)

Streambanks should be excavated to provide approach sections of 5:1 or flatter.

The width of the ford crossings should be wide enough for the construction equipment to use safely.

Filter fabric material designed for use under riprap (see *Channel Stabilization Practice*) should be installed on the excavated surface of the ford according to the manufacturer's recommendations. The fabric should extend across the bottom of the stream and at least 25 feet up each approach section. All edges of the fabric should be keyed in a minimum of 1 foot.

Mississippi Department of Transportation coarse aggregate No. 1 stone, 6" thick should be installed on the filter fabric and also should be used to fill the 1-foot keyed edges of the fabric.

The final surface of the stone in the bottom of the watercourse should be the same elevation as the watercourse bottom to eliminate any overfall and possible scour problems.




Figure TSC-2 Ford Stream Crossing

Bridge Excavation

If excavation is required, excavate roadways through the abutment approaches (bank) according to the design plan.

Construct the bridge or install a prefabricated structure according to the design plan. A cable should be tied to one corner of the bridge frame, with the other end fastened to a secure object to prevent flood flows from carrying the bridge downstream.

Embankment

Use fill from predetermined borrow areas. It should be clean, stable mineral soil free of roots, woody vegetation, rocks, and other debris and must be wet enough to form a ball without crumbling yet not so wet that water can be squeezed out.

Compact the fill material in 6" to 8" continuous layers over the length of the embankment. One way is by routing construction equipment over the embankment so that each layer is traversed by at least one wheel of the equipment.

Construct and compact the temporary stream crossing embankment to 10% above the design height to allow for settling.

Erosion Control (all kinds of temporary stream crossings)

Minimize the size of all disturbed areas and vegetate as soon as each phase of construction is complete. Riprap or establish vegetation on the slopes of the embankment of the temporary stream crossing. Riprap should be placed on the entrance slope of culvert systems according to the design plan.

Direct all overland flow at low velocity to the ditches along the approach roads.

Safety

Store all construction materials well away from the stream. Consider weather forecasts when determining risks of damage by flooding.

Equipment used to construct stream crossings should be free of leaks of fuel and hydraulic fluids to prevent contamination of surface waters. Operation of equipment in the stream should be minimized. At the completion of each workday, move all construction equipment away from the stream to prevent damage to equipment by flooding. Consider weather forecasts when determining risks of flooding.

The following precautions should be taken:

- Exercise caution on steep slopes.
- Fence the area and post warning signs if trespassing is likely.
- All equipment used for practice installation should be free of leaks of gas, oil, and hydraulic fluid. Measures should be in place to prevent accidental spills from entering the stream.
- Equipment should not be operated within flowing water in the stream.

Construction Verification

Check finished grade and size of culvert. Check to see if culvert is free of obstructions.

Common Problems

Consult with qualified design professional if any of the following occur:

Variations in topography on site indicate crossing will not function as intended; changes in plan may be needed.

Design specifications for fill or conduit cannot be met; substitution may be required. Unapproved substitutions could result in the crossing being washed out.

Maintenance

Inspect the temporary stream crossing for damage to the structure or the vegetation after each storm event.

Repair any damages found during inspections.

Remove debris, trash, and other materials that restrict flow from the culvert or bridge

References

Additional BMPs from Volume 1


Chapter 4

Outlet Protection (OP)	4-199
Channel Stabilization (CS)	4-342

MDOT Drawing ECD-16

Temporary Culvert Stream Crossing	4-390
-----------------------------------	-------


STATE	PROJECT NO.
MISS.	



PLAN VIEW

TEMPORARY CULVERT STREAM CROSSING

TEMPORARY CULVERT STREAM CROSSING



SECTION A-A

- NOTES:
1. TEMPORARY CULVERT STREAM CROSSINGS PROVIDE A MEANS FOR VEHICLES AND EQUIPMENT TO SAFELY CROSS A WATERCOURSE WHILE MINIMIZING DAMAGE TO THE CHANNEL AND/OR BANKS.
 2. TEMPORARY CULVERT STREAM CROSSINGS, WHEN PERMITTED BY THE ENGINEER, SHALL BE CONSTRUCTED TO SAFELY PASS EXPECTED MEAN WATER FLOW OF THE STREAM FOR THE TIME OF YEAR AND LENGTH OF TIME THAT THEY ARE INSTALLED.
 3. TEMPORARY STREAM CROSSINGS SHALL BE DESIGNED TO ENSURE STRUCTURAL INTEGRITY AND STABILITY, AND MAINTAIN NORMAL DOWNSTREAM FLOWS. THE USE OF INSTREAM CROSSINGS AND INSTREAM AGGREGATE FILL SHALL BE MINIMIZED TO THE EXTENT PRACTICABLE.
 4. A CONTINUOUS PROGRAM OF EFFECTIVE EROSION AND SEDIMENT CONTROL MEASURES SHALL BE IMPLEMENTED PRIOR TO AND CONCURRENT WITH ANY TYPE OF CONSTRUCTION ACTIVITY WITHIN THE BANKS OF A STREAM. WHEN A CROSSING IS NO LONGER NEEDED, THE STREAMBED AND STREAM BANKS SHALL BE RESTORED TO PRE-DISTURBANCE CONDITIONS, OR SUCH A CONDITION THAT PROVIDES SUBSTANTIALLY EQUIVALENT PROTECTION OF WATER QUALITY.
 5. LOCATIONS OR TYPES OF TEMPORARY CULVERT STREAM CROSSINGS WILL NOT BE SHOWN ON THE PLANS AS REQUIRED ITEMS.
 6. THE CONTRACTOR MAY PROPOSE OTHER OPTIONS FOR TEMPORARY STREAM CROSSINGS SUCH AS STEEL/TIMBER BRIDGE OR MATS.
 7. THE DETAILS PROVIDED DEPICT A TYPICAL TEMPORARY CULVERT STREAM CROSSING.
 8. TEMPORARY STREAM CROSSINGS WILL NOT BE MEASURED FOR SEPARATE PAYMENT. ALL COSTS FOR MATERIALS, LABOR, EQUIPMENT, CONSTRUCTION, REMOVAL AND MAINTENANCE SHALL BE ABSORBED IN OTHER ITEMS OF WORK.

MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
TEMPORARY CULVERT STREAM CROSSING	
DATE	BY
DESIGN TEAM	DATE
FILENAME: EROSION_CONTROL_MECO-16.DWG	WORKING NUMBER ECD-16
	SHEET NUMBER